

## CONTENTS

<b>1. INTRODUCING THE SW0IX-GPPAE .....</b>	<b>1 - 1 ~ 1 - 8</b>
1.1 Features .....	1 - 1
1.2 Available Functions .....	1 - 3
1.3 Configuration With an A-Series CPU .....	1 - 7
<b>2. BASIC SCREEN SPECIFICATIONS AND OPERATIONS .....</b>	<b>2 - 1 ~ 2 - 12</b>
2.1 Basic Screen Specifications .....	2 - 1
2.1.1 Basic screen display contents .....	2 - 1
2.1.2 Windows .....	2 - 2
2.2 Mastering Basic Operations .....	2 - 4
2.2.1 Common key operations .....	2 - 4
2.2.2 Storing data in mode .....	2 - 6
2.2.3 Quick entry of instructions .....	2 - 8
2.3 How to Read This Manual .....	2 - 11
<b>3. INSTALLING AND STARTING UP THE SYSTEM .....</b>	<b>3 - 1 ~ 3 - 9</b>
3.1 System Installation .....	3 - 1
3.1.1 Installing the GPP functions .....	3 - 2
3.2 Initial Setting Procedure after Starting Up the System .....	3 - 4
3.2 (1) Creating a file .....	3 - 4
3.2 (2) Reading a file from an HD or FD .....	3 - 6
3.2 (3) Reading a file from a PC .....	3 - 8
<b>4. PROGRAMMING USING LADDER PATTERNS .....</b>	<b>4 - 1 ~ 4 - 109</b>
4.1 Functions Available in the LADDER Mode .....	4 - 1
4.2 Common Operations in the LADDER Mode .....	4 - 2
4.2.1 Common operations when inputting an instruction .....	4 - 2
4.2.2 Restrictions during operations in the LADDER mode .....	4 - 5
4.3 Creating a Program in the Ladder Diagram Format .....	4 - 7
4.3.1 Common operations in creating and modifying a ladder .....	4 - 7
4.3.2 Creating a program .....	4 - 9
4.3.3 Modifying an existing program .....	4 - 13
4.3.3 (1) Modifying an existing ladder by inputting a new symbol over an old symbol .....	4 - 13
4.3.3 (2) Inserting or adding a ladder block into an existing program .....	4 - 16
4.3.3 (3) Inserting or adding a ladder symbol into an existing program .....	4 - 18
4.3.3 (4) Deleting a ladder block from an existing program .....	4 - 20
4.3.3 (5) Deleting a ladder symbol from an existing program .....	4 - 22
4.3.4 Auxiliary functions used for write,insertion,and deletion .....	4 - 24
4.3.4 (1) Function for setting the type of processing of a program after conversion .....	4 - 25
4.3.4 (2) Function for registering a ladder pattern for utilization .....	4 - 27
4.3.4 (3) Utilizing a registered ladder pattern in a program .....	4 - 29

4.3.4	(4) Switching the display of a program from main to sub when creating, inserting, or deleting a ladder block .....	4 - 31
4.3.5	Modifying a sequence program when a PC CPU is online .....	4 - 33
4.4	Reading an Existing Program .....	4 - 36
4.4.1	Procedures for reading an existing program .....	4 - 36
4.4.1	(1) By designating a step number .....	4 - 36
4.4.1	(2) By designating a device number .....	4 - 37
4.4.1	(3) By designating a ladder symbol and a device number .....	4 - 38
4.4.1	(4) By designating a device number with a digit .....	4 - 39
4.4.1	(5) By designating an instruction .....	4 - 40
4.4.1	(6) By designating an instruction (SFT, SET, RST) .....	4 - 41
4.4.1	(7) By designating the final ladder block of a program .....	4 - 42
4.4.2	Auxiliary functions useful for reading a ladder block .....	4 - 44
4.4.2	(1) Switching the display of a program from main to sub when a program is being read (also see Section 4.3.4 (4)) .....	4 - 45
4.4.2	(2) Converting all N/O contacts in a program to N/C contacts and vice versa .....	4 - 46
4.4.2	(3) Simultaneously converting all the designated devices in a program to different devices .....	4 - 48
4.4.2	(4) Changing the set values of timers and counters in a program .....	4 - 51
4.4.2	(5) Clearing all data from a program and comments .....	4 - 53
4.4.2	(6) Changing the program memory capacity in the LADDER mode .....	4 - 54
4.4.2	(7) Copying a ladder block to a designated point .....	4 - 55
4.4.2	(8) Moving a ladder block to a designated point .....	4 - 57
4.4.2	(9) Deleting ladder blocks within a designated range .....	4 - 59
4.4.2	(10) Setting the object to be monitored .....	4 - 61
4.4.2	(11) Listing the contacts and coils of each device used in a program .....	4 - 62
4.4.2	(12) Listing devices used in a program .....	4 - 63
4.4.2	(13) Switching the display of a ladder diagram with or without comment .....	4 - 65
4.4.2	(14) Creating and modifying comments when devices are displayed .....	4 - 67
4.4.2	(15) Adding a comment to a ladder block .....	4 - 69
4.4.2	(16) Adding a comment between lines and to Ps and Is .....	4 - 71
4.4.2	(17) Storing data created in the LADDER mode to a file (See Section 2.2.2) .....	4 - 73
4.5	Monitoring the PC Operation and Control Conditions in the Ladder Diagram Format .....	4 - 74
4.5.1	Screen format common to monitoring functions .....	4 - 74
4.5.2	Ladder monitor operations .....	4 - 76
4.5.2	(1) Monitoring a designated ladder block .....	4 - 76
4.5.2	(2) Switching the display mode of current values selecting from binary, octal, decimal, and hexadecimal display modes .....	4 - 78
4.5.2	(3) Monitoring registered devices which are not being displayed .....	4 - 80
4.5.2	(4) Stopping the monitoring screen .....	4 - 83
4.5.3	Writing data from a PC/AT to a device in a PC CPU during monitoring .....	4 - 86
4.5.3	(1) Forcedly turning ON/OFF the output (Y) .....	4 - 86
4.5.3	(2) Forcedly setting/resetting a bit device .....	4 - 88
4.5.3	(3) Changing the current value of a word device .....	4 - 90
4.5.4	Step run of a PC CPU .....	4 - 92
4.5.4	(1) Stopping the program at each instruction .....	4 - 92

4.5.4	(2) Specifying a loop count, a step number, or a label (P and I) and then, stopping the CPU .....	4 – 94
4.5.4	(3) Stopping a program for a single ladder block .....	4 – 96
4.5.4	(4) Stopping a CPU when the device state is satisfied by a specified condition .....	4 – 97
4.5.5	Separate a device used for the OUT instruction from execution of a PC CPU ( Offline function) .....	4 – 100
4.5.6	Auxiliary that is available at the time of monitoring a ladder .....	4 – 102
4.5.6	(1) Monitor several device states by a batch in 16 point unit .....	4 – 103
4.5.6	(2) Function used for specifying types of devices and monitoring specified ranges in batch .....	4 – 105
4.5.6	(3) Monitoring data in the buffer of a special-function module .....	4 – 108
4.5.6	(4) Switching the display of a monitoring screen with/without comment or statement (see Section 4.4.2 (13)) .....	4 – 109
4.5.6	(5) Switching the display of a program from main to sub during the ladder monitoring operation (see Section 4.3.4 (4)) .....	4 – 109
4.5.6	(6) Setting the object to be monitored (see Section 4.4.2 (10)) .....	4 – 109
<b>5.</b>	<b>LIST MODE IN LIST FORM .....</b>	<b>5 – 1 ~ 5 – 62</b>
5.1	Functions Available in the List Mode .....	5 – 1
5.2	Common Operations List Mode .....	5 – 2
5.2.1	Common Operations when inputting an instruction .....	5 – 2
5.3	Creating a Program in the List Form .....	5 – 5
5.3.1	Creating a new program .....	5 – 6
5.3.2	Correcting an existing program .....	5 – 7
5.3.2	(1) Correcting by overwriting an instruction to an existing program .....	5 – 8
5.3.2	(2) Inserting an instruction in an existing program .....	5 – 10
5.3.2	(3) Deleting an instruction from the existing program .....	5 – 12
5.3.3	Auxiliary functions are available for writing,inserting,and deleting .....	5 – 13
5.3.3	(1) Switching a main/sub program while creating or correcting a list .....	5 – 14
5.3.3	(2) Function used to change N/O contact to N/C,and N/C in a program ..	5 – 16
5.3.3	(3) Function used to convert devices to other devices in a program by batch .....	5 – 18
5.3.3	(4) Function used to change a timer/counter setting value in a program by a batch operation .....	5 – 21
5.3.3	(5) The function used to write an NOP instruction to a specified part of a program or the entire program .....	5 – 24
5.3.3	(6) Function used to continuously insert NOP instruction in a program ...	5 – 26
5.3.3	(7) Function used to delete all NOPs in a program .....	5 – 28
5.3.3	(8) Function used to change the memory capacity of a program in list mode .....	5 – 30
5.3.3	(9) Function used for displaying a condition by using a device in the program .....	5 – 32
5.3.3	(10) Function to display the device use state of a program .....	5 – 34
5.3.3	(11) Function used to store data created in the list made to the user file (see Section 2.2.2) .....	5 – 36
5.4	Reading an Existing Program List .....	5 – 37
5.4.1	Reading a program list .....	5 – 37
5.4.1	(1) Reading a list by specifying a step number .....	5 – 37

5.4.1	(2) Reading a list by specifying a device number .....	5 - 39
5.4.1	(3) Reading a list by specifying a device number with a digit .....	5 - 41
5.4.1	(4) Reading a list by specifying an instruction and device number .....	5 - 43
5.4.1	(5) Reading a list by specifying an instruction .....	5 - 45
5.4.2	Auxiliary functions available for writing, inserting, and deleting .....	5 - 47
5.4.2	(1) Function used to switch the display for the main sequence program and a subsequence program while creating or copying a list (see Section 5.3.3(1)) .....	5 - 48
5.4.2	(2) Function used to copy the program list of a specified range to a specified position .....	5 - 49
5.4.2	(3) Function used to move the program list of a specified range to a specified position .....	5 - 52
5.4.2	(4) Function used to delete the program list of a specified range .....	5 - 55
5.4.2	(5) Function used to change N/O contact to N/C, and N/C to N/O in a program (see Section 5.3.3(2)) .....	5 - 58
5.4.2	(6) Function used to convert devices to other devices in a program by batch (see Section 5.3.3(3)) .....	5 - 58
5.4.2	(7) Function used to change a timer/counter setting value in a program by batch (see Section 5.3.3(4)) .....	5 - 58
5.4.2	(8) Function used to write an NOP instruction to the specified part of program or all of it (see Section 5.3.3(5)) .....	5 - 58
5.4.2	(9) Function used to continuously insert an NOP instruction in a program (see Section 5.3.3(6)) .....	5 - 58
5.4.2	(10) Function used to delete all NOPs in a program (see Section 5.3.3(7)) .....	5 - 58
5.4.2	(11) Function used to change the memory capacity of a program in the list mode (see Section 5.3.3(8)) .....	5 - 58
5.4.2	(12) Function used for the display of a state by using a device in the program (see Section 5.3.3(9)) .....	5 - 58
5.4.2	(13) Function used to display the device step number and instruction of a program (see Section 5.3.3(10)) .....	5 - 58
5.4.2	(14) Function used for switching to the program list display with a comment .....	5 - 59
5.4.2	(15) Function used to store data created in the list mode to the user file (see Section 2.2.2) .....	5 - 62
<b>6.</b>	<b>PROGRAMMING IN THE MICROCOMPUTER MODE .....</b>	<b>6 - 1 ~ 6 - 8</b>
6.1	Functions Available in the Microcomputer Mode .....	6 - 1
6.2	Creating a Microcomputer Program .....	6 - 2
6.2.1	Reading a program area by specifying an address .....	6 - 2
6.2.2	Writing a program in machine language .....	6 - 3
6.2.3	Auxiliary functions available in the microcomputer mode .....	6 - 4
6.2.3	(1) Function used to change the memory capacity of a microcomputer program in the microcomputer mode .....	6 - 4
6.2.3	(2) Switching main/sub microcomputer program in the microcomputer mode .....	6 - 6
6.2.3	(3) Function used to store data created in the microcomputer mode to the user file (See Section 2.2.2) .....	6 - 8

<b>7.</b>	<b>PARAMETER MODE SETTING .....</b>	<b>7 - 1 ~ 7 - 120</b>
7.1	Parameter Mode Functions .....	7 - 1
7.2	Setting of the Memory Capacity for Creating Programs and Writing Comments .....	7 - 3
7.3	Setting the Device Range to be Latched .....	7 - 9
7.4	Setting Communications Contents for Each Station When a Link System is Used ..	7 - 11
7.4.1	Setting link when the MELSECNET mode is selected .....	7 - 11
7.4.2	Link setting when the MELSECNET II (COMPOSIT) is selected .....	7 - 15
7.4.3	Link setting when the MELSECNET II mode is selected .....	7 - 16
7.5	Setting Communications Contents for Each Station and Network when a Network System is Used .....	7 - 17
7.5.1	Setting the number of network modules .....	7 - 19
7.5.2	Establishing correspondence between the PC CPU link devices and network module link devices .....	7 - 22
7.5.2	(1) Establishing correspondence with MELSECNET/10 (PC - to - PC network) link devices .....	7 - 22
7.5.2	(2) Establishing correspondence with MELSECNET/10 (remote I/O network) link devices .....	7 - 25
7.5.2	(3) Establishing the correspondence with MELSECNET II link devices ..	7 - 27
7.5.3	Setting the communications contents for each station when a MELSECNET II data link system is configured with an AnUCPU .....	7 - 29
7.5.3	(1) Link setting method when the MELSECNET mode is selected .....	7 - 29
7.5.3	(2) Link setting method when the MELSECNET II composite mode is selected. ....	7 - 34
7.5.3	(3) Link setting method when the MELSECNET II mode is selected .....	7 - 35
7.5.4	Setting the network configuration specifications .....	7 - 36
7.5.4	(1) Setting the configuration specifications for a PC - to PC network .....	7 - 36
7.5.4	(2) Setting the configuration specifications for a remote I/O network .....	7 - 50
7.5.5	Station specific parameter setting .....	7 - 63
7.5.5	(1) Station specific parameter setting .....	7 - 63
7.5.5	(2) Station specific parameter file reading .....	7 - 65
7.5.5	(3) Rearranging the station order .....	7 - 67
7.5.6	I/O allocation .....	7 - 68
7.5.7	Setting the parameters for data transfer between network modules .....	7 - 70
7.5.8	Correcting set network parameters .....	7 - 72
7.5.9	Routing parameter setting .....	7 - 74
7.6	Allocating I/O Modules .....	7 - 76
7.6.1	Allocating inputs and outputs .....	7 - 76
7.6.2	Module name registration .....	7 - 78
7.7	Setting the Subfunctions of the Parameter Mode .....	7 - 81
7.7.1	Setting the A0J2CPU auxiliary function .....	7 - 83
7.7.2	Setting the auxiliary functions of the A0J2H/A1S/A1/A2/A3/A3HCPU .....	7 - 84
7.7.2	(1) Setting the step relay .....	7 - 84
7.7.2	(2) Timer setting .....	7 - 86
7.7.2	(3) Setting RUN-PAUSE .....	7 - 88
7.7.2	(4) Setting output mode when STOP-RUN .....	7 - 90
7.7.2	(5) Setting the interrupt counter .....	7 - 92
7.7.2	(6) Setting the watchdog timer .....	7 - 94

7.7.2	(7) Setting the operation mode when an error occurs	7 – 96
7.7.2	(8) Setting the annunciator display mode	7 – 98
7.7.2	(9) Setting the I/O control	7 – 100
7.7.3	Setting the A2CCPU auxiliary function	7 – 102
7.7.3	(1) Setting the step relay (see Section 7.7.2 (1))	7 – 102
7.7.3	(2) Setting the timer (see Section 7.7.2 (2))	7 – 102
7.7.3	(3) Setting the RUN-PAUSE (see Section 7.7.2 (3))	7 – 102
7.7.3	(4) Setting the output mode at STOP - RUN (see Section 7.7.2 (4))	7 – 102
7.7.3	(5) Setting the watchdog timer (see Section 7.7.2 (6))	7 – 102
7.7.3	(6) Setting the operation mode when an error occurs (see Section 7.7.2 (7))	7 – 102
7.7.3	(7) Setting the remote I/O and remote terminal	7 – 103
7.7.4	Setting the AnA/AnUCPU auxiliary functions	7 – 106
7.7.4	(1) Setting the step relay (see Section 7.7.2 (1))	7 – 106
7.7.4	(2) Setting the timer	7 – 107
7.7.4	(3) Setting the RUN-PAUSE (see Section 7.7.2 (3))	7 – 110
7.7.4	(4) Setting the output mode at STOP-RUN (see Section 7.7.2 (4))	7 – 110
7.7.4	(5) Setting the interrupt counter	7 – 110
7.7.4	(6) Setting the counter	7 – 112
7.7.4	(7) Setting the operation mode when an error occurs (see Section 7.7.2 (7))	7 – 114
7.7.4	(8) Setting the annunciator display mode (see Section 7.7.2 (8))	7 – 114
7.7.4	(9) Setting the MELSECNET/MINI automatic refresh	7 – 114
7.7.4	(10) CPU operation mode setting	7 – 118
7.8	Setting Parameters to Default Values	7 – 120
7.9	Storing Network Parameter Set Values to the User's File (see Section 2.2.2)	7 – 120
7.10	Storing the Parameter Set Data to the User's File (see Section 2.2.2)	7 – 120

## 8. COMMUNICATIONS BETWEEN A PC/AT AND A PC CPU .....8 – 1 ~ 8 – 131

8.1	Usable Functions in the Online Mode	8 – 1
8.2	Setting the Station to be Accessed	8 – 3
8.3	Data Communications between the PC/AT and a PC CPU	8 – 7
8.3.1	Reading PC CPU programs and data using the PC/AT	8 – 7
8.3.2	Writing PC/AT programs and data to a PC CPU	8 – 11
8.3.3	Verifying programs and data between the PC/AT internal memory and a PC CPU	8 – 16
8.3.4	Writing data from a PC/AT to a PC CPU and confirming the operation state	8 – 21
8.3.4	(1) Forced output	8 – 21
8.3.4	(2) Setting and resetting devices	8 – 23
8.3.4	(3) Changing present values	8 – 25
8.3.4	(4) Error step	8 – 27
8.3.4	(5) Remote operation	8 – 29
8.3.4	(6) Clearing all device memory	8 – 31
8.3.4	(7) Clearing all PC memory	8 – 32
8.3.5	Disabling read and write of a sequence program using an entry code	8 – 33
8.3.5	(1) Registering a new entry code	8 – 33
8.3.5	(2) Changing the entry code	8 – 35

8.3.5	(3) Canceling the entry code .....	8 – 37
8.3.5	(4) Setting the entry code .....	8 – 39
8.3.6	Creating PC CPU data using the PC/AT .....	8 – 41
8.4	Function for Monitoring Link Information on Each Station in the Data Link .....	8 – 43
8.4.1	When the PC model is other than AnU .....	8 – 43
8.4.1	(1) Monitoring the link state of a master, local, or remote I/O station .....	8 – 43
8.4.1	(2) Monitoring the link states of the self and a local station .....	8 – 47
8.4.1	(3) Monitoring the loop state of the a connected remote I/O station .....	8 – 50
8.4.2	Monitoring an I/O station connected in batch .....	8 – 53
8.4.3	When the PC model is AnU .....	8 – 55
8.4.3	(1) Monitoring lines in MELSECNET/10 systems .....	8 – 55
8.4.3	(2) Monitoring MELSECNET/10 data link statuses .....	8 – 64
8.4.3	(3) Monitoring the MELSECNET/10 error history .....	8 – 70
8.4.3	(4) MELSECNET/10 link start/stop .....	8 – 72
8.5	Function for Monitoring the Network Status While MELSECNET/10 is Online (AnUCPU only) .....	8 – 74
8.5.1	Checking the forward/reverse loop state .....	8 – 74
8.5.2	Confirming the setting status of each station .....	8 – 77
8.5.3	Confirming the station order for forward/reverse loops .....	8 – 79
8.5.4	Performing a communication test between networks .....	8 – 81
8.6	Function Used to Read and Display the PC CPU Status Latch Area .....	8 – 84
8.6.1	Status latch operating procedure .....	8 – 84
8.6.2	Setting the status latch .....	8 – 86
8.6.2	(1) Setting the status latch (except AnA and AnUCPU) .....	8 – 86
8.6.2	(2) Setting the status latch when an AnA or AnUCPU is used .....	8 – 90
8.6.3	Reading status latch data from the PC CPU .....	8 – 95
8.6.4	Reading status latch data from a file .....	8 – 96
8.6.5	Writing status latch data to the file .....	8 – 98
8.6.6	Displaying (monitoring) status latch .....	8 – 100
8.7	Function Used to Store Data in a Specified Device in the Sampling Trace Area and to Display the Data .....	8 – 102
8.7.1	Sampling trace procedure .....	8 – 102
8.7.2	Setting the sampling trace .....	8 – 104
8.7.2	(1) When an A2, A3, A3H, A0J2H, A1S, or A2CCPU is used .....	8 – 104
8.7.2	(2) When an AnA or AnUCPU is used .....	8 – 106
8.7.3	Registering devices to be sampled and conditions .....	8 – 108
8.7.4	Displaying sampling trace results .....	8 – 111
8.7.4	(1) Sampling trace results displaying procedure .....	8 – 111
8.7.4	(2) Reading trace data from a PC CPU .....	8 – 114
8.7.4	(3) Reading trace data from a file .....	8 – 115
8.7.4	(4) Writing trace data to the file .....	8 – 117
8.8	When the Sampling Function is Done in the Same Way as the Status Latch Function .....	8 – 119
8.8.1	Monitoring trace procedure .....	8 – 119
8.8.2	Registering the devices and conditions for a monitoring trace .....	8 – 120
8.8.3	Displaying the monitoring trace results .....	8 – 125
8.8.3	(1) Monitoring trace results display procedure .....	8 – 125

8.8.3	(2) Writing the trace data to the file .....	8 – 128
8.8.3	(3) Reading the trace data from the file .....	8 – 130
<b>9.</b>	<b>CREATING A COMMENT STATEMENT .....</b>	<b>9 – 1 ~ 9 – 86</b>
9.1	Creating Comments for Each Device .....	9 – 1
9.1.1	Functions that can be used in the comment mode .....	9 – 1
9.1.2	Setting the range of comments to be created .....	9 – 2
9.1.2	(1) Setting the comment range .....	9 – 2
9.1.2	(2) Changing the comment capacity .....	9 – 4
9.1.2	(3) Deleting comment data and range setting data .....	9 – 6
9.1.3	Editing comments .....	9 – 7
9.1.3	(1) Specifying and reading the devices to which comments will be created .....	9 – 7
9.1.3	(2) Writing a comment to a specified device .....	9 – 9
9.1.3	(3) Switching the comment editing mode between the main program and the sub-program .....	9 – 12
9.1.3	(4) Replacing a specified string of comment data characters .....	9 – 13
9.1.3	(5) Copying or moving created comments .....	9 – 15
9.1.3	(6) Storing a comment in the cut and paste buffer .....	9 – 17
9.1.3	(7) Reading comment data from the cut and paste buffer using a specified device .....	9 – 18
9.1.4	Reading comment data from a specified file to be utilized .....	9 – 19
9.1.5	Storing comment data in the user's file (see Section 2.2.2) .....	9 – 20
9.1.6	Reading comment data from a PC CPU .....	9 – 21
9.1.7	Writing comment data to a PC CPU .....	9 – 23
9.2	Creating Expansion Comments for Each Device .....	9 – 24
9.2.1	Functions that can be used in the expansion comment mode .....	9 – 24
9.2.2	Setting the range of devices where comment data is created .....	9 – 26
9.2.2	(1) Setting the range of expansion comments .....	9 – 26
9.2.2	(2) Changing the expansion comment capacity in the expansion comment1 mode .....	9 – 28
9.2.2	(3) Setting the valid programs for extension comments .....	9 – 30
9.2.2	(4) Deleting expansion comment data and range setting data .....	9 – 31
9.2.3	Editing expansion comments .....	9 – 32
9.2.3	(1) Specifying and reading devices to which expansion comments will be created .....	9 – 32
9.2.3	(2) Writing an expansion comment to a specified device .....	9 – 34
9.2.3	(3) Replacing a specified character string in expansion comment data .....	9 – 36
9.2.3	(4) Copying or moving created expansion comments .....	9 – 38
9.2.3	(5) Saving a created expansion comment in the cut & paste buffer .....	9 – 40
9.2.3	(6) Reading expansion comment data from a cut & paste buffer to a designated device which utilizes the comment data .....	9 – 41
9.2.4	Utilizing data registered in comments 1 and 2 in the expansion comment file .....	9 – 42
9.2.5	Reading expansion comment data from a specified file and utilizing that data .....	9 – 44
9.2.6	Storing expansion comment data in the user's file (see Section 2.2.2) .....	9 – 45
9.2.7	Reading expansion comment data from an AnA or AnUCPU .....	9 – 46
9.2.8	Writing expansion comment data to an AnA or AnUCPU .....	9 – 48



9.3	Creating Statements (Line and P.I.) for Each Ladder Block and Label .....	9 – 49
9.3.1	Functions that can be used in the statement mode .....	9 – 49
9.3.2	Editing a line statement .....	9 – 50
9.3.2	(1) Writing a line statement on a specified line .....	9 – 50
9.3.2	(2) Reading a line statement with a specified step number .....	9 – 52
9.3.2	(3) Deleting a line statement with a specified number .....	9 – 54
9.3.2	(4) Clearing all line statement data being edited .....	9 – 55
9.3.2	(5) Switching the mode between the main sequence program and the sub-sequence program .....	9 – 56
9.3.2	(6) Moving a copy of specified line statement to a specified position .....	9 – 58
9.3.2	(7) Inserting or deleting a line statement .....	9 – 59
9.3.2	(8) Making a copy of a line statement and moving that copy to a specified line .....	9 – 60
9.3.3	Editing a P.I. statement .....	9 – 62
9.3.3	(1) Creating a statement for a specified label .....	9 – 62
9.3.3	(2) Specifying a device number of the P.I. statement to be edited .....	9 – 64
9.3.3	(3) Specifying a device number of the P.I. statement to be deleted .....	9 – 65
9.3.3	(4) Deleting all P.I. statements being edited .....	9 – 66
9.3.3	(5) Switching the mode between the main sequence program and the sub-sequence program while editing a P.I. statement .....	9 – 67
9.3.3	(6) Placing a copy of a P.I. statement saved in the internal buffer in a specified position .....	9 – 69
9.3.4	Creating a title for data to be printed out in the printer mode .....	9 – 71
9.3.5	Creating statements for each printed item to be printed out on each page ..	9 – 73
9.3.6	Creating a print header title .....	9 – 75
9.3.7	Editing notes .....	9 – 77
9.3.7	(1) Writing a note to a specified step No. ....	9 – 77
9.3.7	(2) Reading a note by specifying a step number .....	9 – 79
9.3.7	(3) Deleting a note by specifying a step number .....	9 – 80
9.3.7	(4) Deleting all notes being created .....	9 – 81
9.3.7	(5) Switching the display between the main program and subprogram during note editing .....	9 – 82
9.3.7	(6) Copying a specified note to a specified location .....	9 – 84
9.3.7	(7) Cutting a specified note, storing it in the internal buffer and copying it to a specified location .....	9 – 85
10.	PRINTING DATA CREATED AND SET IN EACH MODE .....	10 – 1 ~ 10 – 64
10.1	Function Available in the PRINTER Mode .....	10 – 1
10.2	Setting a PRINTER and Printing Conditions .....	10 – 2
10.3	Execution of Each Printing Option .....	10 – 5
10.3.1	Printing a sequence program in the LADDER format .....	10 – 5
10.3.2	Printing a sequence program in list format .....	10 – 10
10.3.3	Printing CONTACT COIL LIST in a program .....	10 – 14
10.3.4	Printing devices used in a program in list display format .....	10 – 18
10.3.5	Printing bit device and word device data in list display format .....	10 – 22
10.3.6	Printing COMMENT 1/2, and EX.COMMENT .....	10 – 26
10.3.6	(1) Selecting a COMMENT other than an EX.COMMENT .....	10 – 26
10.3.6	(2) Selecting an EX.COMMENT .....	10 – 30

10.3.7	Printing data set in the PARAMETER mode .....	10 - 34
10.3.8	Printing UTILIZED CIRCUIT pattern .....	10 - 44
10.3.9	Printing a PRINT TITLE set in the STATEMENT mode .....	10 - 48
10.3.10	Printing a LINE or P.I STATEMENT .....	10 - 51
10.3.11	Printing timer/counter setting value lists .....	10 - 55
10.3.12	MULTIPLE printing .....	10 - 59
10.3.13	Printing TROUBLE SHOOTING or GUIDANCE from the HELP menu ...	10 - 62
<b>11.</b>	<b>FILE MAINTENANCE .....</b>	<b>11 - 1 ~ 11 - 41</b>
11.1	Functions Available in the File Maintenance Mode .....	11 - 2
11.2	Displaying the Directory of a File Name Stored in a Disk .....	11 - 4
11.3	Reading Data from a Disk to the PC/AT Internal Memory .....	11 - 6
11.3 (1)	Reading the type selected .....	11 - 6
11.3 (2)	Reading a status latch, sampling trace, monitoring trace, or device memory ...	11 - 12
11.4	Writing Data to Disk from the PC/AT Internal Memory .....	11 - 14
11.4 (1)	Writing by selecting a type .....	11 - 14
11.4 (2)	Writing a status latch, sampling trace, monitoring trace, or device memory ....	11 - 17
11.5	Verifying Data Between the PC/AT Internal Memory and a Disk .....	11 - 20
11.5 (1)	Verifying each type .....	11 - 20
11.5 (2)	Verifying a sampling trace, monitoring trace, status latch, or device memory ...	11 - 23
11.6	Deleting an Unnecessary File from a Disk .....	11 - 25
11.6.1	Deleting a specified system name from the system name list .....	11 - 25
11.6.2	Deleting a specified subsystem name from the subsystem name list .....	11 - 27
11.6.3	Deleting a specified type name from the subsystem name type select display .....	11 - 29
11.7	Copying a File Between Specified Disks .....	11 - 31
11.7.1	Copying all the files of a subsystem name list between specified disks ...	11 - 31
11.7.2	Copying the specified type of subsystem name between specified disks ...	11 - 33
11.8	Creating a New System Name to the Memory Area of a Specified Disk .....	11 - 35
11.9	Setting the Form and Order of a Directory Display .....	11 - 37
11.10	Printing a System Name, Subsystem Name, and Names of all Types of CPUs .....	11 - 39
11.11	Converting the Directory Format of an SW0S User Disk into the Same Format as an SW2IVD .....	11 - 41
<b>12.</b>	<b>THE OPTION MODE .....</b>	<b>12 - 1 ~ 12 - 32</b>
12.1	Functions Available in the Option Mode .....	12 - 1
12.2	Converting Data from an A6GPP File to a PC/AT File .....	12 - 2
12.2.1	Converting a program and comment created with an A6GPP into the data format for a PC/AT .....	12 - 2
12.2.2	Converting a program and comment created with a PC/AT into A6GPP data format .....	12 - 5
12.3	Storing a Parameter and Sequence Program in ROM .....	12 - 8
12.3.1	Connecting a ROM writer and a PC/AT and setting the ROM writer .....	12 - 8
12.3.2	Setting the memory capacity of the EP-ROM .....	12 - 9
12.3.3	Selecting the model of a ROM writer .....	12 - 16
12.3.4	Using a ROM writer to read data from the ROM to a PC/AT .....	12 - 18
12.3.5	Using a ROM writer to write data to the ROM from a PC/AT .....	12 - 21

12.3.5	(1) Writing data to a ROM .....	12 - 21
12.3.5	(2) Writing data to be transferred to the ROM writer into a file .....	12 - 23
12.3.6	Using the ROM writer to verify data between a PC/AT and a ROM .....	12 - 26
12.3.7	Using a ROM writer to check whether ROM data is deleted .....	12 - 29
12.3.8	Setting the PC/AT communication port to which the ROM writer is connected .....	12 - 30
12.4	DOS Mode .....	12 - 32
<b>13.</b>	<b>RESETTING THE INITIAL STATE AND QUITTING THE GPP FUNCTION .....</b>	<b>13 - 1 ~ 13 - 12</b>
13.1	Setting a User File to Write Created Data (Programs, Comments, etc.) .....	13 - 1
13.1	(1) Create .....	13 - 1
13.1	(2) File Read .....	13 - 4
13.1	(3) File Write .....	13 - 6
13.1	(4) PC Type Change .....	13 - 8
13.2	Quitting the GPP Function .....	13 - 11
13.2	(1) Save & Quit .....	13 - 11
13.2	(2) Abort .....	13 - 12
<b>14.</b>	<b>HELP .....</b>	<b>14 - 1 ~ 14 - 4</b>
14.1	The HELP Function at the Time of an Error Occurrence .....	14 - 1
14.2	The HELP Function During Operation .....	14 - 2
14.3	Displaying the Guidance HELP Menu .....	14 - 3
<b>15.</b>	<b>ERROR MESSAGE LIST .....</b>	<b>15 - 1 ~ 15 - 21</b>
15.1	Error Messages in the Ladder Mode .....	15 - 2
15.2	Error Message in the List Mode .....	15 - 6
15.3	Error Message in the Microcomputer Mode .....	15 - 8
15.4	Parameter Mode Error Messages	
15.4.1	Error messages when setting MELSECNET (II) link parameters .....	15 - 9
15.4.2	Error messages in the parameter mode .....	15 - 11
15.5	Error Messages in the On-Line Mode .....	15 - 13
15.6	Error Message in the Printer Mode .....	15 - 15
15.6.1	Error messages in the comment mode .....	15 - 15
15.6.2	Error messages in the expansion comment mode .....	15 - 16
15.6.3	Error message in the statement mode .....	15 - 17
15.7	Error Messages in the Printer Mode .....	15 - 18
15.8	Error Messages in the File Maintenance Mode .....	15 - 19
15.9	Error Messages in the Option Mode .....	15 - 21
<b>APPENDICES</b> .....	<b>APP - 1 ~ APP - 5</b>	
<b>APPENDIX 1</b> PROCESSING TIME .....	<b>APP - 1</b>	
<b>APPENDIX 2</b> REQUIRED MEMORY CAPACITIES FOR FILE WRITING .....	<b>APP - 2</b>	
<b>APPENDIX 3</b> DATA COMPATIBILITY WITH PACKAGES NOT COMPATIBLE WITH AnUCPU .....	<b>APP - 4</b>	

APPENDIX4 PRECAUTIONS ON SOFTWARE PACKAGE COMBINATIONS WHEN USING THE MELSAP-II (SFC) FUNCTION .....	APP-5
---	-------


## 5. LIST MODE IN LIST FORM

The list mode is used to create, correct, and read a sequence program in list form.

The list mode functions are shown below.

## 5.1 Functions Available in the List Mode

The list mode functions consist of the following:



## 5. LIST MODE

### Instruction of key operation

MELSEC-A

#### 5.2 Common Operations in the List Mode


This Section explains the fundamental methods of inputting programming in the list form and restricted items in the ladder mode.

Make sure to read this section carefully before programming.

##### 5.2.1 Common operations when inputting an instruction

The basic operation to input an instruction in the list mode is as follows:

(Instructions that need a set value and data instructions do not apply to this operation.)




When inputting an instruction, use a function key to select a ladder instruction.

The methods of inputting an instruction and the allocation of function keys are common to all functions in this mode.

As shown below, the ladder symbol allocated to a function key is displayed on the bottom of the screen.

Function display when an instruction is input



Function Key	Instruction	Ladder Symbol	Function Key	Instruction	Ladder Symbol
[F5]	LD		[Shift] + [F7]	ORI	
[Shift] + [F5]	LDI		[F8]	ANB	
[F6]	AND		[Shift] + [F8]	NOP	
[Shift] + [F6]	ANI		[F9]	ORB	
[F7]	OR		[F10]	OUT	

## 5. LIST MODE

### Instruction of key operation

MELSEC-A

An example of a simple key operation is shown below.

Instruction		Key Operation	
LD X001		F5	X 1 Enter
OUT T1K100		F10	T 1 SP K 1 0 0 Enter
MOV D0 D1		M	O V SP D 0 SP D 1 Enter

(Section 5.3.1 gives an operation example)

(Keys which simplify operations)

Each function is allocated a function key to simplify operations when creating and displaying a sequence program.

Key Operation	Instruction	Key Operation	Instruction	Key Operation	Instruction	Key Operation	Instruction
Alt + F1	END	Alt + F4	BIN	Alt + F7	PLS	Alt + F10	MCR
Alt + F2	MOV	Alt + F5	SET	Alt + F8	PLF		
Alt + F3	BCD	Alt + F6	RST	Alt + F9	MC		

Key Operation	Instruction	Key Operation	Instruction
Ctrl + F1	File write	Ctrl + F7	Display switching of a program with a statement
Ctrl + F5	Display switching of a program with a comment 1	Ctrl + F8	Display switching deletion of a program with a note
Ctrl + F6	Display switching of a program with a comment 2	Shift + F11	Switching of the program formation (Ladder list)

Precautions when inputting an instruction

- (1) Make sure to press the [SP] key between an instruction and a device number and between a device number and a set value.
- (2) Make sure to press the [Enter] key after inputting an instruction.
- (3) An instruction can be input by using an operation simplifying key instead of pressing a key.

(Section 2.2.3 gives shortening details.)

#### POINT

##### • Input of devices X, Y, and B

The devices (X, Y, and B, etc.) to be expressed in hexadecimal are displayed in three hexadecimal digits. When writing data, zeros don't have to be inputted.

Example:

X 2 → X002  
 (Input) (Display)

##### • Correcting a key operation mistake

Move the cursor to the place to be corrected by using a [←] key. After correcting, input correct data.

##### • Batch clear of display data of a key operation area

Press the [Ctrl] + [Y] keys to batch clear data displayed in a key operation area.

## 5. LIST MODE

### Instruction of key operation

MELSEC-A

#### ADVICE

- Input of the extension timer and the counter of an A2A and A3ACPU (T256~ and C256~)

It is necessary to input a set value to the timer and counter within the ranges of T0 to T255 and C0 to C255.

However, it is not necessary to input a set value to the timer and the counter beyond T256 and C256 that can be set at A2A and A3ACPU.

(If it is necessary to correct data, do so in the parameter mode.)

Example 1: To input C1

F10 (-<->) C 1 SP K 1 0 Enter

Input a set value.

Example 2: To input T300

F10 (-<->) T 3 0 0 Enter

A set value is unnecessary.

Pressing the [Enter] key automatically displays the device and device number set in the parameter.

(see Sections 7.6.4(2) and 7.6.4(6))

- Input the indexes of the contact and the coil of AnA and AnUCPU.

After inputting the indexes of the contact and the coil of AnA and AnUCPU, the listing is shown below.

Instruction	Key Operation
LD X000Z3	F5 X 0 Z 3 Enter
OUT Y010V2	F10 Y 1 0 V 2 Enter

- Key operation error message

Error Description	Error Message
When writing a sequence program, the device and the device number that could not be specified were selected.	CANNOT INPUT DEVICE NUMBER
A command was written that caused a grammatical error.	COMMAND ERROR



## 5.3 Creating a Program in the List Form

This Section provides an explanation of how to write a program in the list form.

Programming in the list form can only be done by a list instruction. Therefore it is simpler and faster than a ladder form. A ladder form could be created by using a circuit diagram.

However, because a list form cannot be created by using a circuit diagram, it is necessary to be very careful about using correct grammar.

**ADVICE**

- **When creating a program, the same device is used two times.**

Thus, when creating a program, if the following instruction of the same device is used two times or more, "COIL ALREADY USED. STEP = XX" is displayed.

The same coil can be used two times or more.

However, pay close attention to the operation of the program.

When correcting the same coil, correct according to the indication of "STEP = XXX".

	Y	M	L	B	F	T	C
OUT	O	O	O	O	O	O	O
SET	O	O	O	O	O		
SFT	O	O	O	O	O		
PLS	O	O	O	O	O		
PLF	O	O	O	O	O		
SFTP	O	O	O	O	O		

Devices P and I are used for the same label check.

When the same label is specified, "LABEL ALREADY USED. STEP = XX" is displayed.

The same label cannot be written.

## 5. LIST MODE

### Creating a new program

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.1 Creating a new program

A program is created using an instruction list.

#### OPERATION EXAMPLE

**BEFORE**

0	NOP
1	NOP
2	NOP
3	NOP
4	NOP
5	NOP
6	NOP
7	NOP
8	NOP

↓

**AFTER**

0	LD	X001
1	NOP	
2	NOP	
3	NOP	
4	NOP	
5	NOP	
6	NOP	
7	NOP	
8	NOP	

To write LDX1 to step No. 0:

F1 → F5 → X → 1 → Enter

Select write in the list mode      LD      Input X1

LDX001 enters step 0 and the cursor moves to step 1.

#### OPERATING PROCEDURE

F1 → F5 → X → 1 → Enter

0	LD	X001
1	NOP	
2	NOP	
3	NOP	
4	NOP	
5	NOP	
6	NOP	
7	NOP	
8	NOP	

- 1 Select list (2) from the programming selection screen. Then, the read function is automatically enabled. A read list is displayed from step 0. Press the [F1] key. The writing function is now enabled and an instruction can be input.

## 5. LIST MODE

### Correcting a program

PC models	ALL TYPES
--------------	-----------

**MELSEC-A**

#### 5.3.2 Correcting an existing program

This Section explains how to correct a program in the list mode.

Correction

- (1) Correction by an overwrite
- (2) Correction by insertion
- (3) Correction by deletion

## 5. LIST MODE

### Correcting by overwriting a list

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.2 (1) Correcting by overwriting an instruction to an existing program

An instruction is overwritten and corrected in an existing program.

#### OPERATION EXAMPLE

**BEFORE**

19 AND	Y070
20 AND	Y0AF
21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
28 OUT	Y0B1
29 LD	X323

↓

**AFTER**

21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X005
27 AND	X000
28 OUT	Y0B1
29 LD	X323
36 AND	Y390
	AND X5

COMPLETED

To overwrite AND X31F to AND X5 of step No. 26:

F1 → 2 → 6 → Enter → F6 → X → 5 → Enter

Select write in the list mode      Read step No.26 to be corrected      AND instruction      Input device

#### OPERATING PROCEDURE

F1 → 2 → 6 → Enter

19 AND	Y070
20 AND	Y0AF
21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
28 OUT	Y0B1
29 LD	X323

1 Input the step number of the instruction to be corrected after pressing the [F1] key.

The cursor is moved to the position of the specified step number.

F6 → X → 5

21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
36 AND	Y390
	AND X5

2 Press the key for the instruction to be corrected.

Keyed-in data is displayed below the bottom step.

## 5. LIST MODE

### Correcting by overwriting a list

MELSEC-A

Enter		
25 LD	X2A0	
26 AND	X31F	
27 AND	X000	
36 AND	Y390	
	AND X5	
COMPLETED		

3 Press the [Enter] key to input the new instruction.

When the correction is completed, the following message is displayed.

#### ADVICE

- Specify a list instruction by using the cursor and display it in the keyed-in data area.

Move the cursor to the modified step number and press the [Enter] key.


Then, the keyed-in data area displays an existing list instruction.

Data can be corrected in the keyed-in data area.

However, this operation enables writing and an insertion function. When a keyed-in data area displays nothing, it is valid.

(Example of correcting data)

To change MOV P K4X020 D0 to MOV P K4X020 D1



## 5. LIST MODE

### Insert and adding to a program

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.2 (2) Inserting an instruction in an existing program

Insert a list instruction in a program.

#### OPERATION EXAMPLE

**BEFORE**

19 AND	Y070
20 AND	Y0AF
21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF

↓

**AFTER**

22 AND	Y000
24 OUT	F102
26 LD	X2A0
27 AND	X31F
28 AND	X000
29 AND	Y07F
30 AND	Y2A0
34 ORB	
	AND Y0

COMPLETED. STEP NUMBER CHANGED.

To insert AND Y0 into step No. 22:

Shift+F1 → 2 → 2 → Enter → F6 → Y → 0 → Enter

Select insert in  
the list mode

Read step No. 22  
to be inserted

AND  
instruction

Input device

#### OPERATING PROCEDURE

Shift+F1 → 2 → 2 → Enter

19 AND	Y070
20 AND	Y0AF
21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF

- When inserting and adding data to a program, press the key of the step number that is inserted after pressing the [Shift] + [F1] keys.

The cursor moves to the position of the specified step number.

F6 → Y → 0

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	Y000
32 AND	Y02F
33 ORB	
34 OUT	F103
	AND Y0

- Press the key of the instruction to be inserted.  
Keyed-in data is displayed below the bottom step.

## 5. LIST MODE

### Insert and adding to a program

MELSEC-A

Enter

22 AND	Y000
23 OUT	F102
26 LD	X2A0
27 AND	X31F
34 ORB	
	AND Y0
COMPLETED. STEP NUMBER CHANGED.	

- 3 Press the [Enter] key to insert an instruction in a specified position.

When the insertion is completed, the following message is displayed.

### POINT

- **Insertion by moving the cursor**

The insertion operation is enabled by moving the cursor to a specified place by using the [↑], [↓], [Page Up], and [Page Down] keys instead of specifying a step number.

- **END check**

If the number of steps increases during an insertion function, and the END and FEND instructions exceed the memory area, "END WILL BE DELETED. EXECUTE?" is displayed.

Select "YES" to execute the insertion.

Or select "NO" to stop the insertion.

If an insertion is executed without erasing the END instruction, increase the memory capacity by using a memory capacity setting.

## 5. LIST MODE

### Deleting a list of program

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.2 (3) Deleting an instruction from the existing program

The following operation deletes the list instruction of a specified step:

#### OPERATION EXAMPLE

**BEFORE**

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	Y000
32 AND	Y02F
33 ORB	
34 OUT	F103
37 LD	X340

To delete AND Y0 of step No. 31:

Shift+F2

3

1

Enter

Enter

Select delete  
in the list mode

Read step No. 31  
to be deleted

Execute

**AFTER**

30 AND	Y2DF
31 AND	X02F
32 ORB	
33 OUT	F103

31  
COMPLETED. STEP NUMBER CHANGED.

#### OPERATING PROCEDURE

Shift+F2 → 3 → 1 → Enter

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	Y02F
32 ORB	
33 OUT	F103
36 LD	X340
37 AND	X38F

- 1 Input the step number of the list instruction to be deleted after pressing the [Shift] + [F2] keys.

The cursor moves to the position of the specified step number.

Enter

30 AND	X2DF
31 AND	X02F
32 ORB	
33 OUT	F103

31  
COMPLETED. STEP NUMBER CHANGED.

- 2 The instruction of the specified step number is deleted. The step number following the deletion is moved up. When the operation is completed, the following message is displayed.

#### POINT


##### • Insertion by moving the cursor

The insertion operation is enabled by moving the cursor to a specified place by using the [↑], [↓], [Page Up] and [Page Down] keys instead of specifying a step number.



## 5.3.3 Auxiliary functions are available for writing, inserting, and deleting

Auxiliary functions are available for writing, inserting, and deleting in the list mode.



## 5. LIST MODE

### Switching a main/sub

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	O	O	X	O	X	O	O

**MELSEC-A**

#### 5.3.3 (1) Switching a main/sub program while creating or correcting a list

This function is used to switch a program to a subsequence program from the main sequence program in order to read the subsequence program when operating the main sequence program in the list mode.

In addition, a program can be switched to the main sequence program from a subsequence program in order to read the main sequence program when operating the subsequence program.

#### OPERATION EXAMPLE

To switch the main sequence program to a subsequence program:

Before switching, write the main sequence program data to a file.

```

graph LR
    F4[F4] --> 1[1]
    1 --> Enter[Enter]
    Enter --> 2[2]
    F4 --- F4_desc[Select an auxiliary function]
    1 --- 1_desc[Select an M/S switch]
    Enter --- Enter_desc[Confirm the M/S switch (Select "YES")]
    2 --- 2_desc[2]
        
```

#### OPERATING PROCEDURE

F4

1

MAIN/SUB PROGRAM SWITCH?

YES      NO

2

MAIN/SUB PROGRAM SWITCH?

YES      NO

**1** Select an auxiliary function.

The auxiliary function window opens.

**REMARK**

An auxiliary function can be selected by pressing a 1 - 4 key or the cursor key.

**2** Select 1 (M/S SWITCH).

"MAIN/SUB PROGRAM SWITCH?" is displayed.


Select "YES".

## 5. LIST MODE

### Switching a main/sub


MELSEC-A

Enter



- 3 Select "YES" to display the program selection screen. SUB PROGRAM 2 and SUB PROGRAM 3 can only be selected if the PC model is A4U.

2



- 4 Switch the displayed screen from the main sequence program to sub-sequence program 1. Switching is completed when, as shown to the left, the M/S switching display on the top line of the screen changes.

#### POINT

##### • When there is no program to be switched

If the file (the file in which a subsequence program is stored) of a subsequence program does not have a program, even if file writing before switching it is selected, then the screen is switched to the new writing mode of a subsequence program (when switching it from the main sequence program to a sub-sequence program).

If the file of a subsequence program does have a program, the list of the subsequence program is displayed from step 0.

##### • Display when switching

When a subsequence program is switched to the main sequence program, the list of the main sequence program is displayed from step 0.

##### • Abbreviated operation for M/S switching

It is possible to execute the M/S switching function by using the following key operation: [Alt] ([CTRL]) + [0] to [4].

[Alt] ([CTRL]) + [0] ...Main sequence program display

[Alt] ([CTRL]) + [1] ...Sub-sequence program 1 display

[Alt] ([CTRL]) + [2] ...Sub-sequence program 2 display

[Alt] ([CTRL]) + [3] ...Sub-sequence program 3 display

[Alt] ([CTRL]) + [4] ...SFC program display  
(valid only when MELSAP 2 function is registered)

These abbreviated key operations are possible when using the read function in list mode. If the PC model is other than A4U, it is not possible to select sub-sequence program 2 or sub-sequence program 3.

##### • Condition of a statement and a note when switching M/S

When switching M/S, a statement and a note are switched simultaneously.

##### • File writing before switching

If M/S switching is done without doing file writing after correcting the main sequence program (or a subsequence program), the data corrected with the main sequence (or subsequence) program is cleared.

##### • Created data on M/S switching

When an M/S switching operation is executed, the program displayed on the screen is temporarily consigned to memory.

Be sure to perform file writing before reading another file or ending the GPP function.

## 5. LIST MODE

### N/O and N/C contacts batch change

PC  
models

ALL TYPES

**MELSEC-A**

#### 5.3.3 (2) Function used to change N/O contact to N/C, and N/C to N/O in a program

A specified device is changed from the N/O contact (—|—) to the N/C contact (—|/—) or it is changed from the N/C contact to the N/O contact.

There are two ways of doing this changing. They are a batch change and a change with confirmation.

The following example explains the batch change.

#### OPERATION EXAMPLE

**BEFORE**

25 OUT	C0	K20
26 AND	Y041	
27 LD	C0	
28 OR	X000	
29 RST	C0	
32 RST	D1	

↓

**AFTER**

25 OUT	C0	K20
26 AND	Y041	
27 LD	C0	
28 ORI	X000	
29 RST	C0	
32 RST	D1	

COMPLETED. CHANGED=4 NOT CHANGED=0

To change a contact which uses X000 from N/O (—|—) to N/C (—|/—) and vice versa:

F4

→

2

→

1

→

X

→

0

→

Enter

→

→

→

Enter

Select an  
auxiliary  
function

Select  
change


Select  
N/O, N/C  
change

Specify the device and device  
number of the source

Batch change

#### OPERATING PROCEDURE

**F4**




**1** Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

**2**



**2** A window opens to select an auxiliary function.

Select 2 (change) from the window.

## 5. LIST MODE

### N/O and N/C contacts batch change

MELSEC-A

1

3

A window opens to select a change.

Select 1 (N/O, N/C CNV.) from the window.

Then a window opens to begin to specify the device to be changed.

X 0

4

Specify X000 used with a program, and execute the change.

Enter

5

Select either batch change or each change after specifying the device to be changed.

[YES] : The program is changed with confirmation.

See the POINT below.

[NO] : The program is changed by a batch.

→ Enter

6

Batch change is executed.

When the change has been executed, "COMPLETED" is displayed.

### POINT

- Select "YES"  
(It is changed with confirmation.)

A corresponding device is positioned in the center of an instruction list, and "CHANGE?" is displayed. Select "YES" to execute the change.

"SEARCH NEXT? YES/NO" is displayed after selecting "NO" after executing the change.

If YES is selected, the next device is searched and is displayed.

The device is searched in the order of the step number.

If a corresponding device does not exist, "COMPLETED." is displayed.

If NO is selected, the operation is interrupted and is completed.

## 5. LIST MODE

### Batch device convert

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.3 (3) Function used to convert devices to other devices in a program by batch


This function is used to convert a device used with a program into a specified device.

This function is useful for changing an I/O address.

#### OPERATION EXAMPLE

```
0 LD X000
1 OUT Y070
2 LD X001
3 SET M0
4 LD X000
5 RST M0
6 NOP
7 OUT Y071
8 LD X005
```

To change devices "M0 to M9" to devices "B10 to B19":



#### OPERATING PROCEDURE

F4

1 Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

2

2 A window opens to select an auxiliary function.

Select 2 (change) from the window.

2

3 A window opens to select the change.


Select 2 (DEVICE CNV.) from the window.

Then, the "BATCH DEVICE CNV." setting window opens.

## 5. LIST MODE

### Batch device convert

MELSEC-A



BATCH DEVICE CONVS			
CONVERT FROM	M0	10	
CONVERT TO	B10	75	
START NO.			
FINAL NO.			
COMMENT MOVE (Y/N)			

Esc:Close

- 4 Input a source head device and a destination head device. Several devices can be converted in the order of a device number by specifying several device numbers.

A device name can be changed. (For example, M0 can be converted into B10.)

M0-M9 is converted into B10-B19 in the operation example.

When it is not necessary to specify the range of a program, the head step number and the last step number (step number in which the END instruction is positioned) of the current program can be automatically set by pressing the [Enter] key.

Type [Y] (move) or [N] (not move). This example assumes that [N] is selected.

Enter

CONFIRM EACH CHANGE?

☒ YES      ☐ NO

- 5 Select either batch change or change after specifying a device to be changed.

[YES]: The program is changed with confirmation.

See POINT.

[NO]: The program is changed by a batch.

→ Enter

32 RST	D1
35 LD	T0
36 PLS	B010
39 NOP	
40 NOP	
41 NOP	

COMPLETED

- 6 The batch change is executed.

When the execution is done, "COMPLETED." is displayed.

### POINT

- Select "YES" (It is changed with confirmation.)

A corresponding device is positioned in the center of an instruction list, and "CHANGE?" is displayed. Select "YES" to execute a change.

"SEARCH NEXT? YES/NO" is displayed if "NO" is selected after executing a change.

When YES is selected, the next device is searched and is displayed. The device is searched in the order of a step number. If a corresponding device does not exist, "COMPLETED." is displayed. When NO is selected, the operation is interrupted and is completed.

- Comments when a batch device conversion is executed

Comment movement "Y" is selected, and the batch device conversion is executed. If a comment is within a setting range, that comment is also converted simultaneously. In addition, a source device comment is cleared. A comment in M0 to M9 is converted into a comment in B10-B19 in the operation example, and any comment in M0-M9 is cleared.

However, even if a comment is within the batch conversion setting range, the comment of a device that is not used with a program is not converted.

If a destination device range is not allocated a comment range, a comment is not registered to the destination device. In addition, a source device comment is cleared.

Comment data contains comment 1, comment 2, and extension comment.

---

POINT

---

• Example when a device is not converted

(1) If Y10 is converted into X10 (the conversion result is erroneous.)

MOV D0 K4Y10 → MOV D0 K4X10

Since Y10 cannot be converted into X10, "CANNOT USE THIS DEVICE WITH THIS COMMAND." is displayed.  
A destination cannot be specified for input X by the MOV command.

(2) If X0 is converted into D0

LD X0 → LD D0

X, Y, M, L, B and F cannot be converted into D, W, R, A, Z and V.  
A bit device cannot be converted into a word device. And, a word device cannot be converted into a bit device.

(3) If T is converted into C or when C is converted into T

OUT T → OUT C

OUT C → OUT T

Since this conversion processing cannot be done, "CANNOT USE THIS DEVICE WITH THIS COMMAND." is displayed.

If a conversion result is logically correct, device conversion is done in batch.



## 5. LIST MODE

### Batch change of T/C setting value

PC models	ALL TYPES
-----------	-----------

**MELSEC-A**

#### 5.3.3 (4) Function used to change a timer/counter setting value in a program by a batch operation

This function is used to change the set value of a timer and a counter used with a program.

The set value can be changed by a batch operation without searching the program for the place where the time and counter are used.

#### OPERATION EXAMPLE

**T/C SETTING VALUE LIST**

DEVICE?	[T 0]		
T0	K10	[K50]	T8
T1	K15		T9
T2			T10
T3			T11
T4			T12
T5			T13
T6			T14
T7			T15

Page Up    Page Down    End SET    Esc STOP

To change the value set at T0 to K50 in a sequence program during PC RUN:

```

F4 → 2 → 3 → T → 0 → Enter → F1 → K → 5
Select an auxiliary function  Select change  T/C set value batch change  Device to be changed  Write
    
```

```

0 → Enter → F3 → ← → Enter → ← → Enter
Input set value  PC write  Select "YES" and execute  RUN write
    
```

#### OPERATING PROCEDURE

**F4**

-----

**AUXILIARY**

1: M/S SWITCH    2: CHANGE    3: DISPLAY    4: FILE WRITE

Esc: Close

**1**

Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

**2**

-----

**CHANGE**

1: NO, NO CNV    2: DEVICE CNV    3: T/C SET VAL    4: NOP WRITE    5: NOP INSERT

6: NOP DELETE    7: MEMORY CAP

Esc: Close

**2**

A window opens to select an auxiliary function.

Select 2 (change) from the window.

## 5. LIST MODE

### Batch change of T/C setting value

MELSEC-A

3

3 A window opens to select the change.

If "3: T, C SET VAL" is selected from the window, "T, C SETTING VALUE LIST" opens.

T → 0 → Enter

4 Specify a timer/counter number to change a set value.

16 points can be displayed by using the [Page Up] and [Page Down] keys after a display.

F1 → K → 5 → 0 → Enter

5 If the [F1] key is pressed, the cursor moves to the set value area.

Move the cursor to the place to be changed after the movement, and input a new set value.

- The set value can be changed from a constant (K) to an indirect specification (D), and the set value can be changed from an indirect specification (D) to a constant (K).

F3 → ←

6 Press the [F3] (PC write) key.

Because the writing to the PC is confirmed, a window opens.

Use the [ ← ] key to select "YES" (execute).

#### REMARK

When the [End] key is pressed, only the internal memory is changed, and the batch change of the T/C set value is completed.

Enter → ←

7 When the PC is in the RUN state, press the [Enter] key.

A window opens.

Use the [ ← ] key to select "YES" (write).

If the PC is in the STOP state, the window is not opened, and writing is executed.

## 5. LIST MODE

### Batch change of T/C setting value

MELSEC-A

Enter

8 Press the [Enter] key.

T/C SETTING VALUE LIST			
DEVICE? [T 0]			
T 0	K 10	[K 50]	T 8
T 1	K 15		T 9
T 2			T 10
T 3			T 11
T 4			T 12
T 5			T 13
T 6			T 14
T 7			T 15
Page Up	Page Down	End SET	Esc STOP
COMPLETED			

Writing to the PC is executed.

The sequence program in the PHP internal memory is also changed simultaneously.

When the writing has been executed, "COMPLETED." is displayed.

### POINT

- Changing the set value of a different device

When the [F2] read key is pressed, the device specification area becomes empty. Thus, another device can be input.

A timer/counter number can be specified again to change a set value.

## 5. LIST MODE

### Batch writing of NOP

PC  
models

ALL TYPES

**MELSEC-A**

#### 5.3.3 (5) The function used to write an NOP instruction to a specified part of a program or to the entire program

This function is used to do NOP writing (program range specification deletion) in the batch NOP range (program all clear) when writing a specification.

This function is valid when creating a new program or when deleting an unnecessary list program.

#### OPERATION EXAMPLE

```

0 NOP
1 NOP
2 NOP
3 NOP
4 NOP
5 NOP
6 NOP
7 NOP
8 NOP

19 NOP
COMPLETED
        
```

To write NOP to step Nos. 0 to 100:


```

F4 → 2 → 4 → Cursor move → Enter → 1 → 0 → 0
Select an auxiliary function  Select change  Write NOP
                                Cursor moves to step 0
                                Specify step 100

Enter → Enter
                                Select "YES"
                                and execute
        
```

#### OPERATING PROCEDURE

**F4**




- 1 Select an auxiliary function. The auxiliary function window opens.

#### REMARK


An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

**2**



- 2 A window opens to select an auxiliary function. Select 2 (change) from the window.

4 → ↑ / ↓ → Enter



- 3 The "CHANGE" window opens.

Select "4: NOP WRITE" from the window.

And then, use the [↑] and [↓] keys to move the cursor to the line where the NOP writing begins.

Press the [Enter] key.

A window opens to set the number of NOPs to write.

## 5. LIST MODE

### Batch writing of NOP

MELSEC-A

1 0 0

BATCH NOP WRITE

Input number of NOPs to write  
[ 100]

Esc: Close

- 4 Set the number of NOPs to write.

When clearing all programs, specify the last number of a step.

Enter

EXECUTE?  

YES NO

- 5 A window opens to confirm execution.

Select "YES" (execute).

Enter

0 NOP

1 NOP

2 NOP

3 NOP

4 NOP

5 NOP

6 NOP

7 NOP

8 NOP

19 NOP

COMPLETED

- 6 Batch NOP writing is executed.

When the execution is completed, the screen is switched.

#### POINT

- If the last step number in which an NOP is written is in the middle of an Instruction

When the last step number in which an NOP is written is in the middle of an instruction, all corresponding instructions become NOPs.

For example, in an instruction (five-step instructions) from step number 5 to step number 9, if the last step number 7 is specified by the NOP writing, NOP is written in all steps from step number 5 to step number 9.

- Note and statement attached to the NOP writing step

If a note and a statement are attached to a step to be rewritten to a NOP, a window opens to confirm execution.

Select "YES" to execute it. Select "NO" to interrupt the execution.

## 5. LIST MODE


### Batch writing of NOP

#### 5.3.3 (6) Function used to continuously insert NOP instructions in a program

This function is used to insert all specified NOP instructions into a program.


This function can divide a program into several parts according to the function of each part.

#### OPERATION EXAMPLE



#### OPERATING PROCEDURE

**F4**




**1** Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.


**2**



**2** A window opens to select an auxiliary function.

Select 2 (change) from the window.

**5** → **↑** / **↓** → **Enter**



**3** "CHANGE" window opens.

Select "5: NOP INSERT" from the window.

And then, use the [↑] and [↓] keys to move the cursor to the line where the NOP writing begins.

Press the [Enter] key.


A window opens to set the number of NOPs to insert.

## 5. LIST MODE

### Batch writing of NOP

MELSEC-A


1 → 0



- 4 Set the number of NOPs to insert.

When clearing all programs, specify the last number of a step.


Enter



- 5 A window opens to confirm execution.

Select "YES" (execute).

Enter



- 6 Batch NOP writing is executed.

When execution is completed, the screen is switched.

## 5. LIST MODE

### Switching a main/sub

PC  
models

ALL TYPES

MELSEC-A

#### 5.3.3 (7) Function used to delete all NOPs in a program

This function is used so that program (0-END) deletes all NOP instructions.  
A step number can be deleted by deleting the NOP instruction in the program.

#### OPERATION EXAMPLE

12 LD	X005	
13 OUT	T0	K50
14 LD	X003	
15 OR	Y072	
16 AND	X004	
17 OUT	Y070	

COMPLETED. STEP NUMBER CHANGED.

To delete an NOP instruction in a program:

F4 → 2 → 6 → Enter

Select an auxiliary function    Select change    Select NOP delete    Select "YES" and execute

#### OPERATING PROCEDURE

F4

AUXILIARY

1: M/S SWITCH	2: CHANGE	3: DISPLAY	4: FILE WRITE
---------------	-----------	------------	---------------

Esc. Close

1 Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

The auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

2

CHANGE

1: M/S SWITCH	2: DEVICE CHG.	3: T, C SET VAL	4: NOP WRITE	5: NOP INSERT
6: NOP DELETE	7: MEMORY CAP.			

Esc. Close

2 A window opens to select an auxiliary function.

Select 2 (change) from the window.

6

DELETE ALL NOP?

YES NO

3 "CHANGE" window opens.

Select "6: NOP DELETE" from the window.

Then, "DELETE ALL NOP" is displayed.

[YES]: execute

[NO]: not execute



## 5. LIST MODE

### Switching a main/sub

MELSEC-A

Enter

12	LD	X005	
13	OUT	T0	K50
14	LD	X003	
15	OR	Y072	
16	ANI	X004	
17	OUT	Y070	

COMPLETED. STEP NUMBER CHANGED

- 4 Press the [Enter] key to delete all NOP instructions in the program.

When the deletion is executed, "COMPLETED. STEP NUMBER CHANGED." is displayed.

#### REMARK

Even when the NOP is deleted by a batch operation, the NOPLF instruction is not deleted.

The NOPLF instruction is used to specify a page overflow line when a circuit diagram and an instruction list are printed.

## 5. LIST MODE

### Switching a main/sub

PC models	ALL TYPES
-----------	-----------

**MELSEC-A**

#### 5.3.3 (8) Function used to change the memory capacity of a program in the list mode

When a program is being created, and the program capacity is insufficient, the memory capacity can be changed in the list mode.

The main sequence program capacity and the subsequence program capacity can likewise be set with the parameter mode.

#### OPERATION EXAMPLE

```

<MEMORY CAPACITY>
MAIN PROGRAM(MAX30) [15] KSTEP
SUB PROGRAM1      [10] KSTEP
SUB PROGRAM2      [ 0] KSTEP
SUB PROGRAM3      [ 0] KSTEP
End SET Esc Close
        
```

To set the main sequence program capacity to 15K steps and the subsequence program capacity to 10K steps:

```

F4 → 2 → 7 → 1 → 5 → Enter
Select an auxiliary function  Select change  Select memory capacity  Set the main sequence program capacity to 15K steps

1 → 0 → End
Set the subsequence program capacity to 10K steps  The setting is completed
        
```

#### OPERATING PROCEDURE

**F4**

```

<AUXILIARY>
1:MS SWITCH  2:CHANGE  3:DISPLAY  4:FILE WRITE
Esc Close
        
```

**1** Select an auxiliary function.

The auxiliary function window opens.

#### REMARK

The auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

**2**

```

<CHANGE>
1:NO. NC CNV.  2:DEVICE CNV.  3:T.C SET VAL  4:NOP WRITE  5:NOP INSERT
6:NOP DELETE  7:MEMORY CAP
Esc Close
        
```

**2** A window opens to select an auxiliary function.

Select 2 (change) from the window.

## 5. LIST MODE

### Switching a main/sub

MELSEC-A

7 → 1 → 5 → Enter → 1 → 0

MEMORY CAPACITY		
MAIN PROGRAM(MAX30)	[15]	KSTEP
SUB PROGRAM1	[10]	KSTEP
SUB PROGRAM2	[0]	KSTEP
SUB PROGRAM3	[0]	KSTEP
End SET Esc Clear		

End

19 AND	Y070
20 AND	Y0AF
21 ORB	
22 OUT	F102
25 LD	X2A0
26 AND	X31F
27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF

- 3 "CHANGE" window opens. Select "7: MEMORY CAP." from the window. Then, the "MEMORY CAPACITY" window opens.

Set the main sequence program capacity. Then, set the subsequence program capacity.

When setting only the subsequence program capacity without changing the main sequence program capacity, use the [↓] key to move the cursor to a subsequence program 1 to 3 capacity setting area.

If the PC model is other than A4U, it is not possible to select SUB PROGRAM 2 or SUB PROGRAM 3.

- 4 Press the [End] key to complete the setting.

#### Point

##### • Parameter area

When the memory capacity is changed by the auxiliary function, the description of a parameter area is automatically changed as well.

##### • Is the program outside the range lost when reducing the program capacity?

If memory capacity is set smaller than a program capacity, a program will be lost if it is written to a file. Such a program will not be lost unless it is written to a file.

## 5. LIST MODE

### Contact and coil list

PC models	ALL TYPES
-----------	-----------

**MELSEC-A**

#### 5.3.3 (9) Function used for displaying a condition by using a device in the program

Every specified device number can display a program use condition.

A utilized step number, a ladder symbol, and an instruction are displayed on a screen by specifying a device and a device number.

#### OPERATION EXAMPLE

CONTACT AND LIST

DEVICE? [Y0]

1-< >-

Page Up Page Down Esc:Close

COMPLETED

To display the contact and coil list of Y0:

F4

3

1

Y

0

Enter

Contact and coil  
list display function


Input device to  
display the list

Instruction symbol

Step No.

#### OPERATING PROCEDURE

**F4**




- 1 Select an auxiliary function.  
The auxiliary function window opens.

#### REMARK

The auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

**3**




- 2 A window opens to select an auxiliary function.  
Select "3: DISPLAY" from the window.

#### REMARK

This can be selected by pressing a 1 to 4 key or the cursor + the [Enter] key.

**1**



- 3 "DISPLAY" window opens.  
Select "1: CNTCT & COIL" from the window.  
Then, the "CONTACT AND COIL LIST" window opens.

## 5. LIST MODE

### Contact and coil list

MELSEC-A

Y 0 Enter

CONTACT AND LIST		HT
DEVICE?	[Y0]	
1-<	>-	
Page Up	Page Down	Esc Close
COMPLETED		

4 Input the device to be searched.

For example, Y0 is searched.

When the search is executed, "COMPLETED." is displayed.

An instruction used in the step number for which a specified device is used, a ladder symbol, and a data instruction are displayed.

#### POINT

- Applicable devices

Applicable devices "X, Y, B, M, L, F, T, C, R, W, D, P, N (for MC, MCR), V, Z, I, A0, A1" are searched.

For example, when a digit ("K4X0") is specified by the MOV instruction, X000-X00F is displayed as a utilized device.

- Display number of points

16 lists can be displayed.

- How to interrupt a search

If, while searching a device, the [Esc] key is pressed, the search is interrupted and the cursor moves to the device specification area.



## 5. LIST MODE

### Device used list

MELSEC-A

Y 1 0 Enter

#### 4 Setting a corresponding device.

For example Y10 is searched.

When the search is executed, "COMPLETED" is displayed.

DEVICE USED LIST				
DEVICE? (Y10) (-<-> USED BLANK UNUSED E ERROR 1-9 * NO. OF COILS)				
Y010	-<->	1E	Y014	Y018
Y011	-<->	2E	Y015	Y019
Y012	-<->	1E	Y016	Y01A
Y013	-  -	1	Y017	Y01B
Page Up Page Down Esc: Close				
COMPLETED				

### POINT

#### • Device use list display list

The -||- area, the -<->- area, and the error condition are displayed on the device use list as follows.

Device	-  - Area Display	-<-- Area Display	Error Condition															
X	LD, LDI, OR, ORI, AND and ANI Software processing instruction source	Software processing instruction destination	(None)															
Y	LD LDI OR ORI AND ANI Software processing instruction source	OUT SET RST  Software processing instruction destination	<table><tr><th>-  -</th><th>-&lt;--</th><th>Error?</th></tr><tr><td>Absent</td><td>Absent</td><td></td></tr><tr><td>Absent</td><td>Present</td><td>Error</td></tr><tr><td>Present</td><td>Absent</td><td>Error</td></tr><tr><td>Present</td><td>Present</td><td></td></tr></table>	-  -	-<--	Error?	Absent	Absent		Absent	Present	Error	Present	Absent	Error	Present	Present	
-  -				-<--	Error?													
Absent				Absent														
Absent				Present	Error													
Present				Absent	Error													
Present				Present														
SP.M																		
M																		
L																		
S																		
B																		
F																		
T																		
C																		
SP.D	Software processing instruction source	Software processing instruction destination Timer/counter setting value																
D																		
W																		
R																		
P	P(pointer)	Software processing instruction																
N	MC	MCR																
I	I(Pointer)	-	(None)															

#### • Applicable devices

Applicable devices "X, Y, M, L, B, F, T, C, D, W, R, P, N, I" are searched.

#### • Display specifications of a device use list

(1) A device use list displays 16 points from the specified device. However, when a ladder with a comment is displayed, 8 points of the device use list with a comment are displayed.

(2) The number that a coil uses is indicated in a device use list. The number used by a coil is indicated to a maximum of 9. But \* is displayed in the case of 10 or more.

#### • How to interrupt a search

If, while searching a device, the [Esc] key is pressed, the search is interrupted and the cursor moves to a device specification area.

#### • Software instruction

The software processing instruction is an instruction with two or more steps. For example, with `MOV K4X0 D0`, the range of X0 to XF is the source and D0 is the destination. As for comparison instruction >, =, <, a second word and a third word are displayed in the -||- area as sources. As for any other data instruction, the second word is the source and the third word is the destination.

#### • An error indication

The "E" (error) display results when the condition of using each device is checked. Even if "E" is displayed, the sequence program will operate normally.

## 5. LIST MODE

### File writing

PC models	ALL TYPES
--------------	-----------

**MELSEC-A**

5.3.3 (11) Function used to store data created in the list mode to the user file (see Section 2.2.2)



## 5. LIST MODE

### Reading by a step number

PC  
models

ALL TYPES

MELSEC-A

#### 5.4 Reading an Existing Program List

##### 5.4.1 Reading a program list

This Section explains how to read a program in the list mode.

Reading a program is the preparatory operation for executing any correction, insertion, addition, deletion, etc.

How to read a program is explained below.

- (1) Reading by step number
- (2) Reading by device number
- (3) Reading by device number with a digit
- (4) Reading by an instruction and a device number
- (5) Reading by an instruction

##### 5.4.1 (1) Reading a list by specifying a step number

A program list is read by specifying a step number.

#### OPERATION EXAMPLE

**BEFORE**

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

To read the program at step No. 31:

F2	3	1	Enter
Select read in the list mode	Specify step No. 31		Execute

**AFTER**

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	Y000
32 AND	Y02F
33 ORB	
34 OUT	F103
37 LD	X340

#### OPERATING PROCEDURE

**F2**

**1** Press the [F2] key to select a read function.

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

## 5. LIST MODE

### Reading by a step number

MELSEC-A

3 → 1

Step	Instruction	Address
0	LD	X00
1	OUT	Y07
2	LD	X001
3	SET	M0
4	LD	X000
5	RST	M0
6	NOP	
31		

2 Input the step number to be read.

The keyed-in data is displayed below the bottom step.

Enter

27	AND	X000
28	AND	X07F
29	LD	Y2A0
30	AND	Y2DF
31	AND	Y000
32	AND	Y02F
33	ORB	
34	OUT	F103
37	LD	X340

3 Press the [Enter] key.

The cursor moves to the position of the specified step number.

Then, 20 lines of the list are displayed centering on the specified step number.

Next, press the [Enter] key.

The list of 20 lines that begins with the step number next to the displayed last step number is displayed.

## 5. LIST MODE

### Reading by a step number

PC  
models

ALL TYPES

**MELSEC-A**

#### 5.4.1 (2) Reading a list by specifying a device number

A program list is read by specifying a device and a device number.

#### OPERATION EXAMPLE

**BEFORE**

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

↓

**AFTER**

12 ANI	X004
13 OUT	Y070
14 LD	Y000
15 OR	Y073
16 ANI	X004
17 OUT	Y070
18 LD	T0
19 OUT	Y073

Y0

To read the program at device Y0:

F2

→

Y

→

0

→

Enter

Select read  
in the list  
mode

Specify device Y0

Execute

#### OPERATING PROCEDURE

**F2**

**1** Press the [F2] key to select a read function.

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

**Y** → **0**

**2** Input the step number to be read.

The keyed-in data is displayed below the bottom step.

0 LD	X001
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	

Y0

## 5. LIST MODE

### Reading by a step number

MELSEC-A

Enter

12 ANI	X004
13 OUT	Y070
14 LD	Y000
15 OR	Y073
16 ANI	X004
17 OUT	Y070
18 LD	T0
19 OUT	Y073
Y0	

3 Press the [Enter] key.

The cursor moves to the position of a specified step number.

Then, 20 lines of the list are displayed centering on the instruction.

Next, press the [Enter] key.

The list of 20 lines centering on the next instruction with the same device and device number is displayed.

When all lists are displayed, "PROGRAM NOT FOUND" is displayed.

#### REMARK

If a specified device has Z and V indexes, the device number is read as a corresponding device.

## 5. LIST MODE

### Reading a list by device number with digit

PC  
models

ALL TYPES

MELSEC-A

#### 5.4.1 (3) Reading a list by specifying a device number with a digit

A program list is read by specifying a device and a device number with a digit.

#### OPERATION EXAMPLE

##### BEFORE


0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005



##### AFTER

19 OUT	Y074
20 LD	X007
21 RST	C0
24 LD	X000
25 MOVP	K4X020 D8
30 LD	X001
31 NOP	
32 NOP	
33 NOP	

To read the program at X21 by specifying a device with a digit:



Select read in  
the list mode

Specify device X21

Specify an instruction  
with a digit

Execute

#### OPERATING PROCEDURE

F2

1 Press the [F2] key to select a read function.

0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

X 2 1 SP / K

2 Input the device and a device number to be read.

Press the [SP],[/], and [K] keys to search an instruction with a digit.

Keyed-in data is displayed below the bottom step.

0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
X21 /K	

## 5. LIST MODE

### Reading a list by device number with digit

MELSEC-A

Enter

19	OUT	Y074	
20	LD	X007	
21	RST	C0	
24	LD	X000	
25	MOV	K4X020	D0
30	LD	X001	
31	NOP		
32	NOP		
33	NOP		

3 Press the [Enter] key.

The cursor moves to the position of the specified step number.

Then, 20 lines of list are displayed centering on the specified step number.

Next, press the [Enter] key.

The list of 20 lines including the next instruction, device, and device number (including an instruction with a digit) is displayed.

When all lists are displayed, "PROGRAM NOT FOUND" is displayed.

#### REMARK

When reading a data instruction containing a corresponding device, an instruction with a digit is searched.

For example, even if a device in X0 to XF is specified for an instruction with a digit, the MOV K4X0 D0 instruction can be read.

## 5. LIST MODE

PC  
models

ALL TYPES

### Reading a list by instruction and device number

MELSEC-A

#### 5.4.1 (4) Reading a list by specifying an instruction and device number

A program list is read by specifying an instruction, a device, and a device number.

#### OPERATION EXAMPLE

**BEFORE**

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

↓

**AFTER**

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	X000
32 AND	Y02F
33 DRB	
34 OUT	F103
37 LD	X340

To read the program at AND X0:

F2 → F6 → X → 0 → Enter

Select read in the list mode
Specify AND X0
Execute

#### OPERATING PROCEDURE

F2

- 1 Press the [F2] key to select a read function.

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

F6 → X → 0

- 2 Input the device and the device number to be read.  
Keyed-in data is displayed below the bottom step.

0 LD	X000
1 OUT	Y07
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
AND X0	

## 5. LIST MODE

### Reading a list by instruction and device number

MELSEC-A

Enter

27 AND	X000
28 AND	X07F
29 LD	Y2A0
30 AND	Y2DF
31 AND	X000
32 AND	Y02F
33 DRB	
34 OUT	F103
37 LD	X340

3 Press the [Enter] key.

The cursor moves to the position of a specified step number.

Then, 20 lines of list are displayed centering on a specified instruction, device and device number.

Next, press the [Enter] key.

A list of 20 lines including the next instruction, device, and device number is displayed.

If all lists are displayed, "PROGRAM NOT FOUND" is displayed.

#### REMARK

- (1) When a specified device has Z and V indexes, the device number is read as a corresponding device.
- (2) An instruction with a digit can be read by pressing the [SP], [/], and [K] keys after a device when reading an instruction, a device, and a device number.



## 5. LIST MODE

### Reading by an instruction

PC  
models

ALL TYPES

MELSEC-A

#### 5.4.1 (5) Reading a list by specifying an instruction

A program is read by specifying an instruction.

#### OPERATION EXAMPLE

**BEFORE**

0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

↓

**AFTER**

19 OUT	Y074
20 LD	X007
21 RST	C0
24 LD	X000
25 MOVP	K4X020 D0
30 LD	X001
31 NOP	
32 NOP	
33 NOP	

To read a program by specifying an MOV instruction:

F2

→

M

→

0

→

V

→

Enter

Select read in  
the list mode

Specify an MOV  
instruction

Execute

#### OPERATING PROCEDURE

**F2**

- 1 Press the [F2] key to select a read function.

0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
7 OUT	Y071
8 LD	X005

**M 0 V**

- 2 Input the device and device number to be read.  
Keyed-in data is displayed below the bottom step.

0 LD	X000
1 OUT	Y007
2 LD	X001
3 SET	M0
4 LD	X000
5 RST	M0
6 NOP	
MOV	

#### REMARK

The MOV instruction can be specified by pressing the [Alt] + [F2] keys.

## 5. LIST MODE

### Reading by an instruction

MELSEC-A

Enter

19	OUT	Y074	
20	LD	X007	
21	RST	C0	
24	LD	X000	
25	MOV	K4X020	D0
30	LD	X001	
31	NOP		
32	NOP		
33	NOP		

3 Press the [Enter] key.

The cursor moves to the position of a specified step number.

Then, 20 lines of list are displayed centering on a specified instruction.

Next, press the [Enter] key.

A list of 20 lines including the same instruction is displayed.

If all lists are displayed, "PROGRAM NOT FOUND" is displayed.

#### REMARK

When a read is executed by an instruction, an instruction with double (D) and pulse (P) can be read.

Double (D) must be read with D.

When doing a read with D and P, only instructions with D and P are read.


## 5. LIST MODE

### Auxiliary functions for reading a list

MELSEC-A

#### 5.4.2 Auxiliary functions available for writing, inserting, and deleting

Auxiliary functions are available for reading in the list mode.



## 5. LIST MODE

### Copy

PC models	ALL TYPES
--------------	-----------

---

**MELSEC-A**

- 5.4.2 (1) Function used to switch the display of the main sequence program and a subsequence program while creating or copying a list (see Section 5.3.3(1))

## 5. LIST MODE Copy

PC  
models


ALL TYPES

MELSEC-A

### 5.4.2 (2) Function used to copy the program list of a specified range to a specified position

This function is used to copy a created list to a specified position in order to create a list pattern that is the same as a created list instruction.

#### OPERATION EXAMPLE



#### OPERATING PROCEDURE

F2 → 8 → Enter

6	NOP	
7	OUT	Y071
8	LD	X003
9	OR	Y072
10	ANI	X004
11	OUT	Y070
12	LD	X005
13	OUT	T0 K50
14	LD	T0

- 1 Press the [F2] key. And then, input a source head step number to read.

The cursor moves to the specified step number.

F4

AUXILIARY			
1:MS SWITCH	2:CHANGE	3:DISPLAY	4:FILE WRITE
Esc Close			

- 2 Press the [F4] key to Select an auxiliary function.  
The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

## 5. LIST MODE Copy

MELSEC-A

2

3

Select "2: CHANGE " from The auxiliary function window.

A change window opens.

8

4

Select "8: COPY " from a change window.

The following message is displayed.

Enter ↓ ↓ ↓ Enter

5

Press the [cursor move] key to set the head list of a source and the last list of a source, then press the [Enter] key.

The message for the setting item is displayed on a screen.

Operate it according to the message.

The source list is highlighted on the screen.

When the last list of the source is set, the following message is displayed.

### REMARK

When specifying the head step number of the source and the step number of the destination, the cursor can be moved by using the [Page Up], [Page Down], [Step Number], and [Enter] keys.

↓ ↓ ↓ Enter

6

Move the cursor to a destination list, and press the [Enter] key.

When the destination list is specified, the following message is displayed.

## 5. LIST MODE Copy

MELSEC-A

Enter

11 OUT	Y070
12 LD	X005
13 OUT	T0 K50
14 LD	X003
15 OR	Y072
16 AND	X004
17 OUT	Y070
18 LD	T0
19 OUT	Y073
COMPLETED, STEP NUMBER CHANGED	

7 Select "YES".

A copied list enters a specified position on the left screen.

When copying is completed, the following message is displayed.

### REMARK

Step numbers after the inserted line will be automatically renumbered.

## POINT

- Notes and statements during copying

Even if a list is copied, notes and statements are not copied.

- A point (P and I) is included in the list to be copied

When a pointer (P and I) is included in the range of a list to be copied, "CANNOT COPY." is displayed.

After deleting a label, copy a list. Or copy a range that does not have a label.

- Interrupted setting

Setting is interrupted by pressing the [Esc] key, and the screen returns to a read function.

## 5. LIST MODE Move

PC  
models


ALL TYPES

MELSEC-A

### 5.4.2 (3) Function used to move the program list of a specified range to a specified position

This function is used to move a created list to a specified position when changing the program composition.

#### OPERATION EXAMPLE



#### OPERATING PROCEDURE

F2 → 8 → Enter

7 OUT	Y071
8 LD	X003
9 OR	Y072
10 ANI	X004
11 OUT	Y070
12 LD	X005
13 OUT	T0
14 LD	T0
15 OR	Y073

- 1 Press the [F2] key. And then, input the head step number of the source to move.

The cursor moves to the specified step number.

F4

-AUXILIARY-			
1: M/S SWITCH	2: CHANGE	3: DISPLAY	4: FILE WRITE
Esc: Close			

- 2 Press the [F4] key to Select an auxiliary function.  
An auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.



## 5. LIST MODE Move

MELSEC-A

2

CHANGE				
1: NO. NEW	2: DEVICE CNV	3: T. C SET VAL	4: NOP WRITE	5: NOP INSERT
6: NOP DELETE	7: MEMORY CAP. 8: COPY	9: MOVE	A: DELETE	Esc: Close

3

Select "2: CHANGE" from the auxiliary function window.  
A change window opens.

9

PRESS [ENTER] TO BEGIN SPECIFYING A COPY BLOCK. (Esc:STOP)

FROM=      TO=      COPY TO=

4

Select "9: MOVE " from the change window.  
The following message is displayed.

Enter → ↓ → ↓ → ↓ → Enter

	7 OUT	Y071
#	8 LD	X003
	9 OR	X005
	10 AND	X072
	11 OUT	Y004
	12 LD	X005

PRESS [ENTER] AT DESTINATION OF COPY (Esc:STOP)

FROM=8      TO=11      MOVE TO=

5

Press the [cursor move] key to set the head list of a source and the last list of a source, and press the [Enter] key.

The message for the setting item is displayed on a screen.

Operate it according to the message.

A source list highlights on the screen.

When the last list of a source is set, the following message is displayed.

### REMARK

When specifying the head step number of a source and the step number of a destination, the cursor can be moved by using the [Page Up], [Page Down] key, a step number and the [Enter] key.

↓ → ↓ → ↓ → Enter

EXECUTE?

YES      NO

6

Move the cursor to a destination list, and press the [Enter] key.

When a destination list is specified, the following message is displayed.

## 5. LIST MODE Move

MELSEC-A

Enter

8 LD	X005	
9 OUT	TO	K50
10 LD	X003	
11 OR	Y072	
12 AND	X004	
13 OUT	Y070	
14 LD	TO	
COMPLETED		

### 7 Select "YES".


The specified list enters the specified position on the left hand side of the screen.

When the movement is completed, the following message is displayed.


### REMARK

Program after the movement

- (1) When a destination list is positioned before a source list, the lists within the range from the destination list to the source list shift in descending order.



- (2) When a destination list is positioned after a source list, the lists within the range from the destination list to the source list shift in ascending order.



### POINT

#### • Notes and statements during movement

When a list is moved, notes and statements also move.

#### • Interrupted setting

Setting is interrupted by pressing the [Esc] key, and the screen returns to a read function.

## 5. LIST MODE

### Batch deletion

PC  
models


ALL TYPES

**MELSEC-A**

#### 5.4.2 (4) Function used to delete the program list of a specified range

This function is used to delete several list instructions by specifying a range.

#### OPERATION EXAMPLE



#### OPERATING PROCEDURE

F2 → 8 → Enter

6	NOP	
7	OUT	Y071
8	LD	X003
9	OR	Y072
10	ANI	X004
11	OUT	Y070
12	LD	X005
13	OUT	T0 K50
14	LD	T0

- 1 Press the [F2] key. Then, input the head step number of a source to delete.

The cursor moves to the specified step number.

F4

AUXILIARY			
1:MS SWITCH	2:CHANGE	3:DISPLAY	4:FILE WRITE
Esc: Close			

- 2 Press the [F4] key to Select an auxiliary function.  
The auxiliary function window opens.

#### REMARK

An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

## 5. LIST MODE

### Batch deletion

MELSEC-A

2

3

Select "2: CHANGE" from the auxiliary function window.  
A change window opens.

A

4

Select "A: DELETE" from the change window.  
The following message is displayed.

Enter ↓ ↓ ↓ Enter

5

Press the [cursor move] key to set the head list of a source and the last list of a source, then press the [Enter] key.

An instruction message for the setting item is displayed on the screen.

Operate in accordance with the message.

A source list is highlighted on the screen.

When the last list of a source is set, the following message is displayed.

#### REMARK

When specifying the head step number of a source and the step number of a destination, the cursor can be moved by using the [Page Up], [Page Down], [Step Number] and [Enter] keys.

Enter

6

Setting the program state after a deletion.

Select "YES" to shift up the step of a deleted list in the program after a batch delete.

Select "NO" to automatically write NOP of the step of a deleted list.

(The step number does not change.)

For example if "YES" is selected, the following message is displayed.

## 5. LIST MODE

### Batch deletion

MELSEC-A

← Enter

7	OUT	Y071	
8	LD	X005	
9	OUT	T0	K50
10	LD	T0	
11	OR	Y073	
12	ANI	X004	

COMPLETED, STEP NUMBER CHANGED

7 Select "YES".

The list of the specified range is deleted, and the step number is shifted up.

When the deletion is completed, the following message is displayed.

#### POINT

- Notes and statements during deleting it

When a list is deleted, notes and statements are also deleted.

- Interrupted setting

Setting is interrupted by pressing the [Esc] key, and the screen returns to a read function.

- 5.4.2 (5) Function used to change N/O contact to N/C, and N/C to N/O in a program  
(see Section 5.3.3(2))
- 5.4.2 (6) Function used to convert devices to other devices in a program by batch  
(see Section 5.3.3(3))
- 5.4.2 (7) Function used to change a timer/counter setting value in a program by batch  
(see Section 5.3.3(4))
- 5.4.2 (8) Function used to write an NOP instruction to the specified part of program or all of it  
(see Section 5.3.3(5))
- 5.4.2 (9) Function used to continuously insert an NOP instruction in a program  
(see Section 5.3.3(6))
- 5.4.2 (10) Function used to delete all NOPs in a program (see Section 5.3.3(7))
- 5.4.2 (11) Function used to change the memory capacity of a program in the list mode  
(see Section 5.3.3(8))
- 5.4.2 (12) Function used for the display of a state by using a device in the program  
(see Section 5.3.3(9))
- 5.4.2 (13) Function used to display the device step number and instruction of a program  
(see Section 5.3.3(10))

## 5. LIST MODE

### Display switch

PC  
models

ALL TYPES

**MELSEC-A**

#### 5.4.2 (14) Function used for switching to the program list display with a comment

This function is used to display a list read with a comment.

#### OPERATION EXAMPLE

**BEFORE**

0 LD	X000
1 OR	M0
2 MPS	
3 ANI	X001
4 ANI	X002
5 OUT	M0
6 MPP	

↓

**AFTER**

0 LD	X000	AUTO	RUN	START
1 OR	M0	IN	AUTO	RUN
2 MPS				
3 ANI	X001	AUTO	RUN	STOP
4 ANI	X002	EMERG	STOP	
5 OUT	M0	IN	AUTO	RUN
6 MPP				
7 ANI	X005			
8 OUT	Y031			

To read a step number to display a list stored with comment 2:

```

F2 → 0 → Enter → F4 → 3 → 3 → 3
Select read in the list mode  Read step No. 0  Select an auxiliary function  Select display  Select the display switch  Select "with comment 2"
    
```

#### OPERATING PROCEDURE

F2 → 0 → Enter


- 1 Press the [F2] key, and input a corresponding step number to read.

0 LD	X000
1 OR	M0
2 MPS	
3 ANI	X001
4 ANI	X002
5 OUT	M0
6 MPP	

## 5. LIST MODE Display switch

MELSEC-A

F4




- 2 Press the [F4] key to Select an auxiliary function.  
An auxiliary function window opens.

### REMARK


An auxiliary function can be selected by pressing a 1 to 4 key or the cursor key.

3



- 3 Select "3: DISPLAY" from the auxiliary function window.  
A change window opens.

3



- 4 Select "3: COMMENT" from the window.  
The following message is displayed.

3

OLD	X000	AUTO	RUN	START
1 OR	M0	IN	AUTO	RUN
2 MPS				
3 ANI	X001	AUTO	RUN	STOP
4 ANI	X002	EMERG	STOP	
5 OUT	M0	IN	AUTO	RUN
6 MPP				
7 ANI	X005			
8 OUT	Y031			

- 5 Select the comment type to be displayed with a list.  
For example, specify a "3: COMMENT 2".  
Then, the comment is displayed on the screen.

### REMARK

If a read function is switched to other functions (writing, insertion and deletion), it is set for display without a comment.

A display with a comment is valid only for a read function.



---

**POINT**

---

- **Switch the display by using the [Ctrl] key (in the ladder and list modes)**

- (1) Press the [Ctrl] + [F5] keys to switch "with/without comment 1".
- (2) Press the [Ctrl] + [F6] keys to switch "with/without comment 2".
- (3) Press the [Ctrl] + [F7] keys to switch "with/without statement".  
(The ladder block where a statement is set displays the "" mark like a step number in the circuit diagram.)
- (4) Press the [Ctrl] + [F8] keys to switch "with/without note".
- (5) Press the [Ctrl] + [F9] keys to enable file writing.

- **Priority display of an extensive comment**

A comment 1 and a comment 2 created by each device in the comment mode are displayed on the screen by selecting a display with a comment.

However, an extensive comment capacity has been set, and when a comment range set in the extensive mode overlaps with a device created in a comment mode, the device comment created in an extensive comment mode is displayed.

## 5. LIST MODE

### File writing

PC models	ALL TYPES
--------------	-----------

---

**MELSEC-A**


5.4.2 (15) Function used to store data created in the list mode to the user file (see Section 2.2.2)

## 6. PROGRAMMING IN THE 3MICROCOMPUTER MODE

## 6.1 Functions Available in the Microcomputer Mode

The microcomputer mode is used to create a program by using a microcomputer command.

If a sequence program is complex, this function enables the creation of a program in the microcomputer mode and operation processing using the sequence program.

**REMARK**

- (1) The microcomputer mode cannot be selected if the CPU model is an A2A, A3A, A0J2, A2U, A3U or A4U.
- (2) When creating a program in the microcomputer mode, values are expressed in hexadecimal (00 to FF).

## 6. MICROCOMPUTER MODE

### Reading a program

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	O	O	O	O	O	O	O	X	X	X	X	X

**MELSEC-A**

### 6.2 Creating a Microcomputer Program

#### 6.2.1 Reading a program area by specifying an address

The address of the program area in internal memory is specified, and the description is read as hexadecimal data.

#### OPERATION EXAMPLE

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00F0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
SUM	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

To read the data of address 1000H:


F2 → 1 → 0 → 0 → 0 → Enter

Select read                      Specify the address

#### OPERATING PROCEDURE

F2

- 1 Select the microcomputer mode.



A dump list is displayed. Press the [F2] key to select a read function.

1 → 0 → 0 → 0 → Enter

- 2 Input the address to be read in hexadecimal, and press the [Enter] key.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
1000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1050	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
1090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
10F0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

The dump list begins with a multiple of 100 H (256).

Confirm whether a cursor moves to the specified address.

#### REMARK

The microcomputer program capacity is not set. When the microcomputer mode is selected, Microcomputer program capacity not set is displayed.

The dump list is not displayed.

#### ADVICE

##### ◦ Sum check

The sum check will be executed horizontally and vertically, and the total will be checked.

##### ◦ How to scroll a dump list

The next page and the previous page are displayed by using the [Page Up] and [Page Down] keys.

(1 screen is scrolled.)

## 6. MICROCOMPUTER MODE

### Writing a program

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	O	O	O	O	O	O	O	X	X	X	X	X

**MELSEC-A**

#### 6.2.2 Writing a program in machine language

The address of the program area in internal memory is specified, and a program is created in machine language.

#### OPERATION EXAMPLE

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	FF	00	00	00	00	00	00	00	00	00	00	FF
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00F0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
SUM	00	00	00	00	00	FF	00	00	00	00	00	00	00	00	00	00	FF

To write "FFH" to address "0055H":

F2

5

5

Enter

F

F

Enter

Read address "0055H"
Write "FFH"

#### OPERATING PROCEDURE



- 1 Select the microcomputer mode.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

Press the [F2] (read) key to read an address where data is written. The address can be specified by moving the cursor.

Confirm whether the cursor has moved to an address to be written.



- 2 Write (machine language) data.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	FF	00	00	00	00	00	00	00	00	00	00	00
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

Execute a sum check to confirm whether correct (machine language) data was written.

When the writing is completed, the following screen appears.

#### ADVICE

##### • Data input position

Input (machine language) data on the screen.

##### • Cursor movement

Use an arrow key to move the cursor.

Use the [→] key to move the cursor to the front of the next line.

Use the [←] key to move the cursor to the end of the previous line.

If the cursor is at the top of the screen, use the [↑] key to move the cursor to the bottom of the screen.

If the cursor is at the bottom of the screen, use the [↓] key to move the cursor to the top of the screen.

##### • Changing an address

When changing an address to write data, press the [F2] (read) key to input an address to be read, then press the [Enter] key.

## 6. MICROCOMPUTER MODE

### Auxiliary functions in the microcomputer mode

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	O	O	O	O	O	O	O	X	X	X	X	X


MELSEC-A

#### 6.2.3 Auxiliary functions available in the microcomputer mode


##### 6.2.3 (1) Function used to change the memory capacity of a microcomputer program in the microcomputer mode

When a program is being created, and the program capacity is insufficient, the program capacity is set except in the parameter mode.

#### OPERATION EXAMPLE



#### OPERATING PROCEDURE



The main microcomputer program capacity can be set without setting a sub-microcomputer program. Likewise, a sub-microcomputer program capacity can be set without setting the main microcomputer program.

## 6. MICROCOMPUTER MODE

### Memory capacity setting

MELSEC-A

End

- 4 Confirm the setting, and press the [End] key to complete the memory capacity setting.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00F0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
SUM	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00

#### REMARK

- (1) The set memory capacity is set to the memory capacity of the parameter mode.
- (2) When the memory capacity setting is completed, a dump list is displayed from address "000H".

#### POINT

- Condition for executing the memory capacity setting of an auxiliary function

Set the sub-microcomputer program capacity to a capacity greater than 2K bytes in the parameter mode before setting or changing.

## 6. MICROCOMPUTER MODE

### Main/sub program switching

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	O	O	X	X	X	X	X

**MELSEC-A**

#### 6.2.3 (2) Switching main/sub microcomputer programs in the microcomputer mode

This function is used to switch a program to a sub-microcomputer program from the main microcomputer program in order to read a sub-microcomputer program when operating the main microcomputer program in the microcomputer mode.

Likewise, a program can be switched to the main microcomputer program from a sub-microcomputer program in order to read the main microcomputer program when operating a sub-microcomputer program.

#### OPERATION EXAMPLE

-AUXILIARY-

1:MEMORY CAP. 2:M/S SWITCH 3:FILE WRITE

Esc:Close

To switch the main sequence program to a subsequence program:  
Before switching, write the main sequence program data to a file:

```

graph LR
    F4[F4] --> 2_1[2]
    2_1 --> Enter[Enter]
    Enter --> 2_2[2]
            
```

F4: Select an auxiliary function  
 2: Select M/S switch  
 Enter: Confirm the M/S switch (Select "YES")  
 2: Select sub-sequence 1

#### OPERATING PROCEDURE

**F4**

-AUXILIARY-

1:MEMORY CAP. 2:M/S SWITCH 3:FILE WRITE

Esc:Close

- 1 Select an auxiliary function. The auxiliary function window opens as shown.

#### REMARK

The auxiliary function can be selected by pressing a 1 – 3 key or moving the cursor key.

**2**

MAIN/SUB PROGRAM SWITCH?

YES
     
 NO

- 2 Select 2 (M/S SWITCH). "MAIN/SUB PROGRAM SWITCH?" is displayed.




## 6. MICROCOMPUTER MODE

### Main/sub program switching

MELSEC-A

Enter → Enter → Enter



- 3 Select "YES" to display the program selection screen.

Select the microcomputer program to be switched to on the program selection screen. As an example, switch to the sub microcomputer program display.

#### REMARK

SUB PROGRAM 2 and SUB PROGRAM 3 cannot be selected in the microcomputer program M/S switching operation.

2

MICRO	WRITE	AS	FF	PC	TEST	SUB	FILE	NAME	FILE	2	HE	P					
	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	SUM
0000	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0010	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0020	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0040	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0050	00	00	00	00	00	FF	00	00	00	00	00	00	00	00	00	00	FF
0060	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0070	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0080	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0090	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00A0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00B0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
00F0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
SUM	00	00	00	00	00	FF	00	00	00	00	00	00	00	00	00	00	FF

- 4 Switch the displayed screen from the main microcomputer program to the sub microcomputer program.

Switching is completed when, as shown to the left, the M/S switching display on the top line of the screen changes.

#### POINT

- When there is not a program to be switched

If the file (the file in which a sub-microcomputer program is stored) of a sub-microcomputer program does not have a program, even if file writing before switching it is selected, then the screen is switched to the writing mode of a sub-microcomputer program (when switching it from the main microcomputer program to a sub-microcomputer program). If the file of a sub-microcomputer program does have a program, the list of the sub-microcomputer program is displayed from step 0000H

- Display when switching

When a sub-microcomputer program is switched to the main microcomputer program, data of the main microcomputer program is displayed from address "000H".

- File writing before switching

When M/S switching is done without doing file writing after correcting the main microcomputer program (or sub-microcomputer program), data corrected with the main microcomputer program (or sub-microcomputer program) is cleared.

## **6. MICROCOMPUTER MODE**

### **Writing a file**

**MELSEC-A**

- 6.2.3 (3) Function used to store data created in the microcomputer mode to the user file**  
(See Section 2.2.2)

## 7. PARAMETER MODE SETTING

When the GPP function is used, set the parameter before selecting the mode. In the parameter setting, the function that can properly work for the CPU is selected and the applicable device range is determined.

This section describes how to set parameters. (The user's manual and programming manual of the CPU module utilized give details on how to find the values to be set as the parameters.)

## 7.1 Parameter Mode Functions

The following functions are available in the parameter mode.

Parameter mode function	Memory capacity setting	Program capacity.....	Sets the capacity of sequence programs and microcomputer programs. ....(see Section 7.2)
		Comment capacity.....	Sets the capacity of comments to be used in sequence programs. ....(see Section 7.2)
		Extension comment capacity.....	Sets the capacity of comments to be used in sequence programs. ....(see Section 7.2)
		File register capacity.....	Sets the number of file register points. ....(see Section 7.2)
		Sampling trace.....	Used to determine if the sampling trace is executed. ....(see Section 7.2)
		Status latch.....	Used to determine if the status latch for each memory is executed. ....(see Section 7.2)
	Latch range setting .....		Specifies the latch range of devices M, B, T, C, and D. ....(see Section 7.3)
	Network/Link setting		
	(Other than AnUCPU)		
	Link setting .....		Setting the number of link stations, inputs, outputs, link relays, link registers, and WDT. ....(see Section 7.4)
	(AnUCPU)		
	Data link parameter setting .....		Setting the various parameters for configuring a network system. ....(see Section 7.5)
	Number of modules setting.....		Setting the number of network modules, the head I/O number, the network module model, and the network No. .... (see Section 7.5.1)
	Network refresh parameter setting .....		Establishing the correspondence between the CPU link devices and link module link devices. .... (see Section 7.5.2)
	MELSECNET II setting.....		Setting the number of link stations, inputs, outputs, link devices, and WDT. .... (see Section 7.5.3)
	Common/remote I/O parameter setting .....		Setting the total number of link stations, WDT, and link device transmission range. .... (see Section 7.5.4)
	Setting station specific parameters...		Setting allocations for additional link devices without changing the program . .... (see Section 7.5.5)
	I/O allocations.....		System I/O allocations for MELSECNET/10 remote I/O stations (set in 0, 16, 32, 48, or 64 point units, including vacant slots). .... (see Section 7.5.6)
	Transfer parameters for data link .....		Setting the link device send/receive range for communication between networks. .... (see Section 7.5.7)
	Network parameter selection.....		Confirming and selecting network parameter setting statuses. .... (see Section 7.5.8)
	Routing parameter setting .....		Setting the transmission route for transient transmission in a multi-tier network. .... (see Section 7.5.9)
	I/O allocation .....		Allocates inputs and outputs on the system (the allocation unit must be selected from 0, 16, 32, 48, or 64 bits) and registers the module model name. ....(see Section 7.6)

Auxiliary	Step relay setting.....	Sets the step relay range setting. ..... (see Sections 7.7.1 and 7.7.2 (1))
	Watchdog timer setting.....	Sets the watchdog timer (available only for the A0J2H, A1, A2, or A3CPU). ..... (see Section 7.7.2 (6))
	Timer setting.....	Sets the ranges of the 100 msec (low speed), 10 msec (high speed), and 100 msec(retentive) timers. ..... (see Sections 7.7.2 (2) and 7.7.4 (2))
	Interrupt counter setting .....	Sets the range of the counter used in interrupt programs. ..... (see Sections 7.7.2 (5) and 7.7.4 (5))
	Counter setting.....	Sets the number of counters to be used (available only for the AnA or AnU). ..... (see Section 7.7.4 (6))
	RUN-PAUSE setting .....	Sets the RUN-PAUSE contact point. .. (see Section 7.7.2 (3))
	Operation mode when an error occurs.....	Sets the operation mode (stop or continue) when such events as a blown fuse and operation, I/O module verification, function, and module operation errors occur. ..... (see Section 7.7.2 (7))
	Annunciator indication mode .....	Used to determine if the annunciator indicator is working. ..... (see Section 7.7.2 (8))
	STOP - RUN output mode .....	Sets the output status when the CPU switches from STOP to RUN. .... (see Section 7.7.2 (4))
	I/O control setting .....	Sets the input/output control mode (available only for the A3HCPU). ..... (see Section 7.7.2 (9))
	Remote I/O / remote terminal setting .....	Sets the operation contents and communication method of the remote input/output and remote terminal (available only for the A2CCPU). ..... (see Section 7.7.3 (7))
	MELSECNET/MINI automatic refresh setting.....	Used for automatic input/output refreshing in the MELSECNET/MINI. .... (see Section 7.7.4 (9))
All clear	Parameter all clear .....	Resets the parameter data registered in internal memory to the default data. (AnUCPU)..... (see Section 7.8)
Network parameter write .....		Writes the set network parameter data to a file (AnUCPU). ..... (Section 2.2.2)
File write .....		Writes the set parameter data to the file. (models other than AnUCPU) ..... (see Section 2.2.2)

**IMPORTANT**

- In the parameter mode, be sure to press the [End] key to complete a setting.

If another operation screen is called without doing the above-mentioned operation, the set data will be aborted.

## 7. PARAMETER MODE

### Memory capacity setting

PC  
models

ALL TYPES

MELSEC-A

### 7.2 Setting of the Memory Capacity for Creating Programs and Writing Comments

This section describes how to set the capacity of sequence programs and microcomputer programs in the main program and sub program areas, the comment capacity, the extension comment capacity, and the file register capacity, and how to determine if the sampling trace and the status latch are executed.

#### OPERATION EXAMPLE

To set the program capacity (main sequence: 16K steps, sub-sequence: 15K steps, microcomputer: 0 for main and sub respectively), comment capacity (1024 points), extension comment capacity (128 points), file register capacity (4K points), sampling trace (YES), status latch (both data memory and file register are set to YES),

(when an A0J2H, A1S, A2C, A2N(F), A3N(F), A3V, A73, A3H, or A3MCP is used):

```

1 → 1 → 6 → ↓ → 1 → 5 → Enter → Enter
Set the memory capacity. Set the main sequence capacity. Move the cursor. Set the subsequence capacity. Move the cursor.

1 → 7 → Enter → 3 → Enter → 4 → Enter
Set the comment capacity. Set the extension comment capacity. Set the file register capacity.

Y → Enter → Y → Enter → Y → End
Set the sampling trace. Set the status latch data memory. Set the status latch file register. Complete the setting.

```

#### OPERATING PROCEDURE

- 1 Select "1: MEMORY CAPACITY" from the parameter menu window.

The memory capacity setting window opens.

1 → 6 → ↓ → 1 → 5 → Enter → Enter

- 2 Set the program capacity.

Press the [Enter] key to go on to the next page.

Use the [→], [←], [↓], or [↑] keys to move the cursor between the fields.

Set the parameters in the corresponding fields.

In the case of an AnUCPU, since the setting capacity for the network parameters (see Section 7.5) takes up some of the main program area, the main program capacities that can be set are those indicated in the table below.

## 7. PARAMETER MODE

### Memory capacity setting

MELSEC-A

PC model	Settable main program capacity (K steps)
A2U	Maximum of 14
A3U, A4U	Maximum of 30 – (network parameter capacity* (Kbytes) ÷ 2)

\* The network parameter capacity is set in the range 0 to 16 Kbytes depending on the setting capacity.

#### REMARKS

- (1) To set the microcomputer capacity, the sequence program capacity needs 1K steps or more.
- (2) Sequence program capacity is set by 1K steps. Microcomputer program capacity is set by 2K bytes.  
1K steps = 2K bytes.

1 → 7 → Enter

```

<MEMORY CAPACITY>
F1 PROGRAM      SEQUENCE(1-30) MICRO(0-58)
                  MAIN [16]KSTEP [0]KBYTE
                  SUB  [15]KSTEP [0]KBYTE
F2 COMMENT      [17]KBYTE (1024 PT.)
                  (0.2-64)
F3 EXTENDED COMMENT [0]KBYTE ( 0 PT.)
                  (0.2-63)
F4 FILE REGISTER [0]K-PT.
                  (0-8)
F5 SAMPLING TRACE [N] (Y: YES N: NO)
F6 STATUS LATCH DATA [N] (Y: YES N: NO)
                  R [N] (Y: YES N: NO)
                  END SET ESc STOP
  
```

3 Set the comment capacity.

The allowable comment capacity ranges from 0 to 64K bytes.

It is set in units of 1K bytes. The capacity can be set to 0, or 2 to 64K bytes.

When the capacity is set, the number of comments is automatically calculated and displayed in parentheses to the right of the input field.

#### REMARK

$$\text{Necessary byte length} = \frac{\text{Number of comments}}{64} + 1 \text{ (k bytes)}$$

Use the above formula to find the set value.

If the calculation involves a decimal, round off the value to an integral number.

3 → Enter

```

<MEMORY CAPACITY>
F1 PROGRAM      SEQUENCE(1-30) MICRO(0-58)
                  MAIN [16]KSTEP [0]KBYTE
                  SUB  [15]KSTEP [0]KBYTE
F2 COMMENT      [17]KBYTE (1024 PT.)
                  (0.2-64)
F3 EXTENDED COMMENT [0]KBYTE ( 128 PT.)
                  (0.2-63)
F4 FILE REGISTER [0]K-PT.
                  (0-8)
F5 SAMPLING TRACE [N] (Y: YES N: NO)
F6 STATUS LATCH DATA [N] (Y: YES N: NO)
                  R [N] (Y: YES N: NO)
                  END SET ESc STOP
  
```

4 Set the extension comment capacity. (extension comment 1)

The capacity can be set to either 0, or 2 to 63K bytes. It is set in units of 1K bytes.

When the capacity is set, the number of comments is automatically calculated and displayed in parentheses to the right of the input field.

#### REMARK

- The necessary byte length can be found in the same way as indicated above.
- Comment capacity setting for extension comments 2 to 4 is not necessary.

## 7. PARAMETER MODE

### Memory capacity setting

MELSEC-A

4 → Enter

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-30)	MICRO(0-58)
	MAIN [16]KSTEP	[0]KBYTE
	SUB [15]KSTEP	[0]KBYTE
F2 COMMENT	[17]KBYTE (1024 PT.)	(0.2-64)
F3 EXTENDED COMMENT	[0]KBYTE (128 PT.)	(0.2-63)
F4 FILE REGISTER	[0]K-PT.	(0-8)
F5 SAMPLING TRACE	[N] (Y: YES N: NO)	
F6 STATUS LATCH DATA	[N] (Y: YES N: NO)	
	R [N] (Y: YES N: NO)	
END SET Esc STOP		

5 Set the file register capacity.

The capacity is set in units of 1K points.

1K points correspond to 1024 points of file registers.

#### REMARK

PC Models	Capacity
A0J2H, A1S	4K points (Max.4096 points)
A2C	
A2N(F)	
A3N(F), A3V, A73	8K points (Max.8192 points)
A3H, A3M	
A2A, A3A	
A2U, A2US, A3U, A4U	

Y → Enter

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-30)	MICRO(0-58)
	MAIN [16]KSTEP	[0]KBYTE
	SUB [15]KSTEP	[0]KBYTE
F2 COMMENT	[17]KBYTE (1024 PT.)	(0.2-64)
F3 EXTENDED COMMENT	[3]KBYTE (128 PT.)	(0.2-63)
F4 FILE REGISTER	[4]K-PT.	(0-8)
F5 SAMPLING TRACE	[Y] (Y: YES N: NO)	
F6 STATUS LATCH DATA	[N] (Y: YES N: NO)	
	R [N] (Y: YES N: NO)	
END SET Esc STOP		

6 Determine if the sampling trace is executed.

Select Y (YES) to execute it.

The default value is set to N (NO).

Y → Enter → Y

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-30)	MICRO(0-58)
	MAIN [16]KSTEP	[0]KBYTE
	SUB [15]KSTEP	[0]KBYTE
F2 COMMENT	[17]KBYTE (1024 PT.)	(0.2-64)
F3 EXTENDED COMMENT	[3]KBYTE (128 PT.)	(0.2-63)
F4 FILE REGISTER	[4]K-PT.	(0-8)
F5 SAMPLING TRACE	[Y] (Y: YES N: NO)	
F6 STATUS LATCH DATA	[Y] (Y: YES N: NO)	
	R [Y] (Y: YES N: NO)	
END SET Esc STOP		

7 Determine if the status latch is executed for the data memory and file register memory.

Select Y (YES) to execute it.


The default value is set to N (NO).

## 7. PARAMETER MODE

### Memory capacity setting

MELSEC-A

End



- 8 Press the [End] key to complete the memory capacity setting.

The window closes. The parameter menu appears; or

Press the [Esc] key to cancel the setting (the set contents are aborted).

#### REMARK

When all items are set, pressing the [Enter] key moves the cursor to the next item.

When some items are set, the items not to be set are skipped by pressing the [F1], [F2], [F3], [F4], [F5], or [F6] key.

#### POINT

- **A0J2CPU program capacity setting**

The A0J2CPU uses all memory areas but the sequence program capacity as microcomputer areas.

However, the microcomputer area is supported by a utility software package.

- **0 setting for subprogram capacity**

It is not possible to set the capacity of a subprogram that is currently being edited to "0".

To set a subprogram capacity to 0, make the setting when editing a program other than the subprogram whose capacity is to be set to "0".

- **Precautions when doing comment capacity setting**

- (1) In internal memory, any CPU can set the comment capacity to 64K bytes and create a 4032-point comment on any CPU.

But the A0J2CPU can register only a 95-point comment data of F0 to F94. The A1(N)CPU can register only a 128-point comment of F0 to F127.

- (2) In internal memory, any CPU can set the extension comment capacity to 63K bytes and create a 3968-point comment on any CPU.

Only the AnA, AnUCPU can be registered to the CPU.



## 7. PARAMETER MODE

### Memory capacity setting

MELSEC-A

#### ADVICE

##### Window

The values in parentheses indicates the allowable setting range.  
The figures in the square brackets [ ] are set values.

The default values appear on the initial screen.

##### The window indication varies for each CPU

The window indication depends on the model of CPU used.

Operation examples when the A3(N), A3V, A73, A3H, or A3M CPU is used.

(1) When an A2(N)/A0J2H/A1S/A2CCPU is used:

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-8) MAIN [6]KSTEP	MICRO(0-14) [0]KBYTE
F2 COMMENT	[0]KBYTE (0.2-64)	( 0 PT.)
F3 EXTENDED COMMENT	[0]KBYTE (0.2-63)	( 0 PT.)
F4 FILE REGISTER	[4]K-PT. (0-4)	
F5 SAMPLING TRACE	[N]	(Y: YES N: NO)
F6 STATUS LATCH DATA	[N]	(Y: YES N: NO)
R		
END/SET ESC/STOP		

(2) When an A1CPU is used:

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-6) MAIN [6]KSTEP	MICRO(0-10) [0]KBYTE
F2 COMMENT	[0]KBYTE (0.2-64)	( 0 PT.)
F3 EXTENDED COMMENT	[0]KBYTE (0.2-63)	( 0 PT.)
END/SET ESC/STOP		

(3) When an A0J2CPU is used:

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE MAIN [3]KSTEP	MICRO NO
F2 COMMENT	(1-7) [0]KBYTE	( 0 PT.)
F3 EXTENDED COMMENT	(0.2-64) [0]KBYTE	( 0 PT.)
END/SET ESC/STOP		

(4) When an AnA/AnU CPU is used (other than A4UCPU):

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-14) MAIN [6]KSTEP	MICRO [0]KBYTE
F2 COMMENT	[0]KBYTE (0.2-64)	( 0 PT.)
F3 EXTENDED COMMENT	[0]KBYTE (0.2-63)	( 0 PT.)
F4 FILE REGISTER	[0]K-PT. (0-8)	
END/SET ESC/STOP		

(5) When an A4UCPU is used:

MEMORY CAPACITY		
F1 PROGRAM	SEQUENCE(1-30) MAIN (MAX30) SUB 1 SUB 2 SUB 3	MICRO(0-58) [ 0]KBYTE [0]KSTEP [0]KSTEP [0]KSTEP
F2 COMMENT	[ 0]KBYTE (0.2-64)	( 0 PT.)
F3 EXTENDED COMMENT	[ 0]KBYTE (0.2-63)	( 0 PT.)
F4 FILE REGISTER	[ 0]K-PT. (0-8)	
END/SET ESC/CLOSE		

##### Setting data clear

Press the [F10] key.

"SET PARAMETER TO DEFAULT VALUES?  
YES/NO" appears on the display screen.

Select "YES" to reset the parameter setting data in the memory capacity setting to the default data.

#### IMPORTANT

##### A0J2CPU setting data

If the microcomputer area contains a utility software package (SW0C-UTLP), "YES" will appear in the microcomputer column.

If the sequence program capacity is changed while "YES" appears on the display, the utility software data will be destroyed.

If this happens, the utility data must be rewritten.

##### Note on setting the extension comment capacity for an AnA or AnUCPU

When the PC model is AnA/AnU, the set extension comment capacity is included in the total memory capacity for parameters.

If the PC model is other than AnA/AnU, the set extension comment capacity is not included in the memory capacity for parameters and is allocated to the capacity of the internal memory of the peripheral device.

## 7. PARAMETER MODE

### Memory capacity setting

MELSEC-A

Reference	Setting ranges and default values
-----------	-----------------------------------

Setting ranges and memory capacity default values are shown below.

Setting range and items differ in PC models.

PC Models			A0J2	A1N(F)	A2N(F)	A3N(F) A3V A73	A3H A3M	A0J2H A1S A1SJ	A2C A2CJ A52G	A2A A2U A2US	A3A A3U	A4U
Item												
Main	Se- quence	Setting ranges	1 to 7K steps	1. to 6K steps	1 to 14K steps	1 to 30K steps		1 to 8K steps		1 to 14K steps	1 to 30K steps	
		Default values	3K steps	6K steps	6K steps	6K steps		6K steps		6K steps	6K steps	
	Microco mputer	Setting ranges	—	0 to 10K bytes	0 to 26K bytes	0 to 58K bytes		0 to 14K bytes		0 to 26K bytes	0 to 58K bytes	
		Default values	Unavail- able	0K bytes	0K bytes	0K bytes		0K bytes		0K bytes	0K bytes	
Sub	Se- quence	Setting ranges	—			0 to 30K bytes		—		0 to 30K steps		0 to 30K steps × 3
		Default values	—			0K step		—		0K step		0K step
	Microco mputer	Setting ranges	—			0 to 58K bytes		—				
		Default values	—			0K bytes		—				
File register		Setting ranges	—	0 to 4K points (Max.4096 points)		0 to 8K points (Max.8192 points)		0 to 4K points (Max.4096 points)		0 to 8K points (Max.8192 points)		
		Default values	—	0K points		0K points		0K points		0K points		
Comment		Setting ranges	0.2 to 64K bytes (Max.4032 points)		0.2 to 64K bytes (Max.4096 points)							
		Default values	64K bytes		0K byte							
Extension comment		Setting ranges	0.2 to 63K bytes (Max.3968 points)									
		Default values	0K bytes									
Sampling trace		Setting ranges	—	Y/N						* —		
		Default values	—	N						* —		
Status latch	Device memory	Setting ranges	—	Y/N						* —		
		Default values	—	N						* —		
	File register	Setting ranges	—	Y/N						* —		
		Default values	—	N						* —		

\* The AnA/AnUCPU status latch and sampling trace are set in the online mode.

## 7. PARAMETER MODE

### Latch range setting

PC  
models

ALL TYPES

MELSEC-A

### 7.3 Setting the Device Range to be Latched

This section describes how to set the latch ranges to be applied to the internal relay (M), link relay (B), timer (T), counter (C), data register (D), link register (W), etc.

#### OPERATION EXAMPLE

**LATCH RANGE**

L	100-2047	< 0-2047 >
B	-	< 000- 3FF >
T 100 ms	0- 199	< 0- 199 >
T 10 ms	200- 255	< 200- 255 >
T 100 ms (RET.)	-	< - >
C	-	< 0- 255 >
D	-	< 0- 1023 >
W	-	< 000- 3FF >

END SET    Esc Close

To latch the ranges of T0 to T199 of the low-speed timer and of T200 to T255 of the high-speed timer (when a CPU other than an A0J2, A2A, and A3ACPU is used):




```

2 → ↓ → ↓ → 0 → → 1 → 9 → 9 → Enter
Set the latch range.      Set the low-speed timer range of T0 to T199.

2 → 0 → 0 → → 2 → 5 → 5 → End
Set the high-speed timer range of T200 to T255.      Complete the setting.
    
```


#### OPERATING PROCEDURE

- 2
- 1 Select "2: LATCH RANGE" from the parameter window.  
The latch setting window opens.



- 2 Move the cursor to the device to be set.  
Type a number in the latch-starting number field.  
Press the [→] or [Enter] key.  
Type a number in the last latch number field.  
To delete the setting range, move the cursor to the corresponding item and press the [Delete] key.

End



- 3 Press the [Enter] key to complete the setting.  
The window closes.  
The parameter menu re-appears; or  
Press the [Esc] key to cancel the setting (the set data is aborted).

## 7. PARAMETER MODE

### Latch range setting

MELSEC-A

#### ADVICE

- When an AnA/AnUCPU is used:

The timer setting range is divided into two parts:

The two ranges of T0 to T255 and T256 to T2047 are applied to the timer. The ranges of C0 to C255 and C256 to C1023 are applied to the counter.

LATCH RANGE			
L		1000-2047	< 0-8191 >
B			< 000- FFF >
T	100 ms	-	< 0- 199 >
T	10 ms	-	< 200 - 255 >
T	100 ms (RET.)	-	< - - - >
C			< 0- 255 >
D			< 0- 6143 >
W			< 000- FFF >
T	100 ms	-	< - - - >
T	10 ms	-	< - - - >
T	100 ms(RET.)	-	< - - - >
C			< - - - >
		END SET	Esc Close

For an AnUCPU, the setting ranges for B, W, and D devices are as follows:

B/W: <000 - 1FFF> D: <0 - 8191>

- Set data clear

Press the [F10] key.

"SET PARAMETER TO DEFAULT VALUES? YES/NO" appears.

Select "YES" to reset the parameter setting data to the default data.

- When an A0J2CPU is used

(1) The latch range can be set for the following devices.

- 1) Internal relay: M0 to M2047 (the latch range is set in field (L).
- 2) Link relay: B0 to 3FF

- 3) Timer

Low-speed (100 msec) timer: T0 to T79

High-speed (10 msec) timer: T80 to T119

Retentive timer: T120 to T127

- 4) Counter : C0 to C127

- 5) Data register : D0 to D511

- 6) Link register : W0 to 3FF

(2) Set the latch range as follows:

- 1) No latch : No devices are latched.

- 2) 1/2 latch : Only the latter half of each device is latched.

- 3) All latch : All devices are latched.

(3) The default value is 1/2.

(4) The latch range is set by using the [F1], [F2], or [F3] key.

The latch range of each device is automatically displayed.

(5) When the latch range of the step relay (S) is set by using the parameters (auxiliary function).

Selecting "no latch" results in no devices being latched;

Selecting "1/2 latch" or "all latch" results in devices S1536 to S2047 being latched.

(6) Press the [End] key to complete the setting. The parameter menu reappears.

#### POINT

- Relationship between the latch relay (L) and the step relay (S)

If the ranges of the latch relay and the step relay overlap, the most recent set data will be valid.

- Relationship between the timer setting and the latch range

(1) After setting the ranges of the 10 msec, 100 msec, and retentive timers using the parameter auxiliary, the timer latch range must be set.

If the setting data is outside the range set in the timer setting mode, the "DEVICE NUMBER OUT OF RANGE" message will appear.

Be sure to confirm the allowable setting range in parentheses.

(2) When the setting range is changed in the timer setting mode after executing the latch range setting, the latch setting data will be forced to be inside the allowable range.

## 7. PARAMETER MODE

### Link setting

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	O	O	O	O	O	O	O	O	O	X	X	X

## MELSEC-A

### 7.4 Setting Communications Contents for Each Station When a Link System is Used

Sets communications contents of the master station (M) and remote I/O station (R) when a link system is used.

#### 7.4.1 Setting link when the MELSECNET mode is selected

Sets communications contents of the master (M) and remote (R) station/local station (L) before using the link system.

### OPERATION EXAMPLE

**LINK SETTING (MELSECNET MODE)**

F1 MAST-ER	SLAVE PC STATIONS	M → ALL	LINK W. D. T. * 10 ms
M	1	-	200

L/R No.	M ← L	M → R	M ← R	M → L/R	M ← L/R
	B	W	W	Y	X/Y
R1	----	----	000-010	020-030	----

Page Up / Page Down    End: CHECK & SET    Esc: Close

To set the link station to 1, watchdog time to 1000 msec, W (from M to R) to W0 through W10, and W (from R to M) to W20 through W30 respectively:

(Models other than A2A/A3ACPU)

```

3 → 1 → 1 → → → → →
Set the link.  Select the MELSECNET mode.  Set the link station number to 1.


1 0 0 Enter → R 0 → → 1 0
Set the watchdog time to 1000 msec.  Set the first link station to the remote station.  Set W from M to R (W0 to W10).

→ 2 0 → → 3 0 End End
Move the cursor to the M R field.  Set W from M to R (W20 to W30).  Check the set data.  Complete the setting.

```

### OPERATING PROCEDURE

- 3




**1** Select "3: NETWORK/LINK" from the parameter menu window.

If an A2A/A3ACPU is used as the CPU, the network setting window opens.

In this case, type 1 (MELSECNET mode).

When the CPU used is not an A2A/A3ACPU, this window does not appear (the link setting window opens).
- 1




**2** Select the MELSECNET mode (available for the A2A/A3ACPU).

The link setting window opens.

## 7. PARAMETER MODE

### Link setting

MELSEC-A



LINK SETTING (MELSECNET MODE)									
F1 MAST- ER	SLAVE PC STATIONS	M → ALL		LINK WDT * 10 ms	M	B	ALL	L	B
		B	W			W	ALL	R	W
M	1	-	-	100		X	ALL <td>R <td>X</td> </td>	R <td>X</td>	X

L/R No.	M ← L	M → R	M ← R	M → L/R	M ← L/R
	B	W	W	Y	X/Y
R1	----	----	000-010	020-030	----
	----	----	----	----	----
	----	----	----	----	----
	----	----	----	----	----

Page Up / Page Down    End CHECK & SET    Esc    Close

- 3 Sets the link ranges from the total number of link stations.

Move the cursor as described below.

- 1) [←] and [→]:

Used for moving the cursor left and right.

- 2) [↑] and [↓]:

Used for moving the cursor up and down (only when the cursor is located in the columns of L/R Nos.).

- 3) [Enter]:

Used for completing the setting on each line and moving the cursor to the beginning of the next line.

When the remote I/O (R) or local station data input on each line in the columns of L/R Nos. is completed, the input data is checked.

When the input data is correct, the cursor goes to the beginning of the next line.

If an error exists in the input data, an error message will appear and the cursor will flash at the field where the error is.

- 4) [F1]:

Used for moving the cursor to the setting field of the total number of stations to be linked.

End

LINK SETTING (MELSECNET MODE)									
F1 MAST- ER	SLAVE PC STATIONS	M → ALL		LINK WDT * 10 ms	M	B	ALL	L	B
		B	W			W	ALL	R	W
M	1	-	-	100		X	ALL <td>R <td>X</td> </td>	R <td>X</td>	X

L/R No.	M ← L	M → R	M ← R	M → L/R	M ← L/R
	B	W	W	Y	X/Y
R1	----	----	000-010	020-030	----
	----	----	----	----	----
	----	----	----	----	----
	----	----	----	----	----

CHECK COMPLETED.

Page Up / Page Down    End CHECK & SET    Esc    Close

- 4 When data for all stations to be linked is set, press the [End] key to complete the setting.

While "Under checking" is displayed, the set data is checked.

End

- 5 If there are no errors in the data, "CHECK COMPLETED" appears.

Press the [End] key to register the data to the parameter area.

If an error exists in the data located in the L/R No columns, the field containing the error will be highlighted.

If this happens, input correct data, and press the [End] key.

## 7. PARAMETER MODE

### Link setting

MELSEC-A

#### ADVICE

##### ◦ Data input for more than five station

Data input for up to 5 stations can be done on the screen. If data input for more than five stations is done, press the [↓] or [Page Down] key after inputting the fifth station data.

Press the [Page Up] key to return to the previous page.

##### ◦ Other error checks to set the link

1) When the [Enter] key is pressed to set the local station:\* Checks if the total number of bytes of W and B from L to M exceeds 1024.

2) When the [Enter] key is pressed to set the remote station

Checks if the total number of bytes of W and Y from M to R and of W and X from R to exceeds 512.

The following checks are common in items 1) and 2).

Check if the remote I/O stations are not numbered from 0.

Check if the number of master station devices is not the same as remote I/O device.

3) When the [End] key is pressed:

- There is a station for which L/R specification is not set.
- The total number of bytes of B, W, and Y from M to all L is 1024 or more.
- B and W between M and all L overlaps with B and W between M and all R in addresses 0 to 7FF.
- There is a remote I/O station for which slot allocation has not been done after completing the I/O allocation in the link setting;

In the link setting, the last I/O number of the last-numbered remote station is not the same as the last number set in the I/O allocation;

Any of these items must be corrected and rechecked.

#### REMARK

A point of W equals two bytes. With regard to B, X, and Y, 16 points are equal to two bytes.

##### ◦ Insertion and deletion of station number

When the system configuration is changed, a station number can be inserted and deleted.

How to insert/delete a station number is described below.

1) Press the [Insert] key in the L/R No. setting column to insert a station number on the line where the cursor is located.

The total number of stations to be linked increases by one.

2) Press the [Delete] key in the L/R No. setting column to delete a station number on the line where the cursor is located.

The total number of stations to be linked decreases by one.

When the setting data is changed in the last part of the L/R No. setting columns:

Return to the first half;

Complete the setting of the first half;

Press the [F8] key to return to the latter half; and

Change the data of the latter half.

3) Be sure to press the [End] key to complete the insertion/deletion.

If another operation screen is called without pressing the [End] key, the changed data will be aborted.

##### ◦ Clearing all registered link setting data

1) Press the [F10] key.

2) Select "YES" in response to the prompt.


3) Press the [End] key to complete the operation.

Internal memory is also cleared.

## 7. PARAMETER MODE

### Link setting

MELSEC-A



#### POINT

#### • Selecting from the mode selecting screen

##### • [1] MELSECNET mode

Select this mode when an A0J2H, A1S, A1, A2, A2C, A3, or A3H is used as the master station in the link system.

##### • [2] MELSECNET II (MULTI) mode

Select this mode when an A2A/A3ACPU is used as the master station and the local stations (L) includes other type modules in the link system.

#### • [3] MELSECNET II

Only A2A/A3ACPU modules make up the link system.



## 7. PARAMETER MODE

### Link setting

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	X	X	O	O	X	X	X

## MELSEC-A

### 7.4.2 Link setting when the MELSECNET II (COMPOSIT) is selected

The MELSECNET II (COMPOSIT) mode is available only for the A2A/A3ACPU.

In the MELSECNET II mode, two areas can be allocated to B and W respectively.

Press the [F8] key to switch the input screen (between the first screen and the last screen).

Other setting operations are the same as for the MELSECNET mode.

Key input in L/R No. setting columns

The following key operations are valid in the L/R No. columns (only on the first screen).

- (1) [F5] or [L] : When a station is set as a local station.
- (2) [F6] or [R] : When a station is set as a remote I/O (R).
- (3) [F7] or [\*] : When a station is set as a MELSECNET II location station (L II).

MELSECNET II data of the first and latter halves when switching between MELSECNET II and MELSECNET

	First Data	Last Data
MNET II → MNET	M ← L M → L From the data set in MNET II, BW and X/Y can be also used in MNET.	The data in the last part remains until the [End] key is pressed. The data will be redisplayed when switching from MNET TO MNET II.
MNET II ← MNET	M ← L From the data set in MNET, BW can be also used in MNET II.	The last part contains no data. The data is displayed when switching from M to L.

#### REMARK

- (1) When the first half is displayed, press the [F8] key to go on to the latter half. When the latter half is displayed, press the [F8] key to go on to the first half.  
During input operation, devices of 0 to 3FF in the first half and of the last device number + 1 to FFF (0 when the first part is zero point) in both halves is checked.
- (2) Other setting operations are the same as the MELSECNET mode.

## 7. PARAMETER MODE

### Link setting

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	X	X	O	O	X	X	X

## MELSEC-A

### 7.4.3 Link setting when the MELSECNET II mode is selected

The MELSECNET II mode is available only for the A2A/A3ACPU.

In the MELSECNET II mode two areas can be allocated to B and W respectively.

Press the [F8] key to switch the input screen (between the first screen and the last screen).

Other setting operations are the same as for the MELSECNET mode.

#### REMARK

- (1) When the first half is displayed, press the [F8] key to go on to the latter half. When the latter half is displayed, press the [F8] key to go on to the first half.(1)
- (2) The CPU automatically verifies if a MELSECNET is utilized as the master using the PC type data initially set.

## 7. PARAMETER MODE

### Network/link settings

MELSEC-A

#### 7.5 Setting Communications Contents for Each Station and Network when a Network System is Used

This section describes the network/link setting operation used when configuring a MELSECNET/10 network system or a MELSECNET (II) or MELSECNET/B data link system with an AnUCPU.

The operation flow when setting the data link parameters in the network/link settings differs according to whether settings are to be made for the first time or settings have already been made.

The explanations of setting methods in this section (Sections 7.5.1 through 7.5.7), deal with the operations after the relevant parameter setting window has been displayed.

For details on the operation up to the point where the relevant parameter window is displayed, see the processing flow in the "POINT" below.

<PARAMETER>		<MENU>
1: MEMORY CAPACITY		ING
2: LATCH RANGE		R
3: NETWORK/LINK		ATION
4: I/O ALLOCATION		NTENANCE
5: AUXILIARY		SETTING
6: ALL CLEAR		
7: NET PARAM. WRITE		
8: FILE WRITE		
Esc Close		Esc Close

Parameter menu window

3

Select NETWORK/LINK.

<PARAMETER>		<MENU>
1: DATA LINK PARAM.		ING
2: ROUTING PARAMETER		R
		ATION
		NTENANCE
		SETTING
6: ALL CLEAR		
7: NET PARAM. WRITE		
8: FILE WRITE		
Esc Close		Esc Close

The network/link setting window opens.  
Select the item to be set by using the numeric keys (1 and 2) or shifting the cursor, and then pressing the [Enter] key.

1 "1: DATA LINK PARAM." (New setting)

1 "1: DATA LINK PARAM." (Existing settings)

2 "2: ROUTING PARAMETER"

MODULES				
NO OF MODULES (1-4)	[]			
MODULE NO. ACCESSED BY GPP	[]			
	MODULE 1	MODULE 2	MODULE 3	MODULE 4
IO NO	[]	[]	[]	[]
NETWORK MODULE TYPE				
NETWORK NO.	[]	[]	[]	[]
END SET/ESC/CLOSE				

The MODULES window opens.  
Set the number, models, network numbers, etc., of the network modules mounted to the station for which the data link parameters are to be written.  
... [7.5.1]

NETWORK PARAMETER				
NET MODULE SETTING	1	2	3	4
NETWORK PARAMETER CAPACITY	1	2	3	4
NETWORK REFRESH PARAMETER				
MELSECNET II	X	X	X	O
COMMON/REMOTE I/O PARAM		X		X
STATION/REMOTE PARAMETER	?	?	X	X
I/O ALLOCATION	X	X	*	X
TRANSFER PARAMETER	?	?	X	?
ESC/CHECK/ESC/CLOSE				

The network parameter window opens.  
Select the items/modules that are to be set and make the settings.  
... [7.5.8]

ROUTING PARAMETER			
NO	DEST NW NO	RELAY NW NO	RELAY STN NO
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
PAGE UP/PAGE DOWN			
END SET/ESC/CLOSE			

The routing parameter window opens.  
Set the transfer destination network No., the relay network No., and the relay station No.  
... [7.5.9]


## 7. PARAMETER MODE

### Network/link settings

MELSEC-A

#### POINT

- Network/link setting processing flow when the PC model is AnU



- About network parameter settings

For details on each type of parameter, refer to the MELSECNET/10 Network System Reference Manual (PC-to-PC Network)/(Remote I/O Network).


### 7.5.1 Setting the number of network modules

This operation sets information relating to the mounted network modules (MELSECNET/10) or data link modules (MELSECNET(II)) when a data link is operated using an AnUCPU.

When setting the data link parameters for the first time, it is essential to set the module information using this operation.

Data can be confirmed and modified after being set by using the operation in Section 7.5.8.

#### OPERATION EXAMPLE



	MODULE 1	MODULE 2	MODULE 3	MODULE 4
IO NO	[00]	[ ]	[ ]	[ ]
NETWORK MODULE TYPE	MELSECNET/10 CONTROL STN			
NETWORK NO	[1]	[ ]	[ ]	[ ]

End SET Esc:CLOSE

To make the following settings: NO. OF MODULES = 1, MODULE NO. ACCESSED BY GPP = 1, I/O NO. = 0, NETWORK MODULE TYPE = MELSECNET/10 (control station), NETWORK NO. = 1:

```

graph LR
    A[1] --> B[Enter]
    B --> C[1]
    C --> D[Enter]
    D --> E[0]
    E --> F[↓]
    F --> G[2]
    G --> H[Enter]
    H --> I[1]
    I --> J[Enter]
    J --> K[End]
    K --> L[The setting is completed.]
    
```

Set the NO. OF MODULE    Set the MODULE NO. ACCESSED BY GPP    Set the I/O NO.    Set the NETWORK MODULE TYPE  
 Set the NETWORK NO.    The setting is completed.

#### EXPLANATION

- 1 Select "1: DATA LINK PARAM." from the network/link setting window; the MODULES window opens.


#### REMARK

If the number of modules settings have already been made, the network parameter window (see Section 7.5.8) opens instead of the the MODULES window.

To enable number of modules setting when the network parameter window is displayed, press the [F1] key.

1 Enter

- 2 Set the NO. OF MODULES (1 to 4). This setting determines the number of network modules or data link modules that can be mounted to one CPU.



	MODULE 1	MODULE 2	MODULE 3	MODULE 4
IO NO.	[ ]	[ ]	[ ]	[ ]
NETWORK MODULE TYPE				
NETWORK NO.	[ ]	[ ]	[ ]	[ ]

End SET Esc:CLOSE

# Network/Link Settings

## Number of modules settings

**MELSEC-A**

1 → Enter

MODULES				
NO OF MODULES(1-4)	[1]			
MODULE NO. ACCESSED BY GPP	[1]			
	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO	[ ]	[ ]	[ ]	[ ]
NETWORK MODULE TYPE				
NETWORK NO	[ ]	[ ]	[ ]	[ ]
End SET Esc-CLOSE				

3 Set the MODULE NO. ACCESSED BY GPP.

This setting determines the network that will be accessed when a peripheral device that is not compatible with MELSECNET/10 is accessed using the other station access function, by specifying the module No. of the module to which that network is connected.

0 ↓ 2 1 → Enter

MODULES				
NO OF MODULES(1-4)	[1]			
MODULE NO. ACCESSED BY GPP	[1]			
	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO	[00]	[ ]	[ ]	[ ]
NETWORK MODULE TYPE	MELSECNET/10 CONTROL STN			
NETWORK NO	[1]	[ ]	[ ]	[ ]
End SET Esc-CLOSE				

4 Set the I/O NO., NETWORK MODULE TYPE, and NETWORK NO.

I/O NO.: Set the most significant two digits of the head I/O number for the relevant network module.

NETWORK MODULE TYPE:

Select one of the network types listed below by specifying the corresponding number.

- 1: MELSECNET/10 (default parameter)
- 2: MELSECNET/10 (CONTROL STATION)
- 3: MELSECNET/10 (NORMAL STATION)
- 4: MELSECNET/10 (REMOTE I/O MASTER)
- 5: MELSECNET II (MASTER STATION)
- 6: MELSECNET II (LOCAL STATION)

### REMARK

When MELSECNET II (MASTER STATION) is selected, the mode is selected in accordance with the MELSECNET II link settings (see Section 7.5.3).

NETWORK NO.: If the network module in question is compatible with MELSECNET/10, set the network number of the network in which that module is connected.

End

5 Complete setting by pressing the [END] key.

---

#### POINT

---

- **Number of modules settings and parameter capacity**

When the PC model is A3U or A4U, if it is not possible to secure a sufficient memory area for the network parameters when setting the number of network modules settings for the first time or when increasing the number of modules, the message "NETWORK PARAMETER CAPACITY IS INSUFFICIENT" will be displayed and setting will not be possible.

When setting the memory capacity in the parameters, decrease the main program capacity and preserve the network parameter capacity. If the PC type is A2U, since the maximum main program capacity is 14 Ksteps (28 Kbytes), 32 Kbytes is allocated as the network parameter capacity and the above restriction does not apply.

- **Transition to data link parameter setting screen after completing the number of modules settings**

On completion of the number of modules settings (for a first time setting), the window for setting the required data link parameters in accordance with the set module information is automatically displayed, enabling the parameters to be set.

It is possible to select whether or not to set those data link parameters whose setting is not essential by using the setting confirmation windows.

- **Confirming and modifying data link parameter settings**

When setting data link parameters for the first time, the settings from the number of modules settings through to the settings for transfer parameters for data link (see Section 7.5.7) are made in one unbroken sequence, and after all the data link parameters have been set the network parameter window is displayed.

To confirm or modify the data link parameter settings, select the relevant parameter item from the network parameter window. (See Section 7.5.8)

## 7.5.2 Establishing correspondence between the PC CPU link devices and network module link devices

This operation sets the range for transfer of the link devices (LB, LW, LX, LY) and data link communication status devices (SB, SW) of network modules to the link devices (B, W, X, Y) etc. of the PC CPU. Since default values are already set for the network refresh parameters in accordance with the number of modules settings, no setting window is displayed even when setting the parameters for the first time.

To set the network refresh parameters, display the network refresh parameter setting window by following the operation in Section 7.5.8 after setting the other network parameters.

### 7.5.2.(1) Establishing correspondence with MELSECNET/10 (PC-to-PC network) link devices

#### OPERATION EXAMPLE

##### [Setting 1]

NETWORK REFRESH PARAMETER			
OTHER MODULES			
LB ↔ B TRANSFER 1:	SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 16)		
2:			
3:			
4:			
[PAGE 1] NETWORK MODULE 1			
MELSECNET/10 (CTRL STN)	VO NO.	00	NETWORK NO.1
LB ↔ B	LB	10000	SIZE 0800H POINTS
LW ↔ W	LW	10000	SIZE 0800H POINTS
LX ↔ X	LX	00000	SIZE 0000H POINTS
LY ↔ Y	LY	00000	SIZE 0000H POINTS
SB COPIED TO	SB	00000	SIZE 100H POINTS
SW COPIED TO	SW	00000	SIZE 100H POINTS
LB ↔ EXTENDER	LB	00000	SIZE 0000H POINTS
LW ↔ EXTENDER	LW	00000	SIZE 0000H POINTS
ERROR HISTORY	RETAIN		
CHANGE MODULE WITH SHH, F1, F2, F3, F4 KEYS. END SET, END, CLOSE			

The operation for setting the following network refresh parameter settings is presented below:

##### [Setting 1]

LB head = 0, B head = 0, LB ↔ B transfer size = 800H points  
 LW head = 0, W head = 0, LW ↔ W transfer size = 800H points  
 SB head = 0, SB transfer destination = M4000,  
 SB transfer size = 100H points  
 SW head = 0, SW transfer destination = D4000,  
 SW transfer size = 100H points

##### [Setting 2]

LB head = 1000, B head = 800, LB ↔ B transfer size = 800H points  
 LW head = 1000, W head = 800, LW ↔ W transfer size = 800H points

##### [Setting 2]

NETWORK REFRESH PARAMETER			
OTHER MODULES			
LB ↔ B TRANSFER 1:	SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 16)		
2:			
3:			
4:			
[PAGE 2] NETWORK MODULE 1			
MELSECNET/10 (CTRL STN)	VO NO.	00	NETWORK NO.1
LB ↔ B	LB	10000	SIZE 0800H POINTS
LW ↔ W	LW	10000	SIZE 0800H POINTS
LX ↔ X	LX	00000	SIZE 0000H POINTS
LY ↔ Y	LY	00000	SIZE 0000H POINTS
SB COPIED TO	SB	00000	SIZE 100H POINTS
SW COPIED TO	SW	00000	SIZE 100H POINTS
LB ↔ EXTENDER	LB	00000	SIZE 0000H POINTS
LW ↔ EXTENDER	LW	00000	SIZE 0000H POINTS
ERROR HISTORY	RETAIN		
CHANGE MODULE WITH SHH, F1, F2, F3, F4 KEYS. END SET, END, CLOSE			

0 → 0 → 8 → 0 → 0 → Enter

Set LB ↔ B transfer (setting 1)

0 → 0 → 8 → 0 → 0 → Enter

Set LW ↔ W transfer (setting 1)

↓ ↓ 0 → M → 4 → 0 → 0 → 0 → 1 → 0 → 0 → Enter

Set the SB transfer devices

0 → D → 4 → 0 → 0 → 0 → 1 → 0 → 0 → Enter

Set the SW transfer devices

F5 1 0 0 0 → 8 → 0 → 0 → 8 → 0 → 0 → Enter

Switch to setting 2

Set LB ↔ B transfer (setting 2)

1 0 0 0 → 8 → 0 → 0 → 8 → 0 → 0 → Enter → End

Set LW ↔ W transfer (setting 2)

The setting is completed.



# Network/Link Settings

## Network refresh parameter settings (PC-to-PC network)

MELSEC-A

### EXPLANATION

- 1 In the network parameter window, locate the cursor at the network refresh parameter field for a network module at a MELSECNET/10 master station or normal station, and press the [Enter] key; the network refresh parameter window opens.

NETWORK REFRESH PARAMETER

OTHER MODULES

LB ↔ B TRANSFER 1: 0000-1FFF

2:

3:

4:

LB ↔ B TRANS

SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 10).

PAGE 1 NETWORK MODULE 1

MELSECNET/10 (CTRL STN.)	I/O NO.	00	NETWORK NO.1
LB ↔ B	LB	(1000) ↔ B (0000)	SIZE (2000) HPOINTS
LW ↔ W	LW	(1000) ↔ W (0000)	SIZE (2000) HPOINTS
LX ↔ X	LX	(0000) ↔ X (0000)	SIZE (0000) HPOINTS
LY ↔ Y	LY	(0000) ↔ Y (0000)	SIZE (0000) HPOINTS
SB COPIED TO	SB	(000) → DEST. (Y) (1000)	SIZE (100) HPOINTS
SW COPIED TO	SW	(000) → DEST. (D) (7168)	SIZE (100) HPOINTS
LB ↔ EXTENDER	LB	(0000) ↔ BLOCK (0) NO. { 0 SIZE (0000) H	
LW ↔ EXTENDER	LW	(0000) ↔ BLOCK (0) NO. { 0 SIZE (0000) H	
ERROR HISTORY	RETAIN		

CHANGE MODULE WITH SHIF F2 F3 F4 KEYS

END SET END CLOSE

0 → 0 → 8 → 0 → 0

Enter 0 → 0 → 8 → 0

0 Enter ↓ ↓ 0 → M

→ 4 → 0 → 0 → 0 → 1 → 0

0 Enter 0 → D → 4 → 0

0 → 0 → 1 → 0 → 0 Enter

- 2 Set the device range for setting 1.

NETWORK REFRESH PARAMETER

OTHER MODULES

LB ↔ B TRANSFER 1:

2:

3:

4:

LB ↔ B TRANS

SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 10).

PAGE 1 NETWORK MODULE 1

MELSECNET/10 (CTRL STN.)	I/O NO.	00	NETWORK NO.1
LB ↔ B	LB	(1000) ↔ B (0000)	SIZE (0800) HPOINTS
LW ↔ W	LW	(1000) ↔ W (0000)	SIZE (0800) HPOINTS
LX ↔ X	LX	(0000) ↔ X (0000)	SIZE (0000) HPOINTS
LY ↔ Y	LY	(0000) ↔ Y (0000)	SIZE (0000) HPOINTS
SB COPIED TO	SB	(000) → DEST. (Y) (4000)	SIZE (100) HPOINTS
SW COPIED TO	SW	(000) → DEST. (D) (4000)	SIZE (100) HPOINTS
LB ↔ EXTENDER	LB	(0000) ↔ BLOCK (0) NO. { 0 SIZE (0000) H	
LW ↔ EXTENDER	LW	(0000) ↔ BLOCK (0) NO. { 0 SIZE (0000) H	
ERROR HISTORY	RETAIN		

CHANGE MODULE WITH SHIF F2 F3 F4 KEYS

END SET END CLOSE

F5

- 3 Switch the window to setting 2.

NETWORK REFRESH PARAMETER

OTHER MODULES

LB ↔ B TRANSFER 1:

2:

3:

4:

LB ↔ B TRANS

SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 10).

PAGE 2 NETWORK MODULE 1

MELSECNET/10 (CTRL STN.)	I/O NO.	01	NETWORK NO.1
LB ↔ B	LB	(0000) ↔ B (0000)	SIZE (0000) HPOINTS
LW ↔ W	LW	(0000) ↔ W (0000)	SIZE (0000) HPOINTS
LX ↔ X	LX	(0000) ↔ X (0000)	SIZE (0000) HPOINTS
LY ↔ Y	LY	(0000) ↔ Y (0000)	SIZE (0000) HPOINTS

CHANGE MODULE WITH SHIF F2 F3 F4 KEYS

END SET END CLOSE


### REMARK

To switch from the window for setting 2 back to the window for setting 1, press the [F5] key again.

## Network/Link Settings

### Network refresh parameter settings (PC-to-PC network)

MELSEC-A



NETWORK REFRESH PARAMETER

OTHER MODULES

LB ↔ B TRANSFER 1:

1 2 3

4

SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 16)

[PAGE 2] NETWORK MODULE 1

MELSECNET/10(CTRL STN)	I/O NO.	00	NETWORK NO.1
LB ↔ B	LB	(1000) ↔ B	0800 SIZE(0800)HPOINTS
LW ↔ W	LW	(1000) ↔ W	0800 SIZE(0800)HPOINTS
LX ↔ X	LX	(0000) ↔ X	0000 SIZE(0000)HPOINTS
LY ↔ Y	LY	(0000) ↔ Y	0000 SIZE(0000)HPOINTS

CHANGE MODULE WITH SW/F1, F2, F3, F4 KEYS END SET END CLOSE

End

5 Complete setting by pressing the [END] key.

## ADVICE

### • Changing module numbers

Setting of the network refresh parameters of other network modules can be enabled by pressing one of keys [F1] to [F4] while holding down the [Shift] key.

[Shift] + [F1]: Module No.1


[Shift] + [F2]: Module No.2

[Shift] + [F3]: Module No.3

[Shift] + [F4]: Module No.4

### • Default values for SB/SW transfer devices

The ranges shown below (256 points each) are allocated to the modules as the default point ranges for the SB/SW transfer devices in the network refresh parameters.



## POINT

### • Setting 1 and setting 2

Network module link devices can be transferred to CPU module link devices in two separate areas. The first transfer area is called "setting 1" and the second transfer area is called "setting 2".

### • Clearing all network refresh parameter settings

All the set network refresh parameter settings (including those for other modules) can be cleared by pressing the [F10] (clear) key in the network refresh parameter window.

# Network/Link Settings

## Network refresh parameter settings (Remote I/O network)


PC  
models

AnUCPU only

**MELSEC-A**

### 7.5.2.(2) Establishing correspondence with MELSECNET/10 (remote I/O network) link devices

#### OPERATION EXAMPLE



The operation for setting the following network refresh parameter settings is presented below:

LB head = 0, B head = 0, LB ↔ B transfer size = 800H points  
 LW head = 0, W head = 0, LW ↔ W transfer size = 800H points  
 SB head = 0, SB transfer destination = M4000,  
 SB transfer size = 100H points  
 SW head = 0, SW transfer destination = D4000,  
 SW transfer size = 100H points

0 → 0 → 8 → 0 → 0 → Enter  
 Set LB ↔ B transfer (setting 1)


0 → 0 → 8 → 0 → 0 → Enter  
 Set LW ↔ W transfer (setting 1)

↓ ↓ 0 → M → 4 → 0 → 0 → 0 → 1 → 0 → 0 → Enter  
 Set the SB transfer devices

0 → D → 4 → 0 → 0 → 0 → 0 → 1 → 0 → 0 → Enter → End  
 Set the SW transfer devices

The setting is completed.

#### EXPLANATION




- 1 In the network parameter window, locate the cursor at the network refresh parameter field for a network module at a MELSECNET/10 remote master station, and press the [Enter] key: the network refresh parameter window opens.

## Network/Link Settings

### Network refresh parameter settings (Remote I/O network)

MELSEC-A



2 Set the head number and transfer range for each device.

NETWORK REFRESH PARAMETER			
OTHER MODULES		LB ↔ B TRANS	
LB ↔ B TRANSFER 1:	2:	SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 16).	
1	2		
3	4		
[PAGE 1] NETWORK MODULE 1			
MELSECNET7/10(RMT MAST)	I/O NO.	00	NETWORK NO.1
LB ↔ B	LB	{1000} ↔ B {0000}	SIZE {0000} HPOINTS
LW ↔ W	LW	{1000} ↔ W {0000}	SIZE {0000} HPOINTS
LX ↔ X	LX	{0000} ↔ X {0000}	SIZE {0000} HPOINTS
LY ↔ Y	LY	{0000} ↔ Y {0000}	SIZE {0000} HPOINTS
SB COPIED TO	SB	{000} → DEST. {0} {4000}	SIZE {100} HPOINTS
SW COPIED TO	SW	{000} → DEST. {0} {4000}	SIZE {100} HPOINTS
ERROR HISTORY	RETAIN		
CHANGE MODULE WITH SHIF F1 F2 F3 F4 KEYS End SET Esc CLOSE			

End

3 Complete setting by pressing the [END] key.

#### ADVICE

##### ◦ Changing module numbers

Setting of the network refresh parameters of other network modules can be enabled by pressing one of keys [F1] to [F4] while holding down the [Shift] key.


- [Shift] + [F1] : Module No.1
- [Shift] + [F2] : Module No.2
- [Shift] + [F3] : Module No.3
- [Shift] + [F4] : Module No.4

##### ◦ Clearing all network refresh parameter settings

All the set network refresh parameter settings (including those for other modules) can be cleared by pressing the [F10] (clear) key in the network refresh parameter window.

## 7.5.2.(3) Establishing the correspondence with MELSECNET II link devices

### OPERATION EXAMPLE



The screenshot shows the 'NETWORK REFRESH PARAMETER' window. The 'OTHER MODULES' section is active, showing 'TRANSFER 1' with a value of 1. The 'MELSECNET II (MASTER STN.)' table is visible, showing settings for LB, LW, and LX/LY transfers. The 'LB' transfer is set to 'LB' with a size of 800H points.

The operation for setting the following network refresh parameter settings is presented below:

LB head = 0, B head = 0, LB ↔ B transfer size = 800H points  
 LW head = 0, W head = 0, LW ↔ W transfer size = 800H points  
 X/Y head = 1000, LX/LY ↔ X/Y transfer size = 200H points

0 → 0 → 8 → 0 → 0 → Enter

LB ↔ B transfer setting

0 → 0 → 8 → 0 → 0 → Enter


LW ↔ W transfer setting

1 → 0 → 0 → 0 → 2 → 0 → 0 → Enter → End

LX/LY ↔ X/Y transfer setting

The setting is completed.

### EXPLANATION




The screenshot shows the 'NETWORK REFRESH PARAMETER' window. The 'OTHER MODULES' section is active, showing 'TRANSFER 1' with a value of 1. The 'MELSECNET II (MASTER STN.)' table is visible, showing settings for LB, LW, and LX/LY transfers. The 'LB' transfer is set to 'LB' with a size of 1000H points.

- 1 In the network parameter window, locate the cursor at the network refresh parameter field for a link module at a MELSECNET II master station or local station, and press the [Enter] key; the network refresh parameter window opens.

# Network/Link Settings

## Network refresh parameter settings (MELSECNET)

MELSEC-A



2 Set the head No. and transfer range for each device.

NETWORK REFRESH PARAMETERS			
OTHER MODULES		LB ↔ B TRANS	
LB	TRANSFER 1:	SET SOURCE LB NUMBER, DESTINATION B NUMBER (UNITS OF 10).	
1	2:		
	3:		
	4:		
[PAGE 2] NETWORK MODULE 1			
MELSECNET/(MASTER STN.)	I/O NO.	00	NETWORK NO.
LB ↔ B	LB	(1000) ↔ B	0000 SIZE (0800) HPOINTS
LW ↔ W	LW	(1000) ↔ W	0000 SIZE (0800) HPOINTS
LX/LY ↔ X/Y	LX/LY	(0000) ↔ X/Y	1000 SIZE (0200) HPOINTS
CHANGE MODULE WITH [SHIFT] F1, F2, F3, F4 KEYS			
END SET SET CLOSE			

End

3 Complete setting by pressing the [END] key.

### ADVICE

#### ◦ Changing module numbers

Setting of the network refresh parameters of other network modules can be enabled by pressing one of keys [F1] to [F4] while holding down the [Shift] key.

[Shift] + [F1] : Module No.1  
 [Shift] + [F2] : Module No.2  
 [Shift] + [F3] : Module No.3  
 [Shift] + [F4] : Module No.4

#### ◦ Clearing all network refresh parameter settings

All the set network refresh parameter settings (including those for other modules) can be cleared by pressing the [F10] (clear) key in the network refresh parameter window.

## Network/Link Settings

### MELSECNET mode link

#### Parameter settings

[illegible]

# MELSEC-A

### 7.5.3 Setting the communications contents for each station when a MELSECNET II data link system is configured with an AnUCPU

This section describes the procedure for setting the communications contents for the master station (M), local stations (L), and remote I/O stations (R) when a MELSECNET II data link system is configured with an AnUCPU.

When an AnUCPU is used, since network refresh parameters are required even when configuring a MELSECNET system, 2 Kbytes of main program capacity are taken up.  
Consequently, when using an A3U or A4UCPU, the main program capacity is decreased by 1 Ksteps.

### 7.5.3.(1) Link setting method when the MELSECNET mode is selected

This operation sets the contents of communication between the master station (M) and local stations (L)/remote I/O stations (R) in advance when configuring a data link system.

## OPERATION EXAMPLE

LINK SETTINGS (MELSECNET MODE)

MASTER	SLAVE PC STN.	M(1st) → ALL L		LINK WDT * 10ms	M/B1 → ALL L B1	-
		B	W		M/W1 → ALL L W1	-
	1	-	-	100	M/W → ALL R W	0000-0010
				M/W → ALL R W	0020-0030	
				M/W → ALL L R	-	
				M/W → ALL R R	0000-000F	
				M/X → ALL L R	-	
				M/X → ALL R R	0010-010F	

L/R NO.	M → L I/R		M ← L I/R		Size
	Y	X/Y	X	Y/X	
L 111	0000-000F	0000-000F	0010-001F	0010-001F	4096
	-	-	-	-	
	-	-	-	-	
	-	-	-	-	
	-	-	-	-	

ADDRESS PARAMETER LDC → Y(1) 0000-FFFF LYC → X(2) LYC → Y(1) 0000-FFFF LYC → Y(2)	4096
---	------

NET MODULE #
1

Page Up Page Down MODULE CHANGE LINK P.52 P.53 LINK CHECK & SETTING CLOSE

The operation for making the following settings is presented below:

Total number of linked slave stations = 1,

WDT = 1000 msec,

W range for  $M \rightarrow R = W_0$  to 10


W range for  $M \leftarrow R = W20$  to 30

Y range for M  $\rightarrow$  L/R = Y0 to F

X/Y range for M  $\rightarrow$  L/R = Y0 to F

X range for M  $\leftarrow$  L/R = X10 to 1F.

Y/X range for  $M \leftarrow L/R = X10$  to 1F



### EXPLANATION

```
<NETWORK/LINK SET>
1: MELSECNET
2: MELSECNET II (COMPOSIT)
3: MELSECNET II
Esc: CLOSE
```

- 1 When the [End] key is pressed after setting the master station for a MELSECNET II system in the MODULES window, or when the [Enter] key is pressed after moving the cursor to the MELSECNET II entry field for MELSECNET II (MASTER STATION) in the network parameter window, the network/link setting window opens.

# Network/Link Settings MELSECNET mode link parameter settings

**MELSEC-A**


1

LINK SETTING (MELSECNET MODE)				
F9 MASTER	SLAVE PC STN.	M(1st) → ALL L		LINK WDT
		B	W	* 10ms
	1	-	-	200
L/R NO.	M → L/U/R		M ← L/U/R	
	Y	X/Y	X	Y/X
L III	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
REFRESH PARAMETER				
LX ← X(1) 0000-0FFF 4096				
LY ← Y(1) 0000-0FFF 4096				
LY ← Y(2) -				
NET MODULE #				
1				

Page Up Page Down MODULE CHANGE SHIF F2 F1 F4 END CHECK & SET & CLOSE

2

Select the MELSECNET mode.  
The link setting (MELSECNET mode) window opens.



3

Make the link range settings sequentially in the left/right direction, starting from the total number of linked slave stations.

Use the following keys to move the cursor in the left/right direction within a line, and on completing the settings on one line.

- 1) [←], [→].....Used to move the cursor in the left/right direction within a line.
- 2) [↑], [↓].....Used to move the cursor in the vertical direction (only in the L/R No. column).
- 3) [Enter]..... Pressed on completing the settings on one line. The cursor moves to the left end of the next line. When data input for a local station (L) or remote I/O station (R) is completed on an L/R No. line, the input data is checked.
  - If the data is correct the cursor moves to the left end of the next line.
  - If there is a mistake in the data an error message is displayed and the cursor flashes at the location of the error.
- 4) [F1].....Moves the cursor to the number of linked slave stations field.

F9

LINK SETTING (MELSECNET MODE)				
F9 MASTER	SLAVE PC STN.	M(1st) → ALL L		LINK WDT
		B	W	* 10ms
	1	-	-	100
L/R NO.	M → L/U/R		M ← L/U/R	
	Y	X/Y	X	Y/X
L III	-	-	-	-
-	-	-	-	-
-	-	-	-	-
-	-	-	-	-
REFRESH PARAMETER				
LX ← X(1) 0000-07FF 2048				
LY ← Y(1) 0000-07FF 2048				
LY ← Y(2) -				
NET MODULE #				
1				

Page Up Page Down MODULE CHANGE SHIF F2 F1 F4 END CHECK & SET & CLOSE

4

After completing the B/W settings, press the [F9] key to make the X/Y setting.  
The X/Y side link setting (MELSECNET mode) window will be displayed.


## REMARK

On the X/Y side link setting (MELSECNET mode) window, the total number of linked slave stations, the M → all L device range, and the WDT can be set and changed.  
To change a setting, press the [F1] key.



# Network/Link Settings MELSECNET mode link parameter settings

MELSEC-A



- 5 Make the X, Y link range settings sequentially in the left/right direction, starting from the L/R No. column. The key operation is the same as that for the B/W side link setting (MELSECNET mode) window.

LINK SETTING (MELSECNET MODE)					
MASTER	SLAVE PC STN.	M(1st) → ALL L	LINK WDT	MST ↔ ALL LB1 -	
	B	W	* 10ms	MW1 ↔ ALL LW1 -	
	1	-	100	MW ↔ ALL RW -	
				MY ↔ ALL L -	
				MY ↔ ALL R -	
				MX ↔ ALL L -	
				MX ↔ ALL R -	
L/R NO.	M(1st) ← L	M → R	M ← R	REFRESH PARAMETER	
	B	W	W	LB ↔ B(1) 0000-07FF 2048	
L 1H	0000-000F	0000-000F	0010-001F	LB ↔ B(2) -	
	-	-	-	LW ↔ W(1) 0000-07FF 2048	
	-	-	-	LW ↔ W(2) -	
	-	-	-	NET MODULE #	
	-	-	-	1	

Page Up/Down: MODULE CHANGE SW: F2/F3/F4 END: CHECK/SET/EXEC/CLOSE

End

- 6 After completing data setting for all stations, press the [End] key. "CHECKING" will be displayed and all the set data will be checked. If all the data is correct, the message "CHECK COMPLETED" will be displayed.

LINK SETTING (MELSECNET MODE)					
MASTER	SLAVE PC STN.	M(1st) → ALL L	LINK WDT	MST ↔ ALL LB1 -	
	B	W	* 10ms	MW1 ↔ ALL LW1 -	
	1	-	100	MW ↔ ALL RW 0000-0010	
				MW ↔ ALL RW 0020-0030	
				MY ↔ ALL L -	
				MY ↔ ALL R 0000-000F	
				MX ↔ ALL L -	
				MX ↔ ALL R 0010-001F	
L/R NO.	M(1st) ← L	M → R	M ← R	REFRESH PARAMETER	
	B	W	W	LB ↔ B(1) 0000-07FF 2048	
L 1H	0000-000F	0000-000F	0010-001F	LB ↔ B(2) -	
	-	-	-	LW ↔ W(1) 0000-07FF 2048	
	-	-	-	LW ↔ W(2) -	
	-	-	-	NET MODULE #	
	-	-	-	1	

Page Up/Down: MODULE CHANGE SW: F2/F3/F4 END: CHECK/SET/EXEC/CLOSE

End

- 7 Press the [End] key after setting all the data: the data will be registered in the parameter area. If there is a mistake in the data in one of the columns, the erroneous data will be highlighted. Input the correct data and press the [End] key.

### ADVICE

#### ◦ Data input for more than 6 stations

Data can be input for a maximum of 6 stations (slave stations) on one screen. If the total number of link stations exceeds 6, either press the [↓] key or [Page Down] after inputting the data for the 6th station; this will enable data input for the next (7th) and following stations. Use [Page Up] to return to the previous screen.

#### ◦ Details of other error checks during link setting

1) When [Enter] is pressed for L station setting:

- The total of the numbers of bytes set for B and W devices for  $M \leftarrow L$  and Y devices for  $M \leftarrow L$  is higher than 1024 bytes.

2) When [Enter] is pressed for an R station setting:

- The total of the numbers of bytes set for W and Y devices for  $M \rightarrow R$  and W and X devices set for  $M \leftarrow R$  is higher than 512 bytes.

In the case of both 1) and 2):

The I/O numbers for the remote I/O station do not start from 0.

The numbers of points set at the master station and remote I/O stations are not the same.

3) When the [End] key is pressed:

- There is a station for which no L/R attribute has been set.
- The total of the numbers of bytes set for the B, W, and Y devices for  $M \rightarrow$  All L is 1024 bytes or greater.
- The B and W settings for  $M \leftrightarrow$  All L and  $M \leftrightarrow$  All R overlap in the range where W is 0 to 33F and Y is 0 to 7FF.
- When the link settings are made after having set the I/O allocations, allocations are not made for all slots although there are remote I/O stations, or the last value in the I/O numbers of the highest number remote station set in the link settings does not match the last value set in the I/O allocations.

If any of the above errors occur, correct the set data and recheck it.

### REMARK

For W devices, 1 point = 2 bytes. For B, X, and Y devices, 16 points = 2 bytes.

#### ◦ Insertion/deletion of station numbers

Station numbers can be inserted and deleted to reflect changes made to the system, etc. The method for insertion/deletion is presented below:

- 1) Press the [Insert] key while the cursor is in the L/R No. setting column to insert a station number in the line on which the cursor is located; the total number of link stations increases by one.
- 2) Press the [Delete] key while the cursor is in the L/R No. setting column to delete the station number in the line on which the cursor is located; the total number of link stations will decrease by one.  
If the change is made on the second half setting screen, return to the first half setting screen and, after completing the first half data, press the [F8] key to switch back to the second half screen and modify the second half data.
- 3) Always press the [End] key on completing an insert or delete operation. If another mode is selected without having pressed the [End] key the data before the insertion or deletion will remain registered.

#### ◦ Clearing all the registered link setting data

- 1) Press the [F10] (clear) key.
- 2) Select "YES" in the dialog box to clear the data.
- 3) Press [End] on completion of the setting. The internal memory is also cleared.

#### ◦ Settings in each field

The contents of the settings made in each setting field in the link setting window are the same as network/link settings for PC models other than AnUCPU.

For details on the setting contents, see the [REMARK] in Section 7.4.1.

---

**POINT**

---

- **Mode selection in the network link setting window**
  - [1] MELSECNET mode  
Selected for a link system in which an A0J2H, A1S, A1, A2, A2C, A3, or A3H is used as the master station.
  - [2] MELSECNET II composite mode  
Selected for a link system in which the master station is an AnA or AnUCPU and both AnA/AnUCPUs and other CPU models are used as the local stations, or there are remote I/O stations.
  - [3] MELSECNET II mode  
Selected for link systems in which the master station and all local stations are AnAs or AnUCPUs.

# **Network/Link Settings** **MELSECNET II composite mode** **Link parameter settings**

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	X	X	X	X	O	O	O

## **MELSEC-A**

### **7.5.3.(2) Link setting method when the MELSECNET II composite mode is selected**

With MELSECNET II, B and W devices can be set at two locations: use the [F8] key to switch between the first half and second half B and W data and set it.

The other setting operations are the same as for the MELSECNET mode.

#### **Key inputs in the L/R No. setting field**

The following key inputs are valid in the L/R No. setting field (setting is only possible on the first half screen).

- 1) [F5] or [L].....Used to set a local station (L)
- 2) [F6] or [R].....Used to set a remote I/O station (R)
- 3) [F7] or [\*].....Used to set a MELSECNET II local station (L II)

#### **Fate of MELSECNET II first half/second half data when switching between MELSECNET II and MELSECNET**

	First Half Data	Second Half Data
MNET II → MNET	<p>M ← L } BW and X/Y setting data  M → L } can be used without alteration.  If the MNET II settings reach B/W400 or higher, the final value will be 3FF.</p>	<p>Remains until checked by pressing the data End key.  Redisplayed on switching from MNET to MNET II.</p>
MNET II ← MNET	<p>M ← L The BW setting data can be used without alteration.</p>	<p>This data is not set.  Displayed when M → L switching is executed.</p>

#### **REMARK**

- (1) Pressing the [F8] key displays the second half data if the first half data is currently displayed and the first half data if the second half data is currently displayed.  
A check on the following device numbers is executed on input: first half 0 to 3FF, (second/first half final device number + 1) to FFF (or 0 if the first half is 0 points).
- (2) Other setting operations are the same as for the MELSECNET mode.

# Network/Link Settings

## MELSECNET II mode

### Link parameter settings

PC models	A0J	A0H	A1S	A1	A2	A2C	A3	A3H	A2A	A3A	A2U	A3U	A4U
	X	X	X	X	X	X	X	X	X	X	O	O	O

## MELSEC-A

### 7.5.3.(3) Link setting method when the MELSECNET II mode is selected

Since B and W devices are set at two locations, the settings are made by switching between the first and second half B and W areas by using the [F8] key.

Other setting operations are the same as for the MELSECNET mode.

#### REMARK

- (1) Pressing the [F8] key displays the second half data if the first half data is currently displayed and the first half data if the second half data is currently displayed.
- (2) It is automatically determined whether the master station is MELSECNET from the PC model given in the initial settings.

## 7.5.4 Setting the network configuration specifications

This section describes the operations for setting the ranges of LB/LW and LX/LY devices that can be transmitted by each station in a network and the settings relating to transient transmission and communication errors.

### 7.5.4.(1) Setting the configuration specifications for a PC-to-PC network

- (a) Set the total number of link stations, WDT, and the communication range for each station.

#### OPERATION EXAMPLE

COMMON PARAM (MELSECNET/PC NETWORK)

MODULE NO.	1	REFRESH PARAMETER	Size
		LB ←→ S(1) 0000-1FFF	8192
		LB ←→ S(2) -	-
		LW ←→ W(1) 0000-1FFF	8192
		LW ←→ W(2) -	-

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE
2	100		
		1	0000-00FF 0000-00FF
		2	0100-01FF 0100-01FF
		-	-
		-	-
		-	-

Page Up Page Down: MODULE CHANGE Shift F1 F2 F3 F4 End CHECK & SET Exit CLOSE

The operation for making the following settings is presented below:

Total number of link stations = 2, WDT = 1000 msec

LB/LW send range for station No.1 = LB: 0 to FF, LW: 0 to FF

LB/LW send range for station No.2 = LB: 100 to 1FF, LW: 100 to 1FF

Block 1 setting = I/O master station: station No.1

LX/LY send/receive range for station No.2 =

(M→L) LY(1): 0 to 3F, LX(1): 0 to 3F

(M←L) LX(1): 40 to 7F, LY(1): 40 to 7F

Block No.2 setting = none

2 → 1 → 0 → 0 → Enter

Set the total number of link stations. Set the WDT.

0 → F → F → Enter

Set the station No.1 LB send range (LB0 to FF).

0 → F → F → Enter

Set the station No.1 LW send range (LW0 to FF).

1 → 0 → 0 → 1 → F → F → Enter

Set the station No.2 LB send range (LB100 to 1FF).

1 → 0 → 0 → 1 → F → F → F9

Set the station No.2 LW send range (LW100 to 1FF). Switch to X/Y

↓ 1 → Enter 0 → 3 → F → 0 → 3 → F → Enter

Set the I/O master station Set the station No.2 LY send range (LY0 to 3F) Set the station No.1 LX send range (LX0 to 3F)

4 → 0 → 7 → F → 4 → 0 → 7 → F → End End

Set the station No.2 LY send range (LY40 to 7F) Set the station No.2 LX send range (LX40 to 7F) Check Setting is completed.

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A

### EXPLANATION

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1	REFRESH PARAMETER	LB ←→ B(1) 0000-1FFF 8192	Size
			LB ←→ B(2) -	
			LW ←→ W(1) 0000-1FFF 8192	
			LW ←→ W(2) -	

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE	
			LB	LW
200			-	-
			-	-
			-	-
			-	-
			-	-
			-	-

Page Up Page Down MODULE CHANGE SHIF F F2 F4 F6 F8 CHECK & SET E X CLOSE

- When a MELSECNET/10 control station has been set in the number of modules settings, the common parameters (MELSECNET/10) for a PC-to-PC network have to be set. The COMMON PARAM. (MELSECNET/10) PC NETWORK window automatically opens in accordance with the set order of module No. positions after the number of modules settings.

2 → 1 → 0 → 0 → Enter

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1	REFRESH PARAMETER	LB ←→ B(1) 0000-1FFF 8192	Size
			LB ←→ B(2) -	
			LW ←→ W(1) 0000-1FFF 8192	
			LW ←→ W(2) -	

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE	
			LB	LW
2	100	1	-	-
		2	-	-
			-	-
			-	-
			-	-
			-	-

Page Up Page Down MODULE CHANGE SHIF F F2 F4 F6 F8 CHECK & SET E X CLOSE

- Set the total number of link stations and the WDT.

Total number of: set the total number of stations connected in the network.

Optical loop system....1 to 64

Coaxial bus system....1 to 32

WDT : Set the time used to judge whether or not communication between the control station and normal stations is normal in 10 msec units (10 to 4000 msec).

Setting range: 1 to 400

0 → F → F → 0 →

F → F → Enter → 1 → 0 → 0 →

1 → F → F → 1 → 0 → 0 →

→ 1 → F → F

- Set the LB and LW send ranges for each station.

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1	REFRESH PARAMETER	LB ←→ B(1) 0000-1FFF 8192	Size
			LB ←→ B(2) -	
			LW ←→ W(1) 0000-1FFF 8192	
			LW ←→ W(2) -	

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE	
			LB	LW
2	100	1	0000-00FF	0000-00FF
		2	0100-01FF	0100-01FF
			-	-
			-	-
			-	-
			-	-

Page Up Page Down MODULE CHANGE SHIF F F2 F4 F6 F8 CHECK & SET E X CLOSE

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A


F9

COMMON PARAM. (MELSECNET/PC NETWORK)					
MODULE NO.		REFRESH PARAMETER		Size	
1		LX←X(1) 0000-1FFF		8192	
		LY←Y(2) -			
		LY←Y(1) 0000-1FFF		8192	
		LY←Y(2) -			
NO. OF STN.	LINK WDT * 10ms	NORMAL STATION NO.	TRANCE. RANGE (M→L)	TRANCE. RANGE (M←L)	
2	100		LY (1)	LX (1)	LX (1) LY (1)
		1	-	-	-
		2	-	-	-
I/O MASTER					
Page Up Page Down MODULE CHANGE Shift F1 F2 F3 F4 End CHECK * SET * Esc CLOSE					

- 4 Switch to the LX, LY send range window by pressing the [F9] key.

### REMARK

To switch from the LX, LY send range window to the LB, LW send range window, press the [F9] key again.



- 5 Set the LX, LY send ranges for the I/O master station and each station.

### REMARK

In the I/O MASTER field, set the station number of the station that is to be the master station for X/Y communication.

Any station that is an AnUCPU can be set as the I/O master station, regardless of whether it is a control station or a normal station.

COMMON PARAM. (MELSECNET/PC NETWORK)					
MODULE NO.		REFRESH PARAMETER		Size	
1		LX←X(1) 0000-1FFF		8192	
		LY←Y(2) -			
		LY←Y(1) 0000-1FFF		8192	
		LY←Y(2) -			
NO. OF STN.	LINK WDT * 10ms	NORMAL STATION NO.	TRANCE. RANGE (M→L)	TRANCE. RANGE (M←L)	
2	100		LY (1)	LX (1)	LX (1) LY (1)
		MST. 1	-	-	-
		2	0000-003F	0000-003F	0040-007F 0040-007F
I/O MASTER					
1					
Page Up Page Down MODULE CHANGE Shift F1 F2 F3 F4 End CHECK * SET * Esc CLOSE					

End

- 6 After completing the data settings for each station, press the [End] key.

The message "CHECKING" is displayed and all the set data is checked. If all the data is correct the message "CHECK COMPLETED" is displayed.

COMMON PARAM. (MELSECNET/PC NETWORK)					
MODULE NO.		REFRESH PARAMETER		Size	
1		LX←X(1) 0000-1FFF		8192	
		LY←Y(2) -			
		LY←Y(1) 0000-1FFF		8192	
		LY←Y(2) -			
NO. OF STN.	LINK WDT * 10ms	NORMAL STATION NO.	TRANCE. RANGE (M→L)	TRANCE. RANGE (M←L)	
2	100		LY (1)	LX (1)	LX (1) LY (1)
		MST. 1	-	-	-
		2	0000-003F	0000-003F	0040-007F 0040-007F
I/O MASTER					
1					
Page Up Page Down MODULE CHANGE Shift F1 F2 F3 F4 End CHECK * SET * Esc CLOSE					
COMPLETED					

End

- 7 Press the [End] key again to complete setting. Pressing the [Esc] key cancels the setting.



## Network/Link Settings

### Common parameter settings (PC-to-PC network)

MELSEC-A

---

#### ADVICE

---

- **Changing module numbers**

Setting of the common parameters (PC-to-PC network) of other network modules can be enabled by pressing one of keys [F1] to [F4] while holding down the [Shift] key.

[Shift] + [F1] : Module No.1

[Shift] + [F2] : Module No.2

[Shift] + [F3] : Module No.3

[Shift] + [F4] : Module No.4

---

#### POINT

---

- **Block 1 and block 2 when setting LX/LY send ranges**

The LX/LY send range can be set in two separate blocks: block 1 and block 2.

The display can be switched between the block 1 settings and the block 2 settings by pressing the [F3] key.

Set the allocations for the LX/LY send ranges for each station in 16-point units; do not overlap block 1 and block 2.

- **I/O master station setting**

I/O master stations can be set in two places: in block 1 and in block 2.

# Network/Link Settings


## Common parameter settings (PC-to-PC network)

MELSEC-A

### (b) Reserve station setting

This operation is used to set the station number and send range for a station that is to be connected in the future in advance, making it a reserve station, and also to set stations that are actually connected as reserve stations.

### OPERATION EXAMPLE



To set station No.2 as a reserve station:


```

graph LR
    F4[F4] --> Arrow[→]
    Arrow --> Enter[Enter]
    Enter --> End[End]
            
```


Select reserve station setting      Shift cursor to 2nd station      Make the reserve station setting      Completion of setting

### EXPLANATION

- F4**



**1** Press the [F4] key while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed. The reserve station setting window opens.
- Enter**



**2** Move the cursor to the station number to be designated as the reserve station and press the [Enter] key. The station number will be highlighted and the reserve station designation completed. If the cursor is moved to the position of a station number that has already been designated and the [Enter] key pressed, the reserve station designation will be cancelled.
- End**

**3** Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting. (The set data is not registered.)

### POINT

- Reserve station setting when setting the send range for each station

Reserve stations can be also be set/cancelled by pressing the [F2] key when setting the send range for each station.

- Reserve station setting for the I/O master station

It is not possible to set the station set as the I/O master station as a reserve station.

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A

### (c) Expansion setting

This operation sets the settings relating to transient transmission.

### OPERATION EXAMPLE

EXTENDED SET:

CONSTANT LINK SCAN [500]ms (0-500)

MAX. # OF RECONNECTION STN. [1]STATION (1-16)

DUPLEX COMMUNICATION [1] 0:NO 1:YES

End SET Esc:CLOSE

To make the following settings,  
 Constant link scan = 500 msec  
 Maximum number of online return stations per scan = 1  
 Multiplex transmission = ON  
 Follow the procedure below:

```

      graph LR
      A[F5] --> B[5]
      B --> C[0]
      C --> D[0]
      D --> E[Enter]
      E --> F[1]
      F --> G[Enter]
      G --> H[1]
      H --> I[Enter]
      I --> J[End]
      
```

Expansion setting      Set the constant link scan time      Set the number of online return stations per scan

Set multiplex transmission      Completion of setting

### EXPLANATION

- F5**

EXTENDED SET:

CONSTANT LINK SCAN [0]ms (0-500)

MAX. # OF RECONNECTION STN. [2]STATION (1-16)

DUPLEX COMMUNICATION [0] 0:NO 1:YES

End SET Esc:CLOSE

**1** Press the [F5] key while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed. The EXTENDED SET window opens.
- 5 0 0 Enter 1 Enter

1 Enter

EXTENDED SET:

CONSTANT LINK SCAN [500]ms (0-500)

MAX. # OF RECONNECTION STN. [1]STATION (1-16)

DUPLEX COMMUNICATION [1] 0:NO 1:YES

End SET Esc:CLOSE

**2** Set the constant link scan time, the maximum number of online return stations per scan, and the multiplex transmission ON/OFF status.
- End


**3** Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting. (The set data is not registered.)

## Network/Link Settings Common parameter settings (PC-to-PC network)

MELSEC-A

- (d) Communication error setting  
This operation sets whether or not the data link will be operated by a sub-control station if the control station goes down.

### OPERATION EXAMPLE



To set operation of the data link by a sub-control station if the control station goes down:


```
graph LR; F6[F6] --> 0[0]; 0 --> Enter[Enter]; Enter --> End[End];
```

Communication error setting      Set control of the data link by a sub-control station      Completion of setting

### EXPLANATION


F6

- 1 Press the [F6] key while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed. The COMMUNICATION ERROR SET window opens.



0 Enter

- 2 Set YES or NO for operation of the data link by a sub-control station if the control station goes down.



End

- 3 Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting. (The set data is not registered.)

## MELSEC-A

This operation is used to allocate link device points to all stations uniformly when there are a large number of stations.

COMMON PARAM. (MELSECNET/II) PC NETWORK

MODULE NO.	REFRESH PARAMETER	Size
1	LB ← R(1) 0000-1FFF	8192
	LW ← W(1) 0000-1FFF	8192
	LX ← X(1) 0000-1FFF	8192
	LY ← Y(1) 0000-1FFF	8192

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE
4	200		
		1	0000-07FF
		2	0800-0FFF
		3	1000-17FF
		4	1800-1FFF

Page Up Page Down MODULE CHANGE SHIF F7 F8 F9 F10 F11 F12 F13 F14 F15 F16 F17 F18 F19 F20 F21 F22 F23 F24 F25 F26 F27 F28 F29 F30 F31 F32 F33 F34 F35 F36 F37 F38 F39 F40 F41 F42 F43 F44 F45 F46 F47 F48 F49 F50 F51 F52 F53 F54 F55 F56 F57 F58 F59 F60 F61 F62 F63 F64 F65 F66 F67 F68 F69 F70 F71 F72 F73 F74 F75 F76 F77 F78 F79 F80 F81 F82 F83 F84 F85 F86 F87 F88 F89 F90 F91 F92 F93 F94 F95 F96 F97 F98 F99 F100 F101 F102 F103 F104 F105 F106 F107 F108 F109 F110 F111 F112 F113 F114 F115 F116 F117 F118 F119 F120 F121 F122 F123 F124 F125 F126 F127 F128 F129 F130 F131 F132 F133 F134 F135 F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F149 F150 F151 F152 F153 F154 F155 F156 F157 F158 F159 F160 F161 F162 F163 F164 F165 F166 F167 F168 F169 F170 F171 F172 F173 F174 F175 F176 F177 F178 F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191 F192 F193 F194 F195 F196 F197 F198 F199 F200 F201 F202 F203 F204 F205 F206 F207 F208 F209 F210 F211 F212 F213 F214 F215 F216 F217 F218 F219 F220 F221 F222 F223 F224 F225 F226 F227 F228 F229 F230 F231 F232 F233 F234 F235 F236 F237 F238 F239 F240 F241 F242 F243 F244 F245 F246 F247 F248 F249 F250 F251 F252 F253 F254 F255 F256 F257 F258 F259 F260 F261 F262 F263 F264 F265 F266 F267 F268 F269 F270 F271 F272 F273 F274 F275 F276 F277 F278 F279 F280 F281 F282 F283 F284 F285 F286 F287 F288 F289 F290 F291 F292 F293 F294 F295 F296 F297 F298 F299 F300 F301 F302 F303 F304 F305 F306 F307 F308 F309 F310 F311 F312 F313 F314 F315 F316 F317 F318 F319 F320 F321 F322 F323 F324 F325 F326 F327 F328 F329 F330 F331 F332 F333 F334 F335 F336 F337 F338 F339 F340 F341 F342 F343 F344 F345 F346 F347 F348 F349 F350 F351 F352 F353 F354 F355 F356 F357 F358 F359 F360 F361 F362 F363 F364 F365 F366 F367 F368 F369 F370 F371 F372 F373 F374 F375 F376 F377 F378 F379 F380 F381 F382 F383 F384 F385 F386 F387 F388 F389 F390 F391 F392 F393 F394 F395 F396 F397 F398 F399 F400 F401 F402 F403 F404 F405 F406 F407 F408 F409 F410 F411 F412 F413 F414 F415 F416 F417 F418 F419 F420 F421 F422 F423 F424 F425 F426 F427 F428 F429 F430 F431 F432 F433 F434 F435 F436 F437 F438 F439 F440 F441 F442 F443 F444 F445 F446 F447 F448 F449 F450 F451 F452 F453 F454 F455 F456 F457 F458 F459 F460 F461 F462 F463 F464 F465 F466 F467 F468 F469 F470 F471 F472 F473 F474 F475 F476 F477 F478 F479 F480 F481 F482 F483 F484 F485 F486 F487 F488 F489 F490 F491 F492 F493 F494 F495 F496 F497 F498 F499 F500 F501 F502 F503 F504 F505 F506 F507 F508 F509 F510 F511 F512 F513 F514 F515 F516 F517 F518 F519 F520 F521 F522 F523 F524 F525 F526 F527 F528 F529 F530 F531 F532 F533 F534 F535 F536 F537 F538 F539 F540 F541 F542 F543 F544 F545 F546 F547 F548 F549 F550 F551 F552 F553 F554 F555 F556 F557 F558 F559 F560 F561 F562 F563 F564 F565 F566 F567 F568 F569 F570 F571 F572 F573 F574 F575 F576 F577 F578 F579 F580 F581 F582 F583 F584 F585 F586 F587 F588 F589 F590 F591 F592 F593 F594 F595 F596 F597 F598 F599 F600 F601 F602 F603 F604 F605 F606 F607 F608 F609 F610 F611 F612 F613 F614 F615 F616 F617 F618 F619 F620 F621 F622 F623 F624 F625 F626 F627 F628 F629 F630 F631 F632 F633 F634 F635 F636 F637 F638 F639 F640 F641 F642 F643 F644 F645 F646 F647 F648 F649 F650 F651 F652 F653 F654 F655 F656 F657 F658 F659 F660 F661 F662 F663 F664 F665 F666 F667 F668 F669 F670 F671 F672 F673 F674 F675 F676 F677 F678 F679 F680 F681 F682 F683 F684 F685 F686 F687 F688 F689 F690 F691 F692 F693 F694 F695 F696 F697 F698 F699 F700 F701 F702 F703 F704 F705 F706 F707 F708 F709 F710 F711 F712 F713 F714 F715 F716 F717 F718 F719 F720 F721 F722 F723 F724 F725 F726 F727 F728 F729 F730 F731 F732 F733 F734 F735 F736 F737 F738 F739 F740 F741 F742 F743 F744 F745 F746 F747 F748 F749 F750 F751 F752 F753 F754 F755 F756 F757 F758 F759 F760 F761 F762 F763 F764 F765 F766 F767 F768 F769 F770 F771 F772 F773 F774 F775 F776 F777 F778 F779 F780 F781 F782 F783 F784 F785 F786 F787 F788 F789 F790 F791 F792 F793 F794 F795 F796 F797 F798 F799 F800 F801 F802 F803 F804 F805 F806 F807 F808 F809 F810 F811 F812 F813 F814 F815 F816 F817 F818 F819 F820 F821 F822 F823 F824 F825 F826 F827 F828 F829 F830 F831 F832 F833 F834 F835 F836 F837 F838 F839 F840 F841 F842 F843 F844 F845 F846 F847 F848 F849 F850 F851 F852 F853 F854 F855 F856 F857 F858 F859 F860 F861 F862 F863 F864 F865 F866 F867 F868 F869 F870 F871 F872 F873 F874 F875 F876 F877 F878 F879 F880 F881 F882 F883 F884 F885 F886 F887 F888 F889 F890 F891 F892 F893 F894 F895 F896 F897 F898 F899 F900 F901 F902 F903 F904 F905 F906 F907 F908 F909 F910 F911 F912 F913 F914 F9

F7	
AVERAGE ALLOCATION	
NO. OF STATION [ 0 ]	NO. OF STATION [ 0 ]
ALLOC. POINTS [0000]H	ALLOC. POINTS [0000]H
ALLOCATION DEVICE LB[0000]	ALLOCATION DEVICE LW[0000]
NO. OF STATION [ 0 ]	NO. OF STATION [ 0 ]
ALLOC. POINTS [0000]H	ALLOC. POINTS [0000]H
ALLOCATION DEVICE LX[0000]	ALLOCATION DEVICE LY[0000]
END SET END CLOSE	


- REMARK

The [F7] key is only valid while the cursor is located at the LB/LW or LX/LY send range setting field.

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A



- 2 Set the conditions for uniform allocation of each link device.

AVERAGE ALLOCATION			
NO. OF STATION [ 4 ]	NO. OF STATION [ 4 ]		
ALLOC. POINTS [2000]H	ALLOC. POINTS [0800]H		
ALLOCATION DEVICE LB[0000]	ALLOCATION DEVICE LW[0000]		
NO. OF STATION [ 4 ]	NO. OF STATION [ 4 ]		
ALLOC. POINTS [2000]H	ALLOC. POINTS [2000]H		
ALLOCATION DEVICE LX[0000]	ALLOCATION DEVICE LY[0000]		
End SET Esc CANCEL			

End

- 3 Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting.

COMMON PARAM. (MELSECNET/10) PC NETWORK			
MODULE NO.		REFRESH PARAMETER	
1		LB ← 8(1) 0000-1FFF 8192	
		LB ← 8(2) -	
		LW ← W(1) 0000-1FFF 8192	
		LW ← W(2) -	
NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE
4	200		
		1	0000-07FF 0000-01FF
		2	0800-0FFF 0200-03FF
		3	1000-17FF 0400-05FF
		4	1800-1FFF 0600-07FF
		-	-
		-	-
		-	-
Page Up Page Down MODULE CHANGE 35/4/1 F2 F3 F4 F5 CHECK & SET Esc CANCEL			

### POINT

- Specifying the head station number for uniform allocation

In uniform allocation, the station number in the send range setting field where the cursor was located before displaying the AVERAGE ALLOCATION window (by pressing [F7]) is taken as the head station number for uniform allocation.

To make allocations starting from a specific station in the set total number of link stations, move the cursor to the send range setting field for that station before displaying the AVERAGE ALLOCATION window.

- Setting the NO. OF STATION

The NO. OF STATION can be set within the range from the head station number for uniform allocation to the final station number (total number of link stations - (head station No. - 1)).

It is not possible to set a number of stations higher than the maximum value indicated above.

If a number of stations lower than the minimum value indicated above is set, uniform allocation is executed for the set number of stations in order starting from the head station number.

When executing uniform allocation for LX/LY devices, if the I/O master station is set before making the uniform allocation setting, it is not possible to include the station number of the I/O master station in the number of uniform allocation stations.

- Setting units for number of allocated points

Set the number of allocated points in the following units.

LB, LX, LY: 16 point units LW: 1 point units

- Processing of remaining points in uniform allocation

If there are points left over in uniform allocation with the set number of allocation stations and number of allocated points, the remaining points are allocated in 16-point units to LB, LX, and LY, and in 1 point units to LW, in order starting from the head station number.

# Network/Link Settings Common parameter settings (PC-to-PC network)

MELSEC-A

- (f) Allocation by specifying the number of points  
This operation is used to allocate different numbers of points for each station, for example when there are many stations.

## OPERATION EXAMPLE

COMMON PARAM. (MELSECNET/PC NETWORK)		PARAM. NAME
MODULE NO.	1	REFRESH PARAMETER Size
		LB ← B(1) 0000-1FFF 8192
		LW ← B(2) 0000-1FFF 8192
		LX ← W(1) 0000-1FFF 8192
		LY ← W(2) - -
NO. OF STN.	4	LINK WDT * 10ms
	200	
STN. NO.	TRANSMISSION RANGE	
	LB	LW
1	0000-07FF	0000-01FF
2	0800-0FFF	0200-03FF
3	1000-17FF	0400-05FF
4	1800-1FFF	0600-07FF

Page Up Page Down MODULE CHANGE SHIF F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12 CHECK SET ESC CLOSE

COMMON PARAM. (MELSECNET/PC NETWORK)		PARAM. NAME
MODULE NO.	1	REFRESH PARAMETER Size
		LX ← X(1) 0000-1FFF 8192
		LX ← X(2) - -
		LY ← Y(1) 0000-1FFF 8192
		LY ← Y(2) - -
NO. OF STN.	4	LINK WDT * 10ms
	200	
IO MASTER		
NORMAL STATION NO.	TRANSMISSION RANGE (M→L) TRANSMISSION RANGE (M←L)	
	LY (1)	LX (1)
1	0000-10FF	1000-10FF
2	1100-14FF	1100-14FF
3	1500-1CFF	1500-1CFF
4	1600-1FFF	1600-1FFF

Page Up Page Down MODULE CHANGE SHIF F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12 CHECK SET ESC CLOSE

To make the following settings for a network in which the total number of link stations is 4,

Head allocated devices = LB: 0, LW: 0, LX: 1000, LY: 1000

Number of points for station No.1 =

LB : 800H (2048) points, LW : 100H (256) points

LX : 100H (256) points, LY : 100H (256) points

Number of points for station No.2 =

LB : 200H (512) points, LW : 200H (512) points

LX : 0H (0) points, LY : 0H (0) points

Number of points for station No.3 =

LB : 100H (256) points, LW : 100H (256) points


LX : 800H (2048) points, LY : 400H (1024) points

Number of points for station No.4 =

LB : 1000H (4096) points, LW : 200H (512) points

LX : 400H (1024) points, LY : 800H (2048) points

Follow the operation below:



# Network/Link Settings Common parameter settings (PC-to-PC network)

MELSEC-A

## EXPLANATION

F8

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0000	0000	0000	0000
2	0000	0000	0000	0000
3	0000	0000	0000	0000
4	0000	0000	0000	0000

- 1 Press the [F8] key while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed. The POINTS ALLOCATION window opens.

### REMARK

The [F8] key is only valid while the cursor is located at the LB/LW or LX/LY send range setting field.

0 → 0 → 1 0 0 0

- 2 Set the head device number for each link device.

→ 1 0 0 0 Enter

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0000	0000	0000	0000
2	0000	0000	0000	0000
3	0000	0000	0000	0000
4	0000	0000	0000	0000

8 0 0 → 1 0 0 →

- 3 Set the number of link device points used by each station.

1 0 0 → 1 0 0

Enter 2 0 0 → 2 0

0 → 0 → 0 Enter

1 0 0 → 1 0 0 →

8 0 0 → 4 0 0

Enter 1 0 0 0 → 2

0 0 → 4 0 0 → 8

0 0

### REMARK

When setting the number of allocated points, remember that the maximum total number of points for all stations is 8192 (2000H) for each device.

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0800	0100	0100	0100
2	0200	0200	0000	0000
3	0100	0100	0800	0400
4	1000	0200	0400	0800



# Network/Link Settings Common parameter settings (PC-to-PC network)

MELSEC-A

End

DEVICE RANGE FOR EACH STATION WILL  
BE CHANGED. OK?

YES NO

- 4 Complete setting by pressing the [End] key.  
Pressing the [Esc] key cancels the setting. (The set data  
is not registered.)

← Enter

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1	REFRESH PARAMETER	Size
		LB ↔ B(1) 0000-1FFF	8192
		LB ↔ B(2) -	-
		LW ↔ W(1) 0000-1FFF	8192
		LW ↔ W(2) -	-

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE
4	200		
		1	0000-07FF 0000-01FF
		2	0800-0FFF 0200-03FF
		3	1000-17FF 0400-05FF
		4	1800-1FFF 0600-07FF
		-	-
		-	-
		-	-

Page Up Page Down MODULE CHANGE F8 F2 F4 F5 F6 CHECK & SET ESC CLOSE

- 5 Select "YES" by pressing the [←] key and press the  
[Enter] key to execute the allocation by specifying the  
number of points.

## POINT

- Specifying the head station number for allocation by specifying the number of points

In allocation by specifying the number of points, the station number in the send range setting field where the cursor was located before displaying the POINTS ALLOCATION window (by pressing [F8]) is taken as the head station number for allocation by specifying the number of points.

To make allocations starting from a specific station in the set total number of link stations, move the cursor to the send range setting field for that station before displaying the POINTS ALLOCATION window.

- Setting units for number of allocated points

Set the number of allocated points in the following units.

LB, LX, LY: 16 point units LW: 1 point units

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A

- (g) Common parameter all clear  
This operation clears all the common parameter data being set.

### OPERATION EXAMPLE

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.		REFRESH PARAMETER		Size
1		LB	←B(1) 0000-1FFF	8192
		LB	←B(2) -	
		LW	←W(1) 0000-1FFF	8192
		LW	←W(2) -	

NO. OF STN.	LINK WDT * 10ms	STN NO.	TRANSMISSION RANGE	
			LB	LW
	200		-	-
			-	-
			-	-
			-	-
			-	-

Page 1 of 2 Data: MODULE CHANGE DATA F10 F2/F3 F4 E1 CHECK & SET E1 CLOSE

To clear all common parameter settings:

F10

←

Enter

Select "all clear" message.      Select "YES" to execute.

### EXPLANATION

F10

CLEAR ALL COMMON PARAMETERS?

YES      NO

- 1 Press the [F10] key while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed.

← Enter

- 2 Confirm execution of the "all clear" operation.

# Network/Link Settings

## Common parameter settings (PC-to-PC network)

MELSEC-A

### (h) Parameter name setting

This operation sets names for parameters in order to make it easy to specify particular parameters after they have been set. A parameter name, like a file name, has no meaning.

### OPERATION EXAMPLE

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1
NO. OF STN.	4
LINK WDT * 10ms	200

STN NO.	TRANSMISSION RANGE
1	LB 0000-07FF LW 0000-01FF
2	LB 0800-0FFF LW 0200-03FF
3	LB 1000-17FF LW 0400-05FF
4	LB 1800-1FFF LW 0600-07FF

To set the name "NETWORK 1" for common parameters:

Shift + F5 → N → E → T → W → O → R → K

Select "PARAMETER NAME". Set the parameter name.

1 → End

Completion of setting

### EXPLANATION

Shift + F5

- 1 Press [Shift] + [F5] while the COMMON PARAM. (MELSECNET/10) PC NETWORK window is displayed.

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1
NO. OF STN.	4
LINK WDT * 10ms	200

STN NO.	TRANSMISSION RANGE
1	LB 0000-07FF LW 0000-01FF
2	LB 0800-0FFF LW 0200-03FF
3	LB 1000-17FF LW 0400-05FF
4	LB 1800-1FFF LW 0600-07FF

PARAMETER NAME

PARAMETER NAME

End SET Esc CLOSE

N E T W O R K 1

- 2 Set the parameter name. The parameter name can be specified as up to eight 1-byte alphanumeric characters. 2-byte characters cannot be used.

COMMON PARAM. (MELSECNET/10) PC NETWORK

MODULE NO.	1
NO. OF STN.	4
LINK WDT * 10ms	200

STN NO.	TRANSMISSION RANGE
1	LB 0000-07FF LW 0000-01FF
2	LB 0800-0FFF LW 0200-03FF
3	LB 1000-17FF LW 0400-05FF
4	LB 1800-1FFF LW 0600-07FF

PARAMETER NAME

PARAMETER NAME NETWORK1

End SET Esc CLOSE

End

- 3 Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting.

**MELSEC-A**

(a) Set the total number of link stations, WDT, and send range for each station.


COMMON PARAM		(MELSECTNET) REMOTE I/O	PARAM NAME
<b>MODULE NO.</b>		<b>REFRESH PARAMETER</b>	<b>Size</b>
1		L <sub>B</sub> ↔ S(1)	-
		L <sub>B</sub> ↔ S(2)	-
		L <sub>W</sub> ↔ W(1)	-
		L <sub>W</sub> ↔ W(2)	-

<b>NO. OF STN.</b>	<b>LINK WD T +10ms</b>	<b>REMOTE I/O STN. NO.</b>	M→R	M←R	M→R	M←R
			L B	L B	L W	L W
1	100	1	0000-000F	0010-001F	0000-000F	0010-001F
		-	-	-	-	-
		-	-	-	-	-
		-	-	-	-	-
		-	-	-	-	-
		-	-	-	-	-

Page Up Page Down MODULE CHANGE SHIF F PPRY Fctd CHECK SET RES CLOSE

Follow the procedure below:



**MELSEC-A**

- 1 When a MELSECNET/10 remote master station has been set in the number of modules settings, the common parameters (MELSECNET/10) for a remote I/O network have to be set.  
The COMMON PARAM. (MELSECNET/10) REMOTE I/O window automatically opens in accordance with the set order of module No. positions after number of modules setting.

**MELSEC-A**

If not changing the set values, press the [Enter] key; the cursor will move to the send range setting field.

**5** Set the LX, LY send ranges for each station.

6 After completing the data settings for each station, press the [End] key.  
The message "CHECKING" is displayed and all the set data is checked. If all the data is correct the message "CHECK COMPLETED" is displayed.

**7** Press the [End] key again to complete setting. Pressing the [Esc] key cancels the setting.

---

**ADVICE**

---

◦ **Changing module numbers**

Setting of the common parameters (remote I/O) of other network modules can be enabled by pressing one of keys [F1] to [F4] while holding down the [Shift] key.

[Shift] + [F1] : Module No.1

[Shift] + [F2] : Module No.2


[Shift] + [F3] : Module No.3

[Shift] + [F4] : Module No.4

### (b) Reserve station setting

This operation is used to set the station number and send range for a station that is to be connected in the future in advance, making it a reserve station, and also to set stations that are actually connected as reserve stations.

### OPERATION EXAMPLE



To set station No.2 as a reserve station:


```

graph LR
    F4[F4] --> Arrow[→]
    Arrow --> Enter[Enter]
    Enter --> End[End]
            
```


Select reserve station setting.      Shift cursor to 2nd station      Make the reserve station setting.      Completion of setting

### EXPLANATION

- F4**



**1** Press the [F4] key while the COMMON PARAM. (MELSECNET/10) REMOTE I/O window is displayed. The RESERVE STATION window opens.
- Enter**



**2** Move the cursor to the station number to be designated for the reserve station and press the [Enter] key. The station number will be highlighted and the reserve station designation completed. If the cursor is moved to the position of a station number that has already been designated and the [Enter] key pressed, the reserve station designation will be cancelled.
- End**

**3** Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting. (The set data is not registered.)

### ADVICE

#### ◦ Reserve station setting when setting the send range for each station

Reserve stations can be also be set/cancelled by pressing the [F2] key when setting the send range for each station.

Move the cursor to the send range setting field for the station number of the reserve station that is to be set/cancelled and press the [F2] key.



# Network/Link Settings

## Common parameter settings (Remote I/O network)

MELSEC-A

### (c) Expansion setting

This operation sets the settings relating to transient transmission.

### OPERATION EXAMPLE

EXTENDED SET:

CONSTANT LINK SCAN	[500]ms (0-500)
MAX. # OF RECONNECTION STN.	[1] STATION (1-16)
DUPLEX COMMUNICATION	[1] 0:NO 1:YES
ACCESSED ZNFR/ZNT0	[5] (1-64)

End: SET Esc: CLOSE

To make the following settings:  
 Constant link scan = 500 msec  
 Maximum number of online return stations per scan = 1  
 Multiplex transmission = ON  
 Number of ZNFR/ZNT0 accesses = 5  
 Follow the procedure below:

```

graph LR
    F5[F5] --> S5[5]
    S5 --> S0[0]
    S0 --> S0[0]
    S0 --> E1[Enter]
    E1 --> S1[1]
    S1 --> E2[Enter]
    E2 --> S1[1]
    S1 --> E3[Enter]
    E3 --> S1[1]
    S1 --> E4[Enter]
    E4 --> S5[5]
    S5 --> E5[Enter]
    E5 --> End[End]
        
```

Select EX-  
TENDED SET.

Set the constant link scan time

Set the maximum number of  
online return stations per scan

Set multiplex transmission

Set the number of ZNFR  
/ZNT0 accesses

Completion of  
setting

### EXPLANATION

- F5**

EXTENDED SET:

CONSTANT LINK SCAN	[0]ms (0-500)
MAX. # OF RECONNECTION STN.	[2] STATION (1-16)
DUPLEX COMMUNICATION	[0] 0:NO 1:YES
ACCESSED ZNFR/ZNT0	[64] (1-64)

End: SET Esc: CLOSE

```

graph LR
    S5[5] --> S0[0]
    S0 --> S0[0]
    S0 --> E1[Enter]
    E1 --> S1[1]
    S1 --> E2[Enter]
    E2 --> S1[1]
    S1 --> E3[Enter]
    E3 --> S5[5]
    S5 --> E4[Enter]
    E4 --> S5[5]
    S5 --> E5[Enter]
    E5 --> End[End]
        
```

EXTENDED SET:

CONSTANT LINK SCAN	[500]ms (0-500)
MAX. # OF RECONNECTION STN.	[1] STATION (1-16)
DUPLEX COMMUNICATION	[1] 0:NO 1:YES
ACCESSED ZNFR/ZNT0	[5] (1-64)

End: SET Esc: CLOSE

**1** Press the [F5] key while the COMMON PARAM. (MELSECNET/10) REMOTE I/O window is displayed. The EXTENDED SET window opens.

**2** Set the constant link scan time, the maximum number of online return stations per scan, the multiplex transmission ON/OFF status, and the number of ZNFR/ZNT0 accesses.

**3** Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting. (The set data is not registered.)

# Network/Link Settings Common parameter settings (Remote I/O network)

MELSEC-A

## (d) Uniform allocation

This operation is used to allocate link device points to all stations uniformly when there are a large number of stations.

## OPERATION EXAMPLE

COMMON PARAM. (MELSECNET/10) REMOTE I/O		PARAM. NAME	
MODULE NO. 1		REFRESH PARAMETER Size	
		LB ← X(1)	0000-FFFF 8192
		LB ← X(2)	-
		LW ← W(1)	0000-FFFF 8192
		LW ← W(2)	-
NO. OF STN. 4	LINK WDT 200	REMOTE IO STN. NO.	M→R L B L W M←R M←R
		1	0000-000F 0040-004F 0010-000F 0040-004F
		2	0010-001F 0050-005F 0020-001F 0050-005F
		3	0020-002F 0060-006F 0030-002F 0060-006F
		4	0030-003F 0070-007F 0040-003F 0070-007F
		-	- - - -
		-	- - - -
		-	- - - -
		-	- - - -

COMMON PARAM. (MELSECNET/10) REMOTE I/O		PARAM. NAME	
MODULE NO. 1		REFRESH PARAMETER Size	
		LX ← X(1)	-
		LX ← X(2)	-
		LY ← Y(1)	-
		LY ← Y(2)	-
NO. OF STN. 4	LINK WDT 200	REMOTE IO STN. NO.	STATION M→STATION R STATION M←STATION R
		1	1000-103F 1000-103F 1000-103F 1000-103F
		2	1040-107F 1040-107F 1040-107F 1040-107F
		3	1080-10BF 1080-10BF 1080-10BF 1080-10BF
		4	10C0-10FF 10C0-10FF 10C0-10FF 10C0-10FF
		-	- - - -
		-	- - - -
		-	- - - -
		-	- - - -

To execute uniform allocation under the following conditions,


LB :Number of stations for uniform allocation: 4  
Number of points allocated: 80H (128) points  
Head device in uniform allocation: LB0000

LX :Number of stations for uniform allocation: 4  
Number of points allocated: 100H (256) points  
Head device in uniform allocation: LX1000

LW :Number of stations for uniform allocation: 4  
Number of points allocated: 80H (128) points  
Head device in uniform allocation: LW0000

LY :Number of stations for uniform allocation: 4  
Number of points allocated: 100H (256) points  
Head device in uniform allocation: LY1000

Follow the procedure below:



## EXPLANATION

F7

AVERAGE ALLOCATION			
NO. OF STATION [ 0 ]	NO. OF STATION [ 0 ]	NO. OF STATION [ 0 ]	NO. OF STATION [ 0 ]
ALLOC. POINTS [0000]H	ALLOC. POINTS [0000]H	ALLOC. POINTS [0000]H	ALLOC. POINTS [0000]H
ALLOCATION DEVICE LB[0000]	ALLOCATION DEVICE LW[0000]	ALLOCATION DEVICE LX[0000]	ALLOCATION DEVICE LY[0000]
END SET END CLOSE			

- Press the [F7] key while the common parameter (MELSECNET/10) remote I/O network window is displayed.  
The AVERAGE ALLOCATION window opens.


## REMARK

The [F7] key is only valid while the cursor is located at the LB/LW or LX/LY send range setting field.

# Network/Link Settings

## Common parameter settings (Remote I/O network)

MELSEC-A



- 2 Set the conditions for uniform allocation of each link device.

AVERAGE ALLOCATION			
NO. OF STATION [ 4]	NO. OF STATION [ 4]		
ALLOC. POINTS [0080]H	ALLOC. POINTS [0080]H		
ALLOCATION DEVICE LB[0000]	ALLOCATION DEVICE LW[0000]		
NO. OF STATION [ 4]	NO. OF STATION [ 4]		
ALLOC. POINTS [0100]H	ALLOC. POINTS [0100]H		
ALLOCATION DEVICE LX[1000]	ALLOCATION DEVICE LY[1000]		
END SET ESC CLOSE			

End

- 3 Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting.

COMMON PARAM (MELSECNET10) REMOTE I/O PARAM NAME					
MODULE NO.		REFRESH PARAMETER Size			
1		LB ← S(1) 0000-1FFF 8192			
		LB ← S(2) -			
		LW ← W(1) 0000-1FFF 8192			
		LW ← W(2) -			
NO. OF STN.	LINK WD T * 10ms	REMOTE I/O STN. NO.	M→R LB	M←R LB	M→R LW
4	200	1	0000-000F	0040-004F	0010-000F
		2	0010-001F	0050-005F	0020-001F
		3	0020-002F	0060-006F	0030-002F
		4	0030-003F	0070-007F	0040-003F
		-	-	-	-
		-	-	-	-
		-	-	-	-
		-	-	-	-
PAGE UP/PAGE DOWN: MODULE CHANGE 5500F F2 F3 F4: SET CHECK SET ESC: CLOSE					

### POINT

- Specifying the head station number for uniform allocation

In uniform allocation, the station number in the send range setting field where the cursor was located before displaying the AVERAGE ALLOCATION window (by pressing [F7]) is taken as the head station number for uniform allocation.

To make allocations starting from a specific station in the set total number of link stations, move the cursor to the send range setting field for that station before displaying the AVERAGE ALLOCATION window.

- Setting the number of uniform allocation stations

The number of uniform allocation stations can be set within the range from the head station number for uniform allocation to the final station number (total number of link stations - (head station No. - 1)).

It is not possible to set a number of stations higher than the maximum value indicated above.

If a number of stations lower than the minimum value indicated above is set, uniform allocation is executed for the set number of stations in order starting from the head station number.

When executing uniform allocation for LX/LY devices, if the I/O master station is set before making the uniform allocation setting, it is not possible to include the station number of the I/O master station in the number of uniform allocation stations.

- Setting units for number of allocated points

Set the number of allocated points in the following units.

LB, LX, LY: 16 point units LW: 1 point units

- Processing of remaining points in uniform allocation

If there are points left over in uniform allocation with the set number of allocation stations and number of allocated points, the remaining points are allocated in 16-point units to LB, LX, and LY, and in 1 point units to LW, in order starting from the head station number.

# Network/Link Settings Common parameter settings (Remote I/O network)

MELSEC-A

## (e) Allocation by specifying the number of points

This operation is used to allocate different numbers of points for each station, for example when there are many stations.

### OPERATION EXAMPLE

COMMON PARAM (MELSECNET-10) REMOTE I/O		PARAM NAME	
MODULE NO.		REFRESH PARAMETER	
1		Size	
		LB ←→B(1) 0000-1FFF 8192	
		LB ←→B(2) -	
		LW ←→W(1) 0000-1FFF 8192	
		LW ←→W(2) -	
NO. OF STN.	LINK WDT * 10ms	REMOTE I/O STN. NO.	M→R
4	200		L B
			L B
			L W
			L W
		1	0000-001F 0000-001F 0000-001F 0000-001F
		2	0020-003F 0020-003F 0020-003F 0020-003F
		3	0040-005F 0040-005F 0040-005F 0040-005F
		4	0060-007F 0060-007F 0060-007F 0060-007F
			-
			-
			-
			-

Page Up Page Down MODULE CHANGE SW F1 F2 F3 F4 EX CHECK & SET EXEC CLOSE

COMMON PARAM (MELSECNET-10) REMOTE I/O		PARAM NAME	
MODULE NO.		REFRESH PARAMETER	
1		Size	
		LX ←→X(1) -	
		LX ←→X(2) -	
		LY ←→Y(1) -	
		LY ←→Y(2) -	
NO. OF STN.	LINK WDT * 10ms	REMOTE I/O STN. NO.	STATION M→STATION R
4	200		L Y
			L Y
			L X
			L X
		1	1000-103F 1000-103F 1000-103F 1000-103F
		2	1040-107F 1040-107F 1040-107F 1040-107F
		3	1080-10BF 1080-10BF 1080-10BF 1080-10BF
		4	10C0-10FF 10C0-10FF 10C0-10FF 10C0-10FF
			-
			-
			-
			-

Page Up Page Down MODULE CHANGE SW F1 F2 F3 F4 EX CHECK & SET EXEC CLOSE

To make the following settings for a network in which the total number of link stations is 4,

Head allocated devices = LB: 0, LW: 0, LX: 1000, LY: 1000

Number of points for station No.1 =

LB : 20H (32) points, LW : 20H (32) points

LX : 40H (64) points, LY : 40H (64) points

Number of points for station No.2 =

LB : 20H (32) points, LW : 20H (32) points

LX : 40H (64) points, LY : 40H (64) points

Number of points for station No.3 =

LB : 20H (32) points, LW : 20H (32) points


LX : 40H (64) points, LY : 40H (64) points

Number of points for station No.4 =

LB : 20H (32) points, LW : 20H (32) points

LX : 40H (64) points, LY : 40H (64) points

Follow the operation below:



# Network/Link Settings

## Common parameter settings (Remote I/O network)

MELSEC-A

### EXPLANATION

F8

POINTS ALLOCATION

**F8** DEVICE ALLOCATION

LB [0000] LW[0000] LX[0000] LY[0000]

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0000	0000	0000	0000
2	0000	0000	0000	0000
3	0000	0000	0000	0000
4	0000	0000	0000	0000

End SET EscCLOSE

- 1 Press the [F8] key while the COMMON PARAM. (MELSECNET/10) REMOTE I/O window is displayed. The POINTS ALLOCATION window opens.

### REMARK

The [F8] key is only valid while the cursor is located at the LB/LW or LX/LY send range setting field.

0 → 0 → 1 0 0 0

- 2 Set the head device number for each link device.

→ 1 0 0 0 Enter

POINTS ALLOCATION

**F8** DEVICE ALLOCATION

LB [0000] LW[0000] LX[1000] LY[1000]

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0000	0000	0000	0000
2	0000	0000	0000	0000
3	0000	0000	0000	0000
4	0000	0000	0000	0000

End SET EscCLOSE

2 0 → 2 0 → 4 0

- 3 Set the number of link device points used by each station.

→ 4 0 Enter 2 0 →

2 0 → 4 0 → 4 0

Enter 2 0 → 2 0 →

4 0 → 4 0 Enter 2

0 → 2 0 → 4 0 →

4 0

### REMARK

The maximum total number of allocated points for all stations is 8192 (2000H) for each device.

POINTS ALLOCATION

**F8** DEVICE ALLOCATION

LB [0000] LW[0000] LX[1000] LY[1000]

STN. NO	NO. OF LB	NO. OF LW	NO. OF LX	NO. OF LY
1	0800	0100	0100	0100
2	0200	0200	0000	0000
3	0100	0100	0800	0400
4	1000	0200	0400	0800

End SET EscCLOSE

# Network/Link Settings Common parameter settings (Remote I/O network)

MELSEC-A

End

- 4 Press the [End] key; the screen for checking the device ranges will be displayed.

DEVICE RANGE FOR EACH STATION WILL  
BE CHANGED. OK?

YES      NO

← Enter

- 5 Select "YES" by pressing the [←] key and press the [Enter] key to execute the allocation by specifying the number of points.

COMMON PARAM. (MELSECNET I/O) REMOTE I/O		PARAM. NAME			
MODULE NO.		REFRESH PARAMETER		Size	
1		LB ←→B(1) 0000-1FFF		8192	
		LB ←→B(2) -			
		LW ←→W(1) 0000-1FFF		8192	
		LW ←→W(2) -			
NO. OF STN.	LINK WDT * 10ms	REMOTE I/O STN. NO.	M→R LB	M←R LB	M→R LW
4	200	1	0000-001F	0000-001F	0000-001F
		2	0020-003F	0020-003F	0020-003F
		3	0040-005F	0040-005F	0040-005F
		4	0060-007F	0060-007F	0060-007F
			-	-	-
			-	-	-
			-	-	-
			-	-	-

Page Up Page Down MODULE CHANGE SETTING F2 F3 F4 F5 CHECK SET EXIT CLOSE

## POINT

- Specifying the head station number for allocation by specifying the number of points

In allocation by specifying the number of points, the station number in the send range setting field where the cursor was located before displaying the allocation by specifying the number of points window (by pressing [F8]) is taken as the head station number for allocation by specifying the number of points. To make allocations starting from a specific station in the set total number of link stations, move the cursor to the send range setting field for that station before displaying the allocation by specifying the number of points window.

- Setting units for number of allocated points

Set the number of allocated points in the following units.

LB, LX, LY: 16 point units    LW: 1 point units

- (f) Common parameter all clear
- This operation clears all the common parameter data during setting.

OPERATION EXAMPLE

COMMON PARAM. (MELSECNET/10) REMOTE I/O

PARAM. NAME

MODULE NO.  
1

REFRESH PARAMETER

Size

LB ↔ B(1) 0000-1FFF 8192

LB ↔ B(2) -

LW ↔ W(1) 0000-1FFF 8192

LW ↔ W(2) -

NO. OF STN  
200

LINK WDT \* 10ms

200

REMOTE I/O STN NO.

M→R

M←R

M→R

M←R

L B

L B

L W

L W

Page Up Page Down

MODULE CHANGE SINCE F10 F11 END CHECK & SETTING CLOSE

To clear all common parameter settings:

F10

Select "all clear" message

←

Enter

Select "YES" to execute.

EXPLANATION

- F10
- CLEAR ALL COMMON PARAMETERS?

YES

NO
- 1 Press the [F10] key while the COMMON PARAM. (MELSECNET/10) REMOTE I/O window is displayed.
- ← Enter
- 2 Confirm execution of the "all clear" operation.

## MELSEC-A

**This operation sets names for parameters.**

COMMON PARAM (MELSENET/IN REMOTE I/O)		PARAM NAME
MODULE NO.		
1		

REFRESH PARAMETER		Size
LB ← S(1)	0000-1FFF	8192
LB ← S(2)	-	-
LW ← W(1)	0000-1FFF	8192
LW ← W(2)	-	-

NO. OF STN.	LINK WDT * 10ms	REMOTE I/O STN. NO.	M→L	M←L	M→L	M←L
			LB	LB	LW	LW
4	200	1	0000-000F	0040-004F	0010-000F	0040-004F
		2	0010-001F	0050-005F	0020-001F	0050-005F
		3	0020-002F	0060-006F	0030-002F	0060-006F
		4	0030-003F	0070-007F	0040-003F	0070-007F
		-	-	-	-	-

To set the name "NETWORK 1" for common parameters:

Shift

+

F5

N

E

T

W

O

R

K

Select PARAMETER name.
Set the parameter name.

1

End

Completion of setting

Page Up Page Down MODULE CHANGE STN. TYPE IN F4 END CHECK & SET F5 CLOSE

Shift → F5

N → E → T → W → O → R → K → 1

**End**

- 1 Press [Shift] + [F5] while the COMMON PARAM. (MELSECNET/10) REMOTE I/O window is displayed. The PARAMETER NAME opens.
- 2 Set the parameter name.  
The parameter name can be specified as up to eight 1-byte alphanumeric characters.  
2-byte characters cannot be used.
- 3 Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting.



#### 7.5.5 Station specific parameter setting

These parameters are set to change the locations at which the link devices (LB, LW) allocated to each station using the common parameters are stored in the network modules.

Setting the station specific parameters makes it easy to change the program even when the link devices are extended.

Station specific parameters are not set for remote I/O networks.

#### 7.5.5.(1) Station specific parameter setting

#### OPERATION EXAMPLE

NO	LB SET 1	LB SET 2	COMMON PARAM.
1	0000-01FF	0300-03FF	0000-01FF
2	0100-01FF	-	0200-02FF
3	0200-02FF	-	0300-03FF
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-
8	-	-	-
9	-	-	-
10	-	-	-
11	-	-	-
12	-	-	-
13	-	-	-
14	-	-	-
15	-	-	-

To make the station specific parameter settings to allocate the second half 256 points for LB devices (LB100 to 1FF) as LB300 to 3FF:

0 to 1FF      200 to 2FF      300 to 3FF

LB      Station No.1      Station No.2      Station No.3

0 to FF      100 to 1FF      200 to 2FF      300 to 3FF

LB      Station No.1      Station No.2      Station No.3      Station No.1

0 → F → F →

Set station No.1 LB setting 1.

3 → 0 → 0 → 3 → F → F → Enter

Set station No.1 LB setting 2.

1 → 0 → 0 → 1 → F → F → Enter

Set station No.2 LB setting 1.

2 → 0 → 0 → 2 → F → F → End

Set station No.3 LB setting 1.

Completion of setting

#### EXPLANATION


NO	LB SET 1	LB SET 2	COMMON PARAM.
1	0000-01FF	-	0000-01FF
2	0200-02FF	-	0200-02FF
3	0300-03FF	-	0300-03FF
4	-	-	-
5	-	-	-
6	-	-	-
7	-	-	-
8	-	-	-
9	-	-	-
10	-	-	-
11	-	-	-
12	-	-	-
13	-	-	-
14	-	-	-
15	-	-	-

- Station specific parameters can be set if a MELSEC-NET/10 control station or MELSECNET/10 normal station was set in the number of modules settings. The station specific parameter (MELSECNET/10) window is opened by selecting "YES" in the station specific parameter setting dialog box, which is displayed on completion of the number of modules settings.

[Station specific parameter setting dialog box]

SET STATION SPECIFIC PARAMETER?

YES      NO



STATION NATIVE PARAM. (MELSECNET/10)		PARAM. NAME	
NET MODULE #	NO	LB SET 1	COMMON PARAM.
1	1	0000-00FF	0300-03FF
	2	0100-01FF	0200-02FF
	3	0200-02FF	0300-03FF
	4	-	-
	5	-	-
	6	-	-
	7	-	-
	8	-	-
	9	-	-
	10	-	-
	11	-	-
	12	-	-
	13	-	-
	14	-	-
	15	-	-

REF. PARAM. SETTING Size  
LB ↔ B(1) 0000-1FFF 8192  
LB ↔ B(2) -

Page Up/Page Down: MODULE CHANGE SHIF F2/F3/F4 End CHECK # SET & CLOSE


- End
- 3 Complete setting by pressing the [End] key.  
Pressing the [Esc] key cancels the setting.

ADVICE


- Setting the LW station specific parameters  
Press the [F9] key to set the LW station specific parameters.  
The setting operation is the same as that for the LB devices.

**MELSEC-A**



**Reads the station specific parameters in created files.**



- F1**
- 1** Press the [F1] key while the STATION NATIVE PARAM. (MELSECNET/10) window is displayed.  
The FILE READ window opens.



- 2** Specify the drive, system name and sub-system name.  
The type selection window opens.



Network/Link Settings  
Station specific parameter setting

MELSEC-A

Enter ↓ Enter

TYPE SELECT  
COMMON PARAM  
ST. NATIVE PARAM  
End SET End RESET

End

READ?  
YES NO

← Enter

STATION NATIVE PARAM (MELSECNET10) PARAM NAME

NET MODULE #	NO	LB SET 1	LB SET 2	COMMON PARAM
1	1	0000-00FF	0300-03FF	0000-01FF
	2	0100-01FF	-	0200-02FF
	3	0200-02FF	-	0300-03FF
	4	-	-	-
	5	-	-	-
	6	-	-	-
	7	-	-	-
	8	-	-	-
	9	-	-	-
	10	-	-	-
	11	-	-	-
	12	-	-	-
	13	-	-	-
	14	-	-	-
	15	-	-	-

REF. PARAM. SETTING Size  
LB ↔ B(1) 0000-1FFF 8192  
LB ↔ B(2) -

Page Up Page Down MODULE CHANGE END F1 F2 F3 F4 END CHECK 1 SET END CLOSE

- 3 Specify the type of parameter to be read by using the [↓]/[↑] and [Enter] keys.  
\*\*\* indicates that the relevant parameters exist in the specified file.  
Pressing the [Enter] key changes the "\*\*\*" to "#", which means the parameters are specified for reading.  
Pressing the [Enter] key alternately sets "\*\*\*" and "#".

- 4 Press the [End] key: the reading confirmation dialog box will be displayed.

- 5 Select "YES" to read the parameters.

# Network/Link Settings

## Station specific parameter setting

MELSEC-A

### 7.5.5.(3) Rearranging the station order

Rearranges the order of stations by setting the allocated ranges of stations set in the station specific parameters so that they become the allocated range for other stations.

#### OPERATION EXAMPLE

ORDER

NO	W STN. NO.
1	1
2	3
3	2
4	4

End SET Esc CLOSE

To change the order of station No.2 and station No.3

```

F5 → ↓ → 3 → 1 → 2 → End
Select Move the Set station No.2
ORDER. cursor.
          
```

#### EXPLANATION

- F5**

ORDER

NO	W STN. NO.
1	1
2	2
3	3
4	4

End SET Esc CLOSE

**1** Press the [F5] key while the STATION NATIVE PARAM. (MELSECNET/10) window is displayed. The ORDER window opens.
- ↓ → 3 → ↓ → 2

ORDER

NO	W STN. NO.
1	1
2	3
3	2
4	4

End SET Esc CLOSE

**2** Set a station number for the set number.
- End**

**3** Complete setting by pressing the [End] key. Pressing the [Esc] key cancels the setting.

#### POINT

#### • Restrictions on station order rearrangement


Station order rearrangement is only valid for the LB setting 1/LW setting 1 setting ranges.

### 7.5.6 I/O allocation

Sets the number of occupied slots and remote I/O allocations for each station when configuring a remote I/O network with a MELSECNET/10 network system.

By setting the remote I/O allocations, the number of points occupied by vacant slots can be saved, and the number of I/O points occupied by vacant slots can be reserved for future expansion.

### OPERATION EXAMPLE



REMOTE I/O ALLOCATION

NETWORK

#2 REMOTE MASTER NETWORK # 1

I/O NO. 00 # OF ALL STN. 3

STN. NO.	1	2	3																	
SLOT NO.	0	5	0																	
STN. NO.																				
SLOT NO.																				
STN. NO.																				
SLOT NO.																				

END CHECK & SET ESC CLOSE

To make the following settings when the total number of link stations is 3, +

Station No.1 : Remote I/O allocation not performed.

Station No.2 : Number of occupied slots = 5, +

Slot 1 : Input module (64 points)

Slot 2 : Output module (64 points)

Slot 3 : Vacant (16 points)

Slot 4 : Special function module (32 points)

Slot 5 : Vacant (16 points)

Station No.3 : Remote I/O allocation not performed.

Follow the procedure below:


```

graph LR
    A[0] --> B[5]
    B --> C[0]
    C --> D[End]
    D --- E[Set the number of occupied slots for each station. Complete check setting.]
    
```

```

graph LR
    F[9] --> G[D]
    G --> H[2]
    H --> I[F]
    I --> J[2]
    J --> K[End]
    K --- L[Remote I/O allocation for station No.2 Complete check setting.]
    
```

### EXPLANATION



REMOTE I/O ALLOCATION

NETWORK

#2 REMOTE MASTER NETWORK # 2

I/O NO. 20 # OF ALL STN. 3

STN. NO.	1	2	3																	
SLOT NO.	0	0	0																	
STN. NO.																				
SLOT NO.																				
STN. NO.																				
SLOT NO.																				


END CHECK & SET ESC CLOSE

1 Remote I/O allocation is possible if a MELSECNET/10 remote master station was set in the number of modules settings.

The REMOTE I/O ALLOCATION window is opened by selecting "YES" in the remote I/O allocation setting dialog box, which is displayed on completion of the number of modules settings.

[Remote I/O allocation setting dialog box]

SET REMOTE I/O ALLOCATIONS?

[illegible]

End

REMOTE I/O ALLOCATION									
COMMON PARAMETER LX - LY - NETWORK MODULE NO. 2									
SLOT NO. I/O MODULE	<b>1ST</b>	1	2	3	4				
SLOT NO. I/O MODULE	-	-	-	-	-	-	-	-	-
SLOT NO. I/O MODULE	-	-	-	-	-	-	-	-	-
SLOT NO. I/O MODULE	-	-	-	-	-	-	-	-	-
VACANCY (S)	1: 0PT.	X	6: 16PT.	Y	A: 16PT	S-MODULE	E: 16PT.		
	2: 16PT	(X)	7: 32PT.	(Y)	B: 32PT.	(F)	F: 32PT.		
	3: 32PT		8: 48PT.		C: 48PT.		G: 48PT.		
	4: 48PT.		9: 64PT.		D: 64PT.		H: 64PT.		
	5: 64PT.								


Page Up Page Down End CHECK & SET FOR CLOSE

- 2** Set the number of occupied slots (0 to 512) for each station.  
Set "0" as the number of slots for station numbers for which remote I/O allocation is not performed.

- 3 After setting the number of occupied slots, press the [End] key.  
The REOTE I/O ALLOCATION window opens.  
The set number of occupied slots is displayed allocated to station number.

## REMARK

When LX and LY devices are set using the common parameters, the LX and LY setting ranges are displayed in the upper part of the window.



REMOTE I/O ALLOCATION

COMMON PARAMETER LX - LY - NETWORK MODULE NO 2

		1ST															
SLOT NO.		1	2	3	4												
I/O MODULE		X16	Y54	S16	F32	S16											
SLOT NO.																	
I/O MODULE																	
SLOT NO.																	
I/O MODULE																	
SLOT NO.																	
I/O MODULE																	

VACANCY 1: 0PT X 6: 16PT Y A: 16PT S-MODULE E: 16PT  
(S) 2: 16PT (X) 7: 32PT B: 32PT (F) F: 32PT  
3: 32PT 8: 48PT C: 48PT G: 48PT  
4: 48PT 9: 64PT D: 64PT H: 64PT  
5: 64PT

Page Up/Down Page Down End/CHECK & SET Esc/CLOSE

- 4** Allocate the I/O modules at each slot number for each station.

**End**

- 5** Complete setting by pressing the [End] key.  
If the [Esc] key is pressed the setting will be cancelled and the display will return to the REMOTE I/O ALLOCATION window.

## ADVICE

- **Clearing all remote I/O allocations**

Pressing the [F10] key sets the default values for the remote I/O allocation parameter data. The [F10] key functions differently depending on whether the Station No. setting window is displayed or the I/O module allocation window displayed.

# Network/Link Settings

## Transfer parameters for data link settings

PC models	AnUCPU only
-----------	-------------

**MELSEC-A**

### 7.5.7 Setting the parameters for data transfer between network modules

This operation sets the parameters for the transfer of the link devices (LB, LW) stored in one network module to another network module.  
Transfer parameters for data link are not set for remote I/O networks.

#### OPERATION EXAMPLE

To make the following settings for a station at which two network modules are installed,  
Transfer of LB 0 to F of the first network module to LB F0 to FF of the second network module.  
Transfer of LB 100 to 10F of the second network module to LB 2F0 to 2FF of the first network module,  
follow the procedure below:

```

graph TD
    F1[F1] --> B[B]
    B --> 0[0]
    0 --> F[F]
    F --> F2[F2]
    F2 --> F1
    F1 --> F0[F 0]
    F0 --> Enter1[Enter]
    Enter1 --> F2
    F2 --> 2[2]
    2 --> F0
    F0 --> F1
    F1 --> B100[B 1 0 0]
    B100 --> 1[1]
    1 --> 0
    0 --> F10F[F 1 0 F]
    F10F --> Enter2[Enter]
    Enter2 --> End[End]
    
```

Select the transfer source.      Make the setting for the transfer source (LB 0 to F).      Move the cursor to the 2nd module.      Select the transfer destination.

Make the setting for the transfer destination (LB F0 to FF).      Select the transfer destination.      Set the head device for the transfer destination (L[ ]2F0 to).      Select the transfer source.

Make the setting for the transfer source (LB 100 to 10F).

End  
Completion of setting

#### EXPLANATION

- Setting the transfer parameters for data link is possible if more than one network module (with the exception of a MELSECNET/10 remote master station) was set in the number of modules settings.  
The TRANSFER PARAMETER window is opened by selecting "YES" in the transfer parameters for data link setting dialog box, which is displayed on completion of the number of modules settings.

[Transfer parameters for data link setting dialog box]

SET TRANSFER PARAMETERS?

YES
NO



# Network/Link Settings

## Transfer parameters for data link settings

MELSEC-A

[F1] [B] [0] → [F] → [F2] [F] [2] Set the transfer ranges.

[0] [Enter] [F2] [2] [F] [0] →

[F1] [B] [1] [0] [0] → [1] [0]

[F] [Enter]

TRANSFER PARAMETER				
NO	1 NET/10 (00)	2 NET/10 (20)	3	4
1	LB0000- 000F→	→LB0000- 000F	-	-
2	LB02F0- 02FF←	←LB0100- 010F	-	-
3	-	-	-	-
4	-	-	-	-
5	-	-	-	-
6	-	-	-	-
7	-	-	-	-
8	-	-	-	-
9	-	-	-	-
10	-	-	-	-
11	-	-	-	-
12	-	-	-	-

END SETTING CLOSE

[End]

[3] Complete setting by pressing the [End] key.  
Pressing the [Esc] key cancels the setting.

### ADVICE

#### ◦ Clearing set values in each setting field

The set data at the cursor position can be cleared by pressing the [Delete] key.

The line of set data at the cursor position can be cleared by pressing the [F9] (line delete) key.

All the set transfer parameters for data link data can be cleared by pressing the [F10] (clear) key.

#### ◦ About transfer size

Make the setting so that the total transfer size for LB/LW does not exceed 8 K points.

With MELSECNET II, set so that neither the transfer size nor device numbers exceed 2 K points.

# Network/Link Settings Selection of network parameters

PC  
models

AnUCPU only

MELSEC-A

## 7.5.8 Correcting set network parameters

Displays the setting window for the relevant parameter to allow checking or correction of set data link parameters.

### OPERATION EXAMPLE

**NETWORK PARAMETER**

NET MODULE SETTING 4 0 MUST BE SET IF WHEN NECESSARY ● ALREADY SET ▲ ALREADY SET

NETWORK PARAMETER CAPACITY 6 KB	1 MODULE NET/10(C)	2 MODULE NET/10(N)	3 MODULE NET/10(R)	4 MODULE NET/10(M)
NETWORK REFRESH PARAMETER	●	●	●	●
MELSECNET II	X	X	X	0
COMMON/REMOTE I/O PARAM	●	X	●	X
STATION NATIVE PARAMETER	▲	▲	X	X
I/O ALLOCATION	X	X	▲	X
TRANSFER PARAMETER	▲	▲	X	▲

END CHECK/SET & CLOSE

To display the station specific parameter setting window for the second MELECNET/10 module (normal station):

### EXPLANATION

**NETWORK PARAMETER**

NET MODULE SETTING 4 0 MUST BE SET IF WHEN NECESSARY ● ALREADY SET ▲ ALREADY SET

NETWORK PARAMETER CAPACITY 6 KB	1 MODULE NET/10(C)	2 MODULE NET/10(N)	3 MODULE NET/10(R)	4 MODULE NET/10(M)
NETWORK REFRESH PARAMETER	●	●	●	●
MELSECNET II	X	X	X	0
COMMON/REMOTE I/O PARAM	●	X	●	X
STATION NATIVE PARAMETER	▲	▲	X	X
I/O ALLOCATION	X	X	▲	X
TRANSFER PARAMETER	▲	▲	X	▲

END CHECK/SET & CLOSE

**1** Select "1: DATA LINK PARAM." from the network/link setting window.  
The network parameter window opens.


**REMARK**

If the number of modules settings have not been set yet, the MODULES window will open instead of the network parameter window. In this case set the number of modules settings by referring to Section 7.5.1.

# Network/Link Settings

## Selection of network parameters

MELSEC-A



STATION NAME PARAM MELSECNET/10		PARAM NAME	
NET MODULE #	2	NO	LB SET 1 LB SET 2 COMMON PARAM
REF PARAM SETTING Size		1	0000-00FF - 0000-00FF
LB ↔ B(1) 0000-1FFF 8192		2	0100-02FF - 0100-02FF
LB ↔ B(2) -		3	0300-03FF - 0300-03FF
		4	0380-03FF - 0380-03FF
		5	0400-04FF - 0400-04FF
		6	0500-05FF - 0500-05FF
		7	- - -
		8	- - -
		9	- - -
		10	- - -
		11	- - -
		12	- - -
		13	- - -
		14	- - -
		15	- - -

Page Up Page Down MODULE CHANGE B(1) F2 F3 F4 END CHECK & SET END CLOSE

- 2 Move the cursor to the module/parameter type field where the setting is to be made and press the [Enter] key.

The setting window for the relevant parameter type will open.

The setting operation for each parameter is the same as the operation used for new settings.

Set the parameters by referring to Sections 7.5.2 to 7.5.7.

Parameter Type		Reference Section
Network refresh parameters	MELSECNET/10 (control station/normal station)	7.5.2(1)
	MELSECNET/10 (remote I/O station)	7.5.2 (2)
	MELSECNET II (master station/local station)	7.5.2 (3)
MELSECNET II		7.5.3
Common/remote I/O parameters	MELSECNET/10 (control station)	7.5.4(1)
	MELSECNET/10 (remote master station)	7.5.4(2)
Station specific parameters		7.5.5
I/O allocations		7.5.6
Transfer parameters for data link		7.5.7

### REMARK

- Setting fields marked "X" cannot be set.
- After correcting data in any parameter setting window, press the [End] key to overwrite the data.

### ADVICE

#### • Setting the number of modules settings

The MODULES window is opened by pressing the [F1] (module) key while the network parameter window is displayed.

For details of operations, refer to Section 7.5.1.

#### • Clearing individual network parameter settings

The network parameter at the cursor position can be deleted by pressing the [Delete] key while the network parameter window is displayed.

However, since the module type has been set, the network refresh parameters cannot be cleared.

#### • Clearing all data link parameters

All the set network parameters can be cleared by pressing the [F10] (clear) key while the network parameter window is displayed.

However, the data is retained immediately after the clear operation is executed and the original data can be displayed by pressing the [Esc] key and redisplaying the data link parameter window.

To irrevocably delete the data, press the [End] key after executing the clear operation.

If, after executing a clear operation, the [F1] key is pressed and number of modules setting carried out, the original data will be deleted.

### 7.5.9 Routing parameter setting

Sets the transmission route between the request source and request destination in order to carry out transient transmission between stations in different networks.

#### OPERATION EXAMPLE

To set the routing parameters for station No.3 of network No.1 that are required to execute transient transmission from station No.1 to station No.2 of network No.3 in the network system shown below:

Transfer destination network No. = 3  
Relay destination network No. = 1  
Relay destination station No. = 2

#### EXPLANATION

- 3**

**1** Select "3. NETWORK/LINK" from the parameter menu window.  
The network/link setting window opens.
- 2**

**2** Select routing parameters.  
The routing parameter window opens.

## Network/Link Settings Routing parameter settings

MELSEC-A

3 → 1 → 2 → Enter

ROUTING PARAMETER			
NO	DEST. N/W NO	RELAY N/W NO.	RELAY STN. NO.
1	3	1	2
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			

Page Up/Page Down      End SET Esc: CLOSE

3 Set the transfer destination network No., the relay destination network No., and the relay destination station No.

End

4 Press the [End] key again to complete setting. Pressing the [Esc] key cancels the setting.

### ADVICE

#### ◦ Clearing the set values in each setting field

[Delete]: The set data at the cursor position can be cleared by pressing the [Delete] key.

[F9]: The line of set data at the cursor position can be cleared by pressing the [F9] (line delete) key.

[F10]: All the routing parameter set data can be cleared by pressing the [F10] (clear) key.