

MITSUBISHI





Mitsubishi Industrial Robot

RH-6FH-Q/12FH-Q/20FH-Q Series

**Special Specifications Manual
(CR750-Q Controller)**

Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

-  **CAUTION** All teaching work must be carried out by an operator who has received special training. (This also applies to maintenance work with the power source turned ON.)
Enforcement of safety training
-  **CAUTION** For teaching work, prepare a work plan related to the methods and procedures of operating the robot, and to the measures to be taken when an error occurs or when restarting. Carry out work following this plan. (This also applies to maintenance work with the power source turned ON.)
Preparation of work plan
-  **WARNING** Prepare a device that allows operation to be stopped immediately during teaching work. (This also applies to maintenance work with the power source turned ON.)
Setting of emergency stop switch
-  **CAUTION** During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc. (This also applies to maintenance work with the power source turned ON.)
Indication of teaching work in progress
-  **WARNING** Provide a fence or enclosure during operation to prevent contact of the operator and robot.
Installation of safety fence
-  **CAUTION** Establish a set signaling method to the related operators for starting work, and follow this method.
Signaling of operation start
-  **CAUTION** As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc.
Indication of maintenance work in progress
-  **CAUTION** Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors.
Inspection before starting work

The points of the precautions given in the separate "Safety Manual" are given below. Refer to the actual "Safety Manual" for details.

-  **CAUTION** Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.)
-  **CAUTION** Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.
-  **CAUTION** Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration.
-  **CAUTION** Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.
-  **CAUTION** Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage.
-  **CAUTION** Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque. Exceeding these values could lead to alarms or faults.
-  **WARNING** Securely install the hand and tool, and securely grasp the workpiece. Failure to observe this could lead to personal injuries or damage if the object comes off or flies off during operation.
-  **WARNING** Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.
-  **CAUTION** Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.
-  **WARNING** When carrying out teaching work in the robot's movement range, always secure the priority right for the robot control. Failure to observe this could lead to personal injuries or damage if the robot is started with external commands.
-  **CAUTION** Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.
-  **CAUTION** After editing the program, always confirm the operation with step operation before starting automatic operation. Failure to do so could lead to interference with peripheral devices because of programming mistakes, etc.
-  **CAUTION** Make sure that if the safety fence entrance door is opened during automatic operation, the door is locked or that the robot will automatically stop. Failure to do so could lead to personal injuries.
-  **CAUTION** Never carry out modifications based on personal judgments, or use non-designated maintenance parts. Failure to observe this could lead to faults or failures.
-  **WARNING** When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.

 CAUTION

Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. Moreover, it may interfere with the peripheral device by drop or move by inertia of the arm.

 CAUTION

Do not turn off the main power to the robot controller while rewriting the internal information of the robot controller such as the program or parameters. If the main power to the robot controller is turned off while in automatic operation or rewriting the program or parameters, the internal information of the robot controller may be damaged.

⚠ CAUTION


Be careful of interference with peripheral equipment.

Especially don't give a shock to the shaft (J3 axis). When you install the hand, be careful not to knock at the shaft end by the hammer etc. The shaft may be damaged.

Take care also of the following items.

- (1) The robot's locus of movement may change with specified speed.

Especially as for the corner section, short cut distance may change. Therefore, when beginning automatic operation, moves at low speed at first, and you should gather speed slowly with being careful of interference with peripheral equipment.



Arch movement (example)

- (2) It can be confirmed whether the specified position exist in the defined area by using the instruction command "Zone". It can utilize as one of the methods for collision evasion. Refer to the "detailed description of the instructions manual/function, and operation" of the separate volume for the details of the instruction command.

■Revision history

| Date of print | Specifications No. | Details of revisions |
|---------------|--------------------|--|
| 2012-06-05 | BFP-A8882 | <ul style="list-style-type: none"> · First print. |
| 2012-06-11 | BFP-A8882-A | <ul style="list-style-type: none"> · The specification (the suction flow rate, the vacuum generator quantity) of inside suction for clean type of RH-12FH/20FH was changed. · The note about the load center-of-gravity position of RH-20FH was added, and the related graph of the offset length and the maximum-speed was corrected. |
| 2012-06-14 | BFP-A8882-B | <ul style="list-style-type: none"> · The specification and dimension of duct was added. · The upper limit of load center-of-gravity position was added. · The quantity of the coupling for the internal suction of RH-12FH / 20FH clean specification was changed. |
| 2012-06-21 | BFP-A8882-C | <ul style="list-style-type: none"> · The graph of "Relationship Between Height of Shaft (J3 Axis) and Acceleration/Deceleration Speed" was corrected. (error in writing) · EC-Statement of Compliance was replaced. (RH-3FH-Q and RH-6FH-Q were added) |
| 2012-07-19 | BFP-A8882-D | <ul style="list-style-type: none"> · The input voltage range (1-phase: AC207 to 253V) was added to RH-12FH/20FH series. · The error in writing of the connector name and the example of the connection in "3.8.1 Wiring of the Additional Axis Interface" was corrected. ("ExtOPT" was mistake) |
| 2012-07-31 | BFP-A8882-E | <ul style="list-style-type: none"> · The connector name of hand input signal/output signal of "Fig.2-48: Wiring and piping for hand" was corrected. · The outside dimension (moving position of the 340mm stroke type) of RH-6FH series clean/oil mist specification were corrected. |
| 2012-09-03 | BFP-A8882-F | <ul style="list-style-type: none"> · The power supply capacity of RH-6FH/12FH/20FH was corrected. · The attachments of optional Internal Wiring/Piping set for hand were corrected. |
| 2012-10-09 | BFP-A8882-G | <ul style="list-style-type: none"> · The notes were added to "Fig 3-17: Example of EMC noise filter installation". · The lithium battery (ER6) was added to The United Nations' Recommendations on the Transport of Dangerous Goods. · The notes about installation of the controller and the robot arm were added. (neither direct rays nor the heat of lighting) |
| 2012-10-18 | BFP-A8882-H | <ul style="list-style-type: none"> · The user's guide of KC mark was added. |
| 2012-11-20 | BFP-A8882-J | <ul style="list-style-type: none"> · The statement about trademark registration was added. · The center distance of Pilot hole of Installation surface was added. (RH-6FH) · The die center distance of Pilot hole of Installation surface was added and changed. (RH-12FH/20FH) · The notes about the input-output connected to the controller were added. (do not ground the + side of 24V power supply prepared by customer) · "Declaration of Incorporation" was updated. · The metal plate which fixes "Hand internal wiring and piping set (option)" was changed to attachment of the robot arm in standard. |
| 2012-12-05 | BFP-A8882-K | <ul style="list-style-type: none"> · The terminal name to connect when using the three phase specification by the single phase power supply was added. · EC-Statement of Compliance was updated. |
| 2013-01-11 | BFP-A8882-M | <ul style="list-style-type: none"> · Note of the external emergency stop were added (opens the connector terminal at factory shipping). · The specification description of CR750-MB was added. |
| 2013-03-19 | BFP-A8882-N | <ul style="list-style-type: none"> · The metal plate which fixes CR750 controller vertically was changed. (upward compatibility) · "Table 3-2: Robot CPU unit standard specification" was added. · The mass of the controller was shown which was divided by each robot type. |
| | | |

■ Introduction

This series offers small-size industrial robots developed using Mitsubishi's latest technology. They are especially designed to handle and assemble mechanical parts. They are Mitsubishi's answer to the customer's need to achieve a compact manufacturing facility capable of highly flexible production, as necessitated by the diffusion of high-density product groups and the shorter product life cycles that have become common-place in recent years.

However, to comply with the target application, a work system having a well-balanced robot arm, peripheral devices or robot and hand section must be structured.

When creating these standard specifications, we have edited them so that the Mitsubishi robot's characteristics and specifications can be easily understood by users considering the implementation of robots. However, if there are any unclear points, please contact your nearest Mitsubishi branch or dealer.

Mitsubishi hopes that you will consider these standard specifications and use our robots.

Note that in this specification document the specifications related to the robot arm is described [Page 10, "2 Robot arm"](#), the specifications related to the controller [Page 99, "3 Controller"](#), and software functions and a command list [Page 140, "4 Software"](#) separately.

This document has indicated the specification of the following types robot.

- *RH-6FH (CR750-Q controller) series
- *RH-12FH (CR750-Q controller) series
- *RH-20FH (CR750-Q controller) series

· About CE Marking in the automization system

The Guidelines of the measures against EMC in the automization system manufactured by the customer is shown in [Page 159, "6.4 EMC installation guideline"](#).

Please refer to it and carry out the measures against EMC of the automization system of the customer.

- No part of this manual may be reproduced by any means or in any form, without prior consent from Mitsubishi.
- The contents of this manual are subject to change without notice.
- The specifications values are based on Mitsubishi standard testing methods.
- The information contained in this document has been written to be accurate as much as possible. Please interpret that items not described in this document "cannot be performed." or "alarm may occur".
Please contact your nearest dealer if you find any doubtful, wrong or skipped point.
- This specifications is original.
- Microsoft, Windows, Microsoft Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The ETHERNET is a registered trademark of the Xerox Corp.
- All other company names and production names in this document are the trademarks or registered trademarks of their respective owners.

Contents

| | Page |
|--|------|
| 1 General configuration | 1-1 |
| 1.1 Structural equipment | 1-1 |
| 1.1.1 Standard structural equipment | 1-1 |
| 1.1.2 Special specifications | 1-1 |
| 1.1.3 Options | 1-1 |
| 1.1.4 Maintenance parts | 1-1 |
| 1.2 Model type name of robot | 1-2 |
| 1.2.1 How to identify the robot model | 1-2 |
| 1.2.2 Combination of the robot arm and the controller | 1-3 |
| 1.3 CE marking specifications | 1-4 |
| 1.4 Indirect export | 1-4 |
| 1.5 Instruction manuals | 1-4 |
| 1.6 Contents of the structural equipment | 1-5 |
| 1.6.1 Robot arm | 1-5 |
| 1.6.2 Controller | 1-7 |
| 1.7 Contents of the Option equipment and special specification | 1-8 |
| 2 Robot arm | 2-10 |
| 2.1 Standard specifications | 2-10 |
| 2.1.1 Basic specifications | 2-10 |
| (1) RH-6FH series | 2-10 |
| (2) RH-12FH series | 2-12 |
| (3) RH-20FH series | 2-14 |
| 2.1.2 The counter-force applied to the installation surface | 2-15 |
| 2.2 Definition of specifications | 2-16 |
| 2.2.1 Pose repeatability | 2-16 |
| 2.2.2 Rated load (mass capacity) | 2-17 |
| 2.2.3 Relationships Among Mass Capacity, Speed, and Acceleration/Deceleration Speed | 2-19 |
| (1) Setting Load Capacity and Size (Hand Conditions) | 2-19 |
| 2.2.4 Vibrations at the Tip of the Arm during Low-Speed Operation of the Robot | 2-19 |
| 2.2.5 Vibration of shaft (J3 axis) position and arm end | 2-20 |
| (1) Relationship Between Mass Capacity and Speed | 2-20 |
| (2) Relationship Between Height of Shaft (J3 Axis) and Acceleration/Deceleration Speed | 2-21 |
| (3) Relation between offset length and the maximum speed | 2-23 |
| (4) Time to reach the position repeatability | 2-24 |
| 2.2.6 Collision detection | 2-24 |
| 2.2.7 Protection specifications | 2-25 |
| (1) Types of protection specifications | 2-25 |
| (2) About the use with the bad environment | 2-26 |
| 2.2.8 Clean specifications | 2-27 |
| (1) Types of clean specifications | 2-27 |
| 2.3 Names of each part of the robot | 2-29 |
| 2.4 Outside dimensions • Operating range diagram | 2-30 |
| 2.4.1 Outside dimensions • Operating range diagram (RH-6FH series) | 2-30 |
| (1) Standard Specification | 2-30 |
| (2) Clean Specification and oil mist specification | 2-36 |
| 2.4.2 Outside dimensions • Operating range diagram (RH-12FH series) | 2-42 |
| (1) Standard Specification | 2-42 |
| (2) Clean Specification and oil mist specification | 2-48 |
| 2.4.3 Outside dimensions • Operating range diagram (RH-20FH series) | 2-54 |
| (1) Standard Specification | 2-54 |
| (2) Clean Specification and oil mist specification | 2-58 |
| 2.4.4 Mechanical interface and Installation surface | 2-62 |
| (1) Mechanical interface and Installation surface of RH-6FH series | 2-62 |
| (2) Mechanical interface and Installation surface of RH-12FH series | 2-63 |
| (3) Mechanical interface and Installation surface of RH-20FH series | 2-64 |

Contents

| | Page |
|---|-------|
| 2.4.5 Change the operating range | 2-65 |
| (1) Operating range changeable angle | 2-65 |
| (2) The change method of the operating range | 2-66 |
| 2.5 Tooling | 2-67 |
| 2.5.1 Wiring and piping for hand | 2-67 |
| 2.5.2 Internal air piping | 2-68 |
| (1) Standard type/Oil mist specifications | 2-68 |
| (2) Clean type | 2-68 |
| 2.5.3 Internal wiring for the hand output cable | 2-68 |
| 2.5.4 Internal wiring for the hand input cable | 2-68 |
| 2.5.5 Ethernet cable | 2-68 |
| 2.5.6 About the Installation of Tooling Wiring and Piping (Examples of Wiring and Piping) | 2-69 |
| (1) RH-6FH series | 2-69 |
| (2) RH-12FH/20FH series | 2-70 |
| (3) Example of wiring and piping <1> | 2-71 |
| (4) Wiring and piping example <2> | 2-72 |
| (5) Precautions for the clean specification | 2-72 |
| 2.5.7 Wiring and piping system diagram for hand | 2-73 |
| 2.5.8 Electrical specifications of hand input/output | 2-75 |
| 2.5.9 Air supply circuit example for the hand | 2-76 |
| 2.6 Shipping special specifications, options, and maintenance parts | 2-77 |
| 2.6.1 Shipping special specifications | 2-77 |
| (1) Machine cable | 2-78 |
| 2.7 Options | 2-79 |
| (1) Machine cable extension | 2-80 |
| (2) Changes J1 axis operating range | 2-83 |
| (3) Solenoid valve set | 2-84 |
| (4) Hand input cable | 2-88 |
| (5) Hand output cable | 2-90 |
| (6) Hand curl tube | 2-91 |
| (7) Internal Wiring/Piping set for hand | 2-92 |
| (8) External Wiring/Piping box | 2-94 |
| 2.8 About Overhaul | 2-97 |
| 2.9 Maintenance parts | 2-98 |
| 3 Controller | 3-99 |
| 3.1 Standard specifications | 3-99 |
| 3.2 Protection specifications and operating supply | 3-100 |
| 3.3 Names of each part | 3-101 |
| 3.3.1 Names of each part of the robot CPU | 3-103 |
| 3.4 Outside dimensions/Installation dimensions | 3-104 |
| 3.4.1 Outside dimensions | 3-104 |
| (1) Outside dimensions of robot CPU unit | 3-105 |
| (2) Battery unit outside dimension | 3-106 |
| 3.4.2 Installation dimensions | 3-107 |
| (1) Robot CPU Unit installation dimensions | 3-109 |
| 3.5 External input/output | 3-110 |
| 3.5.1 Types | 3-110 |
| 3.6 Dedicated input/output | 3-111 |
| 3.7 Emergency stop input and output etc. | 3-114 |
| 3.7.1 Connection of the external emergency stop | 3-114 |
| 3.7.2 Special stop input (SKIP) | 3-119 |
| 3.7.3 Door switch function | 3-120 |
| 3.7.4 Enabling device function | 3-120 |
| (1) When door is opening | 3-120 |
| (2) When door is closing | 3-120 |

Contents

| | Page |
|---|--------------|
| (3) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings | 3-121 |
| 3.8 Additional Axis Function | 3-122 |
| 3.8.1 Wiring of the Additional Axis Interface | 3-122 |
| 3.9 Magnet contactor control connector output (AXMC) for addition axes | 3-125 |
| 3.10 Options | 3-127 |
| (1) Teaching pendant (T/B) | 3-128 |
| (2) Controller protection box | 3-131 |
| (3) RT ToolBox2/RT ToolBox2 mini | 3-136 |
| (4) Instruction Manual(bookbinding) | 3-138 |
| 3.11 Maintenance parts | 3-139 |
| 4 Software | 4-140 |
| 4.1 List of commands | 4-140 |
| 4.2 List of parameters | 4-143 |
| 5 Instruction Manual | 5-145 |
| 5.1 The details of each instruction manuals | 5-145 |
| 6 Safety | 6-146 |
| 6.1 Safety | 6-146 |
| 6.1.1 Self-diagnosis stop functions | 6-146 |
| 6.1.2 External input/output signals that can be used for safety protection measures | 6-147 |
| 6.1.3 Precautions for using robot | 6-147 |
| 6.1.4 Safety measures for automatic operation | 6-148 |
| 6.1.5 Safety measures for teaching | 6-148 |
| 6.1.6 Safety measures for maintenance and inspections, etc. | 6-148 |
| 6.1.7 Examples of safety measures | 6-149 |
| (1) CR750 drive unit | 6-149 |
| (2) External emergency stop connection [supplementary explanation] | 6-154 |
| 6.2 Working environment | 6-157 |
| 6.3 Precautions for handling | 6-157 |
| 6.4 EMC installation guideline | 6-159 |
| 6.4.1 Outlines | 6-159 |
| 6.4.2 EMC directive | 6-159 |
| 6.4.3 EMC measures | 6-160 |
| 6.4.4 Component parts for EMC measures | 6-160 |
| (1) Ferrite core | 6-160 |
| (2) Line noise filter | 6-160 |
| 7Appendix | Appendix-161 |
| Appendix 1 : Specifications discussion material (RH-6FH series) | Appendix-161 |
| Appendix 2 : Specifications discussion material (RH-12FH series) | Appendix-162 |
| Appendix 3 : Specifications discussion material (RH-20FH series) | Appendix-163 |

1 General configuration

1.1 Structural equipment

Structural equipment consists of the following types.

1.1.1 Standard structural equipment

The following items are enclosed as a standard.

- (1) Robot arm
- (2) Controller (CPU unit + Drive unit)
- (3) The connecting cable for the CPU unit and the drive unit
- (4) Machine cable
- (5) Robot arm installation bolts
- (6) Safety manual, CD-ROM (Instruction manual)
- (7) Guarantee card

1.1.2 Special specifications

For the special specifications, some standard configuration equipment and specifications have to be changed before factory shipping. Confirm the delivery date and specify the special specifications at the order.

1.1.3 Options

User can install options after their delivery.

1.1.4 Maintenance parts

Materials and parts for the maintenance use.

1.2 Model type name of robot

This robot has arranged the type name corresponding to load mass, arm length, and environment specification. Details are shown below, please select the robot suitable for the customer's use.

1.2.1 How to identify the robot model

RH - **◇◇** **FH** **□□** **△△** **○** - **●** **Q** **▲** - **SMxx**
 (a) (b) (c) (d) (e) (f) (g) (h) (i) (j)

(a). RH.....Indicates the horizontal multiple-joint robot.
 Ex.)

RV: Vertical multiple-joint type.
 RH: Horizontal multiple-joint type.

(b). ◇◇.....Indicates the maximum load.
 Ex.)

6: 6kg
 12: 12kg
 20: 20kg

(c). FH.....Indicates the FH series.

(d). □□.....Indicates the arm length.
 Ex.)

35: 350mm
 45: 450mm
 55: 550mm
 70: 700mm
 85: 850mm
 100: 1000mm

(e). △△.....Indicates the vertical stroke length.
 Ex.)

20: 200mm stroke
 34: 340mm stroke
 35: 350mm stroke
 45: 450mm stroke

(f). ○.....Indicates environment specification.
 Ex.)

Omitted: General specifications
 C: Clean specifications
 M: Oil mist specifications

(g). ●.....Indicates the controller series.
 Ex.)

Omitted: CR750 controller

(h). Q.....Indicates the controller type.
 Q: iQ Platform

(i). ▲.....Technical standard of Conformity.
 Ex.)

Omitted: No conformity of technical standard.
 1: Conforms to the CE Marking

(j). - S M xx.....Indicates a special model. In order, limit special specification.
 [1] [2]

[1] S: Indicates a special model.
 [2] M: Indicates a specification with protection specification controller. (The controller protection box is attached.)

1.2.2 Combination of the robot arm and the controller

Table 1-1 : Combination of the robot arm and the controller

| Protection specification | Robot arm | Arm length (mm) | J3-axis stroke (mm) | Controller ^{Note1)} |
|-----------------------------|-----------------|-----------------|---------------------|------------------------------|
| RH-6FH series | | | | |
| General-purpose environment | RH-6FH3520-Q | 350 | 200 | CR750-06HQ-1 |
| | RH-6FH4520-Q | 450 | | |
| | RH-6FH5520-Q | 550 | | |
| | RH-6FH3534-Q | 350 | 340 | |
| | RH-6FH4534-Q | 450 | | |
| | RH-6FH5534-Q | 550 | | |
| Clean specifications | RH-6FH3520C-Q | 350 | 200 | |
| | RH-6FH4520C-Q | 450 | | |
| | RH-6FH5520C-Q | 550 | | |
| | RH-6FH3534C-Q | 350 | 340 | |
| | RH-6FH4534C-Q | 450 | | |
| | RH-6FH5534C-Q | 550 | | |
| Oil mist specifications | RH-6FH3520M-Q | 350 | 200 | |
| | RH-6FH4520M-Q | 450 | | |
| | RH-6FH5520M-Q | 550 | | |
| | RH-6FH3534M-Q | 350 | 340 | |
| | RH-6FH4534M-Q | 450 | | |
| | RH-6FH5534M-Q | 550 | | |
| RH-12FH series | | | | |
| General-purpose environment | RH-12FH5535-Q | 550 | 350 | CR750-12HQ-1 |
| | RH-12FH7035-Q | 700 | | |
| | RH-12FH8535-Q | 850 | | |
| | RH-12FH5545-Q | 550 | 450 | |
| | RH-12FH7045-Q | 700 | | |
| | RH-12FH8545-Q | 850 | | |
| Clean specifications | RH-12FH5535C-Q | 550 | 350 | |
| | RH-12FH7035C-Q | 700 | | |
| | RH-12FH8535C-Q | 850 | | |
| | RH-12FH5545C-Q | 550 | 450 | |
| | RH-12FH7045C-Q | 700 | | |
| | RH-12FH8545C-Q | 850 | | |
| Oil mist specifications | RH-12FH5535M-Q | 550 | 350 | |
| | RH-12FH7035M-Q | 700 | | |
| | RH-12FH8535M-Q | 850 | | |
| | RH-12FH5545M-Q | 550 | 450 | |
| | RH-12FH7045M-Q | 700 | | |
| | RH-12FH8545M-Q | 850 | | |
| RH-20FH series | | | | |
| General-purpose environment | RH-20FH8535-Q | 850 | 350 | CR750-20HQ-1 |
| | RH-20FH10035-Q | 1000 | | |
| | RH-20FH8545-Q | 850 | 450 | |
| | RH-20FH10045-Q | 1000 | | |
| Clean specifications | RH-20FH8535C-Q | 850 | 350 | |
| | RH-20FH10035C-Q | 1000 | | |
| | RH-20FH8545C-Q | 850 | 450 | |
| | RH-20FH10045C-Q | 1000 | | |
| Oil mist specifications | RH-20FH8535M-Q | 850 | 350 | |
| | RH-20FH10035M-Q | 1000 | | |
| | RH-20FH8545M-Q | 850 | 450 | |
| | RH-20FH10045M-Q | 1000 | | |

Note1) When you use by adverse environment, please use the controller protection box (CR750-MB).

1.3 CE marking specifications

The robot shown in the [Table 1-2](#) is the CE Marking specification.

Table 1-2 : Robot models with CE marking specifications

| Robot type ^{Note1)} | Controller | External signal logic | Language setting |
|--------------------------------------|-------------------------------------|-----------------------|------------------|
| RH-6FHxxyy-Q1-S15 ^{Note2)} | CR750-06HQ1-1-S15 ^{Note3)} | Source type | English (ENG) |
| RH-6FHxxyyC-Q1-S15 ^{Note4)} | | | |

Note1) The "xx" indicate the arm length, "yy" indicate J3-axis stroke.

Note2) This robot's protection specification is IP54. Although bellows are not installed at the shaft, please give the dealer an order if needed. As long as there is no special description, refers to the details of RH-6FHxxyyM (oil-mist specification).

Note3) The specification and the handling method of the controller are the same as standard type controller CR750-06HD-1.

Note4) This robot is the clean specification. As long as there is no special description, refers to the contents of RH-6FHxxyyC (clean specification).

1.4 Indirect export

The display in English is available by setting parameter LNG as "ENG."

1.5 Instruction manuals

The instruction manuals supplied in CD-ROM, except for the Safety Manual. This CD-ROM (electronic manual) includes instruction manuals in both Japanese and English versions.

1.6 Contents of the structural equipment

1.6.1 Robot arm

The list of structural equipment is shown in below.




Fig.1-1 : Structural equipment (RH-6FH series)


RH-12FH/20FH series

Horizontal four-axis multiple-jointed type
(RH-12FH/20FH series)



* Refer to Page 10, "2.1 Standard specifications" for details on the specifications.

Machine cable
(Standard product:
5m attachment)



Machine cable
(Fix type : 2m)
• 1S-02UCBL-01


Machine cable extension

Fix type: 1S- □□ CBL-01
Flex type: 1S- □□ LCBL-01

Note1) □□ refer the length. Refer to Table 1-3 for details.
Note2) Connect the extension cables to the arm side of the standard cable to extend.

Solenoid valve set


- 1S-VD0*-01 (Sink type)
 - 1S-VD0*E-01 (Source type)
- (*: 1 to 4 = 1 set to 4 set)



* With hand output cable.


Hand output cable

- 1F-GR60S-01 (4sets)




Hand input cable

- 1F-HC35C-02



Hand curl tube

- 1N-ST0608C-01




Changes J1 axis operating range

- 1F-DH-02

Internal Wiring/Piping set for hand


- 1F-HS604S-01(350mm stroke)
- 1F-HS604S-02(450mm stroke)




Pneumatic hand
customer-manufactured parts

External Wiring/Piping box


- 1F-UT-BOX-01




[Caution]




Standard configuration equipment



Option



Special specifications



Prepared by customer

Fig.1-2 : Structural equipment (RH-12FH/20FH series)

1.6.2 Controller

The devices shown below can be installed on the controller.

The controllers that can be connected differ depending on the specification of the robot. (Refer to Page 2, "1.2 Model type name of robot".)




Fig.1-3 : Structural equipment

1.7 Contents of the Option equipment and special specification

A list of all Optional equipment and special specifications are shown below.

Table 1-3 : The list of Option equipment and special specification

| Item | Type | Specifications | Classification Note1) | Description |
|--|---------------------------------|---|--------------------------|--|
| Stopper for changing the operating range (J1 axis) | 1F-DH-01 | The stopper parts for J1 axis | ○ | This must be installed by the customer. For RH-6FH series |
| | 1F-DH-02 | The stopper parts for J1 axis | ○ | This must be installed by the customer. For RH-12FH/20FH series |
| Machine cable (Replaced to shorter cable) | 1S-02UCBL-01 | For fixing (Set of power and signal) | ○□ | 2m (A 2m cable is supplied instead of the 5m cable that is supplied as standard) |
| Extended machine cable | 1S- □□ CBL-01 | For fixing (Set of power and signal) Extension type | ○ | 5、10、15m |
| | 1S- □□ LCBL-01 | For flexing (Set of power and signal) Extension type | ○ | |
| | 1S- □□ LUCBL-01 | For flexing (Set of power and signal) Direct type | ○ | |
| Solenoid valve set | 1F-VD01-01/VD01E-01 | 1 set (Sink type)/(Source type) | ○ | The solenoid-valve set for the hand of the customer setup. For RH-6FH series. 1F-VD0*-01: Sink type 1F-VD0*E-01: Source type |
| | 1F-VD02-01/VD02E-01 | 2 set (Sink type)/(Source type) | ○ | |
| | 1F-VD03-01/VD03E-01 | 3 set (Sink type)/(Source type) | ○ | |
| | 1F-VD04-01/VD04E-01 | 4 set (Sink type)/(Source type) | ○ | The solenoid-valve set for the hand of the customer setup. For RH-12FH/20FH series. 1S-VD0*-01: Sink type 1S-VD0*E-01: Source type |
| | 1S-VD01-01/VD01E-01 | 1 set (Sink type)/(Source type) | ○ | |
| | 1S-VD02-01/VD02E-01 | 2 set (Sink type)/(Source type) | ○ | |
| | 1S-VD03-01/VD03E-01 | 3 set (Sink type)/(Source type) | ○ | |
| 1S-VD04-01/VD04E-01 | 4 set (Sink type)/(Source type) | ○ | | |
| Hand input cable | 1F-HC35C-01 | Robot side: connector. Hand side: wire. | ○ | The cable is connected to the sensor by the customer. Attaches the cable clamp (drip proof type) For RH-6FH series |
| | 1F-HC35C-02 | Robot side: connector. Hand side: wire. | ○ | The cable is connected to the sensor by the customer. Attaches the cable clamp (drip proof type) For RH-12FH/20FH series |
| Hand output cable | 1F-GR60S-01 | Robot side: connector. Hand side: wire | ○ | This cable can be used for the solenoid valve prepared by the customer. |
| Hand curl tube | 1E-ST0408C-300 | For solenoid valve 4set.:Φ4x8 | ○ | Curl type air tube For RH-6FH series |
| | 1N-ST0608C-01 | For solenoid valve 4set.:Φ6x4 | ○ | Curl type air tube For RH-12FH/20FH series |
| External Wiring/Piping box | 1F-UT-BOX | For solenoid valve 4set.:Φ4x8 | ○ | Box which pulls out the Wire/Piping (Hand I/O cable, Hand curl tube) For RH-6FH series |
| | 1F-UT-BOX-01 | For solenoid valve 4set.:Φ4x8 | ○ | Box which pulls out the Wire/Piping (Hand I/O cable, Hand curl tube) For RH-12FH/20FH series |
| Internal Wiring/Piping set for hand | 1F-HS408S-01 | Hand input (eight points) + φ4 eight hoses | ○ | Wiring/Piping to pass in the shaft For RH-6FH series (200mm stroke) |
| | 1F-HS408S-02 | Hand input (eight points) + φ4 eight hoses | ○ | Wiring/Piping to pass in the shaft For RH-6FH series (340mm stroke) |
| | 1F-HS604S-01 | Hand input (eight points) + φ6 four hoses | ○ | Wiring/Piping to pass in the shaft For RH-12FH/20FH series (350mm stroke) |
| | 1F-HS604S-02 | Hand input (eight points) + φ6 four hoses | ○ | Wiring/Piping to pass in the shaft For RH-12FH/20FH series (450mm stroke) |
| Simple teaching pendant | R32TB | Cable length 7m | ○ | With 3-position enable switch IP65 |
| | R32TB-15 | Cable length 15m | ○ | |
| Highly efficient teaching pendant | R56TB | Cable length 7m | ○ | |
| | R56TB-15 | Cable length 15m | ○ | |
| Controller protection box | CR750-MB | IP54 | ○ | The controller protection box is used to protect the controller from an oil mist or other operating environment. |

1 General configuration

| Item | Type | Specifications | Classification Note1) | Description |
|---|-----------------|---------------------------|--------------------------|---|
| RT ToolBox2 (Personal computer Support software) | 3D-11C-WINE | CD-ROM | ○ | MS-Windows2000/XP/Vista/7 (With the simulation function) |
| RT ToolBox2 mini (Personal computer Support software mini) | 3D-12C-WINE | CD-ROM | ○ | MS-Windows2000/XP/Vista/7 |
| Robot CPU unit connection cable set | 2Q-RC-CBL □ □ M | Cable length 05, 20, 30m | □ | This option include TU, DISP, EMI and SSCNET cables. |
| TU cable for robot | 2Q-TUCBL □ M | Cable length 05, 20, 30m | □ | For communication between robot CPU and DU. |
| DISP cable for robot | 2Q-DISPCBL □ M | Cable length 05, 20, 30m | □ | For communication between robot CPU and DU. |
| EMI cable for robot | 2Q-EMICBL □ M | Cable length 05, 20, 30m | □ | For a robot CPU emergency stop input. |
| SSCNET III cable for robot | MR-J3BUS □ M-A | Cable length 05, 20m | □ | For the servo communication between robot CPU and DU . |
| | MR-J3BUS30M-B | Cable length 30m | □ | |
| Instruction Manual | 5F-RB01-PE01 | RH-6FH/12FH/20FH-Q series | ○ | |

Note1) ○ : option, □ : special specifications.

2 Robot arm

2.1 Standard specifications

2.1.1 Basic specifications

(1) RH-6FH series

Table 2-1 : Standard specifications of robot arm

| Item | | Unit | Specifications | | |
|--|---------------------|---------------------|--|---|---|
| Type ^{Note1)} | | | RH-6FH3520/3534 RH-6FH3520C/3534C RH-6FH3520M/3534M | RH-6FH4520/4534 RH-6FH4520C/4534C RH-6FH4520M/4534M | RH-6FH5520/5534 RH-6FH5520C/5534C RH-6FH5520M/5534M |
| Environment | | | Blank: Standard specification C: Clean specification M: Oil mist specification ^{Note2)} | | |
| Installation posture | | | On floor | | |
| Degree of freedom | | | 4 | | |
| Structure | | | Horizontal, multiple-joint type | | |
| Drive system | | | AC servo motor | | |
| Position detection method | | | Absolute encoder | | |
| Motor capacity | J1 | W | 750 | | |
| | J2 | W | 400 | | |
| | J3 (Z) | W | 200 | | |
| | J4 (θ axis) | W | 100 | | |
| Brake | | | J1, J2, J4: no brake, J3: with brake | | |
| Arm length | No. 1 arm | mm | 125 | 225 | 325 |
| | No. 2 arm | mm | 225 | | |
| Max.reach radius(No. 1+ No. 2) | | mm | 350 | 450 | 550 |
| Operating range | J1 | deg | ± 170 | | |
| | J2 | deg | ± 145 | | |
| | J3 (Z) | mm | RH-6FH**20/**20C/**20M: 200 (+133 to +333) RH-6FH**34: 340 (-7 to +333) RH-6FH**34C/**34M: 340 (-43 to +297) | | |
| | J4 (θ axis) | deg | ± 360 | | |
| Speed of motion ^{Note3)} | J1 | deg/s | 400 | | |
| | J2 | deg/s | 670 | | |
| | J3 (Z) | mm/s | 2,400 | | |
| | J4 (θ axis) | deg/s | 2,500 | | |
| Maximum horizontal composite speed ^{Note4)} | | mm/s | 6,900 | 7,600 | 8,300 |
| Cycle time ^{Note5)} | | sec | 0.29 | | |
| Load | Rating | kg | 3 | | |
| | Maximum | (N) | 6 | | |
| Z axis pressing force ^{Note6)} | Maximum | N | 165 | | |
| Allowable inertia | Rating | kg · m ² | 0.01 | | |
| | Maximum | | 0.12 | | |
| Pose repeatability ^{Note7)} | X-Y direction | mm | ± 0.010 | ± 0.010 | ± 0.012 |
| | J3 (Z) | mm | ± 0.010 | | |
| | J4 (θ axis) | deg | ± 0.004 | | |
| Ambient temperature | | °C | 0 to 40 | | |
| Mass | | k | 36 | 37 | |
| Tool wiring | | | <ul style="list-style-type: none"> · Input 8 points/Output 8 points, (total 20 cores) · Dedicated signal cable for multifunctional hand (Two cores + Power cable two cores) · Ethernet cable one cable (100BASE-TX, eight cores)^{Note8)} | | |
| Tool pneumatic pipes | | | Primary: $\phi 6$ x two hoses, Secondary: $\phi 4$ x eight hoses ^{Note9)} | | |
| Supply pressure | | MPa | 0.5 \pm 10% | | |
| Protection specification ^{Note10)} | | | Standard specification: IP20 Clean specification: ISO class 3 ^{Note11)} Oil mist specification: IP65 ^{Note12)} ^{Note13)} CE Marking specification: IP54 ^{Note13)} ^{Note14)} | | |
| Painting color | | | Light gray (Equivalent to Munsell: 0.6B7.6/0.2) | | |

Note1) The table is joint writing on the general environment and clean and oil mist (IP65) specification. If the type ends in a letter C, this corresponds to the clean specification, and where it ends in a letter M, it corresponds to the mist specification. The type in which operating range of J3 axis (Z) is 200mm and 340mm are shown together.


Note2) The oil-mist specification of CE specification is the standards.

Note3) The maximum speed is the value which applied MvTune2 (high-speed movement mode).

Note4) At the maximum speed on the X-Y flat surface in the robot's control point, it is obtained with each speed of J1, J2, and J4. The control point is the position offset by the rated inertia from the flange.

Note5) The value of the following movement which applied MvTune2 (high-speed movement mode) with the carrying mass of 2kg.

- The cycle time may increase with the case where the positioning accuracy of the work etc. is necessary, or by the moving position.



Note6) This is the downwards pressing force that occurs at the end of the load when the maximum load is on board and the J1, J2 and J4 axis are in their resting state. Please operate at this level or below. When pressing for long periods of time, an excess load error may occur. Please operate in a manner that does not cause errors.

Note7) The pose repeatability details are given in [Page 16, "2.2.1 Pose repeatability"](#).

Note8) The 8-wire cable designated for LAN wiring can also be used for backup wiring.

Note9) The $\phi 4$ secondary piping can be obtained with the electromagnetic valve (option). Details regarding the electromagnetic valve (optional) are shown on [Page 84, "\(3\) Solenoid valve set"](#).

Note10) The protection specification details are given in [Page 25, "2.2.7 Protection specifications"](#).

Note11) The details of the clean specifications are described in [Page 27, "2.2.8 Clean specifications"](#). Protection of the cleanness of the robot is required if the down flow in a clean room is 0.3 m/s or more and robot internal suction is 30–50 L/min. A $\phi 8$ joint is prepared at the base rear part for suction.

The protection specification details are given in [Page 25, "2.2.7 Protection specifications"](#).

Note12) Direct jet flow to the bellows section is not included.

Note13) If you use the controller in oil mist or similar environments, use the controller protection box to protect the controller from the operation environment. A robot equipped with the controller protection box as standard is available.

Note14) Please contact dealer since the environmental resistance may not be secured depending on the characteristics of oil you use. (IP54 of the CE specifications prevent direct jet to the shaft.) Mounting a bellows to the shaft tip makes the protection degree compliant with IP65. However, avoid direct jet to the bellows. For the method to mount the bellows, consult with the dealer.

(2) RH-12FH series

Table 2-2 : Standard specifications of robot arm


| Item | | Unit | Specifications | | |
|--|---------------------|---------------------|---|--|--|
| Type ^{Note1)} | | | RH-12FH5535/5545 RH-12FH5535C/5545C RH-12FH5535M/5545M | RH-12FH7035/7045 RH-12FH7035C/7045C RH-12FH7035M/7045M | RH-12FH8535/8545 RH-12FH8535C/8545C RH-12FH8535M/8545M |
| Environment | | | Blank: Standard specification C: Clean specification M: Oil mist specification | | |
| Installation posture | | | On floor | | |
| Degree of freedom | | | 4 | | |
| Structure | | | Horizontal, multiple-joint type | | |
| Drive system | | | AC servo motor | | |
| Position detection method | | | Absolute encoder | | |
| Motor capacity | J1 | W | 750 | | |
| | J2 | W | 750 | | |
| | J3 (Z) | W | 400 | | |
| | J4 (θ axis) | W | 200 | | |
| Brake | | | J1, J2, J4: no brake, J3: with brake | | |
| Arm length | No. 1 arm | mm | 225 | 375 | 525 |
| | No. 2 arm | mm | 325 | | |
| Max.reach radius(No. 1+ No. 2) | | mm | 550 | 700 | 850 |
| Operating range | J1 | deg | ± 170 | | |
| | J2 | deg | ± 145 | | ± 153 |
| | J3 (Z) | mm | RH-12FH**35/**35C/**35M: 350 (-10 ~ +340) RH-12FH**45/**45C/**45M: 450 (-110 ~ +340) | | |
| | J4 (θ axis) | deg | ± 360 | | |
| Speed of motion ^{Note2)} | J1 | deg/s | 420 | | 280 |
| | J2 | deg/s | 450 | | |
| | J3 (Z) | mm/s | 2,800 | | |
| | J4 (θ axis) | deg/s | 2,400 | | |
| Maximum horizontal composite speed ^{Note3)} | | mm/s | 11,435 | 12,535 | 11,350 |
| Cycle time ^{Note4)} | | sec | 0.30 | | |
| Load | Rating | kg | 3 | | |
| | Maximum | (N) | 12 | | |
| Z axis pressing force ^{Note5)} | | Maximum | N 200 | | |
| Allowable inertia | Rating | kg · m ² | 0.025 | | |
| | Maximum | | 0.3 | | |
| Pose repeatability ^{Note6)} | X-Y direction | mm | ± 0.012 | ± 0.015 | |
| | J3 (Z) | mm | ± 0.010 | | |
| | J4 (θ axis) | deg | ± 0.005 | | |
| Ambient temperature | | °C | 0 to 40 | | |
| Mass | | kg | 65 | 67 | 69 |
| Tool wiring | | | · Input 8 points/Output 8 points, (total 20 cores) · Dedicated signal cable for multifunctional hand (Two cores + Power cable two cores) · Ethernet cable one cable (100BASE-TX, eight cores) ^{Note7)} | | |
| Tool pneumatic pipes | | | Primary: $\phi 6$ x two hoses, Secondary: $\phi 4$ x eight hoses ^{Note8)} | | |
| Supply pressure | | MPa | 0.5 \pm 10% | | |
| Protection specification ^{Note9)} | | | Standard specification: IP20 Clean specification: ISO class 3 ^{Note10)} Oil mist specification: IP65 ^{Note11)} ^{Note12)} | | |
| Painting color | | | Light gray (Equivalent to Munsell: 0.6B7.6/0.2) | | |

Note1) The table is joint writing on the general environment and clean and oil mist (IP65) specification. If the type ends in a letter C, this corresponds to the clean specification, and where it ends in a letter M, it corresponds to the mist specification. The type in which operating range of J3 axis (Z) is 350mm and 450mm are shown together.

Note2) The maximum speed is the value which applied MvTune2 (high-speed movement mode).

Note3) At the maximum speed on the X-Y flat surface in the robot's control point, it is obtained with each speed of J1, J2, and J4. The control point is the position offset by the rated inertia from the flange.

- Note4) The value of the following movement which applied MvTune2 (high-speed movement mode) with the carrying mass of 2kg.
- The cycle time may increase with the case where the positioning accuracy of the work etc. is necessary, or by the moving position.



- Note5) This is the downwards pressing force that occurs at the end of the load when the maximum load is on board and the J1, J2 and J4 axis are in their resting state. Please operate at this level or below. When pressing for long periods of time, an excess load error may occur. Please operate in a manner that does not cause errors.
- Note6) The pose repeatability details are given in [Page 16, "2.2.1 Pose repeatability"](#).
- Note7) The 8-wire cable designated for LAN wiring can also be used for backup wiring.
- Note8) The $\phi 4$ secondary piping can be obtained with the electromagnetic valve (option). Details regarding the electromagnetic valve (optional) are shown on [Page 84, "\(3\) Solenoid valve set"](#).
- Note9) The protection specification details are given in [Page 25, "2.2.7 Protection specifications"](#).
- Note10) The details of the clean specifications are described in [Page 27, "2.2.8 Clean specifications"](#). Protection of the cleanness of the robot is required if the down flow in a clean room is 0.3 m/s or more and robot internal suction is 60-140 L/min. A $\phi 8$ joint is prepared at the base rear part for suction.
- Note11) Direct jet flow to the bellows section is not included.
- Note12) If you use the controller in oil mist or similar environments, use the controller protection box to protect the controller from the operation environment. A robot equipped with the controller protection box as standard is available.

(3) RH-20FH series

Table 2-3 : Standard specifications of robot arm

| Item | | Unit | Specifications | |
|--|---------------------|---------------------|--|--|
| Type ^{Note1)} | | | RH-20FH8535/8545 RH-20FH8535C/8545C RH-20FH8535M/8545M | RH-20FH10035/10045 RH-20FH10035C/10045C RH-20FH10035M/10045M |
| Environment | | | Blank: Standard specification C: Clean specification M: Oil mist specification | |
| Installation posture | | | On floor | |
| Degree of freedom | | | 4 | |
| Structure | | | Horizontal, multiple-joint type | |
| Drive system | | | AC servo motor | |
| Position detection method | | | Absolute encoder | |
| Motor capacity | J1 | W | 750 | |
| | J2 | W | 750 | |
| | J3 (Z) | W | 400 | |
| | J4 (θ axis) | W | 200 | |
| Brake | | | J1, J2, J4: no brake, J3: with brake | |
| Arm length | No. 1 arm | mm | 525 | |
| | No. 2 arm | mm | 325 | 475 |
| Max.reach radius(No. 1+ No. 2) | | mm | 850 | 1,000 |
| Operating range | J1 | deg | ± 170 | |
| | J2 | deg | ± 153 | |
| | J3 (Z) | mm | RH-20FH**35/**35C/**35M: 350 (-10 ~ +340) RH-20FH**45/**45C/**45M: 450 (-110 ~ +340) | |
| | J4 (θ axis) | deg | ± 360 | |
| Speed of motion ^{Note2)} | J1 | deg/s | 280 | |
| | J2 | deg/s | 450 | |
| | J3 (Z) | mm/s | 2,400 | |
| | J4 (θ axis) | deg/s | 1,700 | |
| Maximum horizontal composite speed ^{Note3)} | | mm/s | 11,372 | 13,283 |
| Cycle time ^{Note4)} | | sec | 0.30 | 0.36 |
| Load | Rating | kg | 5 | |
| | Maximum | (N) | 20 | |
| Z axis pressing force ^{Note5)} | | N | 230 | |
| Allowable inertia | Rating | kg · m ² | 0.065 | |
| | Maximum | | 1.05 ^{Note6)} | |
| Pose repeatability ^{Note7)} | X-Y direction | mm | ± 0.015 | ± 0.020 |
| | J3 (Z) | mm | ± 0.010 | |
| | J4 (θ axis) | deg | ± 0.005 | |
| Ambient temperature | | °C | 0 to 40 | |
| Mass | | kg | 75 | 77 |
| Tool wiring | | | <ul style="list-style-type: none"> · Input 8 points/Output 8 points, (total 20 cores) · Dedicated signal cable for multifunctional hand (Two cores + Power cable two cores) · Ethernet cable one cable (100BASE-TX, eight cores)^{Note8)} | |
| Tool pneumatic pipes | | | Primary: $\phi 6$ x two hoses, Secondary: $\phi 4$ x eight hoses ^{Note9)} | |
| Supply pressure | | MPa | 0.5 \pm 10% | |
| Protection specification ^{Note10)} | | | Standard specification: IP20 Clean specification: ISO class 3 ^{Note11)} Oil mist specification: IP65 ^{Note12) Note13)} | |
| Painting color | | | Light gray (Equivalent to Munsell: 0.6B7.6/0.2) | |


Note1) The table is joint writing on the general environment and clean and oil mist (IP65) specification. If the type ends in a letter C, this corresponds to the clean specification, and where it ends in a letter M, it corresponds to the mist specification. The type in which operating range of J3 axis (Z) is 350mm and 450mm are shown together.

Note2) The maximum speed is the value which applied MvTune2 (high-speed movement mode).

Note3) At the maximum speed on the X-Y flat surface in the robot's control point, it is obtained with each speed of J1, J2, and J4. The control point is the position offset by the rated inertia from the flange.

Note4) The value of the following movement which applied MvTune2 (high-speed movement mode) with the carrying mass of 2kg.

- The cycle time may increase with the case where the positioning accuracy of the work etc. is necessary, or by the moving position.



Note5) This is the downwards pressing force that occurs at the end of the load when the maximum load is on board and the J1, J2 and J4 axis are in their resting state. Please operate at this level or below. When pressing for long periods of time, an excess load error may occur. Please operate in a manner that does not cause errors.

Note6) When offset hand is used, the adjustment of moving speed and acceleration/deceleration speeds may be the Required. Refers to it, because the details is shown in [Page 17, "2.2.2 Rated load \(mass capacity\)"](#).

Note7) The pose repeatability details are given in [Page 16, "2.2.1 Pose repeatability"](#).

Note8) The 8-wire cable designated for LAN wiring can also be used for backup wiring.

Note9) The $\phi 4$ secondary piping can be obtained with the electromagnetic valve (option). Details regarding the electromagnetic valve (optional) are shown on [Page 84, "\(3\) Solenoid valve set"](#).

Note10) The protection specification details are given in [Page 25, "2.2.7 Protection specifications"](#).

Note11) The details of the clean specifications are described in [Page 27, "2.2.8 Clean specifications"](#). Protection of the cleanness of the robot is required if the down flow in a clean room is 0.3 m/s or more and robot internal suction is 60-140 L/min. A $\phi 8$ joint is prepared at the base rear part for suction.

Note12) Direct jet flow to the bellows section is not included.

Note13) If you use the controller in oil mist or similar environments, use the controller protection box to protect the controller from the operation environment. A robot equipped with the controller protection box as standard is available.

2.1.2 The counter-force applied to the installation surface

The counter-force applied to the installation surface for the strength design of the robot installation surface is shown.

Table 2-4 : Value of each counter-force

| Item | Unit | Value |
|-------------------------------------|------|-------|
| RH-6FH series | | |
| Falls moment: M_L | N•m | 1,640 |
| Torsion moment: M_T | N•m | 710 |
| Horizontal translation force: F_H | N | 1,653 |
| Vertical translation force: F_V | N | 2,318 |
| RH-12FH/20FH series | | |
| Falls moment: M_L | N•m | 3,190 |
| Torsion moment: M_T | N•m | 1,840 |
| Horizontal translation force: F_H | N | 2,240 |
| Vertical translation force: F_V | N | 2,500 |

2.2 Definition of specifications

The accuracy of pose repeatability mentioned in catalogs and in the specification manual is defined as follows.

2.2.1 Pose repeatability

For this robot, the pose repeatability is given in accordance with JIS 8432 (Pose repeatability). Note that the value is based on 100 measurements (although 30 measurements are required according to JIS).

[Caution] The specified "pose repeatability" is not guaranteed to be satisfied under the following conditions.

- [1] Operation pattern factors
 - 1) When an operation that approaches from different directions and orientations are included in relation to the teaching position during repeated operations
 - 2) When the speed at teaching and the speed at execution are different
- [2] Load fluctuation factor
 - 1) When work is present/absent in repeated operations
- [3] Disturbance factor during operation
 - 1) Even if approaching from the same direction and orientation to the teaching position, when the power is turned OFF or a stop operation is performed halfway
- [4] Temperature factors
 - 1) When the operating environment temperature changes
 - 2) When accuracy is required before and after a warm-up operation
- [5] Factors due to differences in accuracy definition
 - 1) When accuracy is required between a position set by a numeric value in the robot's internal coordinate system and a position within the actual space
 - 2) When accuracy is required between a position generated by the pallet function and a position within the actual space

2.2.2 Rated load (mass capacity)

The robot's mass capacity is expressed solely in terms of mass, but even for tools and works of similar mass, eccentric loads will have some restrictions. When designing the tooling or when selecting a robot, consider the following issues.

- (1) The tooling should have the value less or equal than the smaller of the tolerable inertia and the tolerable moment found in [Page 10, "2.1.1 Basic specifications"](#).
- (2) [Fig. 2-1](#) shows the distribution dimensions for the center of gravity in the case where the volume of the load is relatively small. Use this figure as a reference when designing the tooling. Please use the robot in the allowable moment of inertia of maximum moment of inertia shown in [Fig. 2-1](#) to [Fig. 2-3](#), when loading mass is maximum (RH-6FH: 6kg, RH-12FH: 12kg, RH-20FH: 20kg).
- (3) Even if the load is force, not the mass, design the tooling so that moment does not exceed the allowable moment. Refer to [Page 10, "2.1 Standard specifications"](#) for details of allowable moment value.

[Caution] The mass capacity is greatly influenced by the operating speed of the robot and the motion posture. Even if you are within the allowable range mentioned previously, an overload or generate an overcurrnt alarm could occur. In such cases, it will be necessary to change the time setting for acceleration/deceleration, the operating speed, and the motion posture.

[Caution] The overhang amount of the load, such as the mass capacity and the allowable moment of inertia defined in this section, are dynamic limit values determined by the capacity of the motor that drives axes or the capacity of the speed reducer. Therefore, it does not guarantee the accuracy on all areas of tooling. Guaranteed accuracy is measured from the center point of the mechanical interface surface. Please note that if the point of operation is kept away from the mechanical interface surface by long and low-rigid tooling, the positioning accuracy may deteriorate or may cause vibration. Note that the allowable offset value (Z direction) from the lower edge of the shaft to the position of center of gravity is 100 mm.

[Caution] Even within the allowable range previously mentioned, an overload alarm may be generated if an ascending operation continues at a micro-low speed. In such a case, it is necessary to increase the ascending speed.

[Caution] This robot will restrict speed automatically by internal controls when the load center-of-gravity position separates from the shaft center. Refer to [Page 19, "2.2.3 Relationships Among Mass Capacity, Speed, and Acceleration/Deceleration Speed"](#) in detail. When the load center-of-gravity position separate from the center of shaft (RH-6FH: more than 140mm, RH-12FH: more than 150mm, RH-20FH: more than 120mm), an overload alarm may occur depending on the posture. In this case, please reduce acceleration and deceleration (Accel command) speeds and movement speed (Ovr command). Although the standard value to reduce is 50% for each command, please adjust corresponding to the movement posture. Refer to separate "Instruction Manual/Detailed Explanation of Functions and Operations" for details of each command.




Fig.2-1 : Position of center of gravity for loads (for loads with comparatively small volume): RH-6FH series




Fig.2-2 : Position of center of gravity for loads (for loads with comparatively small volume): RH-12FH series




Fig.2-3 : Position of center of gravity for loads (for loads with comparatively small volume): RH-20FH series

2.2.3 Relationships Among Mass Capacity, Speed, and Acceleration/Deceleration Speed

This robot automatically sets the optimum acceleration and deceleration speeds and maximum speed, according to the load capacity and size that have been set, and operates using these automatically set speeds.

To achieve that, it is necessary to correctly set the actual load data (mass and size of hand and work) to be used. However, vibration, overheating and errors such as excessive margin of error and overload may occur, depending on the robot operation pattern or ambient temperature.

In this case, reduce the speed and the acceleration and deceleration rate before continuing to use. This is done by accessing the robot program and adjusting the speed settings (Ovrd) and the acceleration and deceleration settings (Accel).

If a setting is performed in such a way that it falls below the mounted load, the life span of the mechanism elements used in the robot may be shortened. In the case of a work requiring a high degree of accuracy, set up the load correctly and use the robot by lowering the ratios of the acceleration and deceleration speeds.

(1) Setting Load Capacity and Size (Hand Conditions)

Set up the capacity and size of the hand with the "HNDDAT*" parameter (optimum acceleration/deceleration setting parameter), and set up the capacity and size of the work with the "WRKDAT*" parameter. Numbers 0 to 8 can be used for the asterisk (*) part. Designate the "HNDDAT*" and "WRKDAT*" parameters to be used using the "LoadSet" command in a program.

For more details, refer to the separate "Instruction Manual/Detailed Explanation of Functions and Operations." It is the same meaning as "LoadSet 0.0" if not using the "LoadSet".

<Factor default settings>

| | Hand mass kg | size X mm | size Y mm | size Z mm | center-of-gravity position X mm | center-of-gravity position Y mm | center-of-gravity position Z mm |
|----------------|-----------------|--------------|--------------|--------------|------------------------------------|------------------------------------|------------------------------------|
| RH-6FH series | | | | | | | |
| HNDDAT* | 6.0 | 99.0 | 99.0 | 76.0 | 0.0 | 0.0 | 38.0 |
| WRKDAT* | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| RH-12FH series | | | | | | | |
| HNDDAT* | 12.0 | 165.0 | 165.0 | 64.0 | 0.0 | 0.0 | 16.0 |
| WRKDAT* | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| RH-20FH series | | | | | | | |
| HNDDAT* | 20.0 | 165.0 | 165.0 | 109.0 | 0.0 | 0.0 | 37.0 |
| WRKDAT* | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |

Note) The position of the center of gravity is located at the center of the surface at the bottom of the shaft. Set the X, Y and Z center of gravity positions for the tool coordinate directions (the Z center of gravity position will be a plus for downward directions).

2.2.4 Vibrations at the Tip of the Arm during Low-Speed Operation of the Robot

Vibrations at the tip of the arm may increase substantially during the low-speed operation of the robot, depending on the combination of robot operation, hand mass and hand inertia. This problem occurs when the vibration count specific to the robot arm and the vibration count of the arm driving force are coming close to each other. These vibrations at the tip of the arm can be reduced by taking the following measures:

- 1) Change the robot's operating speed by using the Ovrd command.
- 2) Change and move the teaching points of the robot.
- 3) Change the hand mass and hand inertia.

2.2.5 Vibration of shaft (J3 axis) position and arm end

Vibrations at the tip of the arm may increase substantially during operation under the shaft position near the low end or the high end of the robot, depending on the combination of hand mass and hand inertia. This problem occurs according to that inertia, because the distance from the shaft support section to the shaft end becomes long. When this vibration affects the robot's operations, please change operating speed etc. like the above [Page 19, "2.2.4 Vibrations at the Tip of the Arm during Low-Speed Operation of the Robot"](#).

(1) Relationship Between Mass Capacity and Speed

A function to optimize the maximum speed of each axis according to the setting value of the load capacity will be activated (Refer to [Fig. 2-4](#)).

However, this function does not work with the following load mass:

RH-6FH/12FH series: 3kg or less

RH-20FH series: 5kg or less

When the setting of the load mass is changed to following, the maximum speed is compensated according to the load mass:

RH-6FH/12FH series: 3kg or heavier

RH-20FH series: 5kg or heavier

[CAUTION] Depending on the operation pattern, the speed and/or acceleration/deceleration at the front edge may not be parallel with the speed and the rate of change of acceleration/deceleration specified in a program.




Fig.2-4 : Automatic compensation of speed

(2) Relationship Between Height of Shaft (J3 Axis) and Acceleration/Deceleration Speed

A function to optimize the acceleration/deceleration speed according to the height of the shaft (Refer to Fig. 2-5, Fig. 2-6) will be activated. This function is invalid if the shaft (axis J3) operates at a position above P3 in Fig. 2-5. Acceleration/deceleration is compensated for at a position below P3 in Fig. 2-5 if the position of the center of gravity of the load is located at the front edge of the shaft.

This function contains both a standard acceleration and deceleration pattern and a high acceleration and deceleration pattern, both of which can be selected in the parameters. The original settings are set to the standard acceleration and deceleration pattern, which enables operation while keeping vibration at the shaft tip (including residual vibration) to a minimum. Users are also able to select the high acceleration and deceleration pattern and operate the robot at high speed. When doing so, users should make sure that additional vibration will not have a negative impact on work carried out by the robot. Where necessary the pattern should be changed, allowing the robot to be used in the most effective way.

The relevant parameter names and their set values are shown below. For more details about parameters and how to change them, please refer to the separate “Instruction Manual/Detailed Explanation of Functions and Operations”.

- Parameter name.....MAPMODE (acceleration and deceleration optimization pattern selected)
- Set value and function.....0: Standard acceleration and deceleration pattern (original setting)
- 1: High acceleration and deceleration pattern




Fig.2-5 : Area in which acceleration/deceleration speed is compensated


Table 2-5 : Area in which acceleration/deceleration speed is compensated

| Type | J3 axis stroke (mm) | | | Compensation area (P2 to P3) |
|---------------------------------|---------------------|---------------|---------------|------------------------------|
| | Stroke length | P1(Upper end) | P2(Lower end) | |
| RH-6FH series ^{Note1)} | 340 | 333 | -7 | -7 to 133 |
| RH-12FH/20FH series | 350 | 340 | -10 | -10 to 240 |
| | 450 | 340 | -110 | -110 to 155 |


Note1) When stroke of J3 axis is 200mm this function is not operate.

RH-6FH series

J3 axis (Z) stroke 340mm
(Standard Acceleration/deceleration speed)




J3 axis (Z) stroke 340mm
(High acceleration and deceleration rate)




RH-12FH series

J3 axis (Z) stroke 350/450mm
(Standard Acceleration/deceleration speed)




J3 axis (Z) stroke 350/450mm
(Standard Acceleration/deceleration speed)



RH-20FH series

J3 axis (Z) stroke 350/450mm
(Standard Acceleration/deceleration speed)



J3 axis (Z) stroke 350/450mm
(Standard Acceleration/deceleration speed)




Fig.2-6 : Automatic compensation of acceleration/deceleration speed

(3) Relation between offset length and the maximum speed




Fig.2-7 : Relationship of the offset length and maximum velocity

[Supplementary explanation 1]: The setting which shortens execution time

The execution time can be improved by using the following methods.

- 1) Perform continuous path operation using the Cnt command.
- 2) Control the optimum acceleration/deceleration using the Oadl command.
- 3) Control the optimum speed using the Spd command.
- 4) Setting a larger value in the optimum acceleration/deceleration adjustment rate parameter: JADL. (Maximum 100)

The moving time can be shortened by setting a larger value in the optimum acceleration/deceleration adjustment rate parameter (JADL). In this robot, the acceleration/deceleration speed is initialized to allow continuous moving with a short wait time (setting of B in the Fig. 2-8).

This setting is suited for continuous operations that have a short tact time, such as palletizing work.

Conversely, if quick moves (short moving time) are required, such as L/UL work on machined parts, the acceleration/deceleration speed can be increased by initial setting (setting of A in the Fig. 2-8).

However, please note that some setting values of acceleration/deceleration speed tend to cause overload and overheat errors. In such a case, extend the wait time, reduce the acceleration/deceleration speed, or decrease the moving speed.




Fig.2-8 : Relationship between Acceleration/deceleration Speed and Tact Time (Conceptual Drawing)

(4) Time to reach the position repeatability

When using this robot, the time to reach the position repeatability may be prolonged due to the effect of residual vibration at the time of stopping. If this happens, take the following measures:

- 1) Change the operation position of the Z axis to the location near the top as much as possible.
- 2) Increase the operation speed prior to stopping.
- 3) When positioning the work near the bottom edge of the Z axis, if no effectiveness is achieved in step ② above, perform operation ① (robot path: O → A → C). In the case of operation 2 (robot path: O → B → C), residual vibration may occur. (Refer to Fig. 2-9.)




Fig.2-9 : Recommended path when positioning at the bottom edge of the Z axis

2.2.6 Collision detection

This series have the "collision detection function" which detects the abnormalities by the collision of the robot arm, and the initial setting has set this function as the enable to suppress damage to the minimum. Although the enable/disable of this function can be changed by parameter: COL and command: ColChk, you should use in valid condition of this function for protection of the robot and of the peripheral equipment.

The abnormalities are detected by the robot's kinetics model, presuming torque necessary for movement at any time. Therefore, the setting parameter (HNDDAT*, WRKDAT*) of the hand and the work piece conditions should be right. And, it may be detected as the collision in movement as speed and motor torque are changed rapidly. (for example, the movement near the place of the origin by linear interpolation, the reversal movement, the cold condition, the operation after long term stoppage)

In such a case, by adjusting the value of the setting parameter (COLLVL, COLLVLJG) of the collision detection level according to actual use environment, the sensitivity of collision detection can be optimized and the damage risk can be reduced further. And, in the operation after the low temperature or long term stoppage, please operate by accustoming at low speed (warm-up), or use the warm-up operation mode.

Refer to the separate instruction manual "Detailed explanations of functions and operations" for details of related parameter.

Table 2-6 : Factory-shipments condition

| | JOG operation | Automatic |
|-------------------------|---------------|-----------|
| RH-6FH/12FH/20FH series | Valid | Invalid |

2.2.7 Protection specifications

(1) Types of protection specifications

The robot arm has protection specifications that comply with the IEC Standards. The protection specifications and applicable fields are shown in [Table 2-7](#).

Even oil mist environment can be used in addition to the general environment.

Table 2-7 : Protection specifications and applicable fields

| Type | Protection specifications (IEC Standards value) | Classification | Applicable field | Remarks |
|--|--|--|---|---|
| RH-6FHxx20/xx34 RH-12FHxx35/xx45 RH-20FHxx35/xx45 | Robot arm: IP20 | General-purpose environment specifications | General assembly Slightly dusty environment | |
| RH-6FHxx20M/xx34M RH-6FHxx20-SM/xx34-SM Note1) RH-12FHxx35M/xx45M RH-12FHxx35M-SM/ xx45M-SM Note1) RH-20FHxx35M/xx45M RH-20FHxx35M-SM/ xx45M-SM Note1) | Robot arm: IP65 (Direct jet flow to the bellows section is not included.) | Oil mist specifications | Machine tool (cutting) Machine shop with heavy oil mist Dusty work shop | Note that if the cutting machine is using abrasive materials, the robot's life will be shortened. |
| RH-6FHxx20-S15/xx34-S15 | Robot arm: IP54 (Direct jet flow to the bellows section is not included.) | CE marking specifications | Machine tool (cutting) Machine shop with heavy oil mist Dusty work shop | Note that if the cutting machine is using abrasive materials, the robot's life will be shortened. |

Note1) The "-SM" specification comes with the controller protection box (CR750-MB) as standard.



CAUTION

Use the controller protection box to protect the controller from the environment when the controller will be used in the environment such as the oil mist shown in the [Table 2-7](#).

The IEC IP symbols define the degree of protection against solids and fluids, and do not indicate a protective structure against the entry of oil or water.

The IEC standard is described by the following "Information" And, the corrosion of the rust etc. may occur to the robot with the liquids, such as the water and the oil.

【Information】

- The IEC IP20

It indicates the protective structure that prevents an iron ball $12^{+0.05}_0$ mm diameter, which is being pressed with the power of $3.1 \text{ kg} \pm 10\%$, from going through the opening in the outer sheath of the supplied equipment.

- The IEC IP54

The IEC IP54 standard refers to protection structure designed to prevent any harmful effects by fresh water scattering vertically onto the testing equipment in a radius of 180 degrees from a distance of 300 to 500 mm, with 10 ± 0.5 liters of water every minute, at a water pressure of 80 to 100kPa, covering the entire area of the robot with the exception of the installation section at 1 m^2 per minute, for a total of 5 minutes or more.

- The IEC IP65

Protection against water infiltration as specified in IP65 indicates a protective structure that is not harmfully affected when $12.5 \pm 5\%$ liters of water is supplied from a test device at a position approx. 3m away in various directions and a water pressure of 30kPa at the nozzle section. The water is filled one minute per 1 m^2 of test device surface area for a total of three minutes.

(2) About the use with the bad environment

The protection specifications robot has protection methods that conform to IEC's IP65 standards. (Direct jet flow to the bellows section is not included.)

It has protection structure designed to prevent harmful effects caused by splashing water coming from various directions, as the robot is operating. (Direct jet flow to the bellows section is not included.)

Recommended usage conditions

- 1) The robot is designed for use in combination with machining device.
- 2) Robot's protection performance can be improved by pressurizing its interior. If you use a robot in an environment where oil mist is present, it is recommended that the interior of the robot be pressurized to ensure its reliability over a long period of time. Use the provided $\phi 8$ joint (AIR PURGE) to supply dry air for pressurizing. The $\phi 8$ joint (AIR PURGE) can be found at the base rear part of the robot arm.

Table 2-8 : Specification of the dry air for pressurization

| Item | Dew point | Pressure |
|---------------|--|-----------|
| Specification | The atmospheric pressure dew point is - 20 degree or less. | 0 to 3kPa |

- 3) We are confirming examining with the cutting oil, and satisfying protection specification. Our warranty does not cover damages or failure resulting from the robot being operated in any environment where other cutting oils than those listed in the table are used (except cutting oils with respect to which the robot's compatibility with the protection specification is verified through our operability evaluation) or where the robot body may be directly splashed with water, oil or dust in quantities larger than stated in the protection specification.
- 4) Take measures so that the robot will not be exposed to water, oil and/or chips for a long period of time.
- 5) The packing gets deteriorated with the passage of time and must be replaced as required. [Table 2-9](#) provides guidelines for replacing the packing.

Table 2-9 : Packing replacement guideline

| Environment | Whether or not robot is pressurized | When packing must be replaced |
|---------------------|-------------------------------------|---|
| General environment | Not pressurized ^{Note1)} | When signs of cracking or peeling are noted in the packing. |
| Clean room | Not pressurized ^{Note1)} | |
| Oil mist | Pressurized | |
| | Not pressurized | When removing and installing the cover. |

Note1) The pressurization inside the robot arm is unnecessary in general environment and clean room environment.

Failure to replace deteriorated packing permits water or oil to enter the interior of the robot, possibly causing it to become inoperable.

Packing required and liquid gasket used therewith are available from dealer.

Also, entrained water droplets lead to the formation of rust on the robot, but would not usually affect the robot's ability to operate normally.

The warranty is invalid for any faults that occur when the robot is used under the following conditions.

Also, if the cover and/or other parts are damaged by interferences caused by the peripheral devices and the robot, the protection specification (seal performance, etc.) may be degraded. Therefore, please pay extra attention when handling the robot.

Refer to [Page 157, "6.2 Working environment"](#).

- 1) In surroundings that generate inflammable gases or corrosive gasses.
- 2) Atmosphere of the mist containing polish liquid etc.
- 3) Atmosphere in which the water, the oil, and the dust exceeding protection specification fall on the robot arm directly.
- 4) Pressurization by the dry air exceeding the specification of [Table 2-8](#).

2.2.8 Clean specifications

(1) Types of clean specifications

The robot arm with clean specification is made by order. Please check the delivery schedule.

Table 2-10 : Clean specifications

| Type | Degree of cleanliness | Internal suction | Remarks |
|---|-------------------------------|---|--|
| RH-6FHxx20C/xx34C RH-12FHxx35C/xx45C RH-20FHxx35C/xx45C | ISO class 3 ^{Note1)} | <ul style="list-style-type: none"> • Suck the inside of robot arm with vacuum pump. (prepared by customer) • Use it in the clean room with the down flow (flow velocity 0.3 m/s above). | The use of a vacuum generating valve is recommended. |

Note1) The conditions necessary to guarantee cleanliness are as follows: clean room down flow 0.3 m/s or greater, robot internal suction of RH-6FH series: 30-50L/min, RH-12FH/20FH series: 60-140L/min, and installation of an exhaust duct at the rear of the robot's main base. A $\phi 8$ joint is prepared at the rear of the base for suction.

■ Precautions for use

- 1) A $\phi 8$ VACUUM coupling is provided in the base section of the robot arm for vacuum inside the robot arm. (Refer to Fig. 2-48) When using the robot, connect this coupling with the vacuum generating valve (Refer to Table 2-11) and vacuum pump (furnished by the customer).
- 2) To suck in the robot arm, use the vacuum generator of the specification shown in following a) and b).
 - a) When using the vacuum generator

Table 2-11 : Specifications of vacuum generation valve (Confirmed in our company)

| Type | Maker | Air pressure ^{Note1)} | Quantity |
|---------|---------------------|--------------------------------|--|
| MEDT 14 | KONEGAI CORPORATION | • Vacuum rate: 90.0 L/min(ANR) | RH-6FH series : 1 RH-12FH/20FH series : 2 |

Note1) It is the vacuum pump maker's written specification.

- b) When using the vacuum pump

Assure the vacuum flow rate of RH-6FH series: 30-50L/min and of RH-12FH/20FH series: 60-140L/min. And, secure the exhaust course from the pump not to affect the power supply and the cleanness for the vacuum pumps. RH-12FH/20FH has two VACUUME couplings. Please be sure to suck in using both of couplings.

- 3) Remove the CONBOX cover on the robot arm rear and install the attached ventilation duct (refer to Fig. 2-10). As the Z axis moves up and down the volume of the bellows varies, and air is sucked in and released out of the robot's ventilation duct opening. Be sure to locate the ventilation duct's opening in a position that will not affect the robot's cleanliness.

Furthermore, whilst it is only a small amount, internal suction results in external air flowing into the robot through the ventilation duct's opening, and therefore the following two points should be considered when deciding where to locate the ventilation duct's opening.

- The opening should be facing downwards
- The opening should not be located in the vicinity of dust/dirt or liquids, etc.

(Recommended cleanliness of surrounding area: less than ISO class 5)




Fig.2-10 : Installation of Exhaust Duct

- 4) When using the optional electromagnetic valve set, we recommend using the primary piping's spare piping ($\phi 6$ air hose) to release the exhaust fumes.

Please take care as leaking exhaust fumes inside the robot may have an impact on the robot's cleanliness.

2.3 Names of each part of the robot



Fig.2-11 : Names of each part of the robot

2.4 Outside dimensions • Operating range diagram

2.4.1 Outside dimensions • Operating range diagram (RH-6FH series)

(1) Standard Specification




Fig.2-12 : Outside dimensions of RH-6FH35xx





Fig.2-13 : Operating range diagram of RH-6FH35xx

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes (M4 depth 6mm) for fixing user wiring/piping. Six places on both-sides of No.2 arm, Two places on front surface.
- *3) Minimum radius of bending the machine cable.



Note) Refer to Fig. 2-44 for the mechanical interface section and installation base section dimensions.

Fig.2-14 : Outside dimensions of RH-6FH45xx





Fig.2-15 : Operating range diagram of RH-6FH45xx

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes (M4 depth 6mm) for fixing user wiring/piping. Six places on both-sides of No.2 arm, Two places on front surface.
- *3) Minimum radius of bending the machine cable.



Note) Refer to Fig. 2-44 for the mechanical interface section and installation base section dimensions.

Fig.2-16 : Outside dimensions of RH-6FH55xx




Fig.2-17 : Operating range diagram of RH-6FH55xx

(2) Clean Specification and oil mist specification

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes (M4 depth 6mm) for fixing user wiring/piping. Six places on both-sides of No.2 arm. Two places on front surface.
- *3) The duct ($\phi 25$, length: 3m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.




Fig.2-18 : Outside dimensions of RH-6FH35xxC/M




Fig.2-19 : Operating range diagram of RH-6FH35xxC/M

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes (M4 depth 6mm) for fixing user wiring/piping. Six places on both-sides of No.2 arm, Two places on front surface.
- *3) The duct ($\phi 25$, length: 3m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.




Fig.2-20 : Outside dimensions of RH-6FH45xxC/M




Fig.2-21 : Operating range diagram of RH-6FH45xxC/M

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes (M4 depth 6mm) for fixing user wiring/piping. Six places on both-sides of No.2 arm, Two places on front surface.
- *3) The duct ($\phi 25$, length: 3m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.




Fig.2-22 : Outside dimensions of RH-6FH55xxC/M




Fig.2-23 : Operating range diagram of RH-6FH55xxC/M

2.4.2 Outside dimensions • Operating range diagram (RH-12FH series)

(1) Standard Specification




Fig.2-24 : Outside dimensions of RH-12FH55xx





Fig.2-25 : Operating range diagram of RH-12FH55xx

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes for fixing user wiring/piping. (Refer to Fig. 2-49)
- *3) Minimum radius of bending the machine cable.
- *4) Required space to installing/removing the cover.



Note) Refer to Fig. 2-45 for the mechanical interface section and installation base section dimensions.

Fig.2-26 : Outside dimensions of RH-12FH70xx




Fig.2-27 : Operating range diagram of RH-12FH70xx




Fig.2-29 : Operating range diagram of RH-12FH85xx

(2) Clean Specification and oil mist specification




Fig.2-30 : Outside dimensions of RH-12FH55xxC/M





Fig.2-31 : Operating range diagram of RH-12FH55xxC/M

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes for fixing user wiring/piping. (Refer to Fig. 2-49)
- *3) Minimum radius of bending the machine cable.
- *4) Required space to installing/removing the cover.
- *5) The duct (φ 50, length: 2m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.



Note) Refer to Fig. 2-45 for the mechanical interface section and installation base section dimensions.

Fig.2-32 : Outside dimensions of RH-12FH70xxC/M





Fig.2-33 : Operating range diagram of RH-12FH70xxC/M

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes for fixing user wiring/piping. (Refer to Fig. 2-49)
- *3) Minimum radius of bending the machine cable.
- *4) Required space to installing/removing the cover.
- *5) The duct (φ 50, length: 2m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.



Note) Refer to Fig. 2-45 for the mechanical interface section and installation base section dimensions.

Fig.2-34 : Outside dimensions of RH-12FH85xxC/M




Fig.2-35 : Operating range diagram of RH-12FH85xxC/M

2.4.3 Outside dimensions • Operating range diagram (RH-20FH series)

(1) Standard Specification




Fig.2-36 : Outside dimensions of RH-20FH85xx





Fig.2-37 : Operating range diagram of RH-20FH85xx

Note

- *1) Indicates the space necessary to replace the battery.
- *2) Indicates screw holes for fixing user wiring/piping. (Refer to Fig. 2-49)
- *3) Minimum radius of bending the machine cable.
- *4) Required space to installing/removing the cover.



Note) Refer to Fig. 2-46 for the mechanical interface section and installation base section dimensions.

Fig.2-38 : Outside dimensions of RH-20FH100xx




Fig.2-39 : Operating range diagram of RH-20FH100xx

(2) Clean Specification and oil mist specification




Fig.2-40 : Outside dimensions of RH-20FH85xxC/M




Fig.2-41 : Operating range diagram of RH-20FH85xxC/M

Note


*1) Indicates the space necessary to replace the battery.

*2) Indicates screw holes for fixing user wiring/piping. (Refer to Fig. 2-49)

*3) Minimum radius of bending the machine cable.

*4) Required space to installing/removing the cover.

*5) The duct (φ 50, length: 2m) attached to the clean specification. Be careful for the hand etc. not to interfere and arrange the duct.



Note) Refer to Fig. 2-46 for the mechanical interface section and installation base section dimensions.

Fig.2-42 : Outside dimensions of RH-20FH100xxC/M




Fig.2-43 : Operating range diagram of RH-20FH100xxC/M

2.4.4 Mechanical interface and Installation surface

(1) Mechanical interface and Installation surface of RH-6FH series




Fig.2-44 : Mechanical interface and Installation surface (RH-6FH series)

(2) Mechanical interface and Installation surface of RH-12FH series




Fig.2-45 : Mechanical interface and Installation surface of RH-12FH series

(3) Mechanical interface and Installation surface of RH-20FH series




Fig.2-46 : Mechanical interface and Installation surface of RH-20FH series

2.4.5 Change the operating range

The operating ranges of J1 axis can be limited. Change the mechanical stopper and the operating range to be set inside of that area.

If the operating range must be limited to avoid interference with peripheral devices or to ensure safety, set up the operating range as shown below.

(1) Operating range changeable angle

The operating range must be set up at angles indicated by [Table 2-12](#).

Table 2-12 : Operating range changeable angle

| | Type ^{Note1)} | Direction ^{Note2)} | Standard | Change angle ^{Note3)} ^{Note4)} | |
|---------------------|---------------------------------------|-----------------------------|------------|--|------------|
| RH-6FH series | | | | | |
| J1 | RH-6FH35*/45*/55* | + side | +170 deg | +150 deg | +130 deg |
| | | Mechanical stopper angle | +172.3 deg | +152.3 deg | +132.3 deg |
| | | Mechanical stopper position | P10 | P11 | P12 |
| | | - side | -170 deg | -150 deg | -130 deg |
| | | Mechanical stopper angle | -172.3 deg | -152.3 deg | -132.3 deg |
| | | Mechanical stopper position | P10 | N11 | N12 |
| RH-12FH/20FH series | | | | | |
| J1 | RH-12FH55*/70*/85* RH-20FH85*/100* | + side | +170 deg | +150 deg | +130 deg |
| | | Mechanical stopper angle | +173.3 deg | +153.3 deg | +133.3 deg |
| | | Mechanical stopper position | P10 | P11 | P12 |
| | | - side | -170 deg | -150 deg | -130 deg |
| | | Mechanical stopper angle | -173.3 deg | -153.3 deg | -133.3 deg |
| | | Mechanical stopper position | P10 | N11 | N12 |

Note1) The "*" of the robot type indicates up/down stroke length and environment specification. It is possible to change the movement ranges shown in [Table 2-12](#) for any model.

Note2) Refer to [Fig. 2-44](#) for mechanical stopper position.


Note3) The changeable angle shown in [Table 2-12](#) indicates the operation range by the software. The mechanical stopper angle in the table shows the limit angle by the mechanical stopper. Use caution when layout designing of the robot.

Note4) The changeable angle can be set independently on the + side and - side.

(2) The change method of the operating range

■ Installation of the mechanical stopper

- 1) Turn off power to the controller.
- 2) Install the hexagon socket bolt in the screw hole to the angle to set up referring to [Table 2-12](#) and [Fig. 2-47](#). About the mechanical stopper position and the relation of bolt size is shown in [Fig. 2-47](#). When the screw hole is covered by the arm, move the No.1 armslowly by hand.



Installation bolt:

Hexagon socket head cap screw

- RH-6FH series: M10 x 20
- RH-12FH/20FH series: M12 x 20

* Changing the operating range is prepared optional.

Fig.2-47 : Mechanical stopper position

■ Change the operating range parameters

Specify the operating range to parameters MEJAR with appropriate values (variable angles given in [Table 2-12](#)) by the following steps:

- 1) Turn on power to the controller.
- 2) Set up the operating range changed into parameter MEJAR
MEJAR: (J1 minus (-) side, J1 plus (+) side, □ , □ , □ , ...).

■ Change the mechanical stopper origin position parameters

If you have changed operating range on the J1 minus(-) side, change mechanical stopper origin position parameters by the following step:

- 1) Set MORG parameter to the angle which set mechanical stopper position.
MORG: (J1 mechanical stopper position, □ , □ , □ , ...).

■ Check the operating range

After changing the parameter, turn off the controller power and turn on again. Then, move the axis changed by joint jog operation to the limit of the operating range.

Confirm that the robot stops by limit over at the changed angle.

This completes the procedure to change the operating range.

2.5 Tooling

2.5.1 Wiring and piping for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-48 : Wiring and piping for hand

2.5.2 Internal air piping

(1) Standard type/Oil mist specifications

- 1) The robot has two $\phi 6 \times 4$ urethane hoses from the pneumatic entrance on the base section to the No.2 arm. The base and No.2 arm sides of the hose end are two air joints for $\phi 6$ hoses.
- 2) The solenoid valve set (optional) can be installed to the side on No.2 arm.
- 3) Refer to [Page 84, "\(3\) Solenoid valve set"](#) for details on the electronic valve set (optional).
- 4) Protection performance can be improved by pressurizing the inside of the robot arm. Since the joint (AIR PURGE) of $\phi 8$ is prepared at the rear of the base section, please supply the dry air for pressurization from this joint. Refer to [Page 25, "2.2.7 Protection specifications"](#) for the details of dry air.

(2) Clean type

- 1) The clean specification basically includes the same piping as the standard type.
- 2) With the clean specification, a $\phi 8$ coupling is provided in the base section for suction inside the machine. For use, connect it to the suction port of the vacuum pump or the coupling on the "VACUUM" side of the vacuum generating valve. Moreover, to clean the exhaust from the vacuum pump or vacuum generator, use the exhaust filter (prepared by the customer).
- 3) Refer to [Page 27, "2.2.8 Clean specifications"](#) for details of the vacuum for suction.
- 4) Supply clean air to the vacuum generator.

2.5.3 Internal wiring for the hand output cable

- 1) The hand output primary cable extends from the connector PCB of the base section to the back side of the No.2 arm. (AWG#24(0.2mm²)) The cable terminals have connector bridges for eight hand outputs. The connector names are GR1 and GR2.
To pull the wiring out of the arm, following separate options are required.
 - Hand output cable 1F-GR60S-01
 - External wiring and piping box 1F-UT-BOX (RH-6FH series)
1F-UT-BOX-01 (RH-12FH/20FH series)

2.5.4 Internal wiring for the hand input cable

- 1) The hand input cable extends from the connector PCB of the base section to the No.2 arm. (AWG#24(0.2mm²)x 2: 12 cables) The cable terminals have connector bridges for eight hand inputs. The connector names are HC1 and HC2.
- 2) The hand check signal of the pneumatic hand is input by connecting this connector. To extend the wiring to the outside of the arm, following separate options are required.
 - Hand input cable 1F-HC35C-01 (RH-6FH series)
1F-HC35C-02 (RH-12FH/20FH series)
 - External wiring and piping box 1F-UT-BOX (RH-6FH series)
1F-UT-BOX-01 (RH-12FH/20FH series)

2.5.5 Ethernet cable

Ethernet cables are installed from the robot's base section up to the No. 2 arm section, and can be used. Similar to on our previous models, these cables can also be used for backup wiring. For further details please refer to the separate "Instruction Manual/Robot Arm Setup".

Example of use for backup wiring.

- When connecting previously used tools to the robot
- Folding back the hand output cable when attaching the electromagnetic valve to the robot's exterior.
- When attaching 8 devices or more to the hand section such as sensors, (8 input and 8 output dedicated points are available for hand signals.). In this case connect the signals (of the sensors, etc.) to parallel input/output signals.

When shipped from the factory, both ends are LAN connectors.

When using as back up wiring, cut the LAN connectors off and use with user supplied connectors.

Table 2-13 : Ethernet cable specification

| Item | Specification |
|--------------------------|--|
| Communication speed | 100BASE-TX |
| Size | AWG #26 (0.13mm ²) x four pair (total eight cores) |
| Externality of insulator | Approx. 0.98 mm |

2.5.6 About the Installation of Tooling Wiring and Piping (Examples of Wiring and Piping)

The customer is required to provide tooling wiring, piping and metal fixtures.

Screw holes are provided on the robot arm for the installation of tooling wiring, piping and metal fixtures. (Refer to the Fig. 2-49.)

The length of wiring and piping and the installation position on the robot must be adjusted according to the work to be done by the robot. Please use the following example as reference.

- A hand input cable and a hand curl cable are available as optional accessories for your convenience.
 - After performing wiring and piping to the robot, operate the robot at low speed to make sure that each part does not interfere with the robot arm and the peripheral devices.
- Confirm that there is no interference also with bellows of the shaft section by clean specification and oil mist specification.
- Please be aware that dust may be generated from friction if wires and pipes come into contact with the robot arm when using it according to the clean specifications.

(1) RH-6FH series




Fig.2-49 : Location of screw holes for fixing wiring/piping (RH-6FH)

(2) RH-12FH/20FH series




Fig.2-50 : Location of screw holes for fixing wiring/piping (RH-12FH/20FH)

(3) Example of wiring and piping <1>

By feeding wiring and piping through the inside of the shaft, the wiring and piping to the hand becomes compact.

<RH-6FH series>




Fig.2-51 : Example of wiring and piping <1> (RH-6FH series)

<RH-12FH/20FH series>




Fig.2-52 : Example of wiring and piping <1> (RH-12FH/20FH series)

(4) Wiring and piping example <2>

This is an effective method in cases where the wiring and piping is often changed, or when the hand rotation is minimal (within $\pm 90^\circ$), etc.




Fig.2-53 : Example of wiring and piping <2>

(5) Precautions for the clean specification

The top and bottom parts of the through hole of the tip shaft are taped at shipment.

Perform the following actions as necessary in order to ensure that the robot is sufficiently clean during the operation:

- 1) When the through hole of the shaft is not used
 - Keep the tip shaft taped while the robot is in use.
- 2) When the through hole of the shaft is used for wiring.
 - Peel the tape of the tip shaft off and perform the necessary wiring. Once the wiring is completed, seal the tip shaft using liquid seal in order to avoid accumulation of dust.
 - Perform the wiring in such a way that the wires around the area below the tip shaft will not get into contact with other parts while the robot is operating.

2.5.7 Wiring and piping system diagram for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-54 : Wiring and piping system diagram for hand and example the solenoid valve installation (Sink type)




Fig.2-55 : Wiring and piping system diagram for hand and example the solenoid valve installation (Source type)

2.5.8 Electrical specifications of hand input/output

Table 2-14 : Electrical specifications of input circuit





| Item | | Specifications | Internal circuit |
|-------------------------|--------|---|---|
| Type | | DC input | <p><Sink type></p>  <p><Source type></p>  <p>* HCn = HC1 to HC8</p> |
| No. of input points | | 8 | |
| Insulation method | | Photo-coupler insulation | |
| Rated input voltage | | 24VDC | |
| Rated input current | | approx. 7mA | |
| Working voltage range | | DC10.2 to 26.4V (ripple rate within 5%) | |
| ON voltage/ON current | | 8VDC or more/2mA or more | |
| OFF voltage/OFF current | | 4VDC or less/1mA or less | |
| Input resistance | | Approx. 3.3kΩ | |
| Response time | OFF-ON | 10ms or less (DC24V) | |
| | ON-OFF | 10ms or less (DC24V) | |

Table 2-15 : Electrical specifications of output circuit

| Item | | Specification | Internal circuit |
|------------------------------------|--------|---|---|
| Type | | Transistor output | <p><Sink type></p>  <p><Source type></p>  <p>* GRn = GR1 to GR8</p> |
| No. of output points | | 8 | |
| Insulation method | | Photo coupler insulation | |
| Rated load voltage | | DC24V | |
| Rated load voltage range | | DC21.6 to 26.4VDC | |
| Max. current load | | 0.1A/ 1 point (100%) | |
| Current leak with power OFF | | 0.1mA or less | |
| Maximum voltage drop with power ON | | DC0.9V(TYP.) | |
| Response time | OFF-ON | 2ms or less (hardware response time) | |
| | ON-OFF | 2 ms or less (resistance load) (hardware response time) | |
| Protects | | Protects the over-current (0.9A) | |

2.5.9 Air supply circuit example for the hand

Fig. 2-56 shows an example of pneumatic supply circuitry for the hand.

- (1) Place diodes parallel to the solenoid coil.
- (2) When the factory pneumatic pressure drops, as a result of the hand clamp strength weakening, there can be damage to the work. To prevent it, install a pressure switch to the source of the air as shown in Fig. 2-56 and use the circuit described so that the robot stops when pressure drops. Use a hand with a spring-pressure clamp, or a mechanical lock-type hand, that can be used in cases where the pressure switch becomes damaged.
- (3) The optional hand and solenoid valve are of an oilless type. If they are used, don't use any lubricator.
- (4) Supply clean air to the vacuum generation valve when you use clean type robot.
- (5) If the air supply temperature (primary piping) used for the tool etc. is lower than ambient air temperature, the dew condensation may occur on the coupling or the hose surface.




Fig.2-56 : Air supply circuit example for the hand

2.6 Shipping special specifications, options, and maintenance parts

2.6.1 Shipping special specifications

■ What are shipping special specifications?

Shipping special specifications are changed before shipping from the factory. Consequently, it is necessary to confirm the delivery date by the customer.

To make changes to the specifications after shipment, service work must be performed at the work site or the robot must be returned for service.


■ How to order

- (1) Confirm beforehand when the factory special specifications can be shipped, because they may not be immediately available.
- (2) Specify, before shipping from our company.
- (3) Specified method ····· Specify the part name, model, and robot model type.

(1) Machine cable

■ Order type : ● Fixed type.....1S-02UCBL-01 (2m)

■ Outline



This cable is exchanged for the machine cable (5 m for fixed type) that was supplied as standard to shorten the distance between the controller and the robot arm.

■ Configuration

Table 2-16 : Configuration equipment and types

| Part name | | Type | Qty. | Mass (Kg) ^{Note1)} | Remarks ^{Note2)} |
|-----------|--------------------------------|---------------|-----------|-----------------------------|---------------------------|
| Fixed | Set of signal and power cables | 1S-02UCBL-01 | 1 set | 2.6 | 2m |
| | Motor signal cable | BKO-FA0741H02 | (1 cable) | - | |
| | Motor power cable | BKO-FA0739H02 | (1 cable) | - | |

Note1) Mass indicates one set.

Note2) Standard 5 m (for fixed type) is not attached.

[Caution] Orders made after purchasing a robot are treated as purchases of optional equipment. In this case, the machine cable (5 m for fixed type) that was supplied as standard is not reclaimed.

2.7 Options

■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for customer needs. customer installation is required for the options. Options come in two types: "set options" and "single options".


1. Set optionsA combination of single options and parts that together, from a set for serving some purpose.
2. Single optionsThat are configured from the fewest number of required units of a part. Please choose customer's purpose additionally.

(1) Machine cable extension

- Order type:
 - Fixed type.....1S- □□ CBL-01(extension type)
 - Flexed type1S- □□ LCBL-01(extension type)
 - 1S- □□ LUCBL-01(direct type)

Note) The numbers in the boxes □□ refer the length.

■ Outline



The distance between the robot controller and the robot arm is extensible by this option.

A fixed type and flexible type are available.

The extended method is discriminated as follows.

Fixed type ▪ Adds to the machine cable attached in the standards.

Flexed type..... ▪ Adds to the machine cable attached in the standards.

▪ Exchanges with the machine cable attached in the standards.

The fix and flexible types are both configured of the motor signal cable and motor power cable.

■ Configuration

Table 2-17 : Configuration equipment and types

| Part name | Type ^{Note1)} | Qty. | | | Mass (kg) ^{Note2)} | Remarks |
|----------------|--------------------------------|------------------------------|-------------------------------|----------------------------|--------------------------------|------------------------|
| | | Fixed (extension type) | Flexed (extension type) | Flexed (direct type) | | |
| Fixed | Set of signal and power cables | 1S- □□ CBL-01 | 1 set | - | - | 5m, 10m, or 15m each |
| | Motor signal cable | 1S- □□ CBL(S)-01 | (1 cable) | - | - | |
| | Motor power cable | 1S- □□ CBL(P)-01 | (1 cable) | - | - | |
| Flexed | Set of signal and power cables | 1S- □□ LCBL-01 | - | 1 set | - | 5m, 10m, or 15m each |
| | Motor signal cable | 1S- □□ LCBL(S)-01 | - | (1 cable) | - | |
| | Motor power cable | 1S- □□ LCBL(P)-01 | - | (1 cable) | - | |
| Flexed | Set of signal and power cables | 1S- □□ LUCBL-01 | - | - | 1 set | 5m, 10m, or 15m each |
| | Motor signal cable | 1S- □□ LUCBL(S)-01 | - | - | (1 cable) | |
| | Motor power cable | 1S- □□ LUCBL(P)-01 | - | - | (1 cable) | |
| Nylon clamp | NK-14N | - | 2 pcs. | 2 pcs. | - | for motor signal cable |
| Nylon clamp | NK-18N | - | 2 pcs. | 2 pcs. | - | for motor power cable |
| Silicon rubber | | - | 4 pcs. | 4 pcs. | - | |

Note1) The numbers in the boxes □□ refer the length.

Note2) Mass indicates one set.

■ Specifications

The specifications for the fixed type cables are the same as those for standard cables.
Shows usage conditions for flexed type cables in [Table 2-18](#).

Table 2-18 : Conditions for the flexed type cables

| Item | | Specifications |
|-----------------------------------|--------------------|---|
| Minimum flexed radius | | 100R or more |
| Cableveyor, etc., occupation rate | | 50% or less |
| Maximum movement speed | | 2,000mm/s or less |
| Guidance of life count | | 7.5 million times |
| Environmental proof | | Oil-proof specification sheath (for silicon grease, cable sliding lubricant type) IP54 |
| Cable configuration | Motor signal cable | $\phi 6 \times 5$, $\phi 8.5 \times 1$ and $\phi 1.7 \times 1$ |
| | Motor power cable | $\phi 8.9 \times 3$ and $\phi 6.5 \times 6$ |

[Caution] The guidance of life count may greatly differ according to the usage state (items related to [Table 2-18](#) and to the amount of silicon grease applied in the cableveyor.

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

■ Cable configuration

The configuration of the flexible cable is shown in [Table 2-19](#). Refer to this table when selecting the cableveyor.
The configuration is the same between the length difference in the cable, and extension type / direct type.


Table 2-19 : Cable configuration (Flexed type)

| Item | Motor signal cable | | | Motor power cable | |
|--------------------|------------------------------------|------------------------------------|----------------------------------|-------------------------------------|-------------------------------------|
| | AWG#24 (0.2mm ²)-4P | AWG#24 (0.2mm ²)-7P | AWG#18 (0.75mm ²) | AWG#16 (1.25mm ²)-4C | AWG#18 (0.75mm ²)-4C |
| Finish dimensions | Approx. $\phi 6$ mm | Approx. $\phi 8.5$ mm | Approx. $\phi 1.7$ mm | Approx. $\phi 8.9$ mm | Approx. $\phi 6.5$ mm |
| No. of cables used | 5 cables | 1 cable | 1 cable | 3 cable | 6 cable |
| No. in total | 7 cables | | | 9 cables | |

Note) The square in the cable name indicates the cable length.

■ Fixing the flexible cable

- (1) Connect the connector to the robot arm.
- (2) Wind the silicon rubber around the cable at a position 300 to 400 mm from the side of robot arm and extension section as shown in Fig. 2-57, and fix with the nylon clamp to protect the cable from external stress.



CAUTION Cover the extension terminal area with the cover etc. so that it may not be easily touched to the latch lever.

Note1) When direct type, exchanges with the standard cable and connect directly.

Note2) Although the picture is the CR751-D controller, also the connection method is the same in the CR751-Q controller.




Fig.2-57 : Fixing the flexible cable

(2) Changes J1 axis operating range

- Order type: RH-6FH seriesJ1 axis: 1F-DH-01
 RH-12FH/20FH seriesJ1 axis: 1F-DH-02

■ Outline



The operating range of J1 axis is limited by the robot arm's mechanical stopper and the controller parameters.
 If the axis could interfere with the peripheral devices, etc., and the operating range need to be limited, use this.

■ Configuration

Table 2-20 : Configuration devices

| Part name | Type | Qty. | Mass(kg) | Remarks |
|--|----------|-------|----------|--|
| RH-6FH series | | | | |
| Stopper for changing the operating range | 1F-DH-01 | 1 set | 0.05 | hexagon socket head bolt (M10 x 20): 2 bolts |
| RH-12FH/20FH series | | | | |
| Stopper for changing the operating range | 1F-DH-02 | 1 set | 0.05 | hexagon socket head bolt (M12 x 20): 2 bolts |

■ Specifications

Table 2-21 : Specifications


| Axis | | Standard | Changeable angle |
|------|----------|-------------|--------------------------|
| J1 | +/- side | +/- 170 deg | +/- 130 deg, +/- 150 deg |

- (1) The changeable angle shown in [Table 2-21](#) indicates the operation range by the software.
 The limit by the mechanical stopper is positioned 3 degrees outward from that angle, so take care when designing the layout.
- (2) The operating range is changed with robot arm settings (insertion of the pin) and parameter settings. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE", "Instruction Manual/Detailed Explanation of Functions and Operations" or [Page 65, "2.4.5 Change the operating range"](#) for details.
- (3) If the arm collides with mechanical stopper for operating range change at the automatic operation, replacement of the mechanical stopper is necessary.

(3) Solenoid valve set

- Order type: RH-6FH seriesOne set: 1F-VD01-01(Sink type)/1F-VD01E-01(Source type)
 Two sets: 1F-VD02-01(Sink type)/1F-VD02E-01(Source type)
 Three sets: 1F-VD03-01(Sink type)/1F-VD03E-01(Source type)
 Four sets: 1F-VD04-01(Sink type)/1F-VD04E-01(Source type)
- RH-12FH/20FH seriesOne set: 1S-VD01-01(Sink type)/1S-VD01E-01(Source type)
 Two sets: 1S-VD02-01(Sink type)/1S-VD02E-01(Source type)
 Three sets: 1S-VD03-01(Sink type)/1S-VD03E-01(Source type)
 Four sets: 1S-VD04-01(Sink type)/1S-VD04E-01(Source type)

■ Outline



The solenoid valve set is an option that is used for controlling toolings when various toolings, such as the hand, are installed at the end of the arm.
 Also, for easy installation of this electromaagnetic set onto the robot, it comes equipped with a manifold, couplings, silencers, among other things.

- 1F-VD0*-01
- 1F-VD0*E-01
- 1S-VD0*-01
- 1S-VD0*E-01

■ Configuration

Table 2-22 : Configuration equipment

| Part name | Type | Q'ty | Mass(kg) Note1) | Remark |
|-----------------------------|----------------------------|-------------------|--------------------|---|
| RH-6FH series | | | | |
| Solenoid valve set (1 sets) | 1F-VD01-01/ 1F-VD01E-01 | Either one pc. | 1.0 | Hand output cable is already connected. Refer to Page 90 , "(5) Hand output cable". M4 x 8 Two screws (Installation screws) 1F-VD0*-01: Sink type 1F-VD0*E-01: Source type. |
| Solenoid valve set (2 sets) | 1F-VD02-01/ 1F-VD02E-01 | Either one pc. | 1.0 | |
| Solenoid valve set (3 sets) | 1F-VD03-01/ 1F-VD03E-01 | Either one pc. | 1.0 | |
| Solenoid valve set (4 sets) | 1F-VD04-01/ 1F-VD04E-01 | Either one pc. | 1.0 | |
| RH-12FH/20FH series | | | | |
| Solenoid valve set (1 sets) | 1S-VD01-01/ 1S-VD01E-01 | Either one pc. | 1.0 | Hand output cable is already connected. Refer to Page 90 , "(5) Hand output cable". M4 x 8 Two screws (Installation screws) 1S-VD0*-01: Sink type 1S-VD0*E-01: Source type. |
| Solenoid valve set (2 sets) | 1S-VD02-01/ 1S-VD02E-01 | Either one pc. | 1.0 | |
| Solenoid valve set (3 sets) | 1S-VD03-01/ 1S-VD03E-01 | Either one pc. | 1.0 | |
| Solenoid valve set (4 sets) | 1S-VD04-01/ 1S-VD04E-01 | Either one pc. | 1.0 | |

Note1) Mass indicates one set.

■ Specifications

Table 2-23 : Valve specifications

| Item | Specifications |
|-------------------------------------|--|
| Number of positions | 2 |
| Port | 5 ^{Note1)} |
| Valve function | Double solenoid |
| Operating fluid | Clean air ^{Note2)} |
| Operating method | Internal pilot method |
| Effective sectional area (CV value) | 0.64mm |
| Oiling | Unnecessary |
| Operating pressure range | 0.1 to 0.7MPa |
| Response time | 22msec or less (at 0.5 MPa) |
| Max. operating frequency | 5Hz |
| Ambient temperature | -10 to 50 °C (However, there must be no condensation.) |

Note1) Couplings of unused solenoid valves must be blocked with plugs. If they are not blocked, supplied air will blow out from the couplings, lowering the air pressure of the solenoid valves being used and making them nonfunctional
(recommended plugs: KQ2P-04 plugs made by SMC).

Note2)


 **CAUTION** The air to be provided must be clean, i.e., filtered with a mist separator or air filter. Failing to do so may lead to malfunctions.

Table 2-24 : Solenoid specifications

| Item | Specifications |
|--|---|
| Method | Built-in fly-wheel diodes with surge protection |
| Coil rated voltage | DC24V \pm 10% |
| Power consumption | 0.55W |
| Voltage protection circuit with power surge protection | Diode |




Fig.2-58 : Outline dimensional drawing (RH-6FH series)





Fig.2-59 : Outline dimensional drawing (RH-12FH/20FH series)

(4) Hand input cable

- Order type: RH-6FH series 1F-HC35C-01
 RH-12FH/20FH series 1F-HC35C-02

■ Outline



The hand input cable is used for customer-designed pneumatic hands. It is necessary to use this to receive the hand's open/close confirmation signals and grasping confirmation signals, at the controller. One end of the cable connects to the connector for hand input signals, which is in the wrist section of the hand. The other end of the cable connected to the sensor inside the hand customer designed. To extend the wiring to the outside of the robot arm, optional external wiring and piping box (RH-6FH series: 1F-UT-BOX, RH-12FH/20FH series: 1F-UT-BOX-01) is required.

■ Configuration

Table 2-25 : Configuration equipment

| Part name | Type | Qty. | Mass (kg) ^{Note1)} | Remarks |
|---------------------|-------------|---------|-----------------------------|---------|
| RH-6FH series | | | | |
| Hand input cable | 1F-HC35C-01 | 1 cable | 0.2 | |
| RH-12FH/20FH series | | | | |
| Hand input cable | 1F-HC35C-02 | 1 cable | 0.2 | |

Note1) Mass indicates one set.

■ Specifications

Table 2-26 : Specifications

| Item | Specifications | Remarks |
|---------------------|---|---|
| RH-6FH series | | |
| Size x cable core | AWG#24 (0.2mm ²) × 12 | One-sided connector, one-sided cable bridging |
| Total length | 1,650mm (Including the curl section, which is 350mm long) | |
| RH-12FH/20FH series | | |
| Size x cable core | AWG#24 (0.2mm ²) × 12 | One-sided connector, one-sided cable bridging |
| Total length | 1,800mm (Including the curl section, which is 350mm long) | |





Fig.2-60 : Outside dimensional drawing and pin assignment

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

(5) Hand output cable

■ Order type: 1F-GR60S-01

■ Outline



The hand output cable (solenoid valve connection cable) is an option that is used when a solenoid valve other than one of the solenoid valve set options, is used. One end of the cable has a connector that connects to the input terminal inside the robot. The other end of the cable is connected.

To extend the wiring to the outside of the robot arm, optional external wiring and piping box (RH-6FH series: 1F-UT-BOX, RH-12FH/20FH series: 1F-UT-BOX-01) is required.

■ Configuration

Table 2-27 : Configuration equipment

| Part name | Type | Qty. | Mass (kg) ^{Note1)} | Remarks |
|-------------------|-------------|---------|-----------------------------|---------|
| Hand output cable | 1F-GR60S-01 | 1 cable | 0.3 | |

Note1) Mass indicates one set.

■ Specifications

Table 2-28 : Specifications

| Item | Specifications | Remarks |
|-------------------|--|--|
| Size x Cable core | AWG#24(0.2mm ²) x 12 cores | One side connector and one side cable connection |
| Total length | 1,050mm | |





Fig.2-61 : Outline dimensional drawing and pin assignment

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

(6) Hand curl tube

- Order type: RH-6FH seriesFour sets: 1E-ST0408C-300
 RH-12FH/20FH series.....Four sets: 1N-ST0608C-01

■ Outline



The hand curl tube is a curl tube for the pneumatic hand.

■ Configuration

Table 2-29 : Configuration equipment

| Part name | Type | Qty. | Mass(kg) ^{Note1)} | Remarks |
|-----------------------------------|----------------|-------|----------------------------|---------------|
| RH-6FH series | | | | |
| Hand curl tube (Four set: 8 pcs.) | 1E-ST0408C-300 | 1 pc. | 0.1 | Φ4 tube, 8pcs |
| RH-12FH/20FH series | | | | |
| Hand curl tube (Four set: 8 pcs.) | 1N-ST0608C-01 | 1 pc. | 0.4 | Φ6 tube, 8pcs |

Note1) Mass indicates one set.

■ Specifications

Table 2-30 : Specifications

| Item | Specifications | |
|----------|--|--|
| | RH-6FH series | RH-12FH/20FH series |
| Material | Urethane | Urethane |
| Size | Outside diameter: Φ4 x Inside diameterΦ2.5 | Outside diameter: Φ6 x Inside diameterΦ4 |





Fig.2-62 : Outline dimensional drawing

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

(7) Internal Wiring/Piping set for hand

- Order type: RH-6FH series, 200mm stroke..... 1F-HS408S-01
 RH-6FH series, 340mm stroke 1F-HS408S-02
 RH-12FH/20FH series, 350mm stroke..... 1F-HS604S-01
 RH-12FH/20FH series, 450mm stroke..... 1F-HS604S-02

■ Outline



This set, consisting of air hoses and cables, is for feeding air hoses and hand input signal cables from the No. 2 arm through to the shaft tip.
 A plate is already attached to be fixed onto the No. 2 arm, and therefore it is easy to ensure the necessary space for wiring and piping.
 This can be used together with the separately sold electromagnetic valve set option.

■ Configuration

Table 2-31 : Configuration equipment

| Item | Type | Qty. | Mass (Kg) ^{Note1)} | Remarks |
|--|--------------|------|-----------------------------|---|
| RH-6FH series | | | | |
| Internal Wiring/Piping set for hand (For 200mm stroke) | 1F-HS408S-01 | 1 | 0.4 | The air hose and the cable for hand input signals are contained. The grease (for application to shaft top) and the union band (for fixation of the hose and the cable) are attached. |
| Internal Wiring/Piping set for hand (For 340mm stroke) | 1F-HS408S-02 | 1 | 0.4 | |
| RH-12FH/20FH series | | | | |
| Internal Wiring/Piping set for hand (For 350mm stroke) | 1F-HS604S-01 | 1 | 0.4 | The air hose and the cable for hand input signals are contained. The grease (for application to shaft top) and the union band (for fixation of the hose and the cable) are attached. |
| Internal Wiring/Piping set for hand (For 450mm stroke) | 1F-HS604S-02 | 1 | 0.4 | |

Note1) Mass indicates one set.

■ Specification

Table 2-32 : Specification

| Item | Specification | | | Remarks |
|-----------------------------------|------------------------------|--|--------------|---|
| | 1F-HS408S-01 1F-HS408S-02 | 1F-HS604S-01 | 1F-HS604S-02 | |
| Air hose | $\phi 4 \times 8$ pcs | $\phi 4 \times 8$ pcs | | Both ends are free. |
| Hand input signal cable | Signal | AWG #25(0.2mm ²) \times 8pcs | | The robot arm side is connector (HC1, HC2), and one side is free. |
| | Power | AWG #23(0.3mm ²) \times 2pcs | | |
| Useable length from the shaft end | 300mm | 400mm | 300mm | The length from the shaft end which can be used of customer. |

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.





Fig.2-63 : Outline dimension drawing and pin assignment (Hand input cable)

(8) External Wiring/Piping box

- Order type: RH-6FH series 1F-UT-BOX
 RH-12FH/20FH series..... 1F-UT-BOX-01

■ Outline



This is a very useful option when removing the air hoses and signal lines from the rear of the No. 2 arm, and pulling hand wiring and piping out to the robot's exterior. The joint for connects to the external hose is prepared, and the holes which fixes the signal cable to pull out with cable clamp are prepared. Optional hand output cables and hand input cables can be fixed here.

This option can also be used on the oil mist and clean specifications.

■ Configuration

Table 2-33 : Configuration equipment

| Part name | Type | Qty. | Mass (Kg) ^{Note1)} | Remarks |
|----------------------------|--------------|------|-----------------------------|---|
| RH-6FH series | | | | |
| External Wiring/Piping box | 1F-UT-BOX | 1 | 0.5 | Attachment • Eight Air hoses (φ 4, connect to solenoid valve) • Installation screw M4 x 12: 4 screws (Conical spring washer, Plain washer) |
| RH-12FH/20FH series | | | | |
| External Wiring/Piping box | 1F-UT-BOX-01 | 1 | 0.5 | Attachment • Eight Air hoses (φ 6, connect to solenoid valve) • Installation screw M4 x 12: 4 screws (Conical spring washer, Plain washer) |

Note1) Mass indicates one set.

■ Specification

Table 2-34 : Specification

| Item | Specification | Remarks |
|-----------------------------|--------------------------|-----------------------------------|
| RH-6FH series | | |
| Outline | 106(W) x 73.6(D) x 72(H) | The coupling is included. |
| The hole for wiring drawers | φ 21 x 4 places | Fix the cable by cable clamp etc. |
| Coupling | For φ 4 air hose x 8pcs | Installed previously |
| | For φ 6 air hose x 2pcs | |
| RH-12FH/20FH series | | |
| Outline | 100(W) x 91.9(D) x 70(H) | The coupling is included. |
| The hole for wiring drawers | φ 21 x 4 places | Fix the cable by cable clamp etc. |
| Coupling | For φ 6 air hose x 8pcs | Installed previously |

An outside dimension and a component are shown in Fig. 2-64.





Fig.2-64 : Outline dimension and configurations (RH-6FH series)

<RH-12FH/20FH series>



Configuration

| | Part name | Qty. | Specification |
|---|------------------------------------|------|---|
| ① | External Wiring/Piping box housing | 1 | |
| ② | Quick coupling | 8 | φ6 (Elbow) |
| ③ | φ21 hole | 4 | The grommet is attached to each hole. (Two holes are in the right and the left.) |
| ④ | Manifold block | 1 | |
| - | Plug | 8 | Stopper for φ6 quick coupling |
| - | Installation screw | 4 | Installation screw M4 x 12 Conical spring washer, Plane washer (Attachment) |

Fig.2-65 : Outline dimension and configurations (RH-12FH/20FH series)

2.8 About Overhaul

Robots which have been in operation for an extended period of time can suffer from wear and other forms of deterioration. In regard to such robots, we define overhaul as an operation to replace parts running out of specified service life or other parts which have been damaged, so that the robots may be put back in shape for continued use. Overhaul interval for robots presumably varies with their operating conditions and thus with the degree of the equipment's wear and loss of performance. As a rule of thumb, however, it is recommended that overhaul be carried out before the total amount of servo-on time reaches the predetermined levels (24,000 hours for the robot body and 36,000 hours for the controller). (See Fig. 2-66.) For specific information about parts to be replaced and timing of overhaul, contact your local service representative.




Fig.2-66 : Periodic inspection/overhaul periods

2.9 Maintenance parts

The consumable parts used in the robot arm are shown in [Table 2-35](#). Purchase these parts from the designated maker or dealer when required. Some Mitsubishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from the dealer.

Table 2-35 : Consumable part list

| No. | Part name | Type ^{Note1)} | Usage place | Qty. | Supplier |
|---------------------------------|-----------------|------------------------|------------------------------|-----------|---------------------|
| Common parts between robot type | | | | | |
| 1 | Grease | | Reduction gears of each axis | As needed | Mitsubishi Electric |
| 2 | | | Ball screw Ball spline | As needed | |
| 3 | Lithium battery | ER6 | Front section of the base | 3 | |
| RH-6FH series | | | | | |
| 4 | Timing belt | | J3 axis | 1 | Mitsubishi Electric |
| 5 | | | J4 axis motor side | 1 | |
| 6 | | | J4 axis shaft side | 1 | |
| RH-12FH series | | | | | |
| 7 | Timing belt | | J3 axis | 1 | Mitsubishi Electric |
| 8 | | | J4 axis motor side | 1 | |
| 9 | | | J4 axis shaft side | 1 | |
| RH-20FH series | | | | | |
| 10 | Timing belt | | J3 axis | 1 | Mitsubishi Electric |
| 11 | | | J4 axis motor side | 1 | |
| 12 | | | J4 axis shaft side | 1 | |

Note1) Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

3 Controller

3.1 Standard specifications

Use the robot CPU unit which consists of CR751-Q controllers, equipping the base unit of the sequencer of the MELSEC-Q series of our company. Specifications such as the power supply and outside dimension of the robot CPU unit are the same as the sequencer's specification. Refer to [Page 103 "Fig. 3-2"](#) (Names of each part), [Page 105 "Fig. 3-4"](#) and [Page 106 "Fig. 3-5"](#) (Outside dimensions)

Although the specification with which the robot CPU unit and the drive unit (box which mounts the servo amplifier for the robots, the safety circuit, etc.) were put together is shown in [Table 3-1](#), the specification of the drive unit is mainly described.

Table 3-1 : Specifications of controller

| Item | Unit | Specification | Remarks | |
|--------------------------------------|-------------------------------|--|---|--|
| Type | | CR750-06HQ-1 CR750-12HQ-1 CR750-20HQ-1 | CR750-06HD1-1-S15 is the same | |
| Number of control axis | | Simultaneously 4 | | |
| Memory capacity | Programmed positions | point | 13,000 | |
| | No. of steps | step | 26,000 | |
| | Number of program | | 256 | |
| Robot language | | MELFA-BASIC V | | |
| Teaching method | | Pose teaching method, MDI method ^{Note1)} | | |
| External input and output | Input and output | point | 0/0 | Multi-CPU shared device Input 8192/Output 8192 (Max.) |
| | | Dedicated input/output | | |
| | Hand open/close input/output | point | 8/8 | Built-in |
| | Emergency stop input | point | 1 | Dual line |
| | Door switch input | point | 1 | Dual line |
| | Enabling device input | point | 1 | Dual line |
| | Emergency stop output | point | 1 | Dual line |
| | Mode output | point | 1 | Dual line |
| | Robot error output | point | 1 | Dual line |
| | Addition axis synchronization | point | 1 | Dual line |
| Interface | RS-422 | port | 1 | Only for T/B |
| | Ethernet | port | 1 | 10BASE-T/100BASE-Tx |
| | Additional axis interface | Channel | 1 | SSCNET III (Connects with MR-J3-BS, MR-J4-B series) |
| Power source | Input voltage range | V | RH-6FH series: Single phase AC180 to 253 RH-12FH/20FH series ^{Note2)} : Three phase AC180 to 253, or Single phase AC207 to 253 | |
| | Power capacity | kVA | RH-6FH series: 1.0 RH-12/20FH series: 1.5 | Does not include rush current ^{Note3)} |
| | Power supply frequency | Hz | 50/60 | |
| Outline dimensions ^{Note4)} | mm | 430(W) x 425(D) x 174(H) | Excluding protrusions | |
| Mass | kg | RH-6FH series : Approx. 16 RV-12FH/20FH series : Approx. 18 | | |
| Construction | | Self-contained floor type, Opened type. Installation vertically or horizontally | IP20 ^{Note5)} | |
| Operating temperature range | °C | 0 to 40 | | |
| Ambient humidity | %RH | 45 to 85 | Without dew drops | |
| Grounding | Ω | 100 or less | 100Ω or less (class D grounding) ^{Note6)} | |
| Paint color | | Dark gray | | |

Note1) Pose teaching method: The method to register the current position of the robot arm.
MDI method: The method to register by inputting the numerical value Immediate.

Note2) Both the three phase power supply and the single phase power supply can use this product according to voltage conditions.

Note3) The power capacity is the rating value for normal operation. The power capacity does not include the rush current when the power is turned ON. The power capacity is a guideline and the actual operation is affected by the input power voltage. The power consumption in the specific operation pattern with the RH-6FH is approx. 0.3kW and RH-20FH is approx. 0.49kW. The short circuit breaker should use the following.

* Operate by the current leakage under the commercial frequency domain (50–60Hz). If sensitive to the high frequency ingredient, it will become the cause in which below the maximum leak current value carries out the trip.

Note4) Refer to [Page 104, "3.4 Outside dimensions/Installation dimensions"](#) for details.

Note5) This controller is standard specification. (Refer to [Page 100, "3.2 Protection specifications and operating supply"](#).)

Note6) The robot must be grounded by the customer.

Table 3-2 : Robot CPU unit standard specification

| Item | | Unit | Specification | Remarks |
|-----------------------------|-------------------------------|------|----------------------------|-------------------|
| Type | | | Q172DRCPU | |
| Interface | Addition axis synchronization | port | 1 | |
| Power source | Power capacity (DC5V) | A | 1.25 | |
| Outline dimension | | mm | 98(W) x 27.4(D) x 119.3(H) | |
| Mass | | kg | 0.33 | |
| Operating temperature range | | °C | 0 to 55 | |
| Ambient humidity | | %RH | 5 to 95 | Without dew drops |

3.2 Protection specifications and operating supply

A protection method complying with the IEC Standard IP20 (Opened type) is adopted for the controller. The IEC IP symbols refer only to the degree of protection between the solid and the fluids, and don't indicated that any special protection has been constructed for the prevention against oil and water.

【Information】


- The IEC IP20

It indicates the protective structure that prevents an iron ball $12^{+0.05}_0$ mm diameter, which is being pressed with the power of $3.1 \text{ kg} \pm 10\%$, from going through the opening in the outer sheath of the supplied equipment.


Refer to the section [Page 157, "6.2 Working environment"](#) for details on the working environment.

3.3 Names of each part

Drive unit (Front side)




Drive unit (Rear side)




<1>: ACIN terminal

RH-6FH: Single phase



L1 L2: no-CE specifications
N: CE specifications

RH-12FH/20FH: Single phase/Three phase



L1 L2 L3

<20>: The operation panel




Fig.3-1 : Names of drive unit parts (CR750)

- <1> ACIN terminal The terminal box for AC power source (single phase or single phase/three phase, AC200V) input. (Inner side of a cover)
 Note) When using the RH-6FH series, connect the primary power supply to L1 and L2 terminal.
 When using the RH-12FH/20FH series, connect the primary power supply to L1, L2 and L3 terminal when using the three phase primary power supply, and connect the primary power supply to L1 and L3 terminal when using the single phase primary power supply.
- <2> PE terminal The screw for grounding of the cable. (M4 screw x 2 place)
- <3> Power switch This turns the control power ON/OFF
- <4> Machine cable connector (motor signal) (CN1)
 Connect with the CN1 connector of the robot arm.
- <5> Machine cable connector (motor power) (CN2)
 Connect with the CN2 connector of the robot arm.
- <6> T/B connection connector (TB) This is a dedicated connector for connecting the T/B. When not using T/B, connect the attached dummy connector.
- <7><8><9><10> CNUSR connector The connector for input/ output connection dedicated for robot. (a plug connector attached)
 <7>: CNUSR11, <8>: CNUSR12, <9>: CNUSR13, <10>: CNUSR2
 Note) <9>: CNUSR13 connector is not used in this controller.
- <11> DCOUT connector (DCOUT) For emergency stop
- <12> CNDISP connector (CNDISP) For LAN of T/B connection
- <13> CON3 connector (CON3) For RS422 of T/B connection
- <14> OPT connector (OPT) For SSCNETIII connection
- <15> Interface cover USB interface and battery are mounted.
- <16> Mode key switch This key switch changes the robot's operation mode.
 AUTOMATIC Operations from the controller or external equipment are valid. Operations for which the operation mode must be at the external device or T/B are not possible. (Exclude the start of automatic operation.)
 MANUAL When the T/B is valid, only operations from the T/B are valid. Operations for which the operation mode must be at the external device or controller are not possible.
- <17> Emergency stop switch This switch stops the robot in an emergency state. The servo turns OFF.
- <18> Filter cover There is an air filter inside the cover.
- <19> Grounding terminal The grounding terminal for connecting cables of option card. (M3 screw x 2 places)
- <20> Operation panel The operation panel for servo ON/OFF, START/STOP the program etc.
- <21> Display panel (STATUS.NUMBER) The alarm No., program No., override value (%), etc., are displayed.
- <22> CHNGDISP button This button changes the details displayed on the display panel in the order of "Override" → "Program No." → "Line No."
- <23> UP/DOWN button This scrolls up or down the details displayed on the "STATUS. NUMBER" display panel.
- <24> SVO.ON button This turns ON the servo power. (The servo turns ON.)
- <25> SVO.OFF button This turns OFF the servo power. (The servo turns OFF.)
- <26> START button This executes the program and operates the robot. The program is run continuously.
- <27> STOP button This stops the robot immediately. The servo does not turn OFF.
- <28> RESET button This resets the error. This also resets the program's halted state and resets the program.
- <29> END button This stops the program being executed at the last line or END statement.

3.3.1 Names of each part of the robot CPU




Fig.3-2 : Names of each part of the robot CPU

- ① Seven segments LEDIndicates operational status and error information
- ② Rotary switch (SW1).....Set up operation mode. Always set it as "0."
- ③ Rotary switch (SW2).....Set up operation mode. Always set it as "0."
- ④ RUN/STOP switch.....Unused
- ⑤ Emergency stop input (EMI)*1) ...Connects with the connector (DCOUT) of the controller by the EMI cable for robot. (For the emergency stops)
- ⑥ CN1 connector*2)Connects with the connector (OPT) of the controller by the SSCNET III cable for robot. (For the robot-arm servo amplifier connection)
- ⑦ CN2 connector*2)Connect to the servo amplifier of the addition axis (Eight axes)
- ⑧ Lever for unit installationUse this lever, when installing the unit in the base unit.
- ⑨ Hook for unit fixing*3)The hook which fixes the unit to the base unit (For the support at installation)
- ⑩ Unit fixing screw.....The screw for fixing to the base unit (M3 × 13)
- ⑪ The projection for unit fixingThe projection for fixing to the base unit
- ⑫ Battery connector (BAT)*4)The connector for connection with battery holder unit Q170DBATC.
- ⑬ The connector for the networks (DISPLAY I/F)
Connects with the connector (CNDISP) of the controller by the DISP cable for robot. (For the LAN of T/B)
- ⑭ RS422 connector (TU I/F).....Connects with the connector (CON3) of the controller by the TU cable for robot. (For the RS-422 of T/B)

*1) Please be sure to use the emergency stop input cable. The emergency stop cannot be canceled if it does not use. If it manufactures the emergency stop input cable in the customer, cable length should use 30m or less.

*2) Please store in the duct or fix the cable section near robot CPU with the bunch wire rod so that prudence of the cable is not applied to CN1 and CN2 connector section.

*3) It is equipment for the support when installing the unit in the basic base unit. Please be sure to fix the unit to the basic base unit with the attached fixing screw.

*4) Please be sure to use the external battery. Unless the battery cable is connected surely, the program in SRAM with a built-in robot CPU, the parameter, origin position data, etc. are not held.

3.4 Outside dimensions/Installation dimensions

3.4.1 Outside dimensions




Fig.3-3 : Outside dimensions of drive unit (CR750)

(1) Outside dimensions of robot CPU unit




Fig.3-4 : Outside dimensions of robot CPU

(2) Battery unit outside dimension





Fig.3-5 : Outside dimensions of battery unit

3.4.2 Installation dimensions

<Placed horizontally>



<Placed vertically>




Fig.3-6 : Installation of controller (CR750)

⚠ CAUTION

Fixing installation section sure for prevention from the fall, when using the drive unit placing vertically. The reference figure of the metal plate for fixing is shown in Fig. 3-7. You should install the metal plate for fixation to the drive unit with M4 x 8 or the shorter screw. The screw projection length inside the controller (side board thickness is 1.2 mm) surely makes 6.8 mm or less.

⚠ CAUTION

When storing the drive unit in a cabinet, etc., take special care to the heat radiating properties and ventilation properties so that the ambient temperature remains within the specification values. And, don't install the drive unit in the position where direct rays or the heat of lighting hits. The skin temperature of the drive unit may rise, and the error may occur.




Fig.3-7 : Metal plate for fixation to placing vertically (Reference for CR750)

(1) Robot CPU Unit installation dimensions

Because to improve ventilation and to make unit replacement easy, please secure the following distance between the upper and lower sides of the unit and the structure, etc.




Fig.3-8 : Installation of robot CPU Unit

3.5 External input/output

3.5.1 Types

- (1) Dedicated input/output.....These inputs and outputs carry out the robot remote operation and status display.
- (2) General-purpose input/output.....These are inputs and outputs that the customer can program for peripheral device control.
- (3) Hand input/output.....These are inputs and outputs related to the hand that the customer can program.
- (4)Emergency stop/Door switch input.....The wiring for the safe security of the emergency stop etc. is shown in on [Page 114, "3.7 Emergency stop input and output etc."](#) and on [Page 149, "6.1.7 Examples of safety measures"](#).

<For Reference>

Linking our GOT1000 Series (GT15) display equipment to the robot controller over the Ethernet permits you to control robot controller's input/output from a GOT (graphic operation terminal).

3.6 Dedicated input/output

Show the main function of dedicated input/output in the [Table 3-3](#). Refer to attached instruction manual "Detailed explanations of functions and operations" in the product for the other functions. Each parameter indicated with the parameter name is used by designated the signal No., assigned in the order of input signal No. and output signal No.

Table 3-3 : Dedicated input/output list

| Parameter name | Input Note1) | | | Output | |
|--------------------------|---|--|-------|---|--|
| | Name | Function | Level | Name | Function |
| TEACHMD | None | | | Teaching mode output signal | Outputs that the teaching mode is entered. |
| ATTOPMD | None | | | Automatic mode output signal | Outputs that the automatic mode is entered. |
| ATEXTMD | None | | | Remote mode output signal | Outputs that the remote mode is entered. |
| RCREADY | None | | | Controller power ON complete signal | Outputs that external input signals can be received. |
| AUTOENA | Automatic operation enabled input signal | Allows automatic operation. | L | Automatic operation enabled output signal | Outputs the automatic operation enabled state. |
| START | Start input signal | Starts all slots. | E | Operating output signal | Outputs that the slot is operating. |
| STOP | Stop input signal | Stops all slots. The input signal No. is fixed to 0. Note) Use the emergency stop input for stop inputs related to safety. | L | Wait output signal | Outputs that the slot is temporarily stopped. |
| STOP2 | Stop input signal | The program during operation is stopped. Unlike the STOP parameter, change of the signal number is possible. Notes) Specification is the same as the STOP parameter. | L | Wait output signal | Outputs that the slot is temporarily stopped. Notes) Specification is the same as the STOP parameter. |
| SLOTINIT | Program reset input signal | Resets the wait state. | E | Program selection enabled output signal | Outputs that the slot is in the program selection enabled state. |
| ERRRESET | Error reset input signal | Resets the error state. | E | Error occurring output signal | Outputs that an error has occurred. |
| CYCLE | Cycle stop input signal | Carries out cycle stop. | E | In cycle stop operation output signal | Outputs that the cycle stop is operating. |
| SRVOFF | Servo ON enabled input signal | Turns the servo OFF for all mechanisms. | L | Servo ON enabled output signal | Outputs servo-on disable status. (Echo back) |
| SRVON | Servo ON input signal | Turns the servo ON for all mechanisms. | E | In servo ON output signal | Outputs the servo ON state. |
| IOENA | Operation rights input signal | Requests the operation rights for the external signal control. | L | Operation rights output signal | Outputs the operation rights valid state for the external signal control. |
| MELOCK | Machine lock input signal | Sets/resets the machine lock state for all mechanisms. | E | In machine lock output signal | Outputs the machine lock state. |
| SAFEPOS | Evasion point return input signal | Requests the evasion point return operation. | E | In evasion point return output signal | Outputs that the evasion point return is taking place. |
| OUTRESET | General-purpose output signal reset | Resets the general-purpose output signal. | E | None | |
| EMGERR | None | | | Emergency stop output signal | Outputs that an emergency stop has occurred. |
| S1START : S32START | Start input | Starts each slot. | E | In operation output | Outputs the operating state for each slot. |

| Parameter name | Input Note1) | | | Output | |
|---------------------------|---|---|-------|---|--|
| | Name | Function | Level | Name | Function |
| S1STOP : S32STOP | Stop input | Stops each slot. | L | In wait output | Outputs that each slot is temporarily stopped. |
| PRGSEL | Program selection input signal | Designates the setting value for the program No. with numeric value input signals. | E | None | |
| OVRDSEL | Override selection input signal | Designates the setting value for the override with the numeric value input signals. | E | None | |
| IODATA Note2) | Numeric value input (start No., end No.) | Used to designate the program name, override value., mechanism value. | L | Numeric value output (start No., end No.) | Used to output the program name, override value., mechanism No. |
| PRGOUT | Program No. output request | Requests output of the program name. | E | Program No. output signal | Outputs that the program name is being output to the numeric value output signal. |
| LINEOUT | Line No. output request | Requests output of the line No. | E | Line No. output signal | Outputs that the line No. is being output to the numeric value output signal. |
| OVRDOUT | Override value output request | Requests the override output. | E | Override value output signal | Outputs that the override value is being output to the numeric value output signal. |
| ERROUT | Error No. output request | Requests the error No. output. | E | Error No. output signal | Outputs that the error No. is being output to the numeric value output signal. |
| JOGENA | Jog valid input signal | Validates jog operation with the external signals | E | Jog valid output signal | Outputs that the jog operation with external signals is valid. |
| JOGM | Jog mode input 2-bit | Designates the jog mode. | L | Jog mode output 2-bit | Outputs the current jog mode. |
| JOG+ | Jog feed + side for 8-axes | Requests the + side jog operation. | L | None | |
| JOG- | Jog feed - side for 8-axes | Requests the - side jog operation. | L | None | |
| HNDCTRL1 : HNDCTRL3 | None | | | Mechanism 1 hand output signal status : Mechanism 3 hand output signal status | Mechanism 1: Outputs the status of general-purpose outputs 900 to 907. Mechanism 2: Outputs the status of general-purpose outputs 910 to 917. Mechanism 3: Outputs the status of general-purpose outputs 920 to 927. |
| HNDSTS1 : HNDSTS3 | None | | | Mechanism 1 hand input signal status : Mechanism 3 hand input signal status | Mechanism 1: Outputs the status of hand inputs 900 to 907. Mechanism 2: Outputs the status of hand inputs 910 to 917. Mechanism 3: Outputs the status of hand inputs 920 to 927. |
| HNDERR1 : HNDERR3 | Mechanism 1 hand error input signal : Mechanism 3 hand error input signal | Requests the hand error occurrence. | L | Mechanism 1 hand error output signal : Mechanism 3 hand error output signal | Outputs that a hand error is occurring. |

| Parameter name | Input Note1) | | | Output | |
|-------------------------|---|--|-------|---|---|
| | Name | Function | Level | Name | Function |
| AIRERR1 : AIRERR3 | Pneumatic pressure error 1 input signal : Pneumatic pressure error 3 input signal | Request the pneumatic pressure error occurrence. | L | Pneumatic pressure error 1 output signal. : Pneumatic pressure error 3 output signal. | Outputs that a pneumatic pressure error is occurring. |
| M1PTEXC : M3PTEXC | None | | L | Maintenance parts replacement time warning signal | Outputs that the maintenance parts have reached the replacement time. |
| USERAREA Note3) | None | | | User-designated area 8-points | Outputs that the robot is in the user-designated area. |

Note1) The level indicates the signal level.

L: Level signal → The designated function is validated when the signal is ON, and is invalidated when the signal is OFF.

E: Edge signal → The designated function is validated when the signal changes from the OFF to ON state, and the function maintains the original state even when the signal then turns OFF.

Note2) Four elements are set in the order of input signal start No., end No., output signal start No. and end No.

Note3) Up to eight points can be set successively in order of start output signal No. and end output signal No.

3.7 Emergency stop input and output etc.

Do wiring of the external emergency stop, the special stop input, the door switch, and the enabling device from the "special input/output" terminal connector.

Table 3-4 : Special input/output terminal

| Item | Name | Function |
|--------|---|--|
| Input | Emergency stop | Applies the emergency stop. Dual emergency line |
| Input | Special stop input | Applies the stop. (Refer to Page 119 , "3.7.2 Special stop input (SKIP)") |
| Input | Door switch | Servo-off. Dual line, normal close (Page 120 , "3.7.3 Door switch function") |
| Input | Enabling device | Servo-off. Dual line, normal close (Page 120 , "3.7.4 Enabling device function") |
| Output | Robot error output | Contactors are opening during error occurrence. |
| Output | Emergency stop output | The point of contact opens under occurrence of emergency stop of external input signal, emergency stop of OP, emergency stop of T/B. |
| Output | Mode output | MANUAL mode: contactor is opening, AUTOMATIC mode: contactor is closing. |
| Output | Magnet contactor control connector output for addition axes | When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the robot arm. (Page 125 , "3.9 Magnet contactor control connector output (AXMC) for addition axes") |

*At the time of the power supply OFF, the output point of contact is always open.

[Note] The contact capacity of each input/output terminal is DC24V/10mA – 100mA. Don't connect the equipment except for this range. The use exceeding contact capacity causes failure. In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Pin number assignment of each terminal and the circuit diagram are shown in [Fig. 3-10](#).

3.7.1 Connection of the external emergency stop

The external emergency stop input and door switch input and enabling device input are opened at shipment as shown in [Fig. 3-10](#).

Connect the external emergency stop switch and door switch with the following procedure.

And, the example of the connection and notes of the emergency stop are described in [Page 149](#), "6.1.7 Examples of safety measures" Refer to it together

[Caution] The emergency stop circuit is duplicated inside the drive unit. The emergency stop switch uses a double contact-type switch, so please be sure to fix both of the contacts to the connector pins as shown below in order to ensure the wiring is duplicated. An error will continue to occur in the event that only one of the pins is connected.

- 1) Please prepare the emergency stop switch, door switch and enabling device.
 - a) External emergency switch
 - CR750 drive unit.....CNUSR11 connector "between 3 and 4" and CNUSR12 Connector "between 3 and 4".
 - b) Door switch
 - CR750 drive unit.....CNUSR11 connector "between 7 and 8" and CNUSR12 connector "between 7 and 8".
 - c) Enabling device
 - CR750 drive unit.....CNUSR11 connector "between 9 and 10" and CNUSR12 connector "between 9 and 10".

[Caution] Be sure to use a shield cable for the emergency stop wiring cable. And when operating in an environment that is easily affected by noise, be sure to fix the attached ferrite core (model number: E04SR301334, manufacturer: Seiwa Electric Mfg. Co., Ltd.). Be sure to place the ferrite core more than 30 cm from the connecting terminal section.



CAUTION Make sure there are no mistakes in the wiring. Connecting differently to the way specified in the manual can result in errors, such as the emergency stop not being released. In order to prevent errors occurring, please be sure to check that all functions (such as the teaching box emergency stop, customer emergency stop, and door switch) are working properly after the wiring setup is completed.

⚠ CAUTION You should always connect doubly connection of the emergency stop, the door switch, and the enabling switch. In connection of only one side, if the relay of customer use should break down, it may not function correctly.
 And, the output contacts from the robot controller (robot error output, emergency stop output, mode output, addition axis contactor control output) are dual contacts (synchronizes). You should connect surely by dual line with the customer's equipment as well as connection of the emergency stop and the door switch.

⚠ CAUTION Please make sure to wire the multiple emergency stop switches so that they each function independently. Check and make sure that the emergency stop doesn't only function under an AND condition (when multiple emergency stop switches are ON at the same time).




Fig.3-9 : Emergency stop cable connection (CR750)




Fig.3-10 : External emergency stop connection (CR750)

CAUTION

Place the emergency stop switch in an easily operable position, and be sure to wire it to the emergency stop correctly by referencing [Page 149, "6.1.7 Examples of safety measures"](#).

This is a necessary measure in order to ensure safe operation so that the robot can be stopped immediately by pressing the emergency stop switch in the event that the robot malfunctions.




Fig.3-11 : Method of wiring for external emergency stop connection (CR750 (CNUSR11/12))

CAUTION

The connector on the controller side that connects to the user wiring connector is CNUSR11 or CNUSR12. Be careful not to connect to CNUSR13 as the robot will not operate properly.




Fig.3-12 : Method of wiring for external emergency stop connection (CR750 (CNUSR2))

⚠ CAUTION


When soldering please take care to only connect to the specified pin number. Connecting to a different pin number or short-circuiting with another pin will result in the robot breaking down or malfunctioning.

3.7.2 Special stop input (SKIP)

The skip is the input signal to stop the robot. The pin 9, 34 of the CNUSR2 connector shown in Fig. 3-13.

Table 3-5 : Special stop input electric specification

| Item | | Specifications | Internal circuit |
|---------------------------------|----------|--|------------------|
| Type | | DC input | |
| No. of input point | | 1 | |
| Insulation method | | Photo-coupler insulation | |
| Rated input voltage | | DC24V | |
| Rated input current | | Approx. 11mA | |
| Working voltage range | | DC 21.6 ~ 26.4V (Ripple rate within 5%) | |
| ON voltage/ON current | | DC 8V or more / 2mA or more | |
| OFF voltage/OFF current | | DC 4V or less / 1mA or less | |
| Input resistance | | Approx. 2.2 k Ω | |
| Response time | OFF → ON | 1ms or less | |
| | ON → OFF | 1ms or less | |
| Common method | | 1 point per common | |
| External wire connection method | | Connector | |



* Connects with CNUSR2 connector with soldering.
Refer to Page 118 "Fig. 3-12: Method of wiring for external emergency stop connection (CR750 (CNUSR2))".

Note) In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Fig.3-13 : Connection of the special-stop-input (CR750)

3.7.3 Door switch function

This function retrieves the status of the switch installed on the door of the safety fence, etc., and stops the robot when the door is opened. This differs from an emergency stop in that the servo turns OFF when the door is opened and an error does not occur. Follow the wiring example shown in [Page 116 "Fig. 3-10: External emergency stop connection \(CR750\)"](#) and [Page 149, "6.1.7 Examples of safety measures"](#). Those figure explains the wire is contact closes when the door is closed. Details of this function according to the robot status are shown below.

*During automatic operationWhen the door is opened, the servo turns OFF and the robot stops. An error occurs.

The process of the restoration: Close the door, reset the alarm, turn on the servo, and restart

*During teaching.....Even when the door is opened, the servo can be turned ON and the robot moved using the teaching pendant.




Fig.3-14 : Door switch function

3.7.4 Enabling device function

When the abnormalities occur in teaching operations etc., the robot's servo power can be immediately cut only by switch operation of the enabling device^{*1)} (servo-off), and the safety increases. To use the robot safely, please be sure to connect the enabling device.

(1) When door is opening

Please do teaching by two-person operations. One person has T/B, the other has enabling device. Turn on the servo power, in the condition that both of switches are pushed. (Enable switch of T/B and enabling device) Then the jog operation will be available. You can off the servo power only by releasing the switch of the enabling device. And, care that the servo-on and releasing the brake cannot be done in the condition that the switch of the enabling device is released.

(2) When door is closing

You can turn on the servo power by operation of only T/B. In this case perform jog operation outside the safeguard sure.

*1) Recommendation products: HE1G-L20MB (IDEC)

(3) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings

The following is a description of various operations performed on the robot and switch settings that are required.

Table 3-6 : Various operations and necessary switch settings

| No | Operation | Related switch settings ^{Note1)} | | | | | Description |
|----|---------------------------------|---|--------------------|-------------------|--------------------------------|----------------------------|---|
| | | Mode of controller | T/B enable/disable | T/B enable switch | Enabling device input terminal | Door switch input terminal | |
| 1 | Jog operation | Manual | Enable | ON | Close(ON) | — | If the enabling device input is set to Close (On), the state of door switch input does not matter. |
| 2 | Jog operation ^{Note2)} | Manual | Enable | ON | Open(OFF) | Close (Door Close) | If the enabling device input is set to Open (Off), door switch input must be in a state of Close |
| 3 | Brake release ^{Note3)} | Manual | Enable | ON | Close(ON) | — | Irrespective of the state of door switch input, enabling device input must be in a state of Close (On). |
| 4 | Automatic operation | Automatic | Disable | — | — | Close (Door Close) | Door switch input must always be in a state of Close (Door Close). |

Note1) “—” in the table indicates that the state of switch concerned does not matter.

Refer to the following for operation of each switch.

- Mode of controller:Page 101, “3.3 Names of each part”
- T/B enable/disable:..... Page 128, “(1) Teaching pendant (T/B)”
- T/B enable switch:..... Page 128, “(1) Teaching pendant (T/B)”
- Enabling device input terminal:Page 149, “6.1.7 Examples of safety measures”
- Door switch input terminal:Page 149, “6.1.7 Examples of safety measures”

Note2) Jog operation, if door switch input is set for Close (Door Close), must be performed outside the safety barrier.

Note3) It is imperative that brake release operation be carried out by two persons. One person turns on the enabling device (“Close” on the enabling device input terminal) while the other manipulates the T/B. Brake release can be effected only when both of the enabling switch device and the T/B enable switch are placed in intermediate position (lightly gripped position). At this point, the state of door switch input does not matter.




Fig.3-15 : Brake release operation

3.8 Additional Axis Function

This controller is equipped with an additional axis interface for controlling an additional axis when a traveling axis or rotary table is added to the robot. A maximum of eight axes of servo motors can be controlled at the same time by connecting a general-purpose servo amplifier (MR-J3-B, MR-J4-B series) that supports Mitsubishi's SSCNET III.

Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.

3.8.1 Wiring of the Additional Axis Interface

Table 3-7 shows the connectors for additional axes inside the drive unit. Fig. 3-16 shows a connection example (configuration example).

Table 3-7 : Dedicated connectors inside the drive unit

| Name | Connector name | Details |
|-------------------------------|----------------------------------|---|
| Connector for additional axes | CN2(Robot CPU) ^{Note1)} | The connector for connecting the general-purpose servo amplifier. |

Note1) Since the CN1 connector is used for the robot arms, it cannot be used for the addition axis.




Fig.3-16 : Example of addition axis connection (CR750)

(1) Example of the installation of the noise filter

1) EMC filter (recommended)


Please install the recommendation filter shown below according to the example of connection.

1) Combination with the servo amplifier

| Servo amplifier | Recommended filter (Soshin Electric) | | Mass [kg]([lb]) |
|---|--------------------------------------|----------------------|-----------------|
| | Model | Leakage current [mA] | |
| MR-J3-10B to MR-J3-100B MR-J3-10B1 to MR-J3-40B1 | (Note) HF3010A-UN | 5 | 3 (6.61) |
| MR-J3-250B ▪ MR-J3-350B | (Note) HF3030A-UN | | 5.5 (12.13) |
| MR-J3-500B ▪ MR-J3-700B | (Note) HF3040A-UN | 1.5 | 6.0 (13.23) |
| MR-J3-11KB to MR-J3-22KB | (Note) HF3100A-UN | 6.5 | 15 (33.07) |
| MR-J3-60B4 ▪ MR-J3-100B4 | TF3005C-TX | 5.5 | 6(13.23) |
| MR-J3-200B4 to MR-J3-700B4 | TF3020C-TX | | 7.5(16.54) |
| MR-J3-11KB4 | TF3030C-TX | | 12.5(27.56) |
| MR-J3-15KB4 | TF3040C-TX | | |
| MR-J3-22KB4 | TF3060C-TX | | |

Note. A surge protector is separately required to use any of these EMC filters.

2) Connection example



Note1) For 1-phase 200V to 230VAC power supply, connect the power supply to L1, L2 and leave L3 open.

There is no L3 for 1-phase 100 to 120 VAC power supply.

Note2) The example is when a surge protector is connected.

Fig.3-17 : Example of EMC noise filter installation

2) Line noise filter

This filter is effective in suppressing noises radiated from the power supply side and output side of the servo amplifier and also in suppressing high-frequency leakage current (zero-phase current) especially within 0.5MHz to 5MHz band.




Fig.3-18 : Example of noise filter installation


3.9 Magnet contactor control connector output (AXMC) for addition axes

When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the servo ON/OFF status of the robot itself by using the output contact (AXMC) provided on the rear or inside of the drive unit and configuring a circuit so that the power to the servo amplifier for the additional axis can be turned off when this output is open.

An example circuit and an image of how to connect the controller connector are shown below. When you are using an additional axis, please perform appropriate circuit connections by referring to these drawings.

Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.

Note1) you use the addition axis function as a user mechanism who became independent of the robot arm, please do not connect this output signal. Servo-on of the user mechanism may be unable.




Note) The connector and the pin number are shown below.

| Signal | Connector | Pin number |
|--------|-----------|------------|
| AXMC11 | CNUSR2 | 20 |
| AXMC12 | | 45 |
| AXMC21 | CNUSR2 | 19 |
| AXMC22 | | 44 |

Note2) This output is opened, if the robot turns off the servo by occurrence of alarm etc.
 <Electric specification>
 DC24V/10mA to 100mA

[Note] In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Fig.3-19 : Example of circuit for addition axes of Magnet contactor control output



*Connects with CNUSR2 connector with soldering. Refer to Page 118 "Fig. 3-12: Method of wiring for external emergency stop connection (CR750 (CNUSR2))".

Fig.3-20 : AXMC terminal connector (CR750)

3.10 Options

■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for user needs.

User installation is required for the options.

Options come in two types: "set options" and "single options".

1. Set optionsA combination of single options and parts that together, form a set for serving some purpose.
2. Single optionsThat are configured from the fewest number of required units of a part. Please choose user's purpose additionally.

(1) Teaching pendant (T/B)

- Order type: R32TB :Cable length 7m
R32TB-15 :Cable length 15m

■ Outline



This is used to create, edit and control the program, teach the operation position and for jog feed, etc.

For safety proposes, a 3-position enable switch is mounted.*1)

■ Configuration

Table 3-8 : Configuration device

| Part name | Type | Qty. | Mass (kg) ^{Note1)} | Remarks |
|------------------|----------|----------------|-----------------------------|--|
| Teaching pendant | R32TB | Either one pc. | 1.7 | Cable length is 7m. Hand strap is attached. |
| | R32TB-15 | | 2.8 | Cable length is 15m. Hand strap is attached. |

Note1) Mass indicates one set.

■ Specifications

Table 3-9 : Specifications

| Items | Specifications | Remarks |
|--------------------|---|-------------|
| Outline dimensions | 195(W) x 292(H) x 106(D) (refer to outline drawing) | |
| Body color | Dark gray | |
| Mass | Approx. 0.9kg (only arm, excluding cable) | |
| Connection method | Connection with drive unit and connector. | |
| Interface | RS-422 | |
| Display method | LCD method: 24 characters x 8 lines, LCD illumination: with backlight | At 8x8 font |
| Operation section | 36 keys | |

*1) <3-position enable switch>

In ISO/10218 (1992) and JIS-B8433 (1993), this is defined as an "enable device". These standards specify that the robot operation using the teaching pendant is enabled only when the "enable device" is at a specified position. With the Mitsubishi Electric industrial robot, the above "enable device" is configured of an "Enable/Disable switch" and "Enable switch".

The 3-position enable switch has three statuses. The following modes are entered according to the switch state.

- a) "Not pressed"The robot does not operate. *)
- b) "Pressed lightly"The robot can be operated and teaching is possible.
- c) "Pressed with force"The robot does not operate. *)

*) Operations, such as program editing and status display, other than robot operation are possible.

Safety is secured as the servo power is turned OFF simultaneously with the input of the emergency stop.




Fig.3-21 : Outside dimensions of teaching pendant

■ Installation method

The teaching pendant is connected to the T/B connector on the front of the drive unit.

■ Key layout and main functions




Fig.3-22 : Teaching pendant key layout and main functions

(2) Controller protection box

■ Order type: ● CR750-MB

■ Outline



By putting the controller in this box, the controller can be protected from oil mist environment.

Use this option, when the controller is installed where environment is oil mist such as machine shop etc. Therefore, the operation of installing and removing the T/B, and changing the mode switch can be done, with the controller put in.

■ Configuration

Table 3-10 : Configuration equipment and types

| Part name | Type | Qty. | Mass (Kg) ^{Note1)} | 備考 |
|---|----------|------|-----------------------------|---|
| Controller protection box | CR750-MB | 1 | 22 | |
| power supply wiring cable | | 3 | | For connection between the power supply relay terminal and controller inside this box |
| Grounding cable | | 1 | | For connection between the grounding terminal and controller inside this box |
| Seal for the serial number copy | | 1 | | |
| Protection seal clear | | 1 | | |
| Cable tie | T50L | 4 | | |
| Screw for fixing of the controller mounting plate | M4x8 | 4 | | |

Note1) Mass indicates one set.

■ Specifications

Table 3-11 : Specifications

| Item | Unit | Specifications | Remarks |
|-------------------|------|---------------------------------|-----------------------|
| Outside dimension | mm | 500(W) × 725(D) × 250(H) | Excluding protrusions |
| Mass | Kg | 22 | |
| Construction | | Self-contained floor type | IP54 |
| Grounding | Ω | 100 or less (class D grounding) | |
| Paint color | | Dark gray | |

(1) The robot must be grounded by the customer.

(2) The cable for primary power supply connection and the grounding cable are customer preparations.

■ Outside dimension and controller setting position




Fig.3-23 : Outside dimension and controller setting position

■ Names of each part




Fig.3-24 : Names of each part

■ Wiring system diagram




Fig.3-25 : Wiring system diagram

■ Installation dimensions




Fig.3-26 : Installation dimensions

(3) RT ToolBox2/RT ToolBox2 mini

- Order type : ● RT ToolBox2
 *For windows CD-ROM : 3D-11C-WINE
 ● RT ToolBox2 mini
 *For windows CD-ROM : 3D-12C-WINE

■ Outline



This is handy software that fully uses the personal computer functions. It can be used in various stages from the robot specifications study (tact study, etc.) to the design support (creation and editing of programs), start up support (execution, control and debugging of program), and maintenance.

The "personal computer support software" which supports these function fully, and the "personal computer support software mini" which does not have the simulation function are available.

■ Configuration

Table 3-12 : Product configuration

| Part name | Type | Medium | Mass (kg) ^{Note1)} | Remarks |
|------------------|-------------|--------|-----------------------------|---------|
| RT ToolBox2 | 3D-11C-WINE | CD-ROM | 0.2 | |
| RT ToolBox2 mini | 3D-12C-WINE | CD-ROM | 0.2 | |

Note1) Mass indicates one set.


■ Features

- (1) Simple operation with guidance method and menu method
 The Windows standard is used for windows operation, so the controller initialization and startup operations can be carried out easily by following the instructions given on the screen. Even a beginner can easily carry out the series of operations from program creation to execution.
- (2) Increased work efficiency with ample support functions
 The work efficiency is greatly improved with the multi-window method that carries out multiple steps and displays in parallel. The renumbering function, and copy, search, syntax check and step execution are especially sufficient, and are extremely useful when editing or debugging the program.
 With the simulation function support, the program can be debugged and the tact checked before starting the machine at the site. This allows the on-site startup work efficiently to be greatly improved.
- (3) The maintenance forecast function increases the efficiency of maintenance work. Analyze the load condition while the robot is actually operating. Based on this analysis, calculate the time for maintenance, such as lubrication and belt replacement. By utilizing this information, the line stop time as well as the maintenance costs can be reduced.
- (4) The position recovery support function increases the recovery efficiency in the event of origin position displacement. This function compensates the origin settings and position data by just reproducing several previous teaching points when hand and/or arm displacement occurs, when replacing the motor and the belts, or when reloading the robot. This function can reduce the time required for recovery.

■ Functions

Table 3-13 : Functions

| Function | | Functional existence ^{Note1)} | | Details |
|---------------------------|---------------------|--|---|---|
| Compatible model | | ○ | ○ | Personal computer running Microsoft Windows2000/XP/Vista/7. ^{Note2)} |
| Program editing functions | Editing functions | ○ | ○ | <ul style="list-style-type: none"> ▪ MELFA BASIC V language compatible ▪ Multiple editing screen simultaneously display ▪ Command input, comment writing ▪ Position data editing ▪ File operation (writing to controller, floppy disk, personal computer) ▪ Search and replace function (using characters, line Nos., labels) ▪ Copy, cut, paste, insert (per character, line), undo (per command statement, position conversion) ▪ Line No. automatic generation, renumbering ▪ Batch syntax check ▪ Command template ▪ Position conversion batch editing ▪ Position variable template ▪ Print, print preview |
| | Control functions | ○ | ○ | <ul style="list-style-type: none"> ▪ Program file control (list, copy, movement, delete, content comparison, name change, protect) |
| | Debugging functions | ○ | ○ | <ul style="list-style-type: none"> ▪ Direct editing of program in controller ▪ Confirmation of robot program operation (step execution, direct execution) |
| Simulation function | | ○ | × | <ul style="list-style-type: none"> ▪ Off-line simulation of robot program operation using CG (computer graphics) ▪ Tact time calculation |
| Monitor functions | | ○ | ○ | <ul style="list-style-type: none"> ▪ Robot operation monitor (robot operation state, stop signal, error monitor, program monitor (execution program, variables), general-purpose input/output signals (forced output possible), dedicated input/output signals, operation confirmation (operation range, current position, hand, etc.)) ▪ Operation monitor (working time statistics, production information, robot version) ▪ Servo monitor (load) |
| Maintenance function | | ○ | ○ | <ul style="list-style-type: none"> ▪ Parameter setting ▪ Batch, divided backup |



Note1) The functions included with the RT ToolBox2 and the RT ToolBox2 mini are shown below.

○ : Function provided × : Function not provided

Note2) Recommend corresponding to CE Marking, an FCC standard, and a VCCI standard.

(4) Instruction Manual(bookbinding)

■ Order type: ● 5F-RB01-PE01.....RH-6FH/12FH/20FH-Q series

■ Outline



This is a printed version of the CD-ROM (instruction manual) supplied with this product.

■ Configuration

Table 3-14 : Product configuration

| Name | Type | Mass (Kg) ^{Note1)} | Specifications |
|---|--------------|-----------------------------|---|
| Instruction Manual | 5F-RB01-PE01 | 2.6 | The instructions manual set of "RH-6FH/12FH/20FH-Q series". |
| Safety Manual | BFP-A8006 | - | Items relating to safety in handling the robot |
| Standard Specifications | BFP-A8882 | - | Specification of the robot arm and controller |
| Robot Arm Setup & Maintenance | BFP-A8865 | - | Installation method of the robot arm, jog operation, and maintenance and inspection procedures |
| Controller Setup, Basic Operation and Maintenance | BFP-A8886 | - | Installation method of the controller, basic operation, and maintenance and inspection procedures |
| Detailed Explanation of Functions and Operations | BFP-A8869 | - | Functions of the controller and T/B, operation method, and explanation of MELFA-BASIC V |
| Troubleshooting | BFP-A8871 | - | Causes of errors occurred and their countermeasures |
| Additional axis function | BFP-A8863 | - | Function of the additional axis, operation method. |
| Tracking Function Manual | BFP-A8664 | - | Function of the Tracking, operation method. |
| Extended Function | BFP-A8787 | - | Function of the Extended, operation method. |

Note1) Mass indicates one set.

3.11 Maintenance parts

The consumable parts used in the controller are shown in [Table 3-15](#). Purchase these parts from your dealer when required. Some Mitsubishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from your dealer.

Table 3-15 : Controller consumable parts list

| No. | Name | Type <small>Note1)</small> | Qty. | Usage place | Supplier |
|-----|-----------------|----------------------------|------|--|---------------------|
| 1 | Lithium battery | Q6BAT | 1 | The battery unit connected to the robot CPU unit | Mitsubishi Electric |
| 2 | Filter | BKOFA0773H42 | 1 | Inside the filter cover | |

Note1) Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

4 Software

4.1 List of commands

The available new functions in MELFA-BASIC V are given in [Table 4-1](#).

Table 4-1 : List of MELFA-BASIC V commands

| Type | Class | Function | Input format (example) |
|--------------------------------|--|---|--|
| Position and operation control | Joint interpolation | Moves to the designated position with joint interpolation. | Mov P1 |
| | Linear interpolation | Moves to the designated position with linear interpolation. | Mvs P1 |
| | Circular interpolation | Moves along a designated arc (start point → passing point → start point (end point)) with 3-dimensional circular interpolation (360 degrees). | Mvc P1,P2,P1 |
| | | Moves along a designated arc (start point → passing point → end point) with 3-dimensional circular interpolation. | Mvr P1,P2,P3 |
| | | Moves along the arc on the opposite side of a designated arc (start point → reference point → end point) with 3-dimensional circular interpolation. | Mvr2 P1,P9,P3 |
| | | Moves along a set arc (start point → end point) with 3-dimensional circular interpolation. | Mvr3 P1,P9,P3 |
| | | Speed designation | Designates the speed for various interpolation operations with a percentage (0.1% unit). |
| | Designate the speed for joint interpolation operation with a percentage (0.1% unit). | | JOvrd 100 |
| | Designates the speed for linear and circular interpolation with a numerical value (mm/s unit). | | Spd 123.5 |
| | Designates the acceleration/deceleration time as a percentage in respect to the predetermined maximum acceleration/deceleration. (1% unit) | | Accel 50,80 |
| | Automatically adjusts the acceleration/deceleration according to the parameter setting value. | | Oadl ON |
| | Sets the hand and work conditions for automatic adjustment of the acceleration/deceleration. | | Loadset 1,1 |
| | Operation | | Adds a process unconditionally to the operation. |
| | | Adds a process conditionally to the operation. | WthIf |
| | | Designates smooth operation. | Cnt 1,100,200 |
| | | Performance of movement is upgraded corresponding to the application. | MvTune 4 |
| | | Designates the positioning completion conditions with a No. of pulses. | Fine 200 |
| | | Designates the positioning completion conditions with a distance in a straight line | Fine 1, P |
| | | Designates the positioning completion conditions with a joint interpolation. | Fine 0.5, J, 2 |
| | | Turns the servo power ON/OFF for all axes. | Servo OFF |
| | | Limits the operation of each axis so that the designated torque is not exceeded. | Torq 4,10 |
| | Position control | Designates the base conversion data. | Base P1 |
| | | Designates the tool conversion data. | Tool P1 |
| | Float control | The robot arm rigidity is lowered and softened. (XYZ coordinate system) | Cmp Pos ,&B00000011 |
| | | The robot arm rigidity is lowered and softened. (JOINT coordinate system) | Cmp Jnt ,&B00000011 |
| | | The robot arm rigidity is lowered and softened. (TOOL coordinate system) | Cmp Tool ,&B00000011 |
| | | The robot arm rigidity is returned to the normal state. | Cmp Off |
| | | The robot arm rigidity is designated. | CmpG 1.0,1.0,1.0,1.0,1.0,1.0,1.0 |
| | Pallet | Defines the pallet. | Def Plt 1,P1,P2,P3,P4,5,3,1 |
| | | Operates the pallet grid point position. | Plt 1,M1 |
| | Singular point passage | Move to a specified position using linear interpolation passing through a singular point. | Mvs P1 Type 0,2 |

| Type | Class | Function | Input format (example) | |
|--------------------|---|--|--|----------|
| Program control | Branching | Branches unconditionally to the designated place. | GoTo 120 | |
| | | Branches according to the designated conditions. | If M1=1 Then GoTo *L100 Else GoTo 20 End If | |
| | | Repeats until the designated end conditions are satisfied. | For M1=1 TO 10 Next M1 | |
| | | Repeats while the designated conditions are satisfied. | While M1<10 WEnd | |
| | | Branches corresponding to the designated expression value. | On M1 GoTo *La1, *Lb2, *Lc3 | |
| | | Executes program block corresponding to the designated expression value.. | Select Case 1 Break Case 2 Break End Select | |
| | | Moves the program process to the next line. | Skip | |
| | Collision detection | Set to enable/disable the collision detection. | ColChk ON/OFF | |
| | | Set the detection level of the collision detection. | ColLvl 100,80,..... | |
| | Subroutine | Executes the designated subroutine. (Within program) | GoSub *L200 | |
| | | Returns from the subroutine. | Return | |
| | | Executes the designated program. | CallP "P10",M1,P1 | |
| | | Defines the program argument executed with the CALLP command. | FPm M10,P10 | |
| | | Executes the subroutine corresponding to the designated expression value. | On M1 GoSub *La1, *Lb2, *Lc3 | |
| | Interrupt | Defines the interrupt conditions and process. | Def Act 1, M1=1 GoTo *L100 | |
| | | Enables/disables the interrupt. | Act 1=1 | |
| | | Defines the start line of the program to be executed when an interrupt is generated from the communication line. | On Com(1) GoSub *L100 | |
| | | Enables the interrupt from the communication line. | Com(1) On | |
| | | Disables the interrupt from the communication line. | Com(1) Off | |
| | | Stops the interrupt from the communication line. | Com(1) Stop | |
| | Wait | Designates the wait time, and the output signal pulse output time. (0.01s unit) | Dly 0.5 | |
| | | Waits until the variable becomes the designated value. | Wait M_In(1)=1 | |
| | Stop | Stops the program execution. | Hlt | |
| | | Generates an error. During program execution, continue, stop or servo OFF can be designated. | Error 9000 | |
| | End | Ends the program execution. | End | |
| | Hand | Hand open | Opens the designated hand. | HOpen 1 |
| | | Hand close | Closes the designated hand. | HClose 1 |
| Input/output | Assignment | Defines the input/output variables. | Def IO PORT1=BIT,0 | |
| | Input | Retrieves the general-purpose input signal. | M1=M_In(1) | |
| | Output | Calls out the general-purpose output signal. | M_Out(1)=0 | |
| Parallel execution | Mechanism designation | Acquires the mechanism with the designated mechanism No. | GetM 1 | |
| | | Releases the mechanism with the designated mechanism No. | RelM 1 | |
| | Selection | Selects the designated program for the designated slot. | XLoad 2,"P102" | |
| | Start/stop | Carries out parallel execution of the designated program. | XRun 3,"100",0 | |
| | | Stops parallel execution of the designated program. | XStp 3 | |
| | Returns the designated program's execution line to the head and enters the program selection enabled state. | XRst 3 | | |

| Type | Class | Function | Input format (example) |
|--------|------------|--|------------------------|
| Others | Definition | Defines the integer type or real number type variable. | Def Inte KAISUU |
| | | Defines the character string variable. | Def Char MESSAGE |
| | | Defines the layout variable. (Up to 3-dimensional possible) | Dim PDATA(2,3) |
| | | Defines the joint variable. | Def Jnt TAIHI |
| | | Defines the position variable. | Def Pos TORU |
| | | Defines the function. | Def FN TASU(A,B)=A+B |
| | Clear | Clears the general-purpose output signal, variables in program, variables between programs, etc. | Clr 1 |
| | File | Opens a file. | Open "COM1:" AS #1 |
| | | Closes a file. | Close #1 |
| | | Inputs data from a file. | Input# 1,M1 |
| | | Outputs data to a file. | Print# 1,M1 |
| | Comment | Describes a comment. | Rem "ABC" |
| | Label | Indicates the branching destination. | *SUB1 |

4.2 List of parameters

Show the main parameter in the [Table 4-2](#).

Table 4-2 : List of parameters

| Parameter | | Details |
|----------------------------|--------------------------|---|
| Standard tool coordinates. | MEXTL | Set the default value for the tool data. Unit: mm or deg. |
| Standard base coordinates | MEXBS | Set the relation of the world coordinate system and robot coordinate system. Unit: mm or deg. |
| XYZ operation range | MEPAR | Designate the overrun limit value for the world coordinate system. |
| JOINT operation range | MEJAR | Set the overrun limit value for each joint axis. |
| Free plane limit | | This is the overrun limit set with the free plane. Create a plane with the three coordinates x1, y1, z1 to x3, y3, z3, and set the outer side of the plane as the outside operation range (error). The following three types of parameters are used. |
| | SFC1P : SFC8P | Eight types of free plane limits can be set in SFC1P to SFC8P. There are nine elements, set in the order of x1, y1, z1, x2, y2, z2, x3, y3, z3. |
| | SFC1ME : SFC8ME | Designate which mechanism to use eight types of set free plane limits. The mechanism No. to use is set with 1 to 3. |
| | SFC1AT : SFC8AT | Set the validity of the eight types of set free plane limits. (Valid 1/Valid 2/invalid = 1/-1/0) |
| User-defined area | | An area (cube) defined with two XYZ coordinate points can be designated and that area set as the outside operation range. Furthermore, a signal can be output when the axis enters that area. Up to 32 types of area can be designated. |
| | AREA1CS : AREA32CS | Specify the coordinate system of the user definition area *. 0: Base coordinate system (conventional compatibility) 1: Robot coordinate system |
| | AREA1P1 : AREA32P1 | Designated the 1st point of the area. There are eight elements, set in the order of x, y, z, a, b, c, L1, L2. (L1 and L2 are the additional axes.) |
| | AREA1P2 : AREA32P2 | Designated the 2nd point of the area. There are eight elements, set in the order of x, y, z, a, b, c, L1, L2. (L1 and L2 are the additional axes.) |
| | AREA1ME : AREA32ME | Designate which mechanism to use the 32 types of set area. The mechanism No. to use is set with 1 to 3. |
| | AREA1AT : AREA32AT | Designate the area check type. (Invalid/zone/interference = 0/1/2) Zone: The dedicated output signal USRAREA turns ON. Interference: An error occurs.. |
| Automatic return setting | RETPATH | Set to restart the program after returning to the interrupt position when resuming operation after an interruption. |
| Buzzer ON/OFF | BZR | Designate whether to the turn buzzer ON or OFF. |
| Jog setting | JOGJSP | Designate the joint jog and step operation speed. (Set dimension H/L amount, max. override.) |
| | JOGPSP | Designate the linear jog and step operation speed. (Set dimension H/L amount, max. override.) |
| Jog speed limit value | JOGSPMX | Limit the operation speed during the teaching mode. Max. 250[mm/s] |

| Parameter | | Details |
|--|--------------------|--|
| Hand type | HANDTYPE | Set the hand type of the single/double solenoid, and the signal No. (Single/double = S/D) Set the signal No. after the hand type. Example) D900 |
| Stop input B contact designation | INB | Change the dedicated input (stop) to either of normal open or normal close. |
| User-designated origin | USERORG | Designate the user-designated origin position. |
| Program selection memory | SLOTON | Select the program selected previously when initializing the slot. The non-selected state will be entered when not set. |
| Communication setting | CBAU232 | Set the baud rate. |
| | CLEN232 | Set the character length. |
| | CPRTY232 | Set the parity. |
| | CSTOP232 | Set the stop bit. |
| | CTERM232 | Set the end code. |
| Slot table | SLT1 : SLT32 | Make settings (program name, operation type, order of priority, etc.) for each slot during slot initialization. |
| No. of multi-tasks | TASKMAX | Designate the No. of programs to be executed simultaneously. (Max. 32) |
| Multi CPU system setting | QMLTCPUN | At the multi CPU system, set the number of CPU units with which the standard base unit is equipped. |
| | QMLTCPUn | At the multi CPU system, set the number of points performing transmission and receipt between each CPU unit for the high speed communication function between multi CPU nos. 1 to 4. |
| | QMLTCPUS | At the CR750-Q/CR751-Q series controller, set the robot input signal offset for the multi CPU. |
| Select the function of singular point adjacent alarm | MESNGLSW | Designate the valid/invalid of the singular point adjacent alarm. (Invalid/Valid = 0/1) When this parameter is set up "VALID", this warning sound is buzzing even if parameter: BZR (buzzer ON/OFF) is set up "OFF". |
| Display language. | LNG | Change the language to display on the LCD display of teaching pendant. |

5 Instruction Manual

5.1 The details of each instruction manuals

The contents and purposes of the documents enclosed with this product are shown below. Use these documents according to the application.

Instruction manuals enclosed in dashed lines in the list below are for optional products.

For special specifications, a separate instruction manual describing the special section may be enclosed.

| | |
|---|---|
| Safety Manual | Explains the common precautions and safety measures to be taken for robot handling, system design and manufacture to ensure safety of the operators involved with the robot. |
| Standard Specifications | Explains the product's standard specifications, factory-set special specifications, option configuration and maintenance parts, etc. Precautions for safety and technology, when incorporating the robot, are also explained. |
| Robot Arm Setup & Maintenance | Explains the procedures required to operate the robot arm (unpacking, transportation, installation, confirmation of operation), and the maintenance and inspection procedures. |
| Controller Setup, Basic Operation and Maintenance | Explains the procedures required to operate the controller (unpacking, transportation, installation, confirmation of operation), basic operation from creating the program to automatic operation, and the maintenance and inspection procedures. |
| Detailed Explanation of Functions and Operations | Explains details on the functions and operations such as each function and operation, commands used in the program, connection with the external input/output device, and parameters, etc. |
| Troubleshooting | Explains the causes and remedies to be taken when an error occurs. Explanations are given for each error No. |
| Additional axis function | Explains the specifications, functions and operations of the additional axis control. |
| Tracking Function Manual | Explains the control function and specifications of conveyor tracking |
| Extended Function Instruction Manual | Explains the detailed description of data configuration of shared memory, monitoring, and operating procedures, about the PLC(CR750-Q/CR751-Q controller) and the GOT(CR750-D/CR751-D controller). |

6 Safety

6.1 Safety

Measures to be taken regarding safety of the industrial robot are specified in the "Labor Safety and Sanitation Rules". Always follow these rules when using the robot to ensure safety.

6.1.1 Self-diagnosis stop functions

This robot has the self-diagnosis stop functions shown in [Table 6-1](#) and the stop functions shown in [Table 6-2](#) for safe use.

Table 6-1 : Self-diagnosis stop functions

| No. | Function | Details | Remarks |
|-----|--|---|---|
| 1 | Overload protection function | Activates when the total servo current time exceeds the specified value. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 2 | Overcurrent diagnosis function | Activates when an overcurrent flows to the motor circuit. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 3 | Encoder disconnection diagnosis function | Activates when the encoder cable is disconnected. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 4 | Deflection over diagnosis function | Activates when an error occurs between the command value and actual position, and the error exceeds the specified amount. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 5 | AC power voltage drop diagnosis function | Activates when the AC power voltage drops below the specified value. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 6 | CPU error detection function | Activates when an error occurs in the CPU. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 7 | Overrun prevention function | Software limit detection | This is the limit provided by the software to enable operation only in the operation range. |
| | | Mechanical stopper | This is the mechanical stopper provided outside the software. |

Table 6-2 : List of stop functions

| Stop function | Operation panel | Teaching pendant | External input | Details |
|----------------|-----------------|------------------|----------------|--|
| Emergency stop | ○ | ○ | ○ | This is the stop with the highest degree of emergency. The servo power is shut off, and the mechanical brakes (all axes) activate to stop the robot. To recover, reset the alarm, and turn the servo ON with the servo ON command. |
| Stop | ○ | ○ | ○ | This is a stop operation with a high degree of emergency. The robot immediately decelerates and stops. Note that the servo power is not shut off. Use this when using the collision evasion sensor, etc. |

6.1.2 External input/output signals that can be used for safety protection measures

Table 6-3 : External input/output signals that can be used for safety protection measures

| Signal | Connection point | Parameter | Functions | Usage method | |
|--------|-----------------------------------|---------------------------|-----------|--|--|
| Input | External emergency stop Note1) | Connector (CNUSR11/12) | – | This servo power is shut off, and the robot stops immediately. | Externally installed emergency stop switch. Door switch on safety protection fence. Stopping at high-level error occurrence. |
| | Door switch | | – | | The door switch of the safe protection fence |
| | Enabling device input | | – | | Enabling device. The safety switch during teaching work |
| | Stop | Sequencer unit | STOP | The program execution is stopped, and the robot stops. The servo power is not shut off. | The robot is stopped when a peripheral device fault occurs. The servo power is not shut off. |
| | Servo OFF | | SRVOFF | The servo power can be shut off. | The robot is stopped when a peripheral device fault occurs. The servo power is not shut off. |
| | Automatic operation enable | | AUTOENA | Disables automatic operation when inactive. | Door switch on safety protection fence |
| Output | Emergency stop output | Connector (CNUSR11/12) | – | Outputs the input signal of external emergency stop or emergency stop switch of T/B turned on. | Display and warn the pilot lamp, the input signal of external emergency stop or the emergency stop switch of T/B turned on. |
| | In servo ON | Sequencer unit | SRVON | The servo power ON/OFF state is output. | The servo power ON/OFF state is shown and alerted with the display lamps. |
| | Waiting | | STOP | Outputs that the robot is temporarily stopped. | The temporary stop state is shown and alerted with the display lamps. |
| | In alarm | Connector (CNUSR2) | ERRRESET | Outputs when an alarm occurs in the robot. | The alarm state is shown and alerted with the display lamps. |
| | – | | | | |

Note1) The external emergency stop input is prepared as a normal close for safety proposes. Thus, if the emergency stop input circuit is opened when the robot is started up, the robot will not operate. Refer to [Page 149](#), “6.1.7 Examples of safety measures” for details.

And, refer to [Page 121](#), “(3) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings” for the function of the door switch input and the enabling device input.

6.1.3 Precautions for using robot

The safety measures for using the robot are specified in the “Labor Safety and Sanitation Rules”. An outline of the rules is given below.

(1) Robot installation

- Secure sufficient work space required to safely perform work such as teaching and maintenance related to the robot.
- Install the controller outside the robot's motion space. (If a safety fence is provided, install outside the fence.)
- Install the controller where the entire robot operation can be viewed.
- Install display lamps, etc., to indicate the robot's operation state.
- Securely fix the robot arm onto the fixing table with the designated bolts.

(2) Prevention of contact with operator

- Install a safety fence or enclosure so that the operator cannot easily enter the robot's motion space.
- Install an interlock function that will stop the robot if the safety fence or enclosure door is opened.

(3) Work procedures

- Create and observe work procedures for the robot teaching, operation, inspection and emergencies.
- Create hand signals to be followed when several operators are working together.
- Create displays such as “Teaching in Progress” and “Inspection in Progress” to be put up when an operator is in the robot's motion space so that other operators will not operate the operation panel (controller, control panel).

(4) Training

- Train the operators about the operations, maintenance and safety required for the robot work.
- Only trained and registered operators must operate the robot.
Participation in the “Special training for industrial robots” sponsored by the Labor Safety and Sanitation Committee, etc., is recommended for safety training.

(5) Daily inspection and periodic inspection

- Always inspect the robot before starting daily operations and confirm that there are no abnormalities.
- Set the periodic inspection standards in view of the robot's ambient environment and operation frequency, and perform periodic inspections.
- Make records when periodic inspections and repairs have been done, and store the records for three or more years.

6.1.4 Safety measures for automatic operation

- (1) Install safety fences so that operators will not enter the operation area during operation and indicate that automatic operation is in progress with lamps, etc.
- (2) Create signals to be given when starting operation, assign a person to give the signal, and make sure that the operator follows the signals.

6.1.5 Safety measures for teaching

Observe the following measures when teaching, etc., in the robot's operation range.

- (1) Specify and follow items such as procedures related to teaching work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that teaching work is being done.
- (4) Always inspect that stop functions such as the emergency stop device before starting the work.
- (5) Immediately stop the work when trouble occurs, and correct the trouble.
- (6) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (7) The teaching operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (8) Create signals to be used when several operators are working together.


6.1.6 Safety measures for maintenance and inspections, etc.

Turn the power OFF and take measures to prevent operators other than the relevant operator from pressing the start switch when performing inspections, repairs, adjustments, cleaning or oiling.

If operation is required, take measures to prevent hazards caused by unintentional or mistaken operations.

- (1) Specify and follow items such as procedures related to maintenance work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that work is being done.
- (4) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (5) The operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (6) Create signals to be used when several operators are working together.

<Wiring example 2>: Connect the emergency stop switch of peripheral equipment to the drive unit.
 The power supply for emergency stop input uses the power supply of peripheral equipment.
 <Operation of the emergency stop>
 If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state.



- *1) Each of the connectors, CNUSR11 and CNUSR12, are assigned with the same pin number, creating 2 systems in each terminal. It is absolutely necessary to connect the 2 systems.
- *2) You can see in the diagram that connector CNUSR2 has 2 terminals and 2 systems (16/17 indicates 2 terminals at pin number 16 and pin number 17). It is absolutely necessary to connect the 2 systems.


- *3) The T/B emergency stop button connected with the drive unit.
- *4) Emergency stop input relay.
- *5) Refer to Standard specification manual for the enabling device.
- *6) The emergency stop button of the robot controller.
(Only specification with the operation panel.)
- *7) The emergency stop input detection relay uses the drive unit's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.

Fig.6-2 : Example of safety measures (CR750 wiring example 2)

<Wiring example 3>: Connect the emergency stop switch, door switch, and enabling device of peripheral equipment to the drive unit. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of drive unit OFF, peripheral equipment state can be the emergency stop also.




- *1) Each of the connectors, CNUSR11 and CNUSR12, are assigned with the same pin number, creating 2 systems in each terminal. It is absolutely necessary to connect the 2 systems.
- *2) You can see in the diagram that connector CNUSR2 has 2 terminals and 2 systems (16/17 indicates 2 terminals at pin number 16 and pin number 17). It is absolutely necessary to connect the 2 systems.
- *4) Emergency stop input relay.
- *5) Refer to Standard specification manual for the enabling device.
- *6) The emergency stop button of the robot controller.
(Only specification with the operation panel.)
- *7) The emergency stop input detection relay uses the drive unit's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.

Fig.6-3 : Example of safety measures (CR750 wiring example 3)

<Wiring example 4>: Connect the emergency stop switch of peripheral equipment, and the door switch to two drive units, and it interlocks. Connect the enabling device to the robot controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>


If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of drive unit OFF, peripheral equipment state can be the emergency stop also.



- *1) Each of the connectors, CNUSR11 and CNUSR12, are assigned with the same pin number, creating 2 systems in each terminal. It is absolutely necessary to connect the 2 systems.
- *2) You can see in the diagram that connector CNUSR2 has 2 terminals and 2 systems (16/17 indicates 2 terminals at pin number 16 and pin number 17). It is absolutely necessary to connect the 2 systems.
- *3) The T/B emergency stop button connected with the drive unit.
- *4) Emergency stop input relay.
- *5) Refer to Standard specification manual for the enabling device.
- *6) The emergency stop button of the robot controller. (Only specification with the operation panel.)
- *7) The emergency stop input detection relay uses the drive unit's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.

Fig.6-4 : Example of safety measures (CR750 wiring example 4)

<Wiring example 5>: Connect the drive unit to the safety relay
Use the drive unit's emergency stop button command as an input to the safety relay.



[Caution]

- 1) This product has category 3 functionality and therefore the robot's whole unit cannot be set to category 4.
- 2) The controller's internal circuit has polarity. Please adhere to the polarity as detailed in the wiring examples, particularly for emergency stop button output when using user equipment. Connect the positive side of the user equipment (24V DC) to the terminal 2 of CNUSR11/12, then connect the emergency stop button (or contact points) in the user equipment to across the terminals 3 and 4 of CNUSR11/12, and ultimately connect the negative side (0V DC).
- 3) When installing a safety relay to use it as an input point of the controller's emergency stop button command, use a safety relay that is activated by an input from one of the two systems (i.e. Omron's G9S Series).
- 4) The emergency stop input detection relay (internal relay) uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.
- 5) When connecting emergency stop button output to an external safety relay, please take note of the polarity and make sure that the electrical current flows in the same direction as indicated by the dotted arrows in the two places in the diagram. If the polarity is setup incorrectly, this function will not operate correctly. Please connect the terminal 13 of CNUSR11/12 to 24V.

Fig.6-5 : Example of safety measures (CR750 wiring example 5)

(2) External emergency stop connection [supplementary explanation]

- (1) Use a 2-contact type switch for all switches.
- (2) Install a limit switch on the safety fence's door. With a constantly open contact (normal open), wire to the door switch input terminal so that the switch turns ON (is conducted) when the door is closed, and turns OFF (is opened) when the door is open.
- (3) Use a manual-return type of normal close which have two lines for the emergency stop button.
- (4) Classify the faults into minor faults (faults that are easily restored and that do not have a great effect) and major faults (faults that cause the entire system to stop immediately, and that require care in restoration), and wire accordingly.

[Caution] The emergency stop input (terminal block) on the user wiring in the drive unit can be used for safety measures as shown in figure above. Note that there are limits to the No. of switch contacts, capacity and cable length, so refer to the following and install.

- Switch contactPrepare a 2-contact type.*1)
- Switch contact capacity.....Use a normal open contact that operates with a switch contact capacity of approx. 1mA to 100mA/24V. *1)
If you connect the relay etc., rated current of the coil should use the relay which is 100mA/24V or less. (Refer to Fig. 6-6)
- Cable length.....The length of the wire between the switch and terminal block must be max. 15m or less. Please use the shield line, in case of the cable may receive the noise etc. by other equipment, such as servo amplifier. And, since the ferrite core is attached as noise measures parts, please utilize.
The size of the wire that fits to use is shown below.
 - CR750 drive unit..... CNUSR11/12/13 connector:
AWG #26 to #16 (0.14mm² to 1.5mm²)
 - CR750 drive unit..... CNUSR2 connector:
AWG #30 to #24 (0.05mm² to 0.2mm²)

Electric specification of the emergency stop related output circuit is 100mA/24V or less. Don't connect the equipment except for this range.

*1) The minimum load electric current of the switch is more than 5mA/24V.





Fig.6-6 : Limitations when connecting the relay etc. (CR750)

[Supplementary explanation regarding emergency stop circuit]

The drive unit's internal circuit is as shown in the below diagram. Be sure to build a circuit that properly shuts off the emergency stop detection relay when the emergency stop button is pressed.



⚠ CAUTION Be sure to perform wiring correctly. If there are mistakes in the wiring, the robot may not stop when the emergency stop button is pressed and there will be a risk of damage or personal injury occurring.
After wiring, be sure to press each of the installed emergency stop switches and check whether the emergency stop circuit works properly.

⚠ CAUTION Be sure to duplicate connection of the emergency stop, door switch and enabling switch. If not duplicated, these functions may fail due to a broken relay used by customer, etc.

6.2 Working environment

Avoid installation in the following places as the equipment's life and operation will be affected by the ambient environment conditions. When using in the following conditions, the customer must pay special attention to the preventive measures.

(1) Power supply

- Where the voltage fluctuation will exceed the input voltage range.
- Where a momentary power failure exceeding 20ms may occur.
- Where the power capacity cannot be sufficiently secured.

CAUTION

Please use the controller with an input power supply voltage fluctuation rate of 10% or less. In the case of 200 VAC input, for example, if the controller is used with 180 VAC during the day and 220 VAC during the night, turn the servo off once and then on again. If this is not performed, an excessive regeneration error may occur.

(2) Noise

- Where a surge voltage exceeding 1000V, 1 μ s may be applied on the primary voltage. Near large inverters, high output frequency oscillator, large contactors and welding machines. Static noise may enter the lines when this product is used near radios or televisions. Keep the robot away from these items.

(3) Temperature and humidity

- Where the atmospheric temperature exceeds 40 degree , lower than 0 degree.
- Where the relative humidity exceeds 85%, lower than 45%, and where dew may condense.
- Where the robot will be subject to direct sunlight or near heat generating sources such as heaters.

(4) Vibration

- Where excessive vibration or impact may be applied. (Use in an environment of 34m/s² or less during transportation and 5m/s² or less during operation.)

(5) Installation environment

- Where strong electric fields or magnetic fields are generated.
- Where the installation surface is rough. (Avoid installing the robot on a bumpy or inclined floor.)
- Where there is heavy powder dust and oil mist present.

6.3 Precautions for handling

- (1) This robot has brakes on J3 axes. The precision of the robot may drop, looseness may occur and the reduction gears may be damaged if the robot is moved with force with the brakes applied.
- (2) Avoid moving the robot arm by hand. When unavoidable, gradually move the arm. If moved suddenly, the accuracy may drop due to an excessive backlash, or the backed up data may be destroyed.
- (3) Note that depending on the posture, even when within the movement range, the shaft section could interfere with the base section. Take care to prevent interference during jog. ^{*1)}
- (4) The robot arm is configured of precision parts such as bearings. Grease is used for lubricating these parts. When cold starting at low temperatures or starting operation after long-term stoppage, the position accuracy may drop or servo alarms may occur. If these problems occur, perform a 5 to 10 minute running-in operation at a low speed (about a half of normal operating speed).
- (5) The robot arm and controller must be grounded with 100 Ω or less (class D grounding) to secure the noise resistance and to prevent electric shocks.
- (6) The items described in these specifications are conditions for carrying out the periodic maintenance and inspections described in the instruction manual.
- (7) When using the robot arm on a mobile axis or elevating table, the machine cables enclosed as standard configuration may break due to the fixed installation specifications. In this case, use "the machine cable extension (for flexed)" factory shipment special specifications or options.

*1) Jog operation refers to operating the robot manually using the teaching pendant.

-
- (8) If this robot interferes with the workpiece or peripheral devices during operation, the position may deviate, etc.
Take care to prevent interference with the workpiece or peripheral devices during operation.
 - (9) Do not attach a tape or a label to the robot arm and the controller. If a tape or a label with strong adhesive power, such as a packaging tape, is attached to the coated surfaces of the robot arm and controller, the coated surface may be damaged when such tape or label is peeled off.
 - (10) If the robot is operated with a heavy load and at a high speed, the surface of the robot arm gets very hot. It would not result in burns, however, it may cause secondary accidents if touched carelessly.
 - (11) Do not shut down the input power supply to stop the robot. If the power supply is frequently shut down during a heavy load or high-speed operation, the speed reducer may be damaged, backlash may occur, and the program data may be destroyed.
 - (12) During the robot's automatic operation, a break is applied to the robot arm when the input power supply is shut down by a power failure, for instance. When a break is applied, the arm may deviate from the operation path predetermined by automatic operation and, as a result, it may interfere with the mechanical stopper depending on the operation at shutdown. In such a case, take an appropriate measure in advance to prevent any dangerous situation from occurring due to the interference between the arm and peripheral devices.
Example) Installing a UPS (uninterruptible power supply unit) to the primary power source in order to reduce interference.
 - (13) Do not conduct an insulated voltage test. If conducted by mistake, it may result in a breakdown.
 - (14) When the sequencer system becomes large too much, the robot's locus may deteriorate uncommonly. If this phenomenon occurs, inform to the dealer. And, when it turns out that the system is enlarged in advance, please inform our company.
 - (15) Fretting may occur on the axis which moving angle or moving distance move minutely, or not moves. Fretting is that the required oil film becomes hard to be formed if the moving angle is small, and wear occurs. The axis which not moved is moving slightly by vibration etc. To make no fretting recommends to move these axes about once every day the 30 degree or more, or the 20mm or more.
 - (16) The United Nations' Recommendations on the Transport of Dangerous Goods must be observed for trans-border transportation of lithium batteries by air, sea, and land. The lithium batteries (ER6, Q6BAT) used in Mitsubishi industrial robots contain less than 1 g of lithium and are not classified as dangerous goods. However, if the quantity of lithium batteries exceeds 24 batteries for storage, etc., they will be classified as Class 9: Miscellaneous dangerous substances and articles. Shipping less than 24 batteries is recommended to avoid having to carry out transport safety measures as the customer's consignor. Note that some transportation companies may request an indication that the batteries are not dangerous goods be included on the invoice. For shipping requirement details, please contact your transportation company.
 - (17) If the air supply temperature (primary piping) used for the tool etc. is lower than ambient air temperature, the dew condensation may occur on the coupling or the hose surface.
 - (18) Collision detection function is valid condition for both of automatic and jog operation at shipping.
So, the robot stops immediately if the robot's tool or arm interferes with a peripheral device, minimizing damage. Therefore, please use in the valid condition.

6.4 EMC installation guideline

6.4.1 Outlines

The EMC directive is coerced from January 1, 1996, and it is necessary to attach the CE mark which shows that the product is in conformity to directive.

Since the industrial robot is the component of the automation system, it considers that the EMC directive is not the target product of the direct. However, because it is one of the main components, introduces the method and components of the measures for conforming the automation system to the EMC directive.

And also we are carrying out the qualification test about the conformity of the EMC directive under the environment based on the contents of this document. However, the noise level is changed by the kind of equipment to be used, the layout, the construction of the controlling board, the course of wiring, etc. Therefore, please confirm by the customer eventually.

6.4.2 EMC directive

The Mitsubishi Electric industrial robot follows the European EMC directive. This technical standard regulates the following two items.

- (1) Emission (EMI : Electromagnetic Interference) The capacity not to generate the disturbance noise which has a bad influence outside.
- (2) Immunity (EMS : Electromagnetic Susceptibility)..... The capacity which does not malfunction for the disturbance noise from the outside.

Each contents are shown below.

| Item | Name | Contents | Testing technical-standard number |
|---------------------|--|---|---|
| Emission (EMI) | Radiative noise disturbance | The electromagnetic noise etc. which are emitted to environs. | EN61000-6-2 : 2005 EN61000-6-4 : 2007 EN62061:2005(Annex E) |
| | Electrical-conduction noise disturbance | The electromagnetism noise etc. which flow out of the power-supply line. | |
| Immunity (EMS) | Electrostatic discharge immunity test | The noise from the electrified human body. | |
| | Radiated, radio-frequency, electromagnetic field immunity test susceptibility test | The electromagnetism noise from the transceiver, the broadcasting station, etc. | |
| | Electrical fast transient burst immunity test | The relay noise or the electromagnetism noise etc. which are caused in power-supply ON/OFF. | |
| | Immunity to conducted disturbances induced radio-frequency fields | The electromagnetism noise etc. which flow in through the power source wire and the grounding wire. | |
| | Power frequency magnetic field immunity test | The electromagnetism noise with a power supply frequency of 50/60 Hz etc. | |
| | Voltage dips, short interruptions and voltage variations immunity test | The noise in the variation of the source voltage of the power dispatching, etc. | |
| Surge immunity test | The electromagnetism noise by the thunderbolt, etc. | | |

6.4.3 EMC measures

There are mainly following items in the EMC measures.

- (1) Store into the sealed metal board.
- (2) Grounding all the conductor that have floated electrically (makes the impedance low).
- (3) Wiring so that the power source wire and signal wire are separated.
- (4) Use the shield cable for the cable which wired outside of the metal board.
- (5) Install the noise filter.

To suppress the noise emitted out of the board, be careful of the following item.

- (1) Ensure grounding of the equipment.
- (2) Use the shield cable.
- (3) Separate the metal board electrically. Narrows the distance/hole.

The strength of electromagnetic noise emitted to environment is changed a lot by the shielding efficiency of cable and the distance of metal board, so it should be careful.

6.4.4 Component parts for EMC measures


(1) Ferrite core

The ferrite core is mounted by the plastics case as one. It can attach by the one-touch, without cutting the cable. This has the effect in the common-mode noise. The measures against the noise are made not influential in the quality of the signal.

There are the following as an example.


Maker: SEIWA ELECTRIC MFG. Co.,Ltd.

| Type | Outside dimension (mm) | | | | Diameter of the adaptation cable [max] (mm) |
|-------------|------------------------|----|----|----|---|
| | A | B | C | D | |
| E04SR401938 | 61 | 38 | 19 | 40 | 19.0 |
| E04SR301334 | 39 | 34 | 13 | 30 | 13.0 |




Maker: TAKACHI ELECTRONICS ENCLOSURE CO., LTD.

| Type | Outside dimension (mm) | | | | Diameter of the adaptation cable [max] (mm) |
|-------------|------------------------|------|------|---|---|
| | A | B | C | D | |
| TFT-274015S | 43.8 | 27.4 | 20.7 | - | φ 26.5 |



(2) Line noise filter

Type : FR-BLF (Mitsubishi Electric Corp.)



7 Appendix
Appendix 1 : Specifications discussion material (RH-6FH series)

■ Customer information

| | | | |
|--------------|--|-----------|--|
| Company name | | Name | |
| Address | | Telephone | |

■ Purchased mode

| Item | Type | Arm length | Stroke | Controller |
|---|----------------------|--|---|-------------------|
| General specification | RH-6FH □□△△ -Q | <input type="checkbox"/> 350 <input type="checkbox"/> 450 <input type="checkbox"/> 550 | <input type="checkbox"/> 200 <input type="checkbox"/> 340 | CR750-06HQ-1 |
| Clean specification | RH-6FH □□△△ C-Q | <input type="checkbox"/> 350 <input type="checkbox"/> 450 <input type="checkbox"/> 550 | <input type="checkbox"/> 200 <input type="checkbox"/> 340 | |
| Oil mist specification | RH-6FH □□△△ M-Q | <input type="checkbox"/> 350 <input type="checkbox"/> 450 <input type="checkbox"/> 550 | <input type="checkbox"/> 200 <input type="checkbox"/> 340 | |
| CE marking specification | | | | |
| Standard specification (IP54) ^{Note1)} | RH-6FH □□△△ -Q1-S15 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 <input type="checkbox"/> 550 | <input type="checkbox"/> 200 <input type="checkbox"/> 340 | CR750-06HQ1-1-S15 |
| Clean specification | RH-6FH □□△△ C-Q1-S15 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 <input type="checkbox"/> 550 | <input type="checkbox"/> 200 <input type="checkbox"/> 340 | |

Note1) When you wish to have bellows, contact our dealer.

■ Shipping special specifications (Settings can be made only at time of shipment)

| Item | Standard specification | Special shipping specifications |
|------------|---|---|
| Robot arm | Machine cable <input type="checkbox"/> 5m fixed type | <input type="checkbox"/> 2m fixed type: 1S-02UCBL-01 |
| Controller | Robot CPU unit connecting cable set ^{Note1)} <input type="checkbox"/> 10m | <input type="checkbox"/> Not provided <input type="checkbox"/> 5m <input type="checkbox"/> 20m <input type="checkbox"/> 30m: 2Q-RC-CBL □□ M |

Note1) The four type cables shown in below are contained. (Each cable length is the same.)

- 1)2Q-TUCBL □□ M, 2)2Q-DISPCBL □□ M, 3)2Q-EMICBL □□ M,
- 4)MR-J3BUS □□ M-A (5m, 20m) or MR-J3BUS □□ M-B (30m)

■ Options (Installable after shipment)

| Item | Type | Provision, and specifications when provided. | |
|----------------------------|-----------------------------------|--|--|
| Robot arm | J1 axis operating range change | 1F-DH-01 <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | Machine cable extension | 1S- □□ CBL-01 | Fixed type (extension type): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | | 1S- □□ LCBL-01 | Flexed type (extension type): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | | 1S- □□ LUCBL-01 | Flexed type (direct type): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | Solenoid valve set | 1F-VD0 □ -01 1F-VD0 □ E-01 <input type="checkbox"/> Not provide 1F-VD0 □ -01 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1F-VD0 □ E-01 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set | |
| | Hand input cable | 1F-HC35C-01 <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | Hand output cable | 1F-GR60S-01 <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | Hand curl tube | 1E-ST0408C-300 <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| External Wiring/Piping box | 1F-UT-BOX | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | Internal Wiring/Piping for hand | 1F-HS408S-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 200mm stroke) |
| | | 1F-HS408S-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 340mm stroke) |
| Controller | Simple teaching pendant | R32TB- □□ <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m | |
| | Highly efficient teaching pendant | R56TB- □□ <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m | |
| | Controller protection box | CR750-MB <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | RT ToolBox2 | 3D-11C-WINJ <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM | |
| | RT ToolBox2 mini | 3D-12C-WINJ <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM | |
| | Network vision sensor | 4D-2CG5***-PKG <input type="checkbox"/> Not provided <input type="checkbox"/> Provided | |
| | Instructions manual | 5F-RB01-PE01 <input type="checkbox"/> Not provided <input type="checkbox"/> Provided () sets | |

■ Maintenance parts (Consumable parts)

| | |
|-------------------|--|
| Maintenance parts | <input type="checkbox"/> Backup batteries ER6 () pcs. <input type="checkbox"/> Backup batteries Q6BAT () pcs. <input type="checkbox"/> Grease () cans |
|-------------------|--|

■ Robot selection check list

| | | | |
|----------------------|--|--|--|
| Work description | <input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other () | | |
| Workpiece mass () g | Hand mass () g | Atmosphere <input type="checkbox"/> General environment <input type="checkbox"/> Clean <input type="checkbox"/> Oil mist: Confirm oil proof <input type="checkbox"/> request (Oil name:)/ <input type="checkbox"/> not request ^{Note1)} <input type="checkbox"/> Dusts (Please take measures such as a jacket.), <input type="checkbox"/> Chemicals (Please consult), <input type="checkbox"/> Other () | |
| Remarks | | | |

Note1) Refer to Page 25, "2.2.7 Protection specifications" about oil resistance.

Appendix 2 : Specifications discussion material (RH-12FH series)

■ Customer information

| | | | |
|--------------|--|-----------|--|
| Company name | | Name | |
| Address | | Telephone | |

■ Purchased mode

| Item | Type | Arm length | Stroke | Controller |
|------------------------|------------------|--|---|--------------|
| General specification | RH-12FH □□△△ -Q | <input type="checkbox"/> 550 <input type="checkbox"/> 700 <input type="checkbox"/> 850 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | CR750-12HQ-1 |
| Clean specification | RH-12FH □□△△ C-Q | <input type="checkbox"/> 550 <input type="checkbox"/> 700 <input type="checkbox"/> 850 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | |
| Oil mist specification | RH-12FH □□△△ M-Q | <input type="checkbox"/> 550 <input type="checkbox"/> 700 <input type="checkbox"/> 850 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | |

■ Shipping special specifications (Settings can be made only at time of shipment)

| Item | | Standard specification | Special shipping specifications |
|------------|---|--|---|
| Robot arm | Machine cable | <input type="checkbox"/> 5m fixed type | <input type="checkbox"/> 2m fixed type: 1S-02UCBL-01 |
| Controller | Robot CPU unit connecting cable set ^{Note1)} | <input type="checkbox"/> 10m | <input type="checkbox"/> Not provided <input type="checkbox"/> 5m <input type="checkbox"/> 20m <input type="checkbox"/> 30m: 2Q-RC-CBL □□ M |

Note1) The four type cables shown in below are contained. (Each cable length is the same.)

1)2Q-TUCBL □□ M, 2)2Q-DISPCBL □□ M, 3)2Q-EMICBL □□ M,

4)MR-J3BUS □□ M-A (5m, 20m) or MR-J3BUS □□ M-B (30m)

■ Options (Installable after shipment)

| item | | Type | Provision, and specifications when provided. |
|---------------------------------|-----------------------------------|--|---|
| Robot arm | J1 axis operating range change | 1F-DH-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Machine cable extension | 1S- □□ CBL-01 | Fixed type: <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | | 1S- □□ LCBL-01 | Flexed type: <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | Solenoid valve set | 1S-VD0 □ -01 1S-VD0 □ E-01 | <input type="checkbox"/> Not provide 1S-VD0 □ -01 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1S-VD0 □ E-01 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set |
| | Hand input cable | 1F-HC35C-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Hand output cable | 1F-GR60S-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Hand curl tube | 1N-ST0608C-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | External Wiring/Piping box | 1F-UT-BOX-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| Internal Wiring/Piping for hand | 1F-HS604S-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 350mm stroke) | |
| | 1F-HS604S-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 450mm stroke) | |
| Controller | Simple teaching pendant | R32TB- □□ | <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m |
| | Highly efficient teaching pendant | R56TB- □□ | <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m |
| | Controller protection box | CR750-MB | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | RT ToolBox2 | 3D-11C-WINJ | <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM |
| | RT ToolBox2 mini | 3D-12C-WINJ | <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM |
| | Network vision sensor | 4D-2CG5***-PKG | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Instructions manual | 5F-RB01-PE01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided () sets |

■ Maintenance parts (Consumable parts)

| | |
|-------------------|--|
| Maintenance parts | <input type="checkbox"/> Backup batteries ER6 () pcs. <input type="checkbox"/> Backup batteries Q6BAT () pcs. <input type="checkbox"/> Grease () cans |
|-------------------|--|

■ Robot selection check list

| | | | |
|----------------------|--|---|--|
| Work description | <input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other () | | |
| Workpiece mass () g | Hand mass () g | Atmosphere <input type="checkbox"/> General environment, <input type="checkbox"/> Clean <input type="checkbox"/> Oil mist: Confirm oil proof <input type="checkbox"/> request (Oil name:)/ <input type="checkbox"/> not request ^{Note1)} <input type="checkbox"/> Dusts (Please take measures such as a jacket.), <input type="checkbox"/> Chemicals (Please consult), <input type="checkbox"/> Other () | |
| Remarks | | | |

Note1) Refer to Page 25, "2.2.7 Protection specifications" about oil resistance.

Appendix 3 : Specifications discussion material (RH-20FH series)

■ Customer information

| | | | |
|--------------|--|-----------|--|
| Company name | | Name | |
| Address | | Telephone | |

■ Purchased mode

| Item | Type | Arm length | Stroke | Controller |
|------------------------|------------------|--|---|--------------|
| General specification | RH-20FH □□△△ -Q | <input type="checkbox"/> 850 <input type="checkbox"/> 1000 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | CR750-20HQ-1 |
| Clean specification | RH-20FH □□△△ C-Q | <input type="checkbox"/> 850 <input type="checkbox"/> 1000 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | |
| Oil mist specification | RH-20FH □□△△ M-Q | <input type="checkbox"/> 850 <input type="checkbox"/> 1000 | <input type="checkbox"/> 350 <input type="checkbox"/> 450 | |

■ Shipping special specifications (Settings can be made only at time of shipment)

| Item | | Standard specification | Special shipping specifications |
|------------|---|--|---|
| Robot arm | Machine cable | <input type="checkbox"/> 5m fixed type | <input type="checkbox"/> 2m fixed type: 1S-02UCBL-01 |
| Controller | Robot CPU unit connecting cable set <small>Note1)</small> | <input type="checkbox"/> 10m | <input type="checkbox"/> Not provided <input type="checkbox"/> 5m <input type="checkbox"/> 20m <input type="checkbox"/> 30m: 2Q-RC-CBL □□ M |

Note1) The four type cables shown in below are contained. (Each cable length is the same.)

1)2Q-TUCBL □□ M, 2)2Q-DISPCBL □□ M, 3)2Q-EMICBL □□ M,

4)MR-J3BUS □□ M-A (5m, 20m) or MR-J3BUS □□ M-B (30m)

■ Options (Installable after shipment)

| item | | Type | Provision, and specifications when provided. |
|---------------------------------|-----------------------------------|--|---|
| Robot arm | J1 axis operating range change | 1F-DH-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Machine cable extension | 1S- □□ CBL-01 | Fixed type: <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | | 1S- □□ LCBL-01 | Flexed type: <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m |
| | Solenoid valve set | 1S-VD0 □ -01 1S-VD0 □ E-01 | <input type="checkbox"/> Not provide 1S-VD0 □ -01 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1S-VD0 □ E-01 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set |
| | Hand input cable | 1F-HC35C-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Hand output cable | 1F-GR60S-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Hand curl tube | 1N-ST0608C-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | External Wiring/Piping box | 1F-UT-BOX-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| Internal Wiring/Piping for hand | 1F-HS604S-01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 350mm stroke) | |
| | 1F-HS604S-02 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided (For 450mm stroke) | |
| Controller | Simple teaching pendant | R32TB- □□ | <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m |
| | Highly efficient teaching pendant | R56TB- □□ | <input type="checkbox"/> Not provided <input type="checkbox"/> 7m <input type="checkbox"/> 15m |
| | Controller protection box | CR750-MB | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | RT ToolBox2 | 3D-11C-WINJ | <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM |
| | RT ToolBox2 mini | 3D-12C-WINJ | <input type="checkbox"/> Not provided <input type="checkbox"/> Windows2000/XP/Vista/7 English CD-ROM |
| | Network vision sensor | 4D-2CG5***-PKG | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided |
| | Instructions manual | 5F-RB01-PE01 | <input type="checkbox"/> Not provided <input type="checkbox"/> Provided () sets |

■ Maintenance parts (Consumable parts)

| | |
|-------------------|--|
| Maintenance parts | <input type="checkbox"/> Backup batteries ER6 () pcs. <input type="checkbox"/> Backup batteries Q6BAT () pcs. <input type="checkbox"/> Grease () cans |
|-------------------|--|

■ Robot selection check list

| | | | |
|----------------------|--|--|--|
| Work description | <input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other () | | |
| Workpiece mass () g | Hand mass () g | Atmosphere <input type="checkbox"/> General environment, <input type="checkbox"/> Clean <input type="checkbox"/> Oil mist: Confirm oil proof <input type="checkbox"/> request (Oil name:)/ <input type="checkbox"/> not request ^{Note1)} <input type="checkbox"/> Dusts (Please take measures such as a jacket), <input type="checkbox"/> Chemicals (Please consult), <input type="checkbox"/> Other () | |
| Remarks | | | |

Note1) Refer to Page 25, "2.2.7 Protection specifications" about oil resistance.



Product Service

EC-Statement of Compliance

No. E6 12 11 25554 047

Holder of Certificate: Mitsubishi Electric CorporationTokyo BILD., 2-7-3 Marunouchi,
Chiyoda-ku
Tokyo
100-8310 JAPAN**Name of Object:** Industrial, Scientific and Medical
equipment
Industrial Robot**Model(s):** F series
(See Attachment for Nomenclature)**Description of Object:** Rated Voltage: 230 VAC
Rated Power: 1.7 kW
Protection Class: I**Tested according to:** EN 61000-6-4/A1:2011
EN 61000-6-2:2005

This EC-Statement of Compliance is issued according to the Directive 2004/108/EC relating to electromagnetic compatibility. It confirms that the listed apparatus complies with such aspects of the essential requirements of the EMC directive as specified by the manufacturer or his authorized representative in the European Community and applies only to the sample and its technical documentation submitted to TÜV SÜD Product Service GmbH for testing and certification. See also notes overleaf.

Technical report no.: 73539409**Date,** 2012-11-26 (Johann Roidt)

TÜV SÜD Product Service GmbH is Notified Body to the Directive 2004/108/EC of the European Parliament and of the council with the identification number 0123.

Page 1 of 6

Attachment

Statement No.

E6 12 11 25554 047



Product Service

Nomenclature

A: Model name of **F** series Robot description is shown as follows.

A1:RH-3FH,RH6FHseries 1.7kW

RH-x FH xx xx x - x x x-Sxx

(1) (2) (3)(4) (5) (6) (7) (8) (9) (10) (11)

(1)**RH**: Horizontal Robot

(2) Maximum Payload specification:

3 : 3kg

6 : 6kg

(3) **F** : **F** series robot

(4)**H** :4 joints

(5) Robot Arm length(No1 and No2 arm) specification:

35 : 350 mm arm

45 : 450 mm arm

55 : 550 mm arm

(6) Z stroke length specification:

12 : 120 mm arm

15 : 150 mm arm

20 : 200 mm arm

34 : 340 mm arm

(7) Dimension and Ambient specification:

M : Oil mist model(IP65)

C : Clean room model(ISO5)

[none] : Basic model(IP54)

(8) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(9)Robot controller type:

D :Stand alone type

Q :iQ platform type

(10)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(11)Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

Sxx :Mechanical option

Attachment

Statement No.

E6 12 11 25554 047



Product Service

A2:RH-12FH,RH-20FHseries 1.7kW

RH-x FH xx xx x - x x x-Sxx
 (1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)

(1) **RH**: Horizontal Robot

(2) Maximum Payload specification:

12 : 12kg

20 : 20kg

(3) **F** : **F** series robot

(4) **H** : 4 joints

(5) Robot Arm length(No1 and No2 arm) specification:

55 : 550 mm arm

70 : 700 mm arm

85 : 850 mm arm

100 : 1000 mm arm

(6) Z stroke length specification:

35 : 350 mm arm

45 : 450 mm arm

(7) Dimension and Ambient specification:

M : Oil mist model(IP65)

C : Clean room model(ISO3)

N : Special spec. For EU(IP54)

[none] : Basic model(IP20)

(8) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(9)Robot controller type:

D :Stand alone type

Q :iQ platform type

(10)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(11)Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

Sxx :Mechanical option

Attachment

Statement No.

E6 12 11 25554 047



Product Service

A3:RV-2Fseries 1.7kW

RV-x F x - x x x-Sxx
(1) (2) (3) (4) (5) (6) (7) (8)

(1)RV: Vertical Robot

(2) Maximum Payload specification:

2 : 2kg

(3) **F** : **F** series robot

(4)Robot Joint type

B :All axes have brake units.

[none] :J4 axis doesn't have brake unit.

(5) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(6)Robot controller type:

D :Stand alone type

Q :iQ platform type

(7)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(8)Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

Sxx :Mechanical option

Attachment

Statement No.

E6 12 11 25554 047



Product Service

A4:RV-4F,7Fseries 1.7kW

RV-x F x x - x x x-Sxx

(1) (2) (3) (4) (5) (6) (7) (8) (9)

(1) **RV**: Vertical Robot

(2) Maximum Payload specification:

4 : 4kg

7 : 7kg

(3) **F** : **F** series robot

(4) Robot arm length:

L : Long arm model

[none] : normal model

(5) Dimension and Ambient specification:

M : Oil mist model(IP67)

C : Clean room model(ISO3)

[none] : Basic model(IP40)

(6) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(7)Robot controller type:

D :Stand alone type

Q :iQ platform type

(8)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(9)Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

SH :Internal tube and wires are extended to J6 axis.

Sxx :Mechanical option

Attachment

Statement No.

E6 12 11 25554 047



Product Service

B: Model name of **F** series Robot controller description is shown as follows.

CR750- xx x x x - x - x Sxx
 (1) (2) (3) (4) (5) (6) (7) (8)

(1)**CR750**: CR750 controller

(2) Maximum Payload specification:

03 : 3kg

06 : 6kg

12 : 12kg

20 : 20kg

02 : 2kg

04 : 4kg

07 : 7kg

(3) Robot type

H : Horizontal robot

V : Vertical robot

(4)Robot controller type

D :stand alone

Q :iQ platform type

(5)Standard

1 :CE marking model

2 :CE marking and UL model

(6)Operation Panel

[none] :No panel type

1 :Panel type

(7)Power input connector type

[none] :normal type

P2 :Added cable with a connector and a terminal

P3 :Added cable with a connector and a terminal block

(8)Optional Specification

[none] :normal

SM :Added Cabinet box over robot controller for oil mist resist

Sxx :mechanical option



EC DECLARATION OF CONFORMITY
 (According to EMC Directive)
EC DECLARATION OF INCORPORATION
 (According to Machinery Directive)

We,

Manufacturer: MITSUBISHI ELECTRIC Corporation Nagoya Works
 Address 1-14 Yada-Minami 5-Chome Higashi-Ku, Nagoya 461-8670, Japan

(Place of Declare):

Declare under our sole responsibility that the Product

Description: Industrial Robot
 Type of Model: F series
 Notice: Details of Serial No. are as per attached sheet(P7).
 Restrictive use: For industrial environment only

Conforms with the essential requirements of the **EMC Directive 2004/108/EC** and the **Machinery Directive 2006/42/EC**, based on the following specifications applied:

| EU Harmonized Standards | | Non-harmonized Standard |
|-------------------------|---|-------------------------|
| EMC(2004/108/EC) | EN61000-6-4:2007 EN61000-6-2:2005 | N/A |
| Machinery(2006/42/EC) | Type A: Fundamental safety standards EN ISO12100-1:2003 EN ISO12100-2:2003 EN 1050:1997 Type B: Group safety standards B1: Safety aspects EN60204-1:2006, EN294:1992, EN349:1993 ISO13849-1:2006 (Category 3 and Performance level "d") Type C: Machine Safety standard ISO10218-1:2011 | N/A |

and therefore complies with the essential requirements and provisions of the EMC Directive and the Machinery Directive.

< Partly completed Machinery >

This product meets the specification and/or the performance by correct installing.
 So it must not be used until being installed into the final machinery of the customer.

Issue Date (Date of Declaration): November 5, 2012

The identity and signature of the person empowered to bind the manufacturer or his authorized representative.

Tomoyuki Kobayashi
 (signature)

[Tomoyuki Kobayashi]

Senior Manager
 Robot Manufacturing Department
 MITSUBISHI ELECTRIC Corporation Nagoya Works

Authorized representative in Europe
 (The person authorized compiles the relevant Technical documentation)

[Signature]
 (signature)

[Hartmut Putz]

FA Product Marketing Director FA Group
 Gother St. 8, 40880 Ratingen, Germany
 MITSUBISHI Electric Europe B.V Germany

■ Declaration Type of models

RH-xFH xxxxx-xxx-Sxx




Fig.1-1 Nomenclature of F series robot (RH type Robot)

RH-xFH xxxxx - xxx - Sxx




Fig.1-2 Nomenclature of F series robot of RH-12FH,20FH

RV-xF x-xxx Sxx




Fig.1-3 Nomenclature of F series robot of RV-2F

RV-xFx x-xxx-Sxx




Fig.1-4 Nomenclature of F series robot of RV-4F,7F

CR750 - xx x x x - x-x - Sxx




Fig.2-1 Nomenclature of F series robot controller

■ Details of serial number




Fig.3.1 Nomenclature of serial number about F series Robot and robot controller

Revision history

| Date | Specifications No. | Details of revisions | Rev. |
|-----------------|-----------------------|---|------|
| April 16,2012 | | First print | * |
| May 25, 2012 | | Q type added | A |
| October 1,2012 | Fig.1-2,1-3,1-4 added | RH-12/20FH-D series,RV-2F-D series,RV-4F/7F-D series added | B |
| November 1,2012 | P1 P3-P7 | Form changed RH-12/20FH-Q series,RV-2F-Q series,RV-4F/7F-Q series added "Details of serial No." added | C |

사용자안내문 User's Guide

| 기종별 Type of Equipment | 사용자안내문 User's Guide |
|--|---|
| <p>A 급 기기 (업무용 방송통신기자재)</p> <p>Class A Equipment (Industrial Broadcasting & Communication Equipment)</p> | <p>이 기기는 업무용(A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.</p> <p>This equipment is Industrial (Class A) electromagnetic wave suitability equipment and seller or user should take notice of it, and this equipment is to be used in the places except for home.</p> |
| <p>B 급 기기 (가정용 방송통신기자재)</p> <p>Class B Equipment (For Home Use Broadcasting & Communication Equipment)</p> | <p>이 기기는 가정용(B 급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.</p> <p>This equipment is home use (Class B) electromagnetic wave suitability equipment and to be used mainly at home and it can be used in all areas.</p> |



Authorised representative:

MITSUBISHI ELECTRIC EUROPE B.V. GERMANY

Gothaer Str. 8, 40880 Ratingen / P.O. Box 1548, 40835 Ratingen, Germany

HEADQUARTERS

MITSUBISHI ELECTRIC EUROPE B.V. **EUROPE**
 German Branch
 Gothaer Straße 8
D-40880 Ratingen
 Phone: +49 (0)2102 / 486-0
 Fax: +49 (0)2102 / 486-1120

MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. **CZECH REP.**
 Czech Branch
 Avenir Business Park, Radlická 714/113a
CZ-158 00 Praha 5
 Phone: +420 - 251 551 470
 Fax: +420 (0)251-551-471

MITSUBISHI ELECTRIC EUROPE B.V. **FRANCE**
 French Branch
 25, Boulevard des Bouvets
F-92741 Nanterre Cedex
 Phone: +33 (0)1 / 55 68 55 68
 Fax: +33 (0)1 / 55 68 57 57

MITSUBISHI ELECTRIC EUROPE B.V. **IRELAND**
 Irish Branch
 Westgate Business Park, Ballymount
IRL-Dublin 24
 Phone: +353 (0)1 4198800
 Fax: +353 (0)1 4198890

MITSUBISHI ELECTRIC EUROPE B.V. **ITALY**
 Italian Branch
 Viale Colleoni 7
I-20864 Agrate Brianza (MB)
 Phone: +39 039 / 60 53 1
 Fax: +39 039 / 60 53 312

MITSUBISHI ELECTRIC EUROPE B.V. **POLAND**
 Poland Branch
 Krakowska 50
PL-32-083 Balice
 Phone: +48 (0)12 / 630 47 00
 Fax: +48 (0)12 / 630 47 01

MITSUBISHI ELECTRIC EUROPE B.V. **RUSSIA**
 52, bid. 3 Kosmodamianskaya nab 8 floor
RU-115054 Moscow
 Phone: +7 495 721-2070
 Fax: +7 495 721-2071

MITSUBISHI ELECTRIC EUROPE B.V. **SPAIN**
 Spanish Branch
 Carretera de Rubí 76-80
E-08190 Sant Cugat del Vallés (Barcelona)
 Phone: 902 131121 // +34 935653131
 Fax: +34 935891579

MITSUBISHI ELECTRIC EUROPE B.V. **UK**
 UK Branch
 Travellers Lane
UK-Hatfield, Herts. AL10 8XB
 Phone: +44 (0)1707 / 27 61 00
 Fax: +44 (0)1707 / 27 86 95

MITSUBISHI ELECTRIC CORPORATION **JAPAN**
 Office Tower "Z" 14 F
 8-12,1 chome, Harumi Chuo-Ku
Tokyo 104-6212
 Phone: +81 3 622 160 60
 Fax: +81 3 622 160 75

MITSUBISHI ELECTRIC AUTOMATION, Inc. **USA**
 500 Corporate Woods Parkway
Vernon Hills, IL 60061
 Phone: +1 847 478 21 00
 Fax: +1 847 478 22 53

EUROPEAN REPRESENTATIVES

GEVA **AUSTRIA**
 Wiener Straße 89
AT-2500 Baden
 Phone: +43 (0)2252 / 85 55 20
 Fax: +43 (0)2252 / 488 60

Koning & Hartman b.v. **BELGIUM**
 Woluwelaan 31
BE-1800 Vilvoorde
 Phone: +32 (0)2 / 257 02 40
 Fax: +32 (0)2 / 257 02 49

INEA RBT d.o.o. **BOSNIA AND HERZEGOVINA**
 Aleja Lipa 56
BA-71000 Sarajevo
 Phone: +387 (0)33 / 921 164
 Fax: +387 (0)33 / 524 539

AKHNATON **BULGARIA**
 4, Andrei Ljapchev Blvd., PO Box 21
BG-1756 Sofia
 Phone: +359 (0)2 / 817 6000
 Fax: +359 (0)2 / 97 44 06 1

AutoCont C.S. s.r.o. **CZECH REPUBLIC**
 Technologická 374/6
CZ-708 00 Ostrava-Pustkovec
 Phone: +420 595 691 150
 Fax: +420 595 691 199

Beijer Electronics A/S **DENMARK**
 Lykkegårdsvej 17
DK-4000 Roskilde
 Phone: +45 (0)46 / 75 76 66
 Fax: +45 (0)46 / 75 56 26

Beijer Electronics OY **FINLAND**
 Peltoie 37
FIN-28400 Ulvila
 Phone: +358 (0)207 / 463 540
 Fax: +358 (0)207 / 463 541

UTEKO **GREECE**
 5, Mavrogenous Str.
GR-18542 Piraeus
 Phone: +30 211 / 1206 900
 Fax: +30 211 / 1206 999

AXICONT AUTOMATIKA Kft. **HUNGARY**
 (ROBOT CENTER) Reitter F. U. 132
HU-1131 Budapest
 Phone: +36 1 / 412-0882
 Fax: +36 1 / 412-0883

ALFATRADE Ltd. **MALTA**
 99, Paola Hill
Malta- Paola PLA 1702
 Phone: +356 (0)21 / 697 816
 Fax: +356 (0)21 / 697 817

HIFLEX AUTOM. TECHNIK B.V. **NETHERLANDS**
 Wolweverstraat 22
NL-2984 CD Ridderkerk
 Phone: +31 (0)180 - 46 60 04
 Fax: +31 (0)180 - 44 23 55

EUROPEAN REPRESENTATIVES

Koning & Hartman b.v. **NETHERLANDS**
 Haarlerbergweg 21-23
NL-1101 CH Amsterdam
 Phone: +31 (0)20 / 587 76 00
 Fax: +31 (0)20 / 587 76 05

Beijer Electronics AS **NORWAY**
 Postboks 487
NO-3002 Drammen
 Phone: +47 (0)32 / 24 30 00
 Fax: +47 (0)32 / 84 85 77

Fonseca S.A. **PORTUGAL**
 R. João Francisco do Casal 87/89
PT - 3801-997 Aveiro, Esigueira
 Phone: +351 (0)234 / 303 900
 Fax: +351 (0)234 / 303 910

SIRIUS TRADING & SERVICES SRL **ROMANIA**
 Aleea Lacul Morii Nr. 3
RO-060841 Bucuresti, Sector 6
 Phone: +40 (0)21 / 430 40 06
 Fax: +40 (0)21 / 430 40 02

INEA RBT d.o.o. **SERBIA**
 Izletnicka 10
SER-113000 Smederevo
 Phone: +381 (0)26 / 615 401
 Fax: +381 (0)26 / 615 401

SIMAP s.r.o. **SLOVAKIA**
 Jána Derku 1671
SK-911 01 Trenčín
 Phone: +421 (0)32 743 04 72
 Fax: +421 (0)32 743 75 20

PROCONT, spol. s r.o. Prešov **SLOVAKIA**
 Kúpeľná 1/A
SK-080 01 Prešov
 Phone: +421 (0)51 7580 611
 Fax: +421 (0)51 7580 650

INEA RBT d.o.o. **SLOVENIA**
 Stegne 11
SI-1000 Ljubljana
 Phone: +386 (0)1 / 513 8116
 Fax: +386 (0)1 / 513 8170

Beijer Electronics Automation AB **SWEDEN**
 Box 426
SE-20124 Malmö
 Phone: +46 (0)40 / 35 86 00
 Fax: +46 (0)40 / 93 23 01

Robotronic AG **SWITZERLAND**
 Schlachthofstrasse 8
CH-8406 Winterthur
 Phone: +41 (0)52 / 267 02 00
 Fax: +41 (0)52 / 267 02 01

GTS **TURKEY**
 Bayraktar Bulvari Nutuk Sok. No:5
TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL
 Phone: +90 (0)216 526 39 90
 Fax: +90 (0)216 526 3995

CSC Automation Ltd. **UKRAINE**
 4-B, M. Raskovoyi St.
UA-02660 Kiev
 Phone: +380 (0)44 / 494 33 55
 Fax: +380 (0)44 / 494-33-66

MIDDLE EAST REPRESENTATIVE

I.C. SYSTEMS LTD. **EGYPT**
 23 Al-Saad-Al-Alee St.
EG-Sarayut, Maadi, Cairo
 Phone: +20 (0) 2 / 235 98 548
 Fax: +20 (0) 2 / 235 96 625

ILAN & GAVISH Ltd. **ISRAEL**
 24 Shenkar St., Kiryat Arie
IL-49001 Petah-Tiqva
 Phone: +972 (0)3 / 922 18 24
 Fax: +972 (0)3 / 924 0761

AFRICAN REPRESENTATIVE

CBI Ltd. **SOUTH AFRICA**
 Private Bag 2016
ZA-1600 Isando
 Phone: + 27 (0)11 / 977 0770
 Fax: + 27 (0)11 / 977 0761