# MITSUBISHI GT15 CC-Link communication unit

# **User's Manual**

# GT15-75J61BT13-Z

Set of A8GT-J61BT13 and GT15-75IF900

Thank you for purchasing the GOT1000 Series.

Prior to use, please read both this manual and detailed manual thoroughly to fully understand the product.

MODEL	GT15-75J61BT13-Z-U			
MODEL CODE	1D7M31			
IB(NA)-0800316-B(0512)MEE				

GRAPHIC OPERATION TERMINAL



#### ●SAFETY PRECAUTIONS●

(Always read these instructions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

The instructions given in this manual are concerned with this product. In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Note that the ACAUTION level may lead to a serious accident according to the circumstances.

Always follow the precautions of both levels because they are important to personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

#### [DESIGN PRECAUTIONS]

## **DANGER**

 Some faults of this unit may keep the outputs on or off. An external monitoring circuit should therefore be provided to check for output signals which may lead to a serious accident.

Not doing so can cause an accident due to mis-output or misoperation.

 If a communication error (including cable disconnection) occurs during monitoring with the GOT, communication between the GOT and master station is interrupted, disabling operation.

When using the GOT to configure a system, assume that a GOT communication error will occur and configure a system in which switches used to perform significant operation for the system are provided on any device other than the GOT.

Not doing so can cause an accident due to mis-output or misoperation.

#### **A**CAUTION

Do not bunch the control wires or communication cables with the main circuit
or power wires, or lay them close to each other.
 As a guide, separate the lines by a distance of at least 100 mm (3.94 inch)

#### [INSTALLATION PRECAUTIONS]

otherwise malfunctions may occur due to noise.



 Be sure to shut off all phases of the external power supply used by the system before mounting or removing this unit to/from the GOT.
 Not doing so can cause a unit failure or misoperation.

#### [INSTALLATION PRECAUTIONS]

#### **⚠** CAUTION

- Use this unit in the environment given in the general specifications of the GT15 User's Manual.
  - Not doing so can cause an electric shock, fire, malfunction or product damage or deterioration.
- When installing this unit to the GOT, fit it to the connection interface of the GOT and tighten the mounting screws in the specified torque range.
   Undertightening can cause a drop, failure or malfunction.
   Overtightening can cause a drop, failure or malfunction, due to screw or un
  - Overtightening can cause a drop, failure or malfunction due to screw or unit damage.

#### [WIRING PRECAUTIONS]

#### **DANGER**

 Be sure to shut off all phases of the external power supply used by the system before wiring.

Not doing so can cause an electric shock, product damage or misoperation.

#### **⚠** CAUTION

- When switching power on or starting operation after mounting, wiring or other work, always fit the terminal cover supplied to the product.
   Not doing so can cause an electric shock, short circuit or failure.
- Always ground the FG terminal of the GOT power supply and the FG1 termial
  of this unit to the protective ground conducter.
   Be sure to ground the GOT and this unit separately.
   Not doing so may cause an electric shock or misoperation.
- Before wiring the unit, confirm the rated voltage and terminal arrangement of the product.
  - A fire or failure can occur if the power supply connected is different from the rating or wiring is incorrect.
- Use applicable solderless terminals and tighten them with the specified torque. If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.

#### [WIRING PRECAUTIONS]

#### **↑** CAUTION

- Be sure to tighten any unused terminal screws within a tightening torque range (0.36 to 0.48•Nm).
  - Failure to do so may cause a short circuit due to contact with a solderless terminal.
- Tighten the terminal screws within the specified torque range.
   Undertightening can cause a short circuit or misoperation.
   Overtightening can cause a short circuit or misoperation due to damaged screws or unit.
- Ensure that foreign matters such as chips and wire off-cuts do not enter the unit.
- They can cause a fire, failure or misoperation.
- Be sure to fix the wires or cables by ducts or clamps when connecting them to the unit.
  - Not doing so can damage the unit or cables due to dangling, moved or accidentally pulled cables or can cause misoperation due to cable contact fault.
- Do not install the control lines together with the communication cables, or bring them close to each other.
   Failure to do so may cause malfunctions due to noise.
- When disconnecting a communication or power supply cable from the unit, do not pull on the cable itself.
  - Disconnect cables fitted with connectors by holding and pulling the cable connector. Disconnect cables not fitted with a connector by removing the screws from the part connected to the unit.
  - Pulling on a cable that is connected to the unit can cause damage to the unit or cable, or malfunction due to cable connection faults.

#### **[TEST OPERATION PRECAUTIONS]**

# **DANGER**

- Do not output (switch on) any reserved signal among the output signals provided from the master unit to the GOT.
  - Doing so can cause the PLC system to misoperate.

#### [STARTUP AND MAINTENANCE PRECAUTIONS]

# **DANGER**

- Do not touch the terminals while power is on.
   Doing so can cause an electric shock or misoperation.
- Before starting cleaning or terminal screw retightening, always switch power off externally in all phases.

Not doing so can cause a unit failure or misoperation.

Undertightening can cause a drop, short circuit or misoperation.

Overtightening can cause a drop, short circuit or misoperation due to damaged screws or unit.

#### **↑** CAUTION

- Do not disassemble or modify the unit.
   Doing so can cause a failure, misoperation, injury or fire.
- Do not touch the conductive areas and electronic parts of the unit.
   Doing so can cause the unit to misoperate or fail.
- Do not change any switch setting while power is on.
   Doing so can cause a failure or misoperation.
- Do not drop the unit or subject it to strong impact.
   Doing so can damage the unit.
- Always make sure to touch the grounded metal to discharge the electricity charged in the body, etc., before touching the unit.
   Failure to do so may cause a failure or malfunctions of the unit.

#### [DISPOSAL PRECAUTIONS]

#### **↑** CAUTION

Dispose of this product as industrial waste.

#### [TRANSPORTATION PRECAUTIONS]

#### **⚠** CAUTION

 Make sure to transport the GOT main unit and/or relevant unit(s) in the manner they will not be exposed to the impact exceeding the impact resistance described in the general specifications of the GT15 User's Manual, as they are precision devices.

Failure to do so may cause the unit to fail.

Check if the unit operates correctly after transportation.

#### REVISIONS

\* The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Jan., 2005	IB(NA)-0800316-A	First edition
Dec., 2005	IB(NA)-0800316-B	Description of the front cover is reviewed.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

#### **CONTENTS**

1. Overview	'
2. Performance Specifications	2
3. I/O Signals and Remote Register Assignment	4
3.1 I/O Signals Transferred to/from the Master Module	4
3.2 Remote Register Assignment	
4. Part Names and the Settings	6
5. Installation Procedure	9
6. Wiring Method	1
7. External Dimensions	12

#### **Manuals**

The following shows manuals relevant to this product.

**Detailed Manual** 

Manual name	
GT15 User's Manual	
	(Option)
GOT1000 Connection Manual	
	(Option)

Relevant Manuals

For relevant manuals, refer to the PDF manual stored within the drawing software used.

© 2005 MITSUBISHI ELECTRIC CORPORATION

#### 1. Overview


This user's manual introduces the GT15 CC-Link communication unit (hereinafter referred to as GT15-75J61BT13-Z) used in the Control & Communication Link system (hereinafter referred to as CC-Link).

GT15-75J61BT13-Z is configured with the A8GT-J61BT13 CC-Link communication unit (hereinafter referred to as A8GT-J61BT13) and interface converter unit (hereinafter referred to as GT15-75IF900).

After unpacking the box of GT15-75J61BT13-Z, please check if the following items are contained.

Product name	Model name	Quantity
CC-Link communication unit	(A8GT-J61BT13)	1
Interface converter unit	(GT15-75IF900)	1
Fixing bracket for communication unit	-	3

The A8GT-J61BT13 can be connected to the GOT with the GT15-75IF900, which can perform monitoring as an intelligent device station (number of occupied stations selectable from 1 station / 4 stations) in the CC-Link system.



#### 2. Performance Specifications

The following is the performance specification of CC-Link communication unit. For the general specifications of CC-Link communication unit, refer to the GT15 User's Manual.\*1

Item		Specifications		
CC-Link stati	ion type	Intelligent device station		
Number of stations occupied		May be selected between 1 and 4. 1 station : RX/RY 32 points each <sup>-2</sup> , RW write area 4 points each/read area all area 4 stations : RX/RY 128 points each <sup>-2</sup> , RW write area 1 points each /read area all area		
Monitor device	Monitoring by cyclic transmission	Write from GOT : RX, RWs assigned to the GOT (depending on the number of stations occupied (Refer to upper))  Read to GOT : RX/RY (2048 points), RWw/RWr (512points)		
	Monitoring by transient transmission	All devices of the PLC CPU on the Master/local station.		
Transmission	n speed	156kbps/625kbps/2.5Mbps/5Mbps/10Mbps		
Max. transmi	ission distance	Depends on the transmission speed.		
Max. number of modules connected		26 The max. number of modules connected depends on the configuration of the CC-Link system to be used. For more details on the max. number of modules connected, refer to the CC-Link System Master-Local Module User's Manual.		
Connection of	cable	CC-Link dedicated cable		
Terminal bloo	ck	8-pin terminal block (M3 x 8 screws)		
Applicable cable size		0.75mm <sup>2</sup> to 2.00mm <sup>2</sup>		
Applicable crimping terminal		RAV1.25-3, RAV2-3.5 (conforming to JIS C2805)		
Internal current consumption (DC5V)		0.27A in total with GT15-75IF900		
Weight		0.36kg (0.79lb) in total with GT15-75IF900		

\*1 : The vibration resistance of the CC-Link communication unit is as follows. (Differs with the GT15.)

Item	Specifications											
			Frequency	Acceleration	Amplitude	Sweep count						
Vibration	Conforming to	Under intermittent vibration Under continuous	10 to 57Hz		0.075mm (0.003inch)	10 times						
resistance	JIS B 3502,		vibration	vibration	vibration	vibration	vibration	vibration 57 to	57 to 150Hz	9.8m/s <sup>2</sup>		X, Y, Z
	C		10 to 57Hz		0.035mm (0.001inch)	directions (for 80						
			57 to 150Hz	4.9m/s <sup>2</sup>		minch)						

\*2 : Each of the I/O signals (RX, RY) occupies 16 points of a system area within device points.

For more details on the I/O signals, refer to Section 3.1.

### 3. I/O Signals and Remote Register Assignment

#### 3.1 I/O Signals Transferred to/from the Master Module

The following table lists the I/O signals assigned to the GOT.

The I/O signals differ according to the set number of occupied stations (1 or 4 stations).

n in the table indicates the address assigned to the Master module by station number setting.

Signal Direction: GOT → Master module			Signal Direction: Master module → GOT		
Device number			Device		
Number of occ	cupied stations	Signal name	Number of occ	cupied stations	Signal name
1 station	4 stations		1 station	4 stations	
RXn0 to RXnF	RXn0 to RX(n+6)F	User area	RYn0 to RYnF	RYn0 to RY(n+6)F	User area
RX(n+1)0 to RX(n+1)A	RX(n+7)0 to RX(n+7)A	Reserved	RY(n+1)0 to RY(n+1)A	RY(n+7)0 to RY(n+7)A	
RX(n+1)B	RX(n+7)B	Remote ready flag <sup>*1</sup>	RY(n+1)B	RY(n+7)B	Reserved
RX(n+1)C to RX(n+1)F	RX(n+7)C to RX(n+7)F	Reserved	RY(n+1)C to RY(n+1)F	RY(n+7)C to RY(n+7)F	

\*1: The remote ready flag is on during startup of the GOT. It switches on when GOT power is switched on, hardware reset is made, or the GOT is ready to operate. If GOT power is on, the remote ready flag is off when offline operation is performed (during OS installation or screen data downloading) or while initial processing is executed.

Use it for the interlock ladder when writing or reading data to or from the CC-Link Master station.

#### 3.2 Remote Register Assignment

The following is the assignment of the remote registers of the GOT.

The remote registers differ according to the set number of occupied stations (1 or 4 stations).


All areas are use areas.

m and n in the table indicate the addresses assigned to the Master module by station number setting.

	Addre	esses		
Transfer Direction	Number of occ	cupied stations	Description	Default Value
Bircollon	1 station	4 stations		
Master station  ↓  GOT	RWwm to RWwm+3	RWwm to RWwm+F	User write area	0
GOT  ↓  Master station	RWrn to RWrn+3	RWrn to RWrn+F	User read area	0

### 4. Part Names and the Settings

This section provides the names of the A8GT-J61BT13 and GT15-75IF900 parts and how to set the switches.




Number	Name	Description				
1)	Mode setting switch	Used to s (Factory s		ting status of th	ne module.	
	237767	Number	Name	[	Description	
	150084°	0	Online	Data link ena return made	bled and au	tomatic
		1	(Reserved)		-	
		2	Offline	Disconnected	I from data I	ink
		3 to F	(Reserved)		-	
2)	Station number setting switches	Used to set the station number of the A8GT-J61BT13 between 1 and 64. (Factory setting: 01) Use "×10" to set the tens. Use "× 1" to set the units.				BT13
3)	Transmission baudrate setting switch	Used to s (Factory s		nission speed	of the modul	e.
	23	Number to be Set		Transmission	n Baudrate	
	0 6 5	0		156kbps 625kbps 2.5Mbps		
	0870	1				
		2				
		3 5Mbps		os		
		4		10Mb	ps	
		Reserved (If the value you set is 5 to 9, t L.ERR LED is lit to indicate a communic error.)				
4)	Condition setting switches	Used to set the operational conditions. (Factory setting:OFF)			etting:OFF)	
		Number	r Setting Item	na Item		Position
		. 10111001			ON	OFF
		SW1	Input data s data link sta	tatus of faulty ition	Held	Cleared
		SW2	Number of o stations	occupied	4 stations	1 station


Number	Name		Description
5)	Indicator LEDs	Data link status can be conformed by the on/off statuses of the LEDs. $ \\$	
	O RUN	LED Name	Description
	O SD RD	RUN LED	On : Indicates that the module is normal. Off : Indicates a watchdog timer error.
	L ERR.	L RUN LED	On : Indicates that communication is normal. Off : Indicates a communication break (time excess error).
		SD LED	On : Indicates data transmission.
		RD LED	On : Indicates data receive.
		L ERR. LED	On : Indicates a communication data error (CRC error).  Flicker : Indicates that any switch (1 to 4) position was changed while power is on.  Off : Indicates that communication is normal.
6)	Connector	Connector	for connection to the GOT
7)	Module fixing screws	Screws for	r installation to the GOT (M3 × 3 screw)
8)	Terminal block	Terminal block for cable connection (M3 × 8 screw)	
9)	Rating plate	-	
10)	Mounting screw	Mounting :	screw to be fixed with the GOT main unit
11)	Interface connector	Connector connecting to GOT	
12)	Extension connector	Connector connecting with A8GT-J61BT13	

#### 5. Installation Procedure


- (1) Power off the GOT.
- (2) Remove the two extension unit covers of the GOT.




(3) Fit the GT15-75IF900 along the groove of the GOT case.




(4) Fasten the GT15-75IF900 by tightening its mounting screws (3 places) with tightening torque 0.36 to 0.48 N $\cdot$ m.




(5) Attach the communication unit fixing brackets (3 places) to GT15-75IF900, then fasten them with tightening torque of 0.36 to 0.48 N•m.



(6) Mount the A8GT-J61BT13 to GT15-75IF900.




(7) Fasten the unit fixing brackets (3 places) with tightening torque of 0.36 to 0.48N•m.



#### 6. Wiring Method

The following diagram shows how to wire the GOT and CC-Link system modules.


(1) Wiring the GOT and CC-Link system modules by CC-Link dedicated cable



(2) Connection of terminal resistor to the GOT

When connecting a terminal resistor to the GOT, always connect it in the following position.

The terminal resistor is contained in the package of the Master module.




#### POINT


- Tighten terminal block terminal screws (M3 screw) with the tightening torque of 0.36 to 0.48N•m.
- Tighten terminal block mounting screws (M3.5 screw) with the tightening torque of 0.59 to 0.88N\*m.
- The "terminal resistors" supplied with the Master module must be connected to the modules at both ends of data link. (Connect them across DA-DB.)
- Connect the shield wire of the CC-Link dedicated cable to "SLD" of each module.
  - Since "SLD" is connected to "FG/FG1" internally, always ground the FG terminal and FG1 terminal to the protective ground conductor.
- The FG terminal of the GOT power supply and the FG1 terminal of the A8GT-J61BT13 must be connected separately.

#### 7. External Dimensions

#### (1) GT15-75IF900



#### (2) A8GT-J61BT13



Dimensions of X when mounted to the GOT.

8.4"	15.5 (0.61)
10.4", 12.1"	13.5 (0.53)

Unit:mm (inch)

#### Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

#### ♠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the
  product where major accidents or losses could occur if the product fails, install appropriate
  backup or failsafe functions in the system.

Country/Region Sales office/Tel		Country/Region Sales office/Tel	
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Tel: +1-847-478-2100	Hong Kong	Ryoden Automation Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, HongKong Tel: +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso. Sao Paulo. SP Brazil	China	Ryoden Automation Shanghai Ltd. 3F Block5 Building Automation Instrumentation Plaza 103 Cao Bao Rd. Shanghai 200233 China Tel: +86-21-6120-0808
Germany	Tel : +55-11-5908-8331 Mitsubishi Electric Europe B.V. German Branch	Taiwan	Setsuyo Enterprise Co., Ltd. 6F., No.105 Wu-Kung 3rd.RD, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel: +886-2-2299-2499
	Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel: +49-2102-486-0	Korea	HAN NEUNG TECHNO CO.,LTD. 1F Dong Seo Game Channel Bldg.,
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Herts., AL10		660-11, Deungchon-dong Kangsec-ku, Seoul, Korea Tel: +82-2-3660-9552
	8XB,UK Tel: +44-1707-276100	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02,
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, 20041 Agrate B., Milano. Italy	Thailand	Mitsubishi Electric Building Singapore 159943 Tel:+65-6473-2308 F. A. Tech Co.,Ltd. 898/28,29,30 S.V.City Building,Office
Spain	Tel : +39-039-6053344 Mitsubishi Electric Europe B.V. Spanish Branch		Tower 2, Floor 17-18 Rama 3 Road, Bangkpongpang, Yannawa, Bangkok 10120 Tel : +66-2-682-6522
	Carretera de Rubi 76-80 08190 Sant Cugat del Valles, Barcelona, Spain Tel: +34-93-565-3131	Indonesia	P.T. Autoteknindo SUMBER MAKMUR JI. Muara Karang Selatan Block a Utara No.1 Kav. No.11 Kawasan Industri/ Pergudangan Jakarta - Utara 14440
France	Mitsubishi Electric Europe B.V. French Branch	India	Tel: +62-21-663-0833 Messung Systems Put,Ltd.
	25 Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568		Electronic Sadan NO:111 Unit No15, M.I.D.C BHOSARI,PUNE-411026, India Tel: +91-20-712-2807
South Africa	Circuit Breaker Industries LTD. Tripswitch Drive, Elandsfontein Gauteng, South Africa Tel: +27-11-928-2000	Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, PostalBag, No 2, Rydalmere, N.S.W 2116, Australia Tel: +61-2-9684-7777
♣MITSURISHI FLECTRIC CORPORATION			

#### **★**MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 1-14. YADA-MINAMI 5-CHOME. HIGASHI-KU, NAGOYA. JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.