

# **MELSEC QnA Series**

Programmable Logic Controller

User's Manual  
(Hardware)

**AJ72QLP25**

**AJ72QLR25**

**AJ72QBR15**

**MELSECNET/10 Remote I/O Module**

# ● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.


These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the PC system safety precautions. These ●SAFETY PRECAUTIONS● classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  **CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

## [INSTALLATION PRECAUTIONS]

### **CAUTION**

- Use the PC in an environment that meets the general specifications contained in this manual. Using this PC in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not touch the printed circuit board of the module.  
It may cause damage or erroneous operation.
- Install so that the pegs on the bottom of the module fit securely into the base unit peg holes.  
Not installing the module correctly or tightening the screws to the terminal base could result in erroneous operation, damage, or pieces of the product falling.

## [WIRING PRECAUTIONS]

### **DANGER**

- Completely turn off the external power when installing or placing wiring. Not completely turning off all power could result in electric shock or damage to the product.

### **CAUTION**

- When wiring in the PC, be sure that it is done correctly by checking the product's rated voltage and the terminal layout. Connecting a power supply that is different from the rating or incorrectly wiring the product could result in fire or damage.
- Be sure there are no foreign substances such as sawdust or wiring debris inside the module. Such debris could cause fires, damage, or erroneous operation.
- Solder the coaxial cable connector properly. Incomplete soldering may cause a malfunction.
- Tighten terminal screws to the specified torque.  
If a terminal screw is not tightened to the specified torque, it the module may fall out, short circuit, or malfunction.  
If a terminal screw is tightened excessively, exceeding the specified torque, the module may fall out, short circuit, or malfunction due to breakage of the screw or the module.
- Be sure to fix communication cables or power cables leading from the module by placing them in the duct or clamping them.  
Cables not placed in the duct or without clamping may hang or shift, allowing them to be accidentally pulled, which may cause a module malfunction and cable damage.
- When removing the communication cable or power cables from the module, do not pull the cable. When removing the cable with a connector, hold the connector on the side that is connected to the module.  
When removing the cable connected to the terminal block, first loosen the screws on the terminal block.  
Pulling the cable that is still connected to the module may cause malfunction or damage to the module or cable.

## About the Manuals

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

Detailed Manual

Manual name	Manual No. (Model code)
For QnA/Q4AR MELSECNET/10 Network System Reference Manual	IB-66690 (13JF78)

### Correspondence to EMC DIRECTIVE

For instructions to make the PLC compatible with EMC standards, refer to "EMC AND LOW-VOLTAGE DIRECTIVE" in PLC CPU User's Manual (Hardware).

\* When the PLC CPU user's manual (Hardware) does not include Chapter 2 "EMC AND LOW-VOLTAGE DIRECTIVE", refer to QnA Series CPU Compatible High-Speed Accessing Basic Base Unit-Additional Explanation for Product Conforming to EMC Standards (IB-66837) (optional).

## 1. Overview

This manual gives the specifications and nomenclature of the AJ72QLP25, AJ72QLR25, AJ72QBR15 type network module (abbreviated as Remote I/O Modules) to be used in a MELSEC-QnA series MELSECNET/10 network system.

- (1) The following table shows the applications, applicable cable and installation position of the Remote I/O Modules.

Type	Application	Applicable cable		Module installation position
		Optical fiber cable	Coaxial cable	
AJ72QLP25	For remote I/O station of MELSECNET/10	○	-	CPU slot of main base unit
AJ72QLR25		-	○	
AJ72QBR15		-	○	

- (2) Please confirm that the following parts have been supplied on unpacking the package:

(a) AJ72QLP25

Part name	Quantity
AJ72QLP25 network module	1

(b) AJ72QLR25

Part name	Quantity
AJ72QLR25 network module	1

(c) AJ72QBR15

Part name	Quantity
AJ72QBR15 network module	1
F type connector (A6RCON-F)	1

- (3) When configuring a coaxial bus system a terminal resistor (A6RCON-R75) must be installed at both ends. The terminal resistors are not contained in the package and you must be obtained at your own expense.

## 2. Performance Specifications

The following table shows the performance specifications of the Remote I/O Modules.

Item	AJ72QLP25		AJ72QLR25		AJ72QBR15	
	Optical loop system		Coaxial loop system		Coaxial bus system	
Maximum number of link points per network	X/Y	8192 points				
	B	8192 points				
	W	8192 points				
Maximum number of link points per station	<ul style="list-style-type: none"> <li>Remote master station → Remote I/O station  <math display="block">\left[ \frac{Y+B}{8} + (2 \times W) \right] + (2 \times W) \leq 1600 \text{ bytes}</math> </li> <li>Remote I/O station → Remote master station  <math display="block">\left[ \frac{X+B}{8} + (2 \times W) \right] + (2 \times W) \leq 1600 \text{ bytes}</math> </li> <li>Remote master station → Remote sub-master station  Remote sub-master station → Remote master station  <math display="block">\left[ \frac{Y+B}{8} + (2 \times W) \right] + (2 \times W) \leq 2000 \text{ bytes}</math> </li> </ul>					
Maximum number of I/O points per station	X+Y ≤ 2048 (main base plus 7 extension bases)					
Communication speed	10Mbps (20Mbps: multiple transmission)				10Mbps	
Communication method	Token-ring method				Token bus method	
Synchronization system	Frame synchronization					
Coding system	NRZI coding (Non Return to Zero Inverted)				Manchester coding	
Transmission channel type	Duplex loop				Single bus	
Transmission format	Conforms to HDLC (frame format)					
Maximum number of networks	239					
Number of stations connectable per network	65 stations (Master station: 1; remote I/O stations: 64)				33 stations (Master station:1; remote I/O stations:32)	
Overall extension distance	30km		3C-2V		3C-2V	
	SI optical cables: station-to-station distance 500m H-PCF optical cables: station-to-station distance 1km Broad-band H-PCF optical cables: station to station distance 1km		19.2km (inter station 300m)		300m (station-to-station distance 300m)	
			5C-2V 30km (inter station 500m)		5C-2V 500m (station-to-station distance 500m)	
		Repeater unit Extension up to 2.5km possible by using A6BR10 or A6BR10DC				
Error control system	Retry by CRC ( $X^{16}+X^{12}+X^5+1$ ) and overtime					
RAS function	<ul style="list-style-type: none"> <li>Loopback function in response to error detection and cable disconnection (AJ72QLP25, AJ72QLR25)</li> <li>Diagnosis function for self-station link line check</li> <li>Error detection using special relays and registers</li> <li>Network monitor and other diagnosis functions</li> </ul>					
Transient transmission	Monitoring with peripheral device, program up/download					
Connection cable	Optical fiber cable (Arranged by user *1)		3C-2V, 5C-2V or equivalent			

Item	AJ72QLP25	AJ72QLR25	AJ72QBR15
	Optical loop system	Coaxial loop system	Coaxial bus system
Applicable connector	2-core optical connector plug (Arranged by user *1)	BNC connector compatible with 3C-2VC, 5C-2V cable	
5VDC current consumption (A)	0.8	1.3	0.9
Weight (kg)	0.53	0.6	0.6

\*1: Specialised training and specific tools are required to connect the connector to the optical-fiber cable; the connector itself is a custom product. Please contact your nearest Mitsubishi Electric System Service Corporation when purchasing these items.

For general specifications, refer to the user's manual for the PLC CPU used for the network system.

## 3. Handling

### [INSTALLATION PRECAUTIONS]

#### CAUTION

- Use the PC in an environment that meets the general specifications contained in this manual. Using this PC in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not touch the printed circuit board of the module.  
It may cause damage or erroneous operation.
- Install so that the pegs on the bottom of the module fit securely into the base unit peg holes.  
Not installing the module correctly or tightening the screws to the terminal base could result in erroneous operation, damage, or pieces of the product falling.

#### 3.1 Cable length restrictions between stations.




- (1) The main modules case is made of plastic, so do not drop it or subject it to strong impacts.
- (2) Do not dismount the printed wiring board from the case. It may damage the module.
- (3) When wiring, be careful never to let foreign matter from the above module such as wiring scraps get inside the module. If something goes in, get rid of it.
- (4) The module installation screw should be kept within the following range.




Screw Locations	Tightening Torque Range
Module installation screws (M4 screws)	78 to 118N•cm



# 4. The Name and Setting of Each Part




This section gives the names of each part of the Remote I/O Modules and explains their settings.






No.	Name	Contents		
		Name	State	Description
1)	<p>LED</p> <p>AJ72QLP25</p>  <p>AJ72QLR25</p>  <p>AJ72QBR15</p> 	RUN	ON	When the module is normal.
			OFF	When a WDT error occurs.
		PRM.E.	ON	When a blown fuse or I/O check error occurs.(Host station)
		DUAL		During duplex transmission. (Off: when duplex transmission not executed)
		SW.E		When settings of switches (3) to (4) are incorrect.
		ST.E.		When two or more stations have the same number exist in the same network.
		PRM.E.		<ul style="list-style-type: none"> <li>• When I/O allocation is abnormal.</li> <li>• When the number of LB/LW points is insufficient.</li> <li>• When the parameters received from the remote master station are abnormal.</li> </ul>
		POWER		When power is supplied. (Off: when power is not being supplied)
		HOLD		Output status is held when communication is abnormal. Standard network ... Q4ARCPU output hold/reset setting switch is set to "Hold". Duplex network ..... A6RAF is set to "Hold" at "HOLD/RESET MODE" section.
		D.LINK		During data link (Off: when data link stopped)
		T.PASS		When taking part in baton passing. (during transient transmission)
		WAIT		When waiting for communication with special-function module.
		CRC		When there is a code check error in the received data. <Cause> Timing when the station that is sending data to a specific station is set off-line, hardware fault, cable fault, noise, etc.
		OVER		When an error occurs due to delay in processing of received data. <Cause> Hardware fault, cable fault, noise, etc.
		AB.IF		<ul style="list-style-type: none"> <li>• When the number of "1"s received in succession exceeds the specified number.</li> <li>• When an error occurs due to short data length of received data.</li> </ul> <Causes> Timing when the station that is sending data to a specific station is set off-line, WDT setting too short, cable fault, noise, etc.
		TIME		When an error occurs when the data link monitoring timer operates. <Causes> Short WDT time, cable fault, noise, etc.
		DATA		When an error occurs due to receipt of more than 2 Kbytes of data. <Cause> cable fault, noise, etc.
		UNDER		When an error occurs due to internal processing of sent data at irregular intervals. <Cause> Hardware fault
		LOOP		When an error occurs due to abnormal forward or reverse loop. (F.LOOP)/ (R.LOOP) <Cause> Power OFF at adjacent station, cable disconnection, connection not made, etc.
		SD	Dimly	Using data transmission.
		RD	lit	During data reception.

**Caution**

Do not change the setting of the DIP switch on the printed circuit board at the side face of the module.

No.	Name	Contents																																						
2)	Reset switch 	Resets the host station hardware.																																						
3) *1	Station number setting switch 	Station number setting (setting on delivery: 1) <Setting range> 1 to 64 Any number outside the range will result in an error (the SW.E LED will come on).																																						
4) *1	Mode setting switch 	Mode setting (setting on delivery: 0)																																						
		<table border="1"> <thead> <tr> <th>Mode</th> <th>Name</th> <th>Contents</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Online (automatic online return effective)</td> <td>Data link with automatic online return effective</td> </tr> <tr> <td>1</td> <td>Unusable</td> <td></td> </tr> <tr> <td>2</td> <td>Offline</td> <td>Disconnects the host station.</td> </tr> <tr> <td>3</td> <td>Forward loop test</td> <td>Checks the forward loop line of the entire data link system.</td> </tr> <tr> <td>4</td> <td>Reverse loop test</td> <td>Checks the reverse loop line of the entire data link system.</td> </tr> <tr> <td>5</td> <td>Station-to-station test (master station)</td> <td rowspan="2">The mode for a line check between two stations, in which the station with the smaller number is regarded as the master station and the other is considered the slave station.</td> </tr> <tr> <td>6</td> <td>Station-to-station test (slave station)</td> </tr> <tr> <td>7</td> <td>Self-loopback test</td> <td>Check the hardware of a module in isolation, including the communication circuit and cables of the transmission system.</td> </tr> <tr> <td>8</td> <td>Internal self-loopback test</td> <td>Check the hardware of a module in isolation, including the communication circuit of the transmission system.</td> </tr> <tr> <td>9</td> <td>Hardware test</td> <td>Check the hardware inside the network module.</td> </tr> <tr> <td>A to E</td> <td>-</td> <td>Unusable</td> </tr> <tr> <td>F</td> <td>Station number check</td> <td>Checks the number using LEDs</td> </tr> </tbody> </table>	Mode	Name	Contents	0	Online (automatic online return effective)	Data link with automatic online return effective	1	Unusable		2	Offline	Disconnects the host station.	3	Forward loop test	Checks the forward loop line of the entire data link system.	4	Reverse loop test	Checks the reverse loop line of the entire data link system.	5	Station-to-station test (master station)	The mode for a line check between two stations, in which the station with the smaller number is regarded as the master station and the other is considered the slave station.	6	Station-to-station test (slave station)	7	Self-loopback test	Check the hardware of a module in isolation, including the communication circuit and cables of the transmission system.	8	Internal self-loopback test	Check the hardware of a module in isolation, including the communication circuit of the transmission system.	9	Hardware test	Check the hardware inside the network module.	A to E	-	Unusable	F	Station number check	Checks the number using LEDs
		Mode	Name	Contents																																				
		0	Online (automatic online return effective)	Data link with automatic online return effective																																				
		1	Unusable																																					
		2	Offline	Disconnects the host station.																																				
		3	Forward loop test	Checks the forward loop line of the entire data link system.																																				
		4	Reverse loop test	Checks the reverse loop line of the entire data link system.																																				
		5	Station-to-station test (master station)	The mode for a line check between two stations, in which the station with the smaller number is regarded as the master station and the other is considered the slave station.																																				
		6	Station-to-station test (slave station)																																					
		7	Self-loopback test	Check the hardware of a module in isolation, including the communication circuit and cables of the transmission system.																																				
		8	Internal self-loopback test	Check the hardware of a module in isolation, including the communication circuit of the transmission system.																																				
		9	Hardware test	Check the hardware inside the network module.																																				
A to E	-	Unusable																																						
F	Station number check	Checks the number using LEDs																																						
5) *1	Conditions setting switch	Operation condition setting (setting at delivery: all OFF)																																						
		<table border="1"> <thead> <tr> <th>SW</th> <th>OFF</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Peripheral device for QnA series connected</td> <td>Peripheral device for A series connected)</td> </tr> <tr> <td>2</td> <td colspan="2">Unusable (leave OFF at all times)</td> </tr> <tr> <td>3</td> <td colspan="2"></td> </tr> <tr> <td>4</td> <td colspan="2"></td> </tr> <tr> <td>5</td> <td colspan="2"></td> </tr> </tbody> </table>	SW	OFF	ON	1	Peripheral device for QnA series connected	Peripheral device for A series connected)	2	Unusable (leave OFF at all times)		3			4			5																						
		SW	OFF	ON																																				
		1	Peripheral device for QnA series connected	Peripheral device for A series connected)																																				
		2	Unusable (leave OFF at all times)																																					
		3																																						
4																																								
5																																								
6)	RS-422 interface	Connects the peripheral device																																						

No.	Name	Contents
7)	Connector (AJ72QLP25)	<p>An optical fiber cable is connected.</p> 
8)	Connector (AJ72QLR25)	<p>Connect the coaxial type cable.</p> 
9)	Connector	<p>An F type connector is connected.</p> 


\*1: After changing a setting while the power supply is ON, reset using the reset switch (2). However, when the mode setting switch (4) is set to "F", resetting is not necessary.

## 5. Wired

Please refer to the user's manual of connected master module for the wiring for network system.


## 6. External Dimensions

### 6.1 AJ72QLP25




\* Take account of the bending radius of the cable. (Refer to the Reference Manual.)  
Please contact your local Mitsubishi Electric System Service Corporation for detail.

## 6.2 AJ72QLR25



### 6.3 AJ72QBR15



Unit: mm (in.)

## Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

### ⚠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Tel : +1-847-478-2100	Hong Kong	Ryoden Automation Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, HongKong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. AV. Paulista 1471, Conj. 308, Sao Paulo City, Sao Paulo State, Brazil Tel : +55-11-283-2423	China	Ryoden Automation Shanghai Ltd. 3F Block5 Building Automation Instrumentation Plaza 103 Cao Bao Rd. Shanghai 200233 China Tel : +86-21-6475-3228
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F., No.105 Wu-Kung 3rd.RD, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Herts., AL10 8XB,UK Tel : +44-1707-276100	Korea	HAN NEUNG TECHNO CO.,LTD. 1F Dong Seo Game Channel Bldg., 660-11, Deungchon-dong Kangsec-ku, Seoul, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, 20041 Agrate B., Milano, Italy Tel : +39-039-6053344	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 ALEXANDRA ROAD #05-01/02, MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943 Tel : +65-6473-2308
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80 08190 - Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	F. A. Tech Co.,Ltd. 898/28,29,30 S.V.City Building,Office Tower 2,Floor 17-18 Rama 3 Road, Bangkokpong, Yannawa, Bangkok 10120 Tel : +66-2-682-6522
France	Mitsubishi Electric Europe B.V. French Branch 25 Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568	Indonesia	P.T. Autoteknindo SUMBER MAKMUR Jl. Muara Karang Selatan Block A Utara No.1 Kav. No.11 Kawasan Industri/ Pergudangan Jakarta - Utara 14440 Tel : +62-21-663-0833
South Africa	Circuit Breaker Industries LTD. Tripswitch Drive, Elandsfontein Gauteng, South Africa Tel : +27-11-928-2000	India	Messung Systems Put,Ltd. Electronic Sadan NO:111 Unit No15, M.I.D.C BHOSARI,PUNE-411026 Tel : +91-20-712-2807
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, PostalBag, No 2, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : 1-8-12, OFFICE TOWER Z 14F HARUMI CHUO-KU 104-6212, JAPAN  
NAGOYA WORKS : 1-14, YADA-MINAMI5, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.  
Printed in Japan on recycled paper.





**HEADQUARTERS**

MITSUBISHI ELECTRIC EUROPE B.V. **EUROPE**  
 German Branch  
 Gothaer Straße 8  
**D-40880 Ratingen**  
 Phone: +49 (0)2102 / 486-0  
 Fax: +49 (0)2102 / 486-1120

MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. **CZECH REP.**  
 Czech Branch  
 Avenir Business Park, Radlická 714/113a  
**CZ-158 00 Praha 5**  
 Phone: +420 - 251 551 470  
 Fax: +420 - 251-551-471

MITSUBISHI ELECTRIC EUROPE B.V. **FRANCE**  
 French Branch  
 25, Boulevard des Bouvets  
**F-92741 Nanterre Cedex**  
 Phone: +33 (0)1 / 55 68 55 68  
 Fax: +33 (0)1 / 55 68 57 57

MITSUBISHI ELECTRIC EUROPE B.V. **IRELAND**  
 Irish Branch  
 Westgate Business Park, Ballymount  
**IRL-Dublin 24**  
 Phone: +353 (0)1 4198800  
 Fax: +353 (0)1 4198890

MITSUBISHI ELECTRIC EUROPE B.V. **ITALY**  
 Italian Branch  
 Viale Colleoni 7  
**I-20041 Agrate Brianza (MB)**  
 Phone: +39 039 / 60 53 1  
 Fax: +39 039 / 60 53 312

MITSUBISHI ELECTRIC EUROPE B.V. **POLAND**  
 Poland Branch  
 Krakowska 50  
**PL-32-083 Balice**  
 Phone: +48 (0)12 / 630 47 00  
 Fax: +48 (0)12 / 630 47 01

MITSUBISHI ELECTRIC EUROPE B.V. **RUSSIA**  
 52, bid. 3 Kosmodamianskaya nab 8 floor  
**RU-115054 Moscow**  
 Phone: +7 495 721-2070  
 Fax: +7 495 721-2071

MITSUBISHI ELECTRIC EUROPE B.V. **SPAIN**  
 Spanish Branch  
 Carretera de Rubí 76-80  
**E-08190 Sant Cugat del Vallés (Barcelona)**  
 Phone: 902 131121 // +34 935653131  
 Fax: +34 935891579

MITSUBISHI ELECTRIC EUROPE B.V. **UK**  
 UK Branch  
 Travellers Lane  
**UK-Hatfield, Herts. AL10 8XB**  
 Phone: +44 (0)1707 / 27 61 00  
 Fax: +44 (0)1707 / 27 86 95

MITSUBISHI ELECTRIC CORPORATION **JAPAN**  
 Office Tower "Z" 14 F  
 8-12,1 chome, Harumi Chuo-Ku  
**Tokyo 104-6212**  
 Phone: +81 3 622 160 60  
 Fax: +81 3 622 160 75

MITSUBISHI ELECTRIC AUTOMATION, Inc. **USA**  
 500 Corporate Woods Parkway  
**Vernon Hills, IL 60061**  
 Phone: +1 847 478 21 00  
 Fax: +1 847 478 22 53

**EUROPEAN REPRESENTATIVES**

GEVA **AUSTRIA**  
 Wiener Straße 89  
**AT-2500 Baden**  
 Phone: +43 (0)2252 / 85 55 20  
 Fax: +43 (0)2252 / 488 60

TEHNIKON **BELARUS**  
 Oktyabrskaya 16/5, Off. 703-711  
**BY-220030 Minsk**  
 Phone: +375 (0)17 / 210 46 26  
 Fax: +375 (0)17 / 210 46 26

ESCO DRIVES & AUTOMATION **BELGIUM**  
 Culliganlaan 3  
**BE-1831 Diegem**  
 Phone: +32 (0)2 / 717 64 30  
 Fax: +32 (0)2 / 717 64 31

Koning & Hartman b.v. **BELGIUM**  
 Woluwelaan 31  
**BE-1800 Vilvoorde**  
 Phone: +32 (0)2 / 257 02 40  
 Fax: +32 (0)2 / 257 02 49

INEA BH d.o.o. **BOSNIA AND HERZEGOVINA**  
 Aleja Lipa 56  
**BA-71000 Sarajevo**  
 Phone: +387 (0)33 / 921 164  
 Fax: +387 (0)33 / 524 539

AKHNATON **BULGARIA**  
 4 Andrej Ljapchev Blvd. Pb 21  
**BG-1756 Sofia**  
 Phone: +359 (0)2 / 817 6044  
 Fax: +359 (0)2 / 97 44 06 1

INEA CR d.o.o. **CROATIA**  
 Losinjska 4 a  
**HR-10000 Zagreb**  
 Phone: +385 (0)1 / 36 940 -01 / -02 / -03  
 Fax: +385 (0)1 / 36 940 -03

AutoCont C.S. s.r.o. **CZECH REPUBLIC**  
 Technologická 374/6  
**CZ-708 00 Ostrava-Pustkovec**  
 Phone: +420 595 691 150  
 Fax: +420 595 691 199

Beijer Electronics A/S **DENMARK**  
 Lykkegårdsvej 17  
**DK-4000 Roskilde**  
 Phone: +45 (0)46 / 75 76 66  
 Fax: +45 (0)46 / 75 56 26

Beijer Electronics Eesti OÜ **ESTONIA**  
 Pärnu mnt.160i  
**EE-11317 Tallinn**  
 Phone: +372 (0)6 / 51 81 40  
 Fax: +372 (0)6 / 51 81 49

Beijer Electronics OY **FINLAND**  
 Peltoie 37  
**FIN-28400 Ulvila**  
 Phone: +358 (0)207 / 463 540  
 Fax: +358 (0)207 / 463 541

UTEKO **GREECE**  
 5, Mavrogenous Str.  
**GR-18542 Piraeus**  
 Phone: +30 211 / 1206 900  
 Fax: +30 211 / 1206 999

MELTRADE Kft. **HUNGARY**  
 Fertő utca 14.  
**HU-1107 Budapest**  
 Phone: +36 (0)1 / 431-9726  
 Fax: +36 (0)1 / 431-9727

Beijer Electronics SIA **LATVIA**  
 Rītausmas iela 23  
**LV-1058 Rīga**  
 Phone: +371 (0)784 / 2280  
 Fax: +371 (0)784 / 2281

Beijer Electronics UAB **LITHUANIA**  
 Savanorių Pr. 187  
**LT-02300 Vilnius**  
 Phone: +370 (0)5 / 232 3101  
 Fax: +370 (0)5 / 232 2980

**EUROPEAN REPRESENTATIVES**

ALFATRADE Ltd. **MALTA**  
 99, Paola Hill  
**Malta- Paola PLA 1702**  
 Phone: +356 (0)21 / 697 816  
 Fax: +356 (0)21 / 697 817

INTEHSIS srl **MOLDOVA**  
 bld. Traian 23/1  
**MD-2060 Kishinev**  
 Phone: +373 (0)22 / 66 4242  
 Fax: +373 (0)22 / 66 4280

HIFLEX AUTOM.TECHNIEK B.V. **NETHERLANDS**  
 Wolweverstraat 22  
**NL-2984 CD Ridderkerk**  
 Phone: +31 (0)180 - 46 60 04  
 Fax: +31 (0)180 - 44 23 55

Koning & Hartman b.v. **NETHERLANDS**  
 Haarderbergweg 21-23  
**NL-1101 CH Amsterdam**  
 Phone: +31 (0)20 / 587 76 00  
 Fax: +31 (0)20 / 587 76 05

Beijer Electronics AS **NORWAY**  
 Postboks 487  
**NO-3002 Drammen**  
 Phone: +47 (0)32 / 24 30 00  
 Fax: +47 (0)32 / 84 85 77

Fonseca S.A. **PORTUGAL**  
 R. João Francisco do Casal 87/89  
**PT - 3801-997 Aveiro, Esgueira**  
 Phone: +351 (0)234 / 303 900  
 Fax: +351 (0)234 / 303 910

Sirius Trading & Services srl **ROMANIA**  
 Aleea Lacul Morii Nr. 3  
**RO-060841 Bucuresti, Sector 6**  
 Phone: +40 (0)21 / 430 40 06  
 Fax: +40 (0)21 / 430 40 02

Craft Con. & Engineering d.o.o. **SERBIA**  
 Bulevar Svetog Cara Konstantina 80-86  
**SER-18106 Nis**  
 Phone: +381 (0)18 / 292-24-4/5  
 Fax: +381 (0)18 / 292-24-4/5

INEA SR d.o.o. **SERBIA**  
 Izletnicka 10  
**SER-113000 Smederevo**  
 Phone: +381 (0)26 / 617 163  
 Fax: +381 (0)26 / 617 163

SIMAP s.r.o. **SLOVAKIA**  
 Jána Derku 1671  
**SK-911 01 Trenčín**  
 Phone: +421 (0)32 743 04 72  
 Fax: +421 (0)32 743 75 20

PROCONT, spol. s r.o. Prešov **SLOVAKIA**  
 Kúpeľná 1/A  
**SK-080 01 Prešov**  
 Phone: +421 (0)51 7580 611  
 Fax: +421 (0)51 7580 650

INEA d.o.o. **SLOVENIA**  
 Stegne 11  
**SI-1000 Ljubljana**  
 Phone: +386 (0)1 / 513 8100  
 Fax: +386 (0)1 / 513 8170

Beijer Electronics AB **SWEDEN**  
 Box 426  
**SE-20124 Malmö**  
 Phone: +46 (0)40 / 35 86 00  
 Fax: +46 (0)40 / 93 23 01

Omni Ray AG **SWITZERLAND**  
 Im Schörl 5  
**CH-8600 Dübendorf**  
 Phone: +41 (0)44 / 802 28 80  
 Fax: +41 (0)44 / 802 28 28

GTS **TURKEY**  
 Bayraktar Bulvarı Nutuk Sok. No:5  
**TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL**  
 Phone: +90 (0)216 526 39 90  
 Fax: +90 (0)216 526 39 95

CSC Automation Ltd. **UKRAINE**  
 4-B, M. Raskovoyi St.  
**UA-02660 Kiev**  
 Phone: +380 (0)44 / 494 33 55  
 Fax: +380 (0)44 / 494-33-66

**EURASIAN REPRESENTATIVES**

Kazpromautomatiks Ltd. **KAZAKHSTAN**  
 Mustafina Str. 7/2  
**KAZ-470046 Karaganda**  
 Phone: +7 7212 / 50 11 50  
 Fax: +7 7212 / 50 11 50

**MIDDLE EAST REPRESENTATIVES**

ILAN & GAVISH Ltd. **ISRAEL**  
 24 Shenkar St., Kiryat Arie  
**IL-49001 Petah-Tiqva**  
 Phone: +972 (0)3 / 922 18 24  
 Fax: +972 (0)3 / 924 0761

TEXEL ELECTRONICS Ltd. **ISRAEL**  
 2 Ha'umanut, P.O.B. 6272  
**IL-42160 Netanya**  
 Phone: +972 (0)9 / 863 39 80  
 Fax: +972 (0)9 / 885 24 30

CEG INTERNATIONAL **LEBANON**  
 Cebaco Center/Block A Autostrade DORA  
**Lebanon - Beirut**  
 Phone: +961 (0)1 / 240 430  
 Fax: +961 (0)1 / 240 438

**AFRICAN REPRESENTATIVE**

CBI Ltd. **SOUTH AFRICA**  
 Private Bag 2016  
**ZA-1600 Isando**  
 Phone: +27 (0)11 / 977 0770  
 Fax: +27 (0)11 / 977 0761