

MAC Operator Terminal

Human-Machine-Interface

User's Manual

English/Svensk

PROFIBUS DP Communication Module IFC PBDP

MITSUBISHI ELECTRIC EUROPE B.V. FACTORY AUTOMATION

ENGLISH

Manual PROFIBUS DP

Foreword

This manual is an installation and function description for the PROFIBUS DP communication module IFC PBDP. The module is connected to the E300, E700 and E710 terminals. Besides this manual, the following manuals are also available.

- E700, Installation
- E710, Installation
- E700/E710, Manual

For information about Siemens PLC systems, refer to respective manuals.

© Mitsubishi Electric Europe B.V. 1997

All examples in this manual are used solely to promote understanding of how the equipment works and its operation. Mitsubishi Eledtric Europe B.V. take no responsability if these examples are used in real applications.

Because of the great many application areas for this equipment, the user himself must acquire the appropriate knlowledge needed to use the equipment correctly for particular applications.

Mitsubishi Electric Europe B.V. absolves itself of all responsabilities for damage and injuries that may occur during installation or use of this equipment. Mitsubishi Electric Europe B.V. absolves itself of all responsabilities for any type of modification made to the equipment.

SIMATICTM is a trademark of Siemens AG.

The product meets with specifications according to European Standard pr EN 50170.

Mitsubishi Electric Europe B.V. absolves itself of all responsabilities for damage caused to its products by other brands of equipment linked to them.

Safety precautions

General

- Check the delivery for transport damage. If damage is found, advise your supplier.
- The product fulfils the requirements of article 4 of EMC directive 89/336/EEC.
- Do not use the product in an explosive environment.
- Modifications, changes and additions to the product are forbidden.
- Use only spare parts approved by Mitsubishi Electric Europe B.V.
- Read the user instructions carefully before use.
- This equipment should only be operated by qualified personnel.

At installation

- The product is constructed for stationary installation.
- Install the product according to the accompanying installation instructions.
- The product must be grounded according to the accompanying installation instructions.
- This equipment must be installed by qualified personnel.
- High voltage-, signal- and supply cables must be separated.
- The product should not be mounted in direct sunlight.

In use

- Keep the equipment clean.
- Emergency stop- and other safety functions should not be controlled from the terminal.
- Do not touch the keys, displays, etc. with sharp objects.

Service and maintenance

- The agreed guarantee applies.
- Clean the display and face with a soft cloth and mild detergent.
- Use batteries specified by G & L Beijer Electronics AB. Batteries should be changed by qualified personnel. The person changing the batteries should be grounded during the operation; e.g. with a grounded wrist strap.
- Repairs should be made by qualified personnel.

At disassembly and scrapping

- Local regulations apply concerning recycling of products or part.
- Please note that the electrolyte condenser and display contain hazardous substances.

Contents

1 Introduction	1
2 Installation	3
2.1 How to connect the flat cable	3
2.2 How to connect the IFC PBDP card	3
2.3 How to select the physical port	4
2.4 Communication settings for the IFC PBDP card	5
2.5 Cabel to PROFIBUS-DP	5
2.6 Technical data	6
3 Configure the terminal	7
3.1 Define slot	7
4 Connection to MELSEC A	11
4.1 Selection of PLC system	11
4.2 I/O handling	11
4.3 Example	13
5 Connection to SIMATIC S5	
5.1 Selection of PLC system	15
5.2 I/O handling	16
5.3 Description of the PLC program section	17
6 Connection to SIMATIC S7	23
6.1 Selection of PLC system	23
6.2 I/O handling	24
6.3 Description of the PLC program section	25

7 The MMI profile	31
7.1 The data exchange	32
7.2 The request and response containers	33
7.3 The index structure	36
8 Appendix	39
8.1 The type diskette	39
8.2 SIMATIC S5 project	39
8.3 SIMATIC S7 project	39
9 Appendix for printouts	A-1

1 Introduction

PROFIBUS DP is a vendor-independent, open industrial fieldbus which can be used in a very wide range of applications. It is an established technology with a large installed base.

Process automation equipment such as sensors, actuators, transmitters, drives and programmable logic controllers, increasingly use digital microelectronics.

PROFIBUS ensures that devices from different vendors can communicate together without the need to adapt interfaces. PROFIBUS is standardized as European Standard pr EN 50170.

The PROFIBUS DP card is dupplied with a type diskette containing PLC programs for communication with Mitsubishi Electric PLC system MELSEC A and Siemens PLC system SIMATIC S5 and SIMATIC S7.

Introduction

2 Installation

This chapter describes how the IFC PBDP card is connected to the terminal. The IFC PBDP packet includes the IFC PBDP card and a type diskette.

2.1 How to connect the flat cable



- 1. Unscrew the back panel and the slot panel.
- 2. Connect the flat cable to the connector X1.

2.2 How to connect the IFC PBDP card



Mount the IFC PBDP card using the enclosed spacers and screws.

2.3 How to select the physical port



Slot 2 is selected

Slot 1 is selected (For E300 you have to select slot 1.)

2.4 Communication settings for the IFC PBDP card



- 1. Connector for the communication cable.
- 2. Bus termination. Set to ON on the first and last units in the network. The first unit in the network often is the master unit in the PLC system.
- 1: Red, ERR, Configuration or communication error. The LED is red until the unit is configured, Indicates time out.
 2: Green, PWR, Power supply 5 VDC OK.
 3: Green, DIA, Diagnostic error, not used.
- 4. State the station number.

2.5 Cabel to PROFIBUS-DP



2.6 Technical data

I/O area size	32-200 byte
Baudrate	9600 bit/s - 12 MBit/s
Identity code	1002
Max. number of nodes without repeater	32
Max. number of nodes with repeater	96
Max. cable length (without repeater)	3000m, 9.6 kb
Max. cable length (without repeater)	200m, 12 Mb

The cable Unitronic-Bus L2/F.I.P is tested and has the following performance:

Capacitance	30 nF/km
Impedance	150 Ohm (3-20 MHz)
Resistance	115 Ohm/km

3 Configure the terminal

The configuration is done with CIMREX PROG.

Make the following steps to use a PCMCIA Flash memory card.

- 1. Install the IFC MC card in the terminal.
- 2. Connect the Flash memory card in the IFC MC-module.

3.1 Define slot

1. Select **Peripherals** in the **Setup** menu.

<u>S</u> etup	
<u>S</u> ys	tem Signals
Ind	ex Registers
<u>C</u> ou	untry Settings
<u>D</u> at	e/Time Format
<u>0</u> nl	ine Settings
<u>T</u> er	minal Options
<u>A</u> la	rm Settings
Dat	abuffer Setting
Dis	<u>k</u> Setting
<u>M</u> o	dem Settings
Per	ip <u>h</u> erals

2. Select the slot you define with the jumper J1 on the expansion card and press **Edit...**.

Configure the terminal



3. Select type of expansion card, in this case IFC PBDP.



4. Select Settings. Here you select the function the memory card will be formatted for.

Settings:

State the settings for the MMI profile.



Input/Output-area size (bytes):

State the size of the input and output area in bytes. Default setting is 32 bytes.

Configure the terminal

4 Connection to MELSEC A

With the PROFIBUS DP card, the MMI terminal can communicate with the Mitsubishi A(1S)J71PB92 module. For information about the A series PLC system we refer to the respective manual.

4.1 Selection of PLC system

In the dialog Project Settings in MAC Programmer+ you select which PLC system the MMI terminal should be connected to. Select A Series.

	Project Settings		
Terminal:	E700 1.1x	Ŧ	OK
PLC System:	A Series	Ŧ	Cancel
PLC Version:		. <u></u> .	Cancer
IONames File:			<u>B</u> rowse

4.2 I/O handling

The terminal can handle the following data types in MELSEC A.

Data types MELSEC	Data types IEC	Description
X	%IX	Input
Y	% QX	Output
М	% MX	Memory cell
В	% MX	Link memory cell (MELSEC NET)
D	% MW	Data register
w	% MW	Link register (MELSEC NET)
R	% MW	File register
т	% MW	Timer, current value
C	%MW	Counter, current value

Connection to MELSEC A

Note!

The MMI profile uses a number of memory cells and data registers for internal handling. These can not be used for other purposes in the PLC program.

Digital signals

Data type MELSEC	Data type IEC
Xn	% IX b
Yn	% QX b
Mn	% MX0. b
Bn	% MX1. b

n=address, b=bit number

Analog signals

Data type MELSEC	Data type IEC
Dn	% MW0. n
Wn	% MW1. n
R n	% MW2. n
T n	% MW3. n
Cn	% MW4. n

n=address

Refer to the respective manual for more information about addressing to Mitsubishi Electric PLC system MELSEC A.

4.3 Example

In this example we use a Mitsubishi MELSEC A system with the module AJ71PB92 and the PLC program delivered on the typefile diskette together with the IFC PBDP card. The example describes the sequence for making settings and connections to get correct communiction.



- 1. Install the terminal according to the Installation manual delivered with the terminal.
- 2. Configure the terminal via the software package MAC Programmer+. The settings to the IFC PBDP card are made in the **Setup** menu under **Expansion slots**. See the chapter *Configure the MMI terminal*.
- 3. Start the PROFIBUS configuration software e.g. COM ET200.
- 4. Configure the master, baudrate, station number, number of bytes in the transmission area, etc. See the software manual.Type files for the terminal are available on the IFC PBDP diskette.
- 5. Create a binary file. For information see the software manual for the COM ET200 for DOS.
- 6. Start the program SWOIX-DPLD from DOS. Load the binary file to the AJ71PB92 module via the SWOIX-DPLD program. For more information see the manual for SWOIX-DPLD.
- 7. Load the enclosed PLC programs to the A series CPU via MELSEC MEDOC.

Connection to MELSEC A

- 8. Connect the cable between the AJ71PB92 module in the PLC system and the IFC-PBDP card in the terminal.
- 9. Put the PLC system and MMI terminal in run mode.

The following figure shows how to implement the program section and subroutine section in the PLC program.



Printout of PLC program section

In the chapter *Appendix for printouts* at the back of the manual you will find a printout of the PLC program section PROFILE for PROFIBUS DP communication.

With the PROFIBUS DP card the MMI-terminal can communicate with Siemens PLC system SIMATIC S5. This chapter describes how the function blocks are built up, which I/O the terminal can access, and how the PLC program is called. For more information about SIMATIC S5, please refer to the Siemens documentation for the SIMATIC S5.

5.1 Selection of PLC system

I the dialog Project Settings in MAC Programmer+ you select which PLC system the MMI terminal should be connected to. Select S5.

	Project Settin	gs	
Terminal:	E700 1.1x	Ŧ	OK
PLC System:	S5	±	Canad
PLC Version:	English	Ŧ	Lancei
IONames File:			Browse

5.2 I/O handling

The terminal can handle the following data types in SIMATIC S5:

Data type English	Data type German	Description	
F	м	Flag	
Q	Α	Output	
I	E	Input	
DB	DB	Datablock	

The DB (Data block) in SIMATIC S5 can have a maximum length of 256 words. The terminal can access all DBs in the PLC system.

All data types consists of byte areas. Addressing is always byte-specific, regardless of whether it is 1, 16 or 32 bits. The addresses are always decimal, 0-65535.

For information about instructions in SIMATIC S5, refer to the SIMATIC manual.

Digital signals

For digital signals, you state current bit in the byte. For example, I50.3 means bit 3 in input byte 50.

Data type English	Data type German
lxxxxx.b	Exxxxx.b
Q xxxxx.b	Axxxxx.b
Fxxxxx.b	Mxxxxx.b

xxxxx=address 0-65535, b=bit number 0-7

Analog signals

For 16-bit numbers, you state the suffix W after the data type; e.g. MW100 means 2 bytes from memory byte 100-101.

Data type English	Data type German
IWxxxxx	EWxxxxx
QWxxxxx	AWXXXXX
FWxxxxx	MWxxxxx
DBno.DWadr	DB no. DW adr

xxxxx=address 0-65535, no=database number 0-255 and adr=data word within the data base 0-255.

5.3 Description of the PLC program section

The PLC program section consists of three function blocks plus one block (OB1) which addresses the function block 190.

Program block

The PLC program on the type diskette consists of three function blocks and one main program.

Function block	Description
0B1	Main program. Calls the function block 190.
FB 190	This block is called by the OB1 and handles the MMI profile.
FB 191	This block reads one index.
FB 192	This block writes one index.

The following figure shows how to implement OB1 in the PLC program.



END	

The main program, OB1

OB1 is the main program where the parameters are defined for calling the other function blocks.

The following parameters are defined for the function block 190:

Parameter	Description
LEN	State the length of the request container and response container. Must be the same as the setting in the terminal.
READ	State the address to the first byte in the response container in the PROFIBUS area.
WRI	State the address to the first byte in the request container in the PROFIBUS area.
INT	Internal byte
HERR	State the register to contain eventual error code from FB 190.
TMS	Time out in seconds. If communication with the terminal brakes for a longer time than stated in the parameter TMS an error code will be set in the parameter HERR.

For more information about the parameters, refer to the manual for SIMATIC S5.

Example

In this example we use Siemens PLC system S5 and the PLC program on the type diskette. The example describes in which order you make the settings and connections to get the correct communication.



- 1. Install the terminal according to the Installation manual delivered with the terminal.
- 2. Configure the terminal with the software package MAC Programmer+. The settings for the IFC PBDP card is made in the **Setup** menu under **Expansion slots**.
- 3. Start the COM ET200 configuration software.
- 4. Configure the master, baudrate, station number, number of bytes in the transfer container etc. For more information, refer to the software manual. Type files for the terminal are available on the IFC PBDP diskette.
- 5. Load the configuration to the S5. See the SIMATIC S5 manual.
- 6. Load the enclosed PLC program to the S5.
- 7. Connect the cable between the S5 system and the IFC PBDP card in the terminal.

8. Put the PLC system and the MMI terminal in run mode.

Note!

If you try to open a non-existent data block the PLC system will stop. For more information, refer to the SIMATIC manual.

Printout of PLC program section

In the chapter *Appendix for printouts* at the back of the manual you will find a printout of the PROFIBUS DP function block.

With the PROFIBUS DP card, the MMI-terminals E700 and E710 can communicate with Siemens PLC system SIMATIC S7. This chapter describes how the function blocks are built up, which I/O E700 and E710 can access, and how the PLC program is addressed. For more information about S7, refer to the Siemens documentation for the SI-MATIC S7.

6.1 Selection of PLC system

In the diglog Project Settings in MAC Programmer+ you select which PLC system the MMI terminal should be connected to. Select S7.

	Project Set	tings	
Terminal:	E700 1.1x	Ŧ	OK
PLC System:	\$7	±	Cancel
PLC Version:	IEC	±	
IONames File:			Browse

6.2 I/O handling

The E700/E710 can handle the following data types in SIMATIC S7:

Data types IEC	Data types German	Description
м	М	Flag
Q	Α	Output
I	E	Input
DB	DB	Data block

The project memory decides the max length of the DB (Datablock) in SIMATIC S7. The terminal can access one DB in the PLC system.

All data types consists of byte areas. Addressing is always byte-specific, regardless of whether it is 1, 16 or 32 bits. The addresses are always decimal, 0-65535.

For information about the instructions in S7 we refer to the SIMATIC manual.

Digital signals

For digital signals, you state current bit in the byte. For example I50.3 means bit 3 in input byte 50.

Data type IEC	Data type SIMATIC
lxxxxx.b	Exxxxx.b
Q xxxxx.b	Axxxxx.b
Mxxxxx.b	Mxxxxx.b

xxxxx=address 0-65535, b=bit number 0-7

Analog signals

For 16-bit numbers, you state the suffix W after the data type; e.g. MW100 means 2 bytes from memory byte 100-101.

Data type IEC	Data type SIMATIC
IWxxxxx	EWxxxxx
QWxxxxx	AWXXXXX
MWxxxxx	MWxxxxx
DBWXXXXX	DBWXXXXX

xxxxx=address 0-65535.

6.3 Description of the PLC program section

The PLC program consists of one function block and a main program (OB1) which addresses the function block.

Program block

The PLC program on the type diskette consists of three function blocks and one main program.

Function block	Description
OB1	Main program. Calls the function block 110.
FB 110	This block is called by the OB1 and handles the MMI profile.
FC 111	This block reads one index.
FC 112	This block writes one index.
DB 51	Data block used for analog signals.

The following figure shows how to implement OB1 in the PLC program.



The main program, OB1

OB1 is the main program where parameters are defined for calling the function block 110.

The following parameters are defined for the function block 110:

Parameter	Description
CON_LEN	State the length of the request container and response con- tainer in bytes. Must be the same as the setting in the termi- nal.
FB_IN_OFFSET	State the address to the first byte in the response container in the profibus area.
FB_OUT_OFFSET	State the address to the first byte in the request container in the profibus area.
DB_ADDRESS	State the number of the data block used.

For more information, refer to the SIMATIC S7 manual.

Exempel

In this example we use Siemens PLC system S7 and the PLC program on the type diskette. The example describes in which order you make the settings, and connections to get the correct communication.



- 1. Install the terminal according to the Installation manual delivered with the terminal.
- Configure the terminal with the software package MAC Programmer+. The settings for the IFC PBDP card is made in the Setup menu under Expansion slots.
- 3. Start the SC (system configuration) in STEP7.
- 4. Configure the master, baudrate, station number, number of bytes in the transfer container, etc. For more information, refer to the software manual. Type files for the terminal are available on the IFC PBDP diskette.
- 5. Load the configuration to the S7. See the SIMATIC S7 manual.
- 6. Load the enclosed PLC program to the SIMATIC S7.
- 7. Connect the cable between the SIMATIC S7 system and the IFC PBDP card in the terminal.

8. Put the PLC system and the MMI terminal in run mode.

Note!

If you try to open a non-existent data block the PLC system will stop. For more information, refer to the SIMATIC manual.

Printout of PLC program section

In the chapter *Appendix for printouts* at the back of the manual you will find a printout of the PROFIBUS DP function block.
Connection to SIMATIC S7

7 The MMI profile

This chapter describes setup of the MMI profile, and is for the benefit of readers who want to learn more about data exchange via the MMI profile.

The MMI profile allows exchange of an unlimited amout of data, and also allows the terminal to access all type of devices in the PLC system.

Together with the card a type diskette is supplied containing PLC program for communication with the Mitsubishi MELSEC A system via the AJ71PB92 module and Siemens PLC system SIMATIC S5 and S7.

PROFIBUS-DP allows a maximum byte length of 200 bytes in and 200 out per station. The MMI profile uses an input area and an output area. These areas are hereafter referred to as containers. The MMI uses the container to access the PLC.

For more detailed information on the MMI profile see the specifications from the Profibus Organisation.



7.1 The data exchange

- The MMI terminal is a slave in the PROFIBUS-DP net.
- The PLC system is the master.
- The MMI terminal requests data from the PLC system through the input container.
- The PLC program serves the MMI terminal with data through the output container.
- Handshaking between the MMI terminal and the PLC system is performed through a Control byte in the containers.
- The MMI terminal can access all types of PLC devices.

When the MMI terminal toggles the control byte, the PLC knows that the MMI terminal wants to exchange data.

7.2 The request and response containers

The container starts at address 0 with the control byte. The control byte is used for handshaking and for communication failure detection. Addresses 1-3 are reserved for Fast bytes. These are not used in the MMI terminal.

Addresses 4 to 200 are used for communication. The MMI terminal put indexes here (3 byte each) that refer to the PLC devices that the MMI wants to read or write. The PLC system, on the other hand, will put the data here from the PLC devices that the MMI terminal has asked for. If the MMI terminal wants to write to a PLC device, the data is stored immediately after the index.

	Request container	Response container		
00	Control byte	00	Control byte	
01	Not used	01	Not used	
02	Not used	02	Not used	
03	Not used	03	Not used	
04	Index 1 Read	04	Data for index 1	
05		05		
06		06	Data for index 2-	
07	Index 2 Read	07		
08		08		
09		09		
10	Index 3 Write	10		
11		11		
12		12		
13	Data byte for index 3	13	Free	
14	Data byte for index 3	14	Free	
200		200	Free	

The MMI profile

The control byte in the request container

The request container contains a message from the MMI terminal to the PLC system.

7	6	5	4	3	2	1	0
Request	COM	Toggle	Error	Acknowl	edge bits,	not used	

Request

The request byte is used for handshaking between the units. The bit toggles when the MMI terminal wants information for the PLC system.

сом

The COM bit is set by the MMI terminal. If communication breaks the bit will be reset.

Toggle

The toggle bit is always set to the opposite value as the toggle bit in the request container.

Error

This bit is not used.

Acknowledge

These bits are not used.

The control byte in the response container

The response container contains the response from the PLC system to the MMI terminal.

7	6	5	4	3	2	1	0
Response	COM	Toggle	Error	Acknowle	edge bits,	not used	

Response

Is set to the same value as request when data is ready for transfer to the MMI terminal.

сом

The OM bit is set by the PLC program. If communication breaks the bit will be reset.

Toggle

The toggle bit is always set to the same value as the toggle bit in the request container.

Error

This bit is not used.

Action

These bits are not used.

The MMI profile

7.3 The index structure

The index is built up of 3 bytes. The index contains 4 parts of information:

- If the device should be read or written.
- Which type of device (input, data register, timer etc.)
- Number of device (e.g. input 5).
- Data length (from one bit up to 16 bytes).

7	6	5	4	3	2	1	0
Write	Ln2	Ln1	Ln0		PLC dev	ice type	
	Index number bit 15-8						
	Index number bit 7-0						

PLC device type

States the type of PLC device according to the following table.

	MELSEC A		SIMATIC S5		SIMATIC S7	
Number	Data type MELSEC	Data type IEC	Data type English	Data type German	Data type IEC	Data type SIMATIC
1	М	%MX0.	F	М	М	М
2	Х	%IX	I	E	I	E
3	Y	%QX	Q	А	Q	А
4	В	%MX1.				
8	D	%MW0.	DB	DB	DB	DB
9	R	%MW2.				
10	Т	%MW3.				
11	С	%MW4.				
12	W	%MW1.				

Ln0-Ln2

States the data length according to the following table.

Ln2	Ln1	Ln0	Length
0	0	0	bit
0	0	1	1 byte
0	1	0	2 bytes
0	1	1	4 bytes
1	0	0	6 bytes
1	0	1	8 bytes
1	1	0	12 bytes
1	1	1	16 bytes

Sequence of events

- The MMI terminal decides which variables are to be read/written.
- The terminal toggles the request flag in the control byte.
- In the next PROFIBUS cycle, the PLC notices that the request flag has been changed.
- For each read index, the values of the requested devices are copied to the response container.
- Then the response flag in the response container is set to the same value as the request flag in the request container.
- In the next PROFIBUS cycle, the MMI terminal notices that the request flag and the response flag are the same which means that there is data for the terminal.
- The received values will now be used by the objects in the terminal.

The MMI profile

8 Appendix

8.1 The type diskette

The files on the type diskette:

IFCPBDTE.200	Card specification file for DOS software ET200 and STEP 7, English.
IFCPBDTD.200	Card specification file for DOS software ET200 and STEP 7, German.
IFC-PBDP.GSD	Card specification file for Windows software COM ET200.
S5	Directory containing the SIMATIC S5 project.
S7	Directory containing the SIMATIC S7 project.

8.2 SIMATIC S5 project

To change this, simply adjust the PLC program. The following devices are used by the program.

MB200-203, MB206-217, MB220-225, MB230-233, MB240-241 and T2.

8.3 SIMATIC S7 project

To change this, simply adjust the PLC program. The following devices are used by the program.

MB100-101, MB110, MB200-217, MB220-225, MB230-233, MB240-247 and T2.

Appendix

Index

A

AJ71PB92 module, 13

С

Cable, 5 Communication error, 5 Configuration error, 5 Configure the MMI terminal, 7 Connecting the flat cable, 3 Connecting the IFC PBDP card, 3 Connection to MELSEC A, 11 Containers 32

D

Data exchange, 32

F

Files, 39

Μ

MELSEC A Analog signals, 12 Data types, 11 Digital signals, 12 I/O handling, 11 MMI profile, 31

Ρ

Physical port, 4

R

Request container, 32 Control byte, 34 Response container, 32 Control byte, 35

S

S7 Index, 36 SIMATIC S5, 15 Addressing, 16 Analog signals, 17 Data block, 16 Data types, 16 Digital signals, 16 I/O handling, 16 OB1, 17 SIMATIC S7, 23 Addressing, 24 Analog signals, 25 Data block, 24 Data types, 24 Digital signals, 24 I/O handling, 24 OB1, 25 Slot, 4, 7

T

Type diskette, 39

SVENSK

Manual PROFIBUS DP

Förord

Denna manual är en installations och funktionsbeskrivning för PROFIBUS DP kommunikationsmodulen IFC PBDP. Modulen kan användas till E300, E700 och E710 terminalerna. Förutom denna manual finns också följande manualer tillgängliga.

- E700, Installation
- E710, Installation
- E700/E710, Manual

För information om Siemens PLC-system hänvisas till respektive manual.

© G & L Beijer Electronics AB 1997

Alla exempel i denna manual är enbart ämnade för att öka förståelsen av utrustningens funktion och handhavande. G & L Beijer Electronics AB tar inget ansvar om dessa exempel används i verkliga applikationer.

På grund av det stora antalet användningsområden för denna utrustning, måste användaren själv inhämta tillräckligt med kunskap för att rätt använda denna i sin speciella applikation.

G & L Beijer Electronics AB fråntager sig allt ansvar för skador som kan uppstå vid installation eller användning av denna utrustning.

G & L Beijer Electronics AB förbjuder all modifiering, ändring eller ombyggnad av utrustningen.

SIMATIC[™] är ett av Siemens AG registrerat varumärke.

Produkten är standardiserad efter Europa Standard pr EN 50170.

G & L Beijer Electronics AB fråntager sig allt ansvar för skador på produkterna orsakade av anslutna produkter från andra leverantörer.

Säkerhetsföreskrifter

Allmänt

- Kontrollera de levererade produkterna för att upptäcka eventuella transportskador. Meddela din leverantör om skador upptäcks.
- Produkten uppfyller kraven enligt artikel fyra i EMC-direktivet 89/336/EEC.
- Produkten får ej användas i explosiv miljö.
- All modifiering, ändring och ombyggnad av produkten är förbjuden.
- Endast reservdelar godkända av G & L Beijer Electronics AB får användas.
- Läs användarbeskrivningen noga innan produkten används.
- Utrustningen måste hanteras av personal med adekvat utbildning.

Vid installation

- Produkten är konstruerad för fasta installationer.
- Installera produkten enligt medföljande installationsbeskrivning.
- Jordning skall ske enligt medföljande installationsbeskrivning.
- Installation skall göras av personal med adekvat utbildning.
- Högspännings-, signal-, och spänningskablar måste separeras.
- Produkten bör ej monteras i direkt solljus.

Vid användning

- Håll utrustningen ren.
- Nödstoppsfunktioner eller andra säkerhetsfunktioner får ej styras från MAC-terminalen.
- Tangenter, displayglas etc. får ej påverkas med vassa föremål.

Service och underhåll

- Garanti gäller enligt avtal.
- Använd lätt rengöringsmedel och mjuk trasa för att rengöra displayglaset och fronten.
- Använd batterier enligt specifikation från G & L Beijer Electronics AB. Batteribyte ska utföras av personal med adekvat utbildning. Person som utför arbetet måste vara jordad under tiden utbytet sker, t ex med jordat handledsband.
- Reparationer ska utföras av auktoriserad personal.

Vid nedmontering och skrotning

- Återvinning av produkten eller delar av produkten skall ske enligt gällande regler i respektive land.
- Beakta att följande komponenter innehåller farliga ämnen: elektrolytkondensatorer samt display.

Innehåll

1 Introduktion	1
2 Installation	3
2.1 Anslutning av flatkabeln	3
2.2 Anslutning av IFC PBDP kortet	3
2.3 Val av fysisk port	4
2.4 Kommunikationsinställningar för IFC PBDP kortet	5
2.5 Kabel till PROFIBUS DP	5
2.6 Tekniska data	6
3 Konfigurering av MMI-terminalen	7
4 Anslutning till MELSEC A	9
4.1 Val av PLC-system	9
4.2 I/O hantering	10
4.3 Exempel	12
5 Anslutning till SIMATIC S5	15
5.1 Val av PLC-system	15
5.2 I/O hantering	16
5.3 Beskrivning av PLC-programdelen	17
6 Anslutning till SIMATIC S7	23
6.1 Val av PLC-system	23
6.2 I/O hantering	24
6.3 Beskrivning av PLC-programdelen	25
7 MMI-profilen	31
7.1 Datautbyte	32
7.2 Areorna för begäran och svar	32
7.3 Strukturen på index	36

8 Appendix	
8.1 Typdisketten	
8.2 MELSEC MEDOC projekt	
8.3 SIMATIC S5 projekt	40
8.4 SIMATIC S7 projekt	40
9 Appendix for printouts	A-1

1 Introduktion

PROFIBUS DP är en leverantörsoberoende, öppen industrifältbuss som kan användas i många olika applikationer. Det är en etablerad teknologi med ett stort antal installationer.

Extern fältutrustning installerad för processautomatisering som sensorer, ställdon, sändare, drivenheter och PLC-system använder mer och mer mikroelectronik.

PROFIBUS DP medger att enheter från olika leverantörer kan kommunicera på ett effektivt sätt i ett nätverk. PROFIBUS är standardiserad som Europa Standard pr EN 50170.

Tillsammans med PROFIBUS DP kortet levereras en typdiskett som innehåller bl a PLC-program för kommunikation med Mitsubishi Electric PLC-system MELSEC A samt Siemens PLC-system SIMATIC S5 och SIMATIC S7. Introduktion

2 Installation

Detta kapitlet beskriver hur IFC PBDP kortet ansluts till MMI-terminalerna. IFC PBDP paketet innehåller IFC PBDP kortet och en typdiskett.

2.1 Anslutning av flatkabeln



- 1. Skruva av täckplåten på terminalens baksida samt kortplatspanelen.
- 2. Anslut flatkabeln till kontakten X1.

2.2 Anslutning av IFC PBDP kortet



Montera IFC PBDP kortet med medföljande distanser och skruvar.

2.3 Val av fysisk port



2.4 Kommunikationsinställningar för IFC PBDP kortet



- 1. Kontakt för anslutning av kommunikationskabel.
- 2. Bussterminering. Sätts i läge ON på den första och sista enheten i nätverket. Den första enheten i nätverket är oftast masterenheten i PLC-systemet.
- 1: Röd, ERR, Konfigurerings- eller kommunikationsfel. Lysdioden är röd tills enheten är konfigurerad. Indikerar time out.
 2: Grön, PWR, Spänningsmatning, 5 VDC OK.
 3: Grön, DIA, Diagnostikfel. Används inte.
- 4. Anger stationsnummer.

2.5 Kabel till PROFIBUS DP



2.6 Tekniska data

I/O area storlek	32-200 byte
Överföringshastighet	9600 bit/s - 12 MBit/s
Identitetskod	1002
Max. antal noder utan repeater	32
Max. antal noder med repeater	96
Max. kabellängd (med repeater)	3000m, 9.6 kb
Max. kabellängd (utan repeater)	200m, 12 Mb

Kabeln Unitronic-Bus L2/F.I.P är testad och har följande prestanda:

Kapacitans	30 nF/km
Impedans	150 Ohm (3-20 MHz)
Resistans	115 Ohm/km

3 Konfigurering av MMI-terminalen

Terminalen konfigureras med *MAC Programmer*+. Inställningarna görs under **Setup** menyn, **Expansion slots**.

😑 Expansion Slo	Expansion Slots			
Expansion slot 1:	OK			
IFL-PBUP ± Settings	Cancel			
Expansion slot 2:				
Not used ± Settings				

Expansion slot 1-2:

Välj IFC PBDP för aktuell kortplats. Inställningen måste vara samma som inställningen av bygeln på IFC PBDP kortet.

Settings:

Inställningar för MMI profilen.

<mark>—</mark> IFC-PB[P Settings	
Input/Output-area size (bytes):	32	OK
		Cancel

Input/Output-area size (bytes):

Anger storleken på ingångs- och utgångsarean i antal bytes. Grundinställningen är 32 bytes. Konfigurering av MMI-terminalen

4 Anslutning till MELSEC A

Med PROFIBUS DP kortet kan terminalen kommunicera med Mitsubishi PLC-system i A-serien via modulen A(1S)J71PB92. För information om A-seriens PLC-system och terminalerna hänvisas till respektive manual.

4.1 Val av PLC-system

I dialogen Project Settings i MAC Programmer+ väljer du vilket PLCsystem MMI-terminalen ska vara uppkopplad mot. Välj A Series.

-	Project Settings			
Terminal:	E700 1.1x	Ŧ	OK	
PLC System:	A Series	Ŧ	Capad	
PLC Version:			Cancer	
IONames File:			<u>B</u> rowse	

Anslutning till MELSEC A

4.2 I/O hantering

Terminalen kan hantera följande datatyper i MELSEC A.

Datatyper MELSEC	Datatyper IEC	Betydelse	
X	%IX	Ingång	
Y	% QX	Utgång	
м	% MX	Minnescell	
В	% MX	Länkminnescell (MELSEC NET)	
D	% MW	Dataregister	
w	% MW	Länkregister (MELSEC NET)	
R	% MW	Filregister	
Т	%MW	Tidkrets, aktuellt värde	
C	%MW	Räknare, aktuellt värde	

Observera!

MMI-profilen använder ett antal minnesceller och dataregister för intern hantering. Dessa kan inte användas till någonting annat i PLC-programmet.

Digitala signaler

Datatyp MELSEC	Datatyp IEC
X n	% IX b
Yn	% QX b
Mn	% MX0. b
B n	% MX1. b

n=adress, b=bitnummer.

Analoga signaler

Datatyp MELSEC	Datatyp IEC	
D n	% MW0. n	
Wn	% MW1. n	
Rn	% MW2. n	
Tn	% MW3. n	
Cn	% MW4. n	

n=adress

För mer information om adressering till Mitsubishi Electric PLCsystem MELSEC A hänvisas till respektive manual. Anslutning till MELSEC A

4.3 Exempel

I detta exemplet använder vi Mitsubishi modulen AJ71PB92 och PLCprogrammet som finns på medföljande typdiskett. Exemplet beskriver i vilken ordning du gör inställningarna och anslutningarna för att få en korrekt kommunikation.



- 1. Installera terminalen enligt Installationsmanualen som levereras med terminalen.
- 2. Konfigurera terminalen via programpaketet MAC Programmer+. Inställningarna för IFC PBDP kortet görs i **Setup** menyn under **Expansion slots**. Se kapitlet *Konfigurering av MMI-terminalen*.
- 3. Starta PROFIBUS konfigureringsprogramvara (exempelvis COM ET200).
- 4. Konfigurera mastern, överföringshastighet, stationsnummer, antal bytes i överföringsarean etc. För mer information hänvisas till manualen för programvaran. Typfilen för terminalen finns på IFC PBDP disketten.
- 5. Skapa en binärfil. För information hänvisas till manualen för programvaran COM ET200 för DOS.

- 6. Starta programmet SWOIX-DPLD från DOS. Skicka ner binärfilen till AJ71PB92 modulen via SWOIX-DPLD programmet. För mer information hänvisas till manualen för programmet SWOIX-DPLD.
- 7. Skicka ner medföljande PLC-program till A-seriens CPU via MELSEC MEDOC.
- 8. Anslut kabeln mellan AJ71 PB 92 modulen i PLC-systemet och IFC PBDP kortet i terminalen.
- 9. Sätt PLC-systemet och MMI-terminalen i driftläge.

Nedanstående figur visar hur programdel och subrutindel placeras i PLC-programmet.



Anslutning till MELSEC A

Utskrift av PLC-programdel

I kapitlet *Appendix for printouts* längst bak i manualen finns en utskrift av PLC-programdelen PROFILE för PROFIBUS DP kommunikation.

5 Anslutning till SIMATIC S5

Med PROFIBUS DP kortet kan MMI-terminalen kommunicera med Siemens PLC-system SIMATIC S5. Detta kapitlet beskriver hur funktionsblocken är uppbyggda, vilka I/O terminalen kan adressera samt hur PLC-programmet anropas. För mer information om SIMATIC S5 hänvisas till Siemens dokumentation för systemet SIMATIC S5.

5.1 Val av PLC-system

I dialogen Project Settings i MAC Programmer+ väljer du vilket PLCsystem MMI-terminalen ska vara uppkopplad mot. Välj S5.

	Project Settings				
Terminal:	E700 1.1x	Ŧ	OK		
PLC System:	\$5	±	Canad		
PLC Version:	English	Ŧ	Lancel		
IONames File:			Browse		

Anslutning till SIMATIC S5

5.2 I/O hantering

Terminalen kan hantera följande datatyper i SIMATIC S5:

Datatyp Engelska	Datayp Tyska	Betydelse	
F	М	Flagga	
Q	Α	Utgång	
I	E	Ingång	
DB	DB	Datablock	

DB (Datablock) i SIMATIC S5 kan vara max 256 ord långa. Terminalen kan adressera alla DB i PLC-systemet.

Alla datatyper består av byte-areor. Adresseringen sker alltid med avseende på bytes oavsett om det är 1, 16 eller 32 bitar. Adresserna är alltid decimala, 0-65535.

För information om instruktioner i SIMATIC S5 hänvisas till SIMATIC manualen.

Digitala signaler

För digitala signaler anges vilken bit i byten som avses. T ex betyder I50.3 bit 3 i ingångsbyte 50.

Datatyp Engelsk	Datatyp Tysk	
Ixxxxx.b	Exxxxx.b	
Q xxxxx.b	Axxxxx.b	
Fxxxxx.b	Mxxxxx.b	

xxxxx=adress 0-65535, b=bitnummer 0-7

Analoga signaler

För 16-bitars tal anges suffixet W. T ex betyder MW100 att 2 bytes från minnesbyte 100-101 tas.

Datatyp Engelsk	Datatyp Tysk
IWxxxxx	EWxxxxx
QWxxxxx	AWXXXXX
FWxxxxx	MWxxxxx
DBno.DWadr	DBno.DWadr

xxxxx=adress 0-65535, no=databasnummer 0-255 och adr=dataord inom databasen 0-255.

5.3 Beskrivning av PLC-programdelen

PLC-programdelen består av tre funktionsblock plus ett block (OB1) som anropar funktionsblock 190.

Programblock

PLC-programdelen som finns på typdisketten innehåller tre funktionsblock och ett huvudprogram:

Funktionsblock	Förklaring		
0B1	Huvudprogram. Anropar funktionsblock 190.		
FB 190	Detta block anropas av OB1 och sköter hanteringen av MMI- profilen.		
FB 191	Detta block läser 1 index.		
FB 192	Detta block skriver 1 index.		

Anslutning till SIMATIC S5

Nedanstående figur visar hur OB1 placeras i PLC-programmet.



Segment 3



Segment 4

0000		:JU	FΒ	190
0001		: PROFILE		
0002	Name	:	KF	+32
0003	LEN	:	KF	+6
0004	WRI	:	KF	+6
0005	INT	:	FΥ	100
0006	HERR	:	FΥ	101
0007	TEMS	:	т1	


Huvudprogrammet, OB1

OB1 är huvudprogrammet där parametrar definieras för anrop av övriga funktionsblock. Följande parametrar definieras för funktionsblocket 190:

Parameter	Förklaring
LEN	Anger längden på areorna för begäran och svar i bytes. Måste vara samma som inställningen i terminalen.
READ	Anger adressen till första byten i arean för svar i PROFIBUS-arean.
WRI	Anger adressen till första byten i arean för begäran i PROFIBUS- arean.
INT	Intern byte
HERR	Anger det register som ska innehålla eventuell felkod från FB 190.
TMS	Time out i sekunder. Bryts kommunikationen med terminalen under längre tid än angivet värde i parametern TMS ges felkod i parame- tern HERR.

För mer information hänvisas till Siemens manual för SIMATIC S5.

Exempel

I detta exemplet använder vi Siemens PLC-system SIMATIC S5 och PLC-programmet som finns på typdisketten. Exemplet beskriver i vilken ord-ning du gör inställningarna och anslutningarna för att få rätt kommunikation.



- 1. Installera terminalen enligt Installationsmanualen som levereras med terminalen.
- Konfigurera terminalen via programpaketet MAC Programmer+. Inställningarna för IFC PBDP kortet görs i Setup menyn under Expansion slots.
- 3. Starta COM ET200 konfigureringsprogramvara.
- 4. Konfigurera mastern, överföringshastighet, stationsnummer, antal bytes i överföringsarean etc. För mer information hänvisas till manualen för programvaran. Typfiler för terminalen finns på IFC PBDP disketten
- 5. Skicka ner konfigurationen till S5. Se Siemens manual för S5.
- 6. Skicka ner medföljande PLC-programdel till S5.

- 7. Anslut kabeln mellan S5 systemet och IFC PBDP kortet i terminalen.
- 8. Sätt PLC-systemet och MMI-terminalen i driftläge.

Observera!

Försöker du öppna ett datablock som inte finns stannar PLC-systemet. För mer information hänvisas till SIMATIC manualen.

Utskrift av PLC-programdelen

I kapitlet *Appendix for printouts* längst bak i manualen finns en utskrift av PROFIBUS funktionsblocken.

Med PROFIBUS DP kortet kan MMI-terminalen kommunicera med Siemens PLC-system SIMATIC S7. Detta kapitlet beskriver hur funktionsblocken är uppbyggda, vilka I/O terminalen kan adressera samt hur PLC-programmet anropas. För mer information om S7 hänvisas till Siemens dokumentation för SIMATIC S7.

6.1 Val av PLC-system

Idialogen Project Settings i MAC Programmer+ väljer du vilket PLCsystem MMI-terminalen ska vara uppkopplad mot. Välj S7.

Project Settings							
Terminal:	E700 1.1x	±	OK				
PLC System:	\$7	Ŧ					
PLC Version:	IEC	±	Lancei				
10Names File:			<u>B</u> rowse				

6.2 I/O hantering

Terminalen kan hantera följande datatyper i SIMATIC S7:

Datatyp IEC	Datayp SIMATIC	Betydelse
м	м	Flagga
Q	Α	Utgång
I	E	Ingång
DB	DB	Datablock

DB (Datablock) i S7 kan vara hur stora som helst. Endast projektminnet begränsar storleken. Terminalen kan adressera ett DB i PLCsystemet.

Alla datatyper består av byte-areor. Adresseringen sker alltid med avseende på bytes oavsett om det är 1, 16 eller 32 bitar. Adresserna är alltid decimala, 0-65535.

För information om instruktioner i SIMATIC S7 hänvisas till SIMATIC manualen.

Digitala signaler

För digitala signaler anges vilken bit i byten som avses. T ex betyder I50.3 bit 3 i ingångsbyte 50.

Datatyp IEC	Datatyp SIMATIC
lxxxxx.b	Exxxxx.b
Q xxxxx.b	A xxxxx.b
Mxxxxx.b	Mxxxxx.b

xxxxx=adress 65535, b=bitnummer 0-7

Analoga signaler

För 16-bitars tal anges suffixet W. T ex betyder MW100 att 2 bytes från minnesbyte 100-101 tas.

Datatyp IEC	Datatyp SIMATIC
IWxxxxx	EWxxxxx
QWxxxxx	AWXXXXX
MWxxxxx	MWxxxxx
DBWxxxxx	DBWxxxxx

xxxxx=adress 0-65535

6.3 Beskrivning av PLC-programdelen

PLC-programdelen består av ett funktionsblock plus ett huvudprogram (OB1) som anropar funktionsblocket.

Programblock

PLC-programdelen som finns på typdisketten innehåller tre funktionsblock och ett huvudprogram:

Funktionsblock	Förklaring
OB1	Huvudprogram. Anropar funktionsblock 110.
FB 110	Detta block anropas av OB1 och sköter hanteringen av MMI- profilen.
FC 111	Detta block läser 1 index.
FC 112	Detta block skriver 1 index.
DB 51	Datablock som används för analoga signaler.

Nedanstående figur visar hur OB1 placeras i PLC-programmet.



Huvudprogrammet, OB1

OB1 är huvudprogrammet där parametrar definieras för anrop funktionsblock 110.

Följande parametrar definieras för funktionsblock 110:

Parameter	Förklaring
CON_LEN	Anger längden på areorna för begäran och svar i bytes. Måste vara samma som inställningen i terminalen.
FB_IN_OFFSET	Anger adressen till första byten i arean för svar i PROFIBUS- arean.
FB_OUT_OFFSET	Anger adressen till första byten i arean för begäran i PROFI- BUS-arean.
DB_ADDRESS	Anger numret på datablocket som används.

För mer information om parametrarna hänvisas till Siemens manual för SIMATIC S7.

Exempel

I exemplet använder vi Siemens PLC-system SIMATIC S7 och PLCprogramdelen som finns på typdisketten. Exemplet beskriver i vilken ordning du gör inställningarna och anslutningarna för att få rätt kommunikation.



- 1. Installera terminalen enligt Installationsmanualen som levereras med terminalen.
- 2. Konfigurera terminalen via programpaketet MAC Programmer+. Inställningarna för IFC PBDP kortet görs i **Setup** menyn under **Expansion slots**.
- 3. Starta SC (system configuration) i STEP7.
- 4. Konfigurera mastern, överföringshastighet, stationsnummer, antal bytes i överföringsarean etc. För mer information hänvisas till manualen för programvaran. Typfiler för terminalen finns på IFC PBDP disketten.
- 5. Skicka ner konfigureringen till S7. Se Siemens manual för S7.
- 6. Skicka ner medföljande PLC-programdel till S7.

- 7. Anslut kabeln mellan S7 systemet och IFCPBDP kortet i terminalen.
- 8. Sätt PLC-systemet och MMI-terminalen i driftläge.

Observera!

Försöker du öppna ett datablock som inte finns stannar PLC-systemet. För mer information hänvisas till SIMATIC manualen.

Utskrift av PLC-programdelen

I kapitlet *Appendix for printouts* längst bak i manualen finns en utskrift av PLC-programdelen för PROFIBUS DP kommunikation.

7 MMI-profilen

Detta kapitlet beskriver hur MMI-profilen är uppbyggd och är riktad till de användare som vill veta lite mer om datautbyte via MMI-profilen.

MMI-profilen tillåter utbyte av obegränsat antal data. Dessutom tillåter den terminalen att accessa alla datatyper i PLC-systemet.

Tillsammans med kortet levereras en typdiskett som innehåller PLCprogramdelar för kommunikation med Mitsubishi MELSEC A system via AJ71PB92 modulen samt Siemens PLC-system SIMATIC S5 och S7.

PROFIBUS-DP tillåter max byte längd på 200 bytes in och 200 bytes ut per station. MMI-profilen använder en area för begäran och en area för svar. Areorna används för att accessa PLC-systemet.

För mer information om MMI-profilen hänvisas till specifikationer från the Profibus Organisation.



MMI-profilen

7.1 Datautbyte

- MMI-terminalen är alltid slav i ett PROFIBUS DP nät.
- PLC-systemet är master.
- MMI-terminalen begär data från PLC-systemet via arean för begäran.
- PLC-program förser MMI-terminalen med data via arean för svar.
- Handskakning mellan MMI-terminalen och PLC-systemet sköts via en kontrollbyte i respektive area.
- MMI-terminalen kan accessa alla datatyper.

När MMI-terminalen växlar status på kontrollbyten vet PLC-systemet att MMI-terminalen vill utbyta data.

7.2 Areorna för begäran och svar

MMI-profilen är uppbyggd av areor mellan vilka datautbytet sker.

Areorna startar på adress 0 med en kontrollbyte. Kontrollbyten används för handskakning och för detektering av kommunikationsfel. Adresserna 1-3 är reserverade för Snabba bytes. Dessa används inte i terminalen.

Adresserna 4 till 200 används för kommunikation. Här sätter MMIterminalen index (3 byte/index) i arean för begäran, som refererar till de PLC-adresser som MMI-terminalen vill läsa eller skriva till. PLCsystemet lägger den data MMI-terminalen önskar från PLC-systemet i motsvarande index i arean för svar. Om MMI-terminalen vill skriva till en PLC-adress lagras data direkt efter index i arean för svar.

	Area för begäran		Area för svar
00	Kontrollbyte	00	Kontrollbyte
01	Används inte	01	Används inte
02	Används inte	02	Används inte
03	Används inte	03	Används inte
04	Index 1 Läs	04	Data för index 1
05		05	
06		06	Data för index 2
07	Index 2 Läs	07	
08		08	
09		09	
10	Index 3 Skriv	10	
11		11	
12		12	
13	Databyte för index 3	13	Ledig
14	Databyte för index 3	14	Ledig
200		200	Ledig

MMI-profilen

Kontrollbyten i arean för begäran

Arean för begäran innehåller meddelande från MMI-terminalen till PLC-systemet.

7	6	5	4	3	2	1	0
Request	СОМ	Toggle	Error	Acknowl	edge bits,	not used	

Request

Request-biten används för handskakning mellan enheterna. Biten växlar status när MMI-terminalen vill ha information från PLC-systemet.

сом

COM-biten sätts av MMI-terminalen. Bryts kommunikationen nollställs COM-biten.

Toggle

Toggle-biten har alltid motsatt status som toggle-biten i arean för begäran.

Error

Denna bit används inte.

Acknowledge

Dessa bitar används inte.

Kontrollbyten i arean för svar

Arean för svar innehåller svaret från PLC-systemet till MMI-terminalen.

7	6	5	4	3	2	1	0
Response	СОМ	Toggle	Error	Acknowledge bits, not used			

Response

Sätts till samma värde som request-biten när data är klart för överföring till MMI-terminalen.

СОМ

COM-biten sätts av PLC-programmet. Bryts kommunikationen nollställs biten.

Toggle

Toggle-biten sätts alltid till samma status som toggle-biten i arean för begäran.

Error

Denna bit används inte.

Acknowledge

Dessa bitar används inte.

MMI-profilen

7.3 Strukturen på index

Ett index byggs upp av tre bytes. Indexet innehåller fyra delar med information:

- Om datatypen ska läsas/skrivas.
- Vilken datatyp (ingång, dataregister, tidkrets etc.)
- Datatypens adress (t ex ingång 5).
- Datalängd (från en bit till 16 bytes).

7	6	5	4	3	2	1	0	
Skriv	Ln2	Ln1	Ln0	PLC datatyp				
	Index nummer bit 15-8							
	Index nummer bit 7-0							

PLC datatyp

Anger PLC datatyp enligt följande tabell:

Nummer	MELS	SEC A	SIMA	ric S5	SIMATIC S7		
	Datatyp MELSEC	Datatyp IEC	Datatyp Engelsk	Datatyp Tysk	Datatyp IEC	Datatyp SIMATIC	
1	М	%MX0.	F	М	М	М	
2	Х	%IX	I	E	I	E	
3	Y	%QX	Q	А	Q	A	
4	В	%MX1.					
8	D	%MW0.	DB	DB	DB	DB	
9	R	%MW2.					
10	Т	%MW3.					
11	С	%MW4.					
12	W	%MW1.					

Ln0-Ln2

Anger datalängden enligt följande tabell:

Ln2	Ln1	Ln0	Längd
0	0	0	bit
0	0	1	1 byte
0	1	0	2 bytes
0	1	1	4 bytes
1	0	0	6 bytes
1	0	1	8 bytes
1	1	0	12 bytes
1	1	1	16 bytes

Händelseförlopp

- MMI-terminalen bestämmer vilken variabel som ska läsas/skrivas.
- Terminalen växlar status på request flaggan i kontrollbyten.
- Nästa PROFIBUS cykel upptäcker PLC-systemet att requestflaggan har ändrats.
- För varje läsindex kopieras värdet i den begärda datatyper till arean för svar.
- Därefter sätts response-flaggan i arean för svar till samma värde som request-flaggan i arean för begäran.
- Nästa PROFIBUS cykel upptäcker MMI-terminalen att requestflaggan och response-flaggan har samma värde vilket betyder att det finns data till terminalen.
- De mottagna värdena kommer nu att användas av objekten i terminalen.

MMI-profilen

8 Appendix

8.1 Typdisketten

Följande filer finns på typdisketten:

IFCPBDTE.200	Kortspecifikationsfil för DOS-programvaran ET200 samt STEP 7 på engelska.
IFCPBDTD.200	Kortspecifikationsfil för DOS-programvaran ET200 samt STEP 7 på tyska.
IFC-PBDP.GSD	Kortspecifikationsfil för Windowsprogramvaran COM ET200.
MELSEC	Bibliotek som innehåller MELSEC MEDOC projekt.
S5	Bibliotek som innehåller SIMATIC S5 projekt.
S7	Bibliotek som innehåller SIMATIC S7 projekt.

8.2 MELSEC MEDOC projekt

Projektet kallas PROFILE. Vi antar följande:

- AJ71PB92 modulen är placerad på kortplats 0 i PLC-systemet.
- AJ71PB92 modulen kommunicerar med IFC PBDP med stationsnummer 3.

Följande datatyper kan accessas från terminalen:

Digital: X, Y, M, B Analog: D, R, W, T, C

Följande datatyper supportas inte: Special D, special M, digital T, digital C och digital F.

För att ändra detta behöver endast PLC-programmet justeras. Följande datatyper används av programmet.

D100-134, D140-171, D180-211 och M100-M115, M120-M121, M200.

Appendix

8.3 SIMATIC S5 projekt

För att ändra detta behöver endast PLC-programmet justeras. Följande datatyper används av programmet.

MB200-203, MB206-217, MB220-225, MB230-233, MB240-241 och T2.

8.4 SIMATIC S7 projekt

För att ändra detta behöver endast PLC-programmet justeras. Följande datatyper används av programmet.

MB100-101, MB110, MB200-217, MB220-225, MB230-233, MB240-247 och T2.

Index

A

AJ71PB92 modulen, 12 Anslutning av flatkabeln, 3 Anslutning av IFC PBDP kortet,3 Anslutning till MELSEC A, 9 Area för begäran, 32 Kontrollbyte, 34 Area för svar, 32 Kontrollbyte, 35

В

Bussterminering, 5

D

Datautbyte, 32

F

Fysisk port, 4

Ingående filer, 39 Installera kortet, 3

Κ

Kabe, 1 5 Kommunikationsfel, 5 Kommunikationsinställningar, 5 Konfigurera MMI-terminalen, 7 Konfigureringsfel, 5 Kortplats, 4, 7

Μ

MELSEC A Analoga signaler, 10 Datatyper, 9 Digitala signaler, 10 I/O-hantering, 9 MMI-profilen, 31

Ρ

Projekt, 39

S

SIMATIC S5, 15 Adressering, 16 Analoga signaler, 17 Datablock, 16 Datatyper, 16 Digitala signaler, 16 I/O-hantering, 16 OB1, 17 SIMATIC S7, 23 Adressering, 24 Analoga signaler, 25 Datablock, 24 Datatyper, 24 Digitala signaler, 24 I/O-hantering, 24 OB1, 25

Т

Typdiskett, 39

Index

9 Appendix for printouts

The PLC program section for Mitsubishi MELSEC A



Appendix for printouts







Appendix for printouts



Appendix for printouts













Appendix for printouts






A-13



The PLC program section for SIMATIC S5

FB 190		D:TESTARST.S5D	LEN=168
Segment 1	MA	IN PROFILE HANDLER	rage
This function	block is the main	handler of the MMI prof	ile container
The function found, FB191	block handles one of is called. If write	complete container in on e index found, FB192 is	e PLC scan. If read ind called
Name : PROFILE Decl :LEN Decl :READ Decl :WRI Decl :INT Decl :HERR Decl :TEMS	I/Q/D/B/T/C: D I/Q/D/B/T/C: D I/Q/D/B/T/C: D I/Q/D/B/T/C: I I/Q/D/B/T/C: Q I/Q/D/B/T/C: T	KM/KH/KY/KS/KF/KT/KC/KG KM/KH/KY/KS/KF/KT/KC/KG KM/KH/KY/KS/KF/KT/KC/KG BI/BY/W/D: BY BI/BY/W/D: BY	: KF : KF : KF
0017 :LW 0018 :T 0019 :T	V =READ FW 220 FW 230	Incontai	ner start address
001A :DC 001B :L 001C :T 001D :LW) FW 220 IB 0 FY 206 / =WRI	Read con Store it	trol byte from incont.
001E :T 001F :T 0020 :L	FW 222 FW 232 =INT	Outconta	iner start address
0021 :T 0022 :L 0024 :T 0025 :A	FY 240 KF +0 =HERR F 240 0	Clear er	ror code
0025 :R 0026 :R 0027 :A 0028 :JC	F 240.0 F 206.6 C =TPRE	Clear er Terminal	ror flag present ?
0029 :L 002B :JU 002C :	KF +1 J =ERR	Error 1	: Comm error
002D TPRE :A 002E :L 0030 :SD	F 206.5 KT 002.2) =TEMS	Does the Timeout	terminal toggle TGL?
0031 :AN 0032 :JC 0033 :L 0035 :JU 0036 :	I =TEMS 2 =YTGL KF +2 J =ERR	Error 2	: Terminal not in RUN
0037 YTGL :A 0038 :A 0039 :O	F 206.7 F 240.7	Test if Compare	new container available old with new
003A :AN 003B :AN 003C :JC	I F 206.7 I F 240.7 C =END	No new c	ontainer
003D : 003E :A 003F :=	F 206.7 F 240.7	Pulse	
0040 : 0041 :L 0042 :L	FW 222 KF +4	First ou	tcontainer pos : 4
0044 :+F 0045 :T 0046 :	FW 222		

FB 190			D:TESTARS	T.S5D LEN=168 Page
0047 0048	:L :L	FW 220 KF +4		First incontainer pos : 4
004A	:+F			
004B	: T	FW 220		
004C LOOP	:			
004D	:DO	FW 220		Road first index byte
004E	:ц .т	IB 0 FV 206		Store it
0050	: T.	FY 206		50010 10
0051	:L	KF +0		Was it 0 ?
0053	:!=F			
0054	:JC	=END		Then , no more indexes
0055	: AN	F 206.7		Was it a read index ?
0055 Name	· REAL	LR TAT		Then call lead thdex function
0058 READ	:	FW 220		
0059 WRI		FW 222		
005A NBR	:	FY 224		
005B	:L	FY 224		Check return value from FB191
0050	:L	KF +0		
005E	JC	=OKRT		Was there an error return ?
0060	:AN	F 240.0		
0061	:S	F 240.0		Then, set error bit
0062	:L	FY 224		
0063	:00	=ERR		
0065 OKRT	: AN	F 206.7		Was it a write index ?
0066	:JC	=CONT		
0067	: JU	FB 192		Then call write index function
0069 READ	: WK1.	FW 220		
006A NBR	• •	FY 224		
006B	:L	FY 224		Check return value from FB192
006C	:L	KF +0		
0065	:!=F	-CONT		Was there an error return ?
0070	:AN	F 240.0		
0071	:S	F 240.0		Then, set error bit
0072	:L	FY 224		
0073	:00	=ERR		
0075 CONT	·L	FW 220		Check if incontainer done
0076	:L	FW 230		
0077	:-F			
0078	:LW	=LEN		
0079	: <f< td=""><td></td><td></td><td></td></f<>			
007B	: L	FW 222	01	or that outcontainer is done
007C	:L	FW 232	01	
0.07D	:-F		01	
007E	:LW	=LEN	01 01	
0080	; <r< td=""><td></td><td>01</td><td></td></r<>		01	
0081	:JC	=LOOP	an shiri	
0082	:JU	=END		
0083	:			Emmon handling. Chang are and
0084 ERR	:Т •Т.	=HEKK KF +0		Fill container with zeros
0087	:DO	FW 222		

FB 190			D:TESTARST.S5D	LEN=168
0088	:Т	QB 0		rage
0089	: Ц	KF +1		
008B	:Ъ	FW 222		
008C	:+F			
008D	:Т	FW 222		
008E	:L	FW 232		
008F	:-F			
0090	:LW	=LEN ·		
0091	: <f< td=""><td></td><td></td><td></td></f<>			
0092	: JC	=FILL		
0093	:			
0094 END	:DO	FW 230		
0095	:L	IB 0	Get ctrl byte from inco	ntainer
0096	:T	FY 206		
0097	:AN	F 206.6		
0098	:S	F 206.6	Set the COM-bit	
0099	:A	F 240.0		
009A	:= , • •	F 206.4	Toggle the TGL-bit	
009B	:L	FY 206		
009C	:DO	FW 232	and the second	
009D	: T	QB 0	Write dtri byte to outo	ontainer
009E	:T	FY 206		
009F	:	TTT 0.40		
OOAO	:L	FY 240		
LAUU	T D	= T IN T		
UUAZ	:BE			

FB 19	91				D:TES	TARS	F.S5D	LEN=245 Page
Segme	ent 1	L		RE.	AD INDEX			1490
Calcu	ulate	point	ters and byte	siz				
Decl Decl Decl	:REAL :REAL :WRI :NBR		I/Q/D/B/T/C: I/Q/D/B/T/C: I/Q/D/B/T/C:	I Q Q	BI/BY/W/D: BI/BY/W/D: BI/BY/W/D:	W W BY		
000F		. T	KE 10					
0010		:T	=NBR				Clear return value	
0011		:L	=READ				Incontainon start addre	~~
0012		:1 :L	FW 200 KF +3				incontainer start addre	55
0015		:+F				1.1		
0016		: T : Ti	=READ =WRT				Point to next index	
0018		: T	FW 202				Outcontainer start addr	ess
0019		:DO	FW 200				Cot HICH buto of index	
001A		:ц :Т	FW 206				Store it	
001C		:L	FW 200					
001D		:11 :+F	KF +1				Point to next byte	
0020		: T	FW 200					
0021		:DO	FW 200				Get MIDDLELLOW (-device	addrogg
0022		:п	FW 208				Store it in 208-209	auuress
0024		:L	FW 200					
0025		:L	KF +2					
0028		:T	FW 200				Point to next index	
0029		:L	FY 207				Calculate how many byte	S
002A		:SKW	KH 0007					
002D		:AW						
002E		:Т •д(FY 212					
0030		:AN	F 212.2		01			
0031		: AN	F 212.1		01			
0032		:0			UΤ			
0034		:A(
0035		: AN • A	F 212.2 F 212.1		01			
0037		:AN	F 212.0		01			
0038		;)	FND		01			
0039 003A		:0C :A	= DND F 212.2					
003B		:JC	=TST6					
003C		:L	KF +4 =STOR				Length 1s 4 bytes	
003F	TST6	:A	F 212.1					
0040		:0	F 212.0					
0041		:JC :L	=1518 KF +6				Length is 6 bytes	
0044		:JU	=STOR					
0045	TST8	:A	F 212.1					
0040		.00	-1012					

LEN=245 FB 191 D:TESTARST.S5D Page :L KF +8 :JU =STOR Length is 8 bytes 0047 0049 004A TS12 :A F 212.0 :JC =TS16 004B :L KF +12 Length is 12 bytes 004C :JU =STOR 004E 004F : -0050 TS16 :L Length is 16 bytes KF +16 Store length 0052 STOR :T FY 212 0053 END : :*** 0054 Segment 2 _____ Handle reading of bit devices (F/Q/I) :L KF +0 0055 Reset device type flags :T FY 250 :O F 207 0057 :O F 207.0 :ON F 207.1 Test if input device 0058 0059 :0 F 207.2 :0 F 207.3 005A 005B :JC =TSTQ 005C F 250.0 Read inputs is selected :S 005D :JU =STRT 005E
 005F
 TSTQ
 :O0
 F
 207.0

 0060
 :ON
 F
 207.0

 0061
 :O
 F
 207.2

 0062
 :O
 F
 207.3
 Test if output device 0063 :JC =TSTM F 250.1 Read outputs is selected :S 0064 0065 :JU =STRT 0066 TSTM :ON F 207.0 0067 :O F 207.1 Test if memory device :0 :0 F 207.2 :0 F 207.3 0068 0069 :0 006A :JC =M001 No bits selected, jump out Read memory is selected Outcontainer pointer F 250.2 FW 202 006B :S 006C STRT :L 006D :T FW 216 F 207.6 006E :0 F 207.5 006F :0 F 207.4 0070 :0 0071 :JC =BYTE Jump if more than one bit 0072 : The following handles 1-bit rea 0073 : 0074 : 0075 :L FY 211 :SLW 0076 8 :L FY 209 0077 0078 :OW :T FW 214 :AN F 250.0 0079 Input bit ? 007A 007B :JC =M030 :DO FW 214 007C :A I (:JC =M003 Get input bit 007D 0.0 007E 007F :JU =M040

FB 191			D:TESTARS	T.S5D	LEN=245 Page
0080	:			-	<u> </u>
0081 M030	:AN	F 250.1		Output bit ?	
0083	:DO	FW 214			
0084	:A	Q 0.0		Get output bit	
0085	:JC	=M003			
0086 0087 M031	:00	=M040 FW 214			
0088	:A	F 0.0		Get flag bit	
0089	:JC	=M003			
008A 008B M040	:JU •T	=M040		Bit value OFF	
008D	:JU	=M004			
008E M003	:L	KF +1		Bit value ON	
0090 M004	• DO	FW 202			
0092	:T	QB 0		Write bit value to o	utcontainer
0093	:JU	=M005			
0094	:			The following handle	s byte read
0096	:				
0097 BYTE	:L	FW 208		Device address from	index
0098	:SRW	3 FW 208		Divide by 8	.n.
009A LOOP	: AN	F 250.0		Is it input byte ?	
009B	:JC	=M050			
0090	: DO	FW 208 TB 0		Get input byte	
009E	:JU	=M060			
009F M050	:AN	F 250.1		Is it output byte ?	
00A0	: JC	=M051 FW 208			
00A2	:L	QB 0		Get output byte	
00A3	:JU	=M060			
00A4 M051	: DO	FW 208 FY 0		Get memory byte	
00A6 M060	:DO	FW 202			
00A7	:T	QB 0		Store in outcontaine	r i stari
00A8	: Ц • Т.	KE +1 FM 508		Increment data sourc	e pointer
00AB	:+F	, and the second se		auto auto bouro	
OOAC	:T	FW 208			
OUAD	:Ц •Т	FW 202 KF +1		Increment data dest	pointer
00B0	:+F				Pozitor
00B1	:Т	FW 202			
00B2	:L	FW 216			•
00B4	:L	FY 212		All bytes read ?	
0085	: <f< td=""><td></td><td></td><td>Ga farr marsh hash-</td><td></td></f<>			Ga farr marsh hash-	
00B6 00B7 M005	:JC	=LOOP FW 202		GO for next byte	
00B8	.п	=WRI			
00B9 M001	•				
00BA	:***				
Segment 3		READ D	ATABASE		

FB 191					D:TESTARS	T.S5D	LEN=245 Page
Handle rea	ading	of	data blocks	(DB)			
00BB 00BC	:0 :0	F F	207.0 207.1			Test if D	
00BD	:0	F	207.2				
OOBE	:ON	- F' Mi	207.3				
0000	:		001				
00C1	:L	FW	202			Outcontainer pointer	
00C2	:T	FW	216				
00C4							
00C5	:L	FY	208			Datablock number to use	
00C6	: T	FW	210				
0007	:DO	FW	210			Open datablock	
00C9	:L	FY	209			Dataword in block	
00CA	: T	FW	210				
00CB	:A	F	213.0			Flag to select high/low	byte
00CC MOOF	R	F	213.0				
00CE MOUS	:JC	=M	002				
OOCF	:DO	FW	210				_
00D0	:L	DL	0			Get low byte fron datab	lock
00D2 M002	:00	=M FW	210				
00D2 11002	:L	DR	0			Get high byte from data	block
00D4 M003	:AN	F	213.0			i de la companya de la companya 🖌 🖌	
00D5	:=	F	213.0				
0006	: • DO	FW	202				
00D8	:T	QB	0			Put data in outcontaine	r
00D9							
00DA 00DB	:A	F	213.0				
00DC	:UC :L	FW	210			Increase data source pt	r
00DD	:L	KF	+1			요. 전화 가지 않는 것 같아요. 이 가지 않는 것이 같아.	
OODF	:+F						
00E0 00E1	:1	F.M	210				
00E2 M004	:L	FW	202				
00E3	:L	KF	+1			Increase data dest ptr	
00E5	·:+F						
00E6	:1 • T.	F.M.	202				
00E8	:-F	7. 14	210				
00E9	:L	FY	212				
00EA	: <f< td=""><td>3.4</td><td>0.05</td><td></td><td></td><td>Do all byteg</td><td></td></f<>	3.4	0.05			Do all byteg	
OOEC	:0C :Te	=M FW	202			DO AIT DYCES	
OOED	:T	=W]	RI				
00EE M001	:						
OOEF	:BE						

LEN=216 D:TESTARST.S5D FB 192 Page WRITE INDEX Segment 1 _____ Calculate pointers and data size Name :WRITE ID I/Q/D/B/T/C: I BI/BY/W/D: W I/Q/D/B/T/C: Q BI/BY/W/D: BY Decl :READ Decl :NBR 000B :L KF +0 Clear return value 000D Τ: =NBR 000E =READ :L Incontainer start address 000F : TFW 200 0010 : L KF +3 :+F 0012 Ptr to next index =READ 0013 :T 0014 :DO FW 200 Get HIGH byte of index 0015 IB 0 : L FW 206 :T 0016 0017 $: \mathbf{L}$ FW 200 0018 :L KF +1 Point to next index byte 001A :+F FW 200 001B :Т 001C :DO FW 200 Device address 001D IW O :L FW 208 001E : T 001F : :Ц FW 200 Point to the data to write 0020 KF +2 0021 :L 0023 :+F 0024 : T FW 200 0025 : ' FY 207 0026 : L 0027 :SRW 4 KH 0007 0028 :L :AW 002A FY 212 This is the size from index 002B :Т 002C :A(F 212.2 F 212.1 01 002D : AN 01 002E :AN 01 002F :) 0030 :0 0031 :A(01 :AN F 212.2 0032 0033 :A F 212.1 01 0034 :AN F 212.0 01 01 0035 :) 0036 :JC =END 0037 F 212.2 :A :JC =TST6 0038 KF +4 4 bytes 0039 :L :JU =STOR 003B 003C TST6 :A F 212.1 003D :O F 212.0 :0 :JC =TST8 003E 003F :L KF +6 6 bytes :JU =STOR 0041 0042 TST8 :A F 212.1 =TS120043 JC: 0044 :L KF +8 8 bytes

D:TESTARST.S5D LEN=216 FB 192 Page 0046 :JU =STOR 0047 TS12 :A F 212.0 0048 :JC =TS16 12 bytes KF +12 0049 :L :JU =STOR 004B 004C TS16 :L KF +16 16 bytes 004E STOR :T FY 212 Store size 004F END : :*** 0050 Segment 2 Handle writing of bit devices (Q/I/F) _____ 0051 :L KF +0 :T Reset devicetype flags FY 250 0053 :ON F 207.0 Test for output 0054 0055 :ON F 207.1 F 207.2 F 207.3 :0 0056 0057 :0 :JC =TSTM 0058 0059 :S F 250.0 Output selected :JU =STRT 005A 005B TSTM :ON F 207.0 005C :O F 207.1 Test for memory F 207.2 005D :0 :0 F 207.3 005E :JC =END 005F F 250.1 Memory selected 0060 :S 0061 STRT :L FW 200 FW 216 0062 :Т 0063 :0 F 207.6 F 207.5 F 207.4 0064 :0 0065 :0 :JC =BYTE Jump if more than one bit 0066 0067 :DO FW 200 0068 :L Get new data (ON/OFF) form inco TB 0 FY 213 :T 0069 Get device address 006A :L FW 208 006B :SRW 3 Divide by 8 :T This is the byte nbr 006C FY 211 006D :L FW 208 006E KH 0007 :L 0070 :AW This is the bit nbr : T FY 210 0071 0072 :AN F 250.0 0073 :JC =ISM 0074 F 213.0 :A 0075 :DO FW 210 Write data to output 0076 := Q 0.0 0077 :JU =DONE F 213.0 0078 ISM :A FW 210 0079 :DO 007A F 0.0 Write data to memory := :JU =DONE 007B 007C : 007D The following handles byte writ : 007E :

FB 192 D:TESTARST.S5D LEN=216 Page Get device address 007F BYTE :L FW 208 0080 :SRW 3 Divide by 8 :T FW 208 0081 0082 LOOP :DO FW 200 Read input data 0083 ;L IB 0 0 :AN F 250.0 0084 :JC =SETM 0085 0086 :DO FW 208 0087 :Т QB 0 Store data in outputs :JU =NEXT 8800 0089 SETM :DO FW 208 Store data in memory A800 :T FY 0 008B NEXT :L FW 208 :L KF +1 008C :+F 008E 008F : T FW 208 Increase data dest ptr 0090 FW 200 :L 0091 :L KF +1 0093 :+F :T FW 200 Increase data src ptr 0094 FW 216 0095 :L \$ 0096 :-F All bytes done ? 0097 :L FY 212 0098 :<F :JC =LOOP Continue until completed 0099 009A DONE :L FW 200 :T =READ 009B 009C END : :*** 009D sis. WRITE DB Segment 3 Handle writing of DB-data _____ _____ 009E :O F 207.0 Test if D :0 F 207.1 :0 F 207.1 :0 F 207.2 :0N F 207.3 009F 00A0 00A1 :JC =END :L FY 208 00A2 00A3 :L :T FW 210 :DO FW 210 Datablock number to use 00A4 00A5 :C DB 0 Open the data base 00A6 FY 209 FW 210 Dataword in datablock 00A7 :L 00A8 : T 00A9 : Ъ FW 200 Input data ptr 00AA :T FW 216 :A F 213.0 Flag to select high/low byte 00AB :R F 213.0 00AC 00AD . 00AE LOOP :DO FW 200 Get input data IB 0 F 213.0 00AF :L 00B0 :A :JC =M002 00B1 :DO FW 210 00B2 Store low byte 00B3 : T DL0 00B4 : 00B5 :JU =M003

FB 192			D:TESTARST.S5D LEN=216 Page
00B6 M002	:DO	FW 210	
00B7	:T	DR 0	Store high byte
00B8	:		
00B9 M003	:AN	F 213.0	
00BA	:=	F 213.0	
00BB	:		
00BC	:A	F 213.0	
00BD	:JC	=M004	The second s
OOBE	:L	FW 210	Increase data dest ptr
00BF	: "	KF +1	
0001	:+b,	TH 010	
0002	: T	FW 210	
0003	:	EW 200	Increase data arc ntr
0004 M004	:ш •Т.	FW 200 KF +1	increase data sic pti
0000		KI +I	
0008	Т	FW 200	
0009	: L	FW 216	
00CA	-F		
00CB	:L	FY 212	Check that all bytes done
00CC	: <f< td=""><td></td><td></td></f<>		
00CD	:JC	=LOOP	
00CE	:L	FW 200	
00CF	:T	=READ	
00D0	:L	FY 212	
00D1 END	:		
00D2	:BE		

The PLC program section for SIMATIC S7

c ...ion 1\CPU315-2DP1\S7 Program(3)\AP-off\FB110 01/22/1997 14:22:25
<off-line> SIMATIC

Philo - (oll line)	
Name:	Family:
Author:	Version: 00.00
Time stamp Code:	DT#1996-12-10-16:14:57.000
Interface:	DT#1996-12-09-09:53:29.000
Length (Block / MC7 Code	/ Data): 00560 00424 00008

Address	Decl.	Symbol	Data Type	Initial Value	Comment
0.0	in	fb in offset	DWORD	DW#16#0	
4.0	in	fb out offset	DWORD	DW#16#0	
8.0	in	con len	WORD	W#16#0	1.
10.0	in	db address	WORD	W#16#0	
	out		1. S.		1.
	in out			1	
12.0	stat	out last cycle	BYTE	B#16#0	
13.0	stat	out this cycle	BYTE	B#16#0	
14.0	stat	m 110	BYTE	B#16#0	-
	temp		1		

This is the main handler of the MMI profile container

Parameters : fb_in offset First byte in the input container fb_out_offset First byte in the output container db_address Number of the database to use con_len Length of container in bytes (min.32)

Example : The terminal is configured to be on input and output byte 64, 32 bytes allocated and database to communcate with is 51: fb_in_offset = 64 fb_out_offset = 64 db_address = 51 con_len = 32

The function block handles one complete container in one scan. If read index, FC111 is called. If write index, FC112 is called. Note that the control byte is not set until next scan, to avoid timing problems

ę

Netwo	rk: 1		COM_E700		
	L	#fb	in offset	. 11	Incontainer start address
	т	MW	220		Remember incontainer start
	φ. ·	MW	230		
11	÷ ·		200		
11.	2	1.01			To control on a brint address
	1	#ID_	in_offset		Incontainer Start address
	SLD	3		11	
	LAR1				
	L	EB []	AR1, P#0.0]	11	Get the proper control byte from inp.container
	T	MB	206	- 11	Store it
11	- · ·				
//		465	out offeet		Outcontainor start address
	1	#10_	out_orrset		Steve it
	T .	PIW	222	//	Store it
	т	MW	232		
11					
	L	#m 1	10	11	Previous input control byte
	T	MB	240	11.	Store it
11					
//	T	0			
	ш.	ND ND	444		Olean annan acda
	т	MB	111		Clear error code
//					
	υ	м	240.0		
	R	М	240.0	11	Clear error flag
11					
	Π	м	206.6	11	Terminal present ?
	CDD	WET1		11	
	T	1		11	Error 1 : Comm error
	0.0.7	1			BIIOF I . COMM CIIOF
	SPA	PEH			
//					
WEI1:	U	M	206.5		Does the terminal toggle the toggle bit ?
	UN	М	206.5		
	L	S5T#	2S	11	Timeout timer
	SE	T	99		
	TIM .	÷	99		
	ann		55		
	SPB	WEIZ			
	L	2			Error 2 : Terminal not in RUN
	SPA	FEH			
11					
WEI2:	U	М	206.7	11	Test if new container
	Π.	M	240.7	11	Compare old container byte with the new one
	0				
	TIM .	м	206 7		
	0M	14	200.7		

<pre>// U M 206.7 // Plate // U M 206.7 // Plate // U M 206.7 // Plate // U M 222 // Outcontainer pointer I M 222 // Distribution 14 // L MM 220 // First data position 14 // L MM 220 // Incontainer pointer I M 220 // First data position 14 // L MM 220 // Incontainer pointer I M 226 // Store it M M 226 // Incontainer pointer I M 226 // Incontainer indone I M 226 // Incontainer in</pre>		UN	M 2	40.7	11	No new container
<pre>// - M 240.7. // L MW 222 // Outcontainer pointer + I / T NM 222 // First data position : 4 // L MW 220 // Incontainer pointer + I / T NM 220 // First index position : 4 // T NM 220 // Incontainer pointer ITTO SD M 220 // Incontainer is done ITTO SD M 220 // Incontainer done I SD M 220 // In</pre>	11 -	υ	M 2	06.7	11	Pulse
L MW 222 // Outcontainer pointer 1 4 7 MW 222 // First data position : 4 // L MW 220 // First index position : 4 // JOP: MW 220 // First index position : 4 // JOP: MW 220 // Incontainer pointer 1 T MW 220 // Jump out if index is 0 // J MW 206.7 // Is it a read index 7 SFP MKI3 // Jump to error SFN MKI4 // Jump to error SFN MK14 // Jump to error SFN MK14 // Jump to error SFN MK 240.0 // Then set error bit 1 MW 220 // Check if incontainer is done 1 MW 220 // Check if incontainer is done 1 SFN SINGULING // Container done I 1 MW 222 // Container done I 1 MW 222 // Container done I 1 MW 222 // Store it 2 MB 100 // Store it 2 MB 11 // Store error code FFN: t MM 112 // Store error code FFN: t MM 1222 // Store error code FFN: t MM 222 // Store error code FFN: t MM 222 // Store error code	11	200	м 2	40.7		
<pre>// I MW 222 // First data position : 4 // L MW 220 // First data position : 4 // L MW 220 // Incontainer pointer L 4 // T MW 220 // First index position : 4 // LOPE. NOP 0 L MW 220 // Incontainer pointer TTD SLD 3 // MW 220 // Incontainer pointer TTD SLD 3 // SLD 3 // Store it // U M 220 // Store it // U M 206.7 // Jump out if index is 0 // U M 206.7 // T MM 220 // T MM 220 // T MM 224 // Check return value from FCll1 L M 224 // Then call read index ? SED MULL NULL M 224 // Check return value from FCll1 L M 224 // Then call write index ? SED MULL NULL M 224 // Check return value from FCll1 L M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Then call write index ? SED MULL NULL M 224 // Check return value from FCll2 L M 224 // Check return value from FCll2 L M 224 // Check return value from FCll2 L M 224 // Check if incontainer is done I M 240.0 // Then set error bit L M 224 // Check if incontainer is done I M 240.0 // Then set error bit L M 222 // or that outcontainer is done I M 240.0 // Then set error bit L M 222 // or that outcontainer is done I M 240 // Containes id constiner not completed // Containes id constiner not completed // Containes id constiner not completed // T M 222 // // Store error code // T M 224 // // Store error code // T M 224 // // Store error code // T M 224 // //</pre>		L	MW 2 4	22	11	Outcontainer pointer
<pre>// I WM 220 // Incontainer pointer I 4 // T MW 220 // Incontainer pointer IT T MW 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 T MM 220 // Incontainer pointer ITD SLD 3 SLD 3 T MM 220 // Container done is done I I MM 220 // Incontainer is done I I MM 220 // Incontainer is done I I MM 220 // Incontainer is done I I MM 220 // Container done is SLD 3 SLD 3 SLD 3 SLD 3 SLD 3 T MM 220 // Store it SLD 3 T MM 220 /</pre>		+1 T	MW 2	22	//	First data position : 4
<pre>+1 T MW 220 // First index position : 4 //OP: NOP 0 DD I TO WW 220 // Incontainer pointer TD WW 220 // Incontainer pointer TD WW 220 // Incontainer pointer T WD 242 // Kake it double word 1 E EN [D0 242] // Get first index pyte =10 =575 DONE // Jump out if index is 0 // U W 206.7 // Is it a read index 7 TD W W 226.7 // Is it a read index function DotaBases:HD address ANKI NOP 0 L W WD 224 // Check return value from FCI11 L WW 224 // Check return value from FCI11 L WW 224 W Was there an error return ? WW W 240.0 // Then, set error bit SFF FW 06.7 // Is it a write index ? BON WM 240.0 // Then, set error bit L WW 224 L WW 222 L WW 220 T SFF WIG SFF FWIG SFF FWIG SFF WIG SFF WIG</pre>		L	MW 2 4	20	, <u> </u> ,''	Incontainer pointer
<pre>// With the set of the set o</pre>		+I T	MW 2	20	//	First index position : 4
TTD SLD 3 T MD 2421 // Make it double word L EB [MD 242] // Get first index byte // Get first index byte // Get first index byte // U M 206.7 // Is it a read index ? SFB ANKI CDL FC 111 // Then call read index function T M 206.7 // Is it a read index ? SFB ANKI CDL FC 111 // Then call read index function for the best 224 // Check return value from FCll1 L 0 =	LOOP:	NOP	0 MW 2	20	11	Incontainer pointer
<pre>T MD 242 // Make it could word L EE [MD 242] // Ket fits index byte L HM 206 // Store it F MD 206 // Store it F MD 206 // Jump out if index is 0 // U M 206.7 // Is it a read index ? SFB ANKI CALL FC 111 // Then call read index function CALL FC 111 // Then call read index function CALL FC 111 // Then call read index function S M 240.0 // Then, set error bit L M 240.0 // Then, set error bit SFB WEI3 // Jump to error WEI3: UM M 206.7 // Is it a write index ? SFB WEI4 L 0</pre>		ITD SLD	3			
<pre>L ME 2006 L 0 L 0 SFB DONE // Jump out if index is 0 // U M 206.7 // Is it a read index 7 SFB ANKL CALL FC 111 // Then call read index function DataBase:=#ab_address ANKL: NOP 0 ANKL: NOP 0</pre>		T L T	MD 2 EB [MD MB 2	42 0 242] 06		Make it double word Get first index byte Store it
<pre>T SPB DONE // Jump out if index is 0 // U M 206.7 // Is it a read index ? SPB ANKL CALL FC 111 // Then call read index function ; DataBase:=db_address ANKL MOP 0W 224 // Check return value from FC111 </pre>		L ·	MB 2 0	06		
<pre>// U M 206.7 // Is it a read index ? SFB ANK1 CALL FC 111 // Then call read index function DataBase:=40_address ANK1: NOP 0 ANK1: NOP</pre>		see I SPB	DONE		11	Jump out if index is 0
CALL FC 111 // Then call read index function f DataBase:=#db_address ANK1: NOP 0 I NOP 0 	11	U SPB	M 2 ANK1	06.7	11	Is it a read index ?
ANKI: NOP 0 L WB 224 // Check return value from FC111 L 0 		CALL Data	FC 1 Base:=#	11 db_address	11	Then call read index function
<pre></pre>	ANK1:	NOP L L	0 MB 2 0	24	11	Check return value from FC111
<pre>ON # 240.0 // Then, set error bit L ME 224 // Jump to error WEI3: UN M 206.7 // Is it a write index ? SPB WEI4 // Then call write index function DataBase:=#d_address // Check return value from FC112 L 0 // Then call write index function UN M 224.0 // Check return value from FC112 L ME 224 // Check return ? UN M 240.0 // Then set error bit L ME 224 // Jump to error WEI4: L MW 220 // Check if incontainer is done L MW 220 // Check if incontainer is done L MW 220 // Check if incontainer is done L MW 222 // or that outcontainer is done L MW 222 // Continue id conatiner not completed DONE: L #fcoin_offset // Continue id conatiner not completed LARI L EE [AR1,P#0.0] // Get input control byte // T ME 206 // Store it SPA ENDE // SPA ENDE // SPA ENDE // SPA ENDE // Store error code FEH: L MW 222 //</pre>		==I SPB	WEI3	140.0	,11	Was there an error return ?
<pre>EPA TEL // Jump to error WEI3: UN M 206.7 // Is it a write index ? SPB WEI4 // Is it a write index function DataBase:=40_address // Check return value from FC112 L ME 224 // Check return value from FC112 L 0 ==I SPB WEI4 // Was there an error return ? UN M 240.0 // Then set error bit L ME 224 /// SPA FEH // Jump to error WEI4: L' MW 220 // Check if incontainer is done L MM 230</pre>		UN S	M 2 MB 2 MB 2	240.0	//	Then, set error bit
SPB WE14 CALL FC 112 // Then call write index function DataBase:=#dD_address L MM 224 // Check return value from FC112 L 0 =	WEI3:	SPA UN	FEH M 2	206.7	// //	Jump to error Is it a write index ?
L MM 224 L MM 240.0 WEI4: L' MM 240.0 SPB WEI4 // Was there an error return ? UN M 240.0 S M 240.0 // Then set error bit SPA FEH // Jump to error WEI4: L' MM 220 // Check if incontainer is done L MM 220 // Check if incontainer is done L MM 220 // Check if incontainer is done L MM 222 // or that outcontainer is done L MW 232 // or that outcontainer is done L MW 232 // or that outcontainer is done L WW 232 // or that outcontainer is done L WW 232 // or that outcontainer is done L WW 232 // or that outcontainer not completed DONE: L #Con_len CI SPB LOOP // Continue id conatiner not completed DONE: L #ED [AR1, F#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE // T MB 206 // Store it SPA ENDE // Store stror code FEH: T MM 111 // Store error code FEH: T MM 242 //		SPB CALL Data	WEI4 FC 1	.12 db. address	//	Then call write index function
<pre></pre>		L L	MB 2 0	224	11	Check return value from FC112
S M 240.0 // Then set error bit L MM 224 // SPA FEH // Jump to error WETA: L MW 220 // Check if incontainer is done L MW 230		==I SPB	WEI4	40.0	//	Was there an error return ?
<pre>SPA FEH // Jump to error WEI4: L. MW 220 // Check if incontainer is done L MW 230 -I L #con_len <i U(L MW 222 // or that outcontainer is done L MM 232 -I L #con_len <i SPB LOOP // Continue id conatiner not completed DONE: L #fD_in_offset // Container done ! SLD 3 LARL L EB [AR1,P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE SPA ENDE FEH: I MM 222 FEH: I MM 222 ITD SLD 3 T MD 242 //</i </i </pre>		S L	M 2 MB 2	40.0	11	Then set error bit
L MW 230 -I L #con_len (I U(L MW 222 // or that outcontainer is done L MW 232 -I L #con_len (I) DONE: L #fb_in_offset // Continue id conatiner not completed DONE: L #fb_in_offset // Container done ! SLD 3 LARU L EE [ARI,P#0.0] // Get input control byte // T MB 206 // Store it SED 21 SLD 3 T MD 242 // 	WEI4:	SPA L	FEH MW 2	20		Jump to error Check if incontainer is done
<pre>cr Non-char U(U(L WW 222 // or that outcontainer is done L WW 232 -I L #con_len cl SPB LOOP // Continue id conatiner not completed DONE: L #fb_in_offset // Container done ! LD 3 LARI L EE [AR1,P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE // STORE ERROR HANDLING FEH: T MB 111 // Store error code FEH: L MW 222 ITD SLD 3 T MD 242 //</pre>		ь -т ь	#con 1	en		
L MW 222 // or that outcontainer is done I. MW 232 -I E. #con_len (I) SFB LOOP // Continue id conatiner not completed DONE: L #fD_in_offset // Container done ! SLD 3 LARL L EB [AR1,P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE FEN: T MB 111 // Store error code FEN: T MB 111 // Store error code FEN: T MD 242 //		<i U (</i 				
L #con_len (I SPB LOOP // Continue id conatiner not completed DONE: L #fD_in_offset // Container done ! SLD 3 LARI L EB [ARI, P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE // ERROR HANDLING FEH: T MB 111 // Store error code FEH: L MW 222 SLD 3 T MD 242 //		L	MW 2 MW 2	222 232	//	or that outcontainer is done
) SPB LOOP // Continue id conatiner not completed DONE: L #fb_in_offset // Container done ! LARL L EB [AR1,P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE // ERNOR HANDLING FEH: T MB 111 // Store error code FEH: L MW 222 SLD 3 T MD 242 //		L <i< td=""><td>#con_1</td><td>.en</td><td></td><td></td></i<>	#con_1	.en		
SLD 3 LAR1 EB [AR1, P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE ENDE ENDE // ERROR HANDLING FEH: T ME 111 // Store error code FEH: L MW 222 ITD SLD 3 T MD 242	DONE:) SPB L	LOOP #fb_ir	offset	11	Continue id conatiner not completed Container done !
L EB [AR1, P#0.0] // Get input control byte // T MB 206 // Store it SPA ENDE // ERROR HANDLING FEH: T MB 111 // Store error code FEH: L MW 222 SLD 3 T MD 242 //		SLD LAR1	3			
SPA ENDE // ERROR HANDLING FEH: T MB 111 // Store error code FEH: L MW 222 ITD SLD 3 T MD 242 //	//	L	EB [AF	x1,P#0.0]	11 11	Get input control byte
FEH: T MB 111 // Store error code FEH: L MW 222 ITD SLD 3 T MD 242 //	//	SPA	ENDE ERROR F	HANDLING		
SLD 3 T MD 242 //	FEH: FEH1:	T L ITD	MB 1 MW 2	111 222	//	Store error code
		SLD	3 MD 2	242		
	//					

	L ·	0		/ /	Write controlbyte to output container
,	Т	AB [MD 242]			
/	г. Г	1			
	L	MW 222			
<i>'</i>					
	+1 T	MW 222			
ſ.					
	-L T	MW 232		11	/ INTERNES MERKERBYTE SICHERN
/	÷.,				
	L	32			
,	<1				
	SPB	FEH1			
IDE:	NOP	0			
	UN	M 206.6			
	S	M 206.6			'Set the COM-bit
	UN —	M 206.5			Toggle the Toggel-bit
	υ	M 240.0			
,	=	M 206.4			
·	L	MB 206	-	11	/ Delay answer one scan to avoid timing problems
	т	#out_this_c	ycle		
	L	#fb_out_off	set		
	LAR1	3			
	L	#out_last_c	ycle		
	T	AB [AR1, P#0	.0]		
	T	#out_last c	ycle		
	L	MB 240	- -		
	T	#m_110			
	NOF	0			
	1.1				
		·			
					and the product of the second seco

Page 3

 SIMATIC
 ...ion 1\CPU315-2DP1\S7 Program(3)\AP-off\FC111 02/12/1997 12:57:52

 FC111 - <0ff-line>

Name: LESE IND	Family:
Author: Sia	Version: 00.01
Time stamp Code:	DT#1997-02-06-10:12:53.000
Interface:	DT#1996-12-05-10:00:32.000
Length (Block / MC7 Code	/ Data): 00888 00724 00002

Address	Decl.	Symbol	Data Type	Initial Value	Comment
0.0	in	DataBase	WORD	W#16#0	
	out	14.14			
	in out	· · · ·			
0.0	temp	IsX	BOOL		
0.1	temp	IsY	BOOL		100 C
0.2	temp	IsM	BOOL		

This function handles one read index

CwO	rk: 1	Inde	k handli	ng		the second s	
is	netwo	rk picks ou	ut index	and con	verts :	size to read	
	т.	0					
	T.	MB 224			11	Clear return value	
	T.	MW 220			11	Incontainer start address	
	T	MW 200			11		
	L	3					
	+I						
	т	MW 220			- 11	Point to next index	
	L	MW 222			11	Outcontainer start address	
	т	MW 202					
	L ·	MW 200			//	Get HIGH byte of index	
	TTD	2					
	SLD	MD 242					
	T	EB (MD 242	21		11	Byte ready.	
	τ. Γ.	MW 206	~ 1		11	Store HIGH in MW206	
	÷.	1111 200			.,		1
	ь.	MW 200					
	L	1					
	+I						
	т	MW 200					
	L	MW 200			- 11	Get MIDDLE byte of index	
	ITD						
	SLD	3					
	т	MD 242					
	L	EB [MD 24	2]		· //	Byte ready	
	т	MW 208				 A second s	
	L	MW 200					
	Г.	T ·					
	+1	100					
	T.	MW 200			11	Cet LOW byte of index	
	TTD	1110 2.00				det how byte of index	
	SLD	3					
	т	MD 242					
	Ē.	EB [MD 24	21		11	Bvte readv	
	т	MW 210					
	L	MB 207			- 11.	Calculate nbr of bytes to read	
	SRW	4					
	L	W#16#7					
	WU						
	т	MB 212			- //	This is the size from index	
	U (· ·				
	ON .	M 212.	1				
	UN N	M 212.	± .				
	/	M 212	2				
	SPB	TR ZIZ.	-				
	Dr.D.						
	σ	M 212.	2				
	SPB	WEI1	-				
	L	4			11	Convert length to 4 bytes	
	SPA	TR					
I1:	υ(1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 -					
	0	M 212.	0				
	1.1						

SIMA	TIC			ion	1\CPU3	15-2DP1\S7	Program(3)	\AP-off\FC111	02/12/1997	12:57:52
	0	М	212.1					e		
)									
	SPB	WEI2								
	L.	6.				// Convert 1	ength to 6 by	tes		
	SPA	TR -								
WEI2:	U	м	212.1							
	SPB	WEI3								
	L	8				// Convert 1	ength to 8 by	/tes		
	SPA	TR								
WEI3:	υ	м	212.0							
	SPB	WEI4								
	L	12				// Convert 1	ength to 12 h	oytes		
	SPA	TR								
WEI4:	L	16		•		// Convert 1	ength to 16 h	oytes		
TR:	т	MB	212			// Save leng	th in MB212			
	NOP	0				-				

atwo	ork: 2		READ 1	MEMO	RY			
nis	networ	k han	dles	the	reading	of	device	memory (MB/MW/MD/QB/QW/QD/IB/IW/ID)
			-					
	R	#IsX						
	R	#IsY						
	R	#IsM	007.0					Read moments bit?
	ON ON	M	207.1					Read memory bree
	ŏ	M	207.2					
	0	м	207.3	3				
	SPB	TstY						
	SPA	GOON						
tY:	NOP	0						
	UN	м	207.1				- 11	Read outputs ?
	ON	M	207.0					
	0	M.	207.3					
	SPB	TstX	207.0					
	S	#IsY						
	SPA	GOON						
tX:	NOP	0	207 1					Read inputs 2
	ON .	M	207.0				11	Keau Inputs r
	0	M	207.2					
	ō	м	207.3					
	SPB	END2						
	S	#IsX						
UN:	NOP	0						
	L .	MW	202				11	Outcontainer pointer
	т	MW	216					
	-		200					Today middle in upper position
	STW	MB .8	209				11	index middle in upper posicion
	L	мв	211					
	OW							
	т	MW	210					
			007 4					
	0	m M	207.5					
	õ	M	207.6	5 .				
	SPB	M202					1 /	IF MORE THEN ONE BIT
		HANI	DLING	OFF	SIT REAL	DING	(NOT	USED IN E700 V1.1x)
	L	MW	210				. //	BIT NUMBER
	L	W#164	#/					
	TTD							
	L	MW	210				11	BYTE NUMBER
	SRW	3						
	TTD	2						
	OD OD	з					11	BIT AND BYTE
	T	MD	242				11	POINTER TO MEMORY BIT
	L .	MW	202				//	
	TTD							

Page 2

	GT 77	2					
	SLW T	MD 2	246				
	UN	#IsM					
	SPB	L1					
	U U	M [MD	242]				
	SPB	ACT2	-				
	L QDA	0 acm2					
:	NOP	0					
	UN	#ISX					
	L	1					for the second
	U	E [MD	242]				
	L	ACT2 0					
	SPA	ACT2					
• • •	NOP	0					
	U U	A [MD	242]				
	SPB	ACT2					
	SPA	ACT2					
F2:	т	AB [MI	246]				
	SPA	M204					
	F	ANDLING	G OF BY	TE READIN	G (USED	BY	E700 V1.1x)
	NOR	0					
52:	L	MW 2	210			// 1	Memory address from index
	SRW	3				77-1	Divide by 8
ne.	T ·	MW 2	214				
10:	L	MW 2	214				
	ITD					11	Make it double word
	SLW T	з. мр. 2	242			11	This is the pointer to the data source
	^						
	L	MW 2	202			11	Output container pointer
	SLW	3				11	Put byte in upper position
	т	MD 2	246			M	This is the pointer to the data destination
	IIN	#TsM					
	SPB	L10					
	L	MB [MI	242]			// 0	Get byte from data source
0:	NOP	0 0					
	UN	#IsX					
	SPB T.	EB IMI	2421				
	SPA	LDON					
1:	NOP	0	2421				
DN:	NOP	0 (ML	242]				
	т	AB [MI	246]		,	// :	Store it in the output container
	т.	MW 2	21.4			11 :	Increment data source pointer
	Ľ	1					이렇게 잘 하는 것 같은 것 같은 것 같은 것 같은 것 같이 많이?
	+I	MIG	51.4				
	· .	PIW 2					
	L .	MW 2	202			// :	Increment data destination pointer
	ь +т	. 1					
	т	MW 2	202				
	-	1.67.7	216				Check if all butes read according to data length in index
	-I	P1W 2				,, (check if all bytes fear accoluting to vata tength in index
	L	MB 2	212				
	<i SPB</i 	M206				11 1	Go for next byte
04:	NOP	0			· · · · · · · · · · · · · · · · · · ·		
	L	MW 2	202				
D2:	TNOP	MW 2	422				
		-					

Page 3

Notw		PEAD DATABASE WORDS	
Necwo	JIK. 5	NERD DATABABLE WORDS	
This	netwo	rk handles the reading of	database words (DBB/DBW/DBD)
	UN	м 207.3	// Read database ?
	SPB	END3	
//			
	L '	MW 202	// Outcontainer pointer
<i>, ,</i>	т	MW 216	
<i>'</i> .			
<i>, ,</i>	T.	#DataBase	// Number of the database to use
	т	MW 100	
	AUF	DB [MW 100]	// Open the database
LP3:	NOP	0	
	L	MW 210	// Database device address
	ITD	2	
	T SLD	MD 242	// This is the pointer to the data source
//	•		,, into to one position to one and total
	L	MW 202	// Output container pointer
	ITD		// Make it double word
	SLW	3	// Put byte in upper position
, ,	T.	MD 246	// This is the pointer to the data destination
· ·	т	DBB [MD 242]	// Get byte from data source
	T	AB [MD 246]	// Store it in the output container
11			
	L	MW 210	// Increment data source pointer
	L	1	
	+1	мы 210	
11	1	MW 210	
	L	MW 202	// Increment data destination pointer
	L	1	
	+1		
	т.	MW 202	
	τ.	MW 216	// Check if all bytes read according to data length in index
	μ	111 210	// oncon it all byccb icaa according co aaca songen in inaan
	L	MB 212	// Nbr of bytes to read
	<1		
	SPB	LP3	
	L	MW 202	
END3 •	T	222 WP	
50D3:	NOF	0	

<u>SIMATIC</u> ...ion 1\CPU315-2DP1\S7 Program(3)\AP-off\FC112 02/12/1997 12:57:58 FC112 - <Off-line>

Name: WRI IND	Family:
Author: Sia	Version: 00.01
Time stamp Code:	DT#1997-02-11-13:20:50.000
Interface:	DT#1996-11-21-15:32:33.000
Length (Block / MC7 Code	/ Data): 00716 00572 00002

Address	Decl.	Symbol	Data Type	Initial Value	Comment
0.0	in	DataBase	WORD	W#16#0	
1.00	out	1 .		and the second	
	in out				
0.0	temp	IsM	BOOL		

This function handles one write index

Netwo.	$\frac{rk: 1}{r}$	0	INDEX HANDL	ING			
	ц Т	MB	224	/	/ c7	lear return value	
	T.	MW	220	1	/ Tr	container start address	
	τ ·	MM	200		,		
	Ť	2	200				
	17 17	5					
	m	MU	220		/ Pr	pinter to next index	
.,	1	1.144	220		/	Since to none indon	
'		MIG	200		1 64	at HIGH byte of index	
	TIT	1.144	200	'	/ 00	et mon byte of inden	
	TID	2					
	270	MD	242			and the second	
	1	ED ED	242 IND 2421	,	/ Ъ.	uto roadu	
	m 11	MM	206	· · · · · ·	/ 91	tore HIGH in MW206	
	1	1-144	200	· · · · · · · · · · · · · · · · · · ·	/ 00	core mean in imizeo	
/		MIN	200		10	at MIDDLE byte of index	
	1	1	200		/ 66	SC MIDDLE DYCC OF INGER	
	14	, т					
	+1		000				
	T	MM	200				
	TTD	<u> </u>					
	SLD	3	· · · ·				. * .
	т	MD	242				
	г	EB	[MD 242]	7	/ B7	yte ready	
	т	MW	208				
/							
	L ·	MW	200				
	ь ,	1					
	+I						
	т	MW	200	/	/ Ge	et LOW byte of index	
	ITD						
	SLD	3					
	т	MD	242				
	L	EB	[MD 242]	/	/ By	yte ready	
	т	MW	210				
/							
	ь .	MW	200				
	L	1					
	+I						1 - C - C - C - C - C - C - C - C - C -
	т.	MW	200	1	/ Pc	pint to the data to be written	
1							
	L .	MB	207	/	/ Ca	alculate nbr of byte to write	
	SRW	4					
	L	W#1(5#7				
	UW						
	т	MB	212	1	/ T.	is is the size from index	
	U (
	UN	м	212.1				
	UN	м	212.2			and the second	
)						
	o.						
	п. ^с						
	UN	м	212.0				
	11	M	212.1				
	TIN	M	212.2			 A set of the set of	
	1						
	, SPB	END	e				
	11	M	212 2				
	CDD	MET.					
	JED L	4 G L . A	 A state 		1 0	onvert length to 4 bytes	
	CDA	ч тр			,	ontone rongen to a bytes	
PT1.	DFA TI	M	212 1				
ETT:	0	M	212 0				
		171	616.0				
	CDD	MPT					·

	110	and the second second	ion 1\CPU315-	-2DPI(S7 Program(3) (AP-off(FCI12 02/12/1997 12:57:58
	L	6	11	Convert length to 6 bytes
WET2:	SPA U	TR M 212.1		
	SPB	WEI3		
	SPA	8 TR	11	Convert length to 8 bytes
WEI3:	U	M 212.0		
	SPB T.	WEI4	11	Convert length to 16 bytes
	SPA	TR		
WEI4:	L	32 MB 212	11	Convert length to 32 bytes
ENDE:	NOP	0		
Netwo	ork: 2	WRITE	MEMORY	
This	netwo:	rks writes d	ata to device memory	(MB/MW/MD) and outputs (QB/QW/QD)
	UN	M 207.0		Write M ?
	0	M 207.1		
	0	M 207.2 M 207.3		
	SPB	TstY		Elag indicating M
	SPA	ST		Fiag indicating M
CstY:	NOP	0 M 207.0	11	Write outputs ?
	ON	M 207.1		e
	0	M 207.2 M 207.3		
	SPB	END2		
ST:	R NOP	#1SM 0		
$\prime\prime_{\pm}$	÷	MRJ 202		Outcontainer nointer
	Ť.	MW 216		outcontainer pointer
·	0	M 212.0		
	0	M 212.1 M 212.2		
	SPB	M202	11	Calculate bit number from device address
	L	W#16#FF		Calculate Dit Hamber 110M acvice adalebb
	UW T.	MW 208		
	SLW	8		
	L	8		
	/1	NFR 242		
11	Ŧ	PIW 242		and the second
	L . L	MW 210 W#16#FF	11	Calculate byte number from device address
	บีพ			
	L SLŴ	MW 208 8		
	OW	0		
	MOD			
	т	MW 244		
	L	MW 242		Pointer to bit
	ITD SLW	3		
	L	MW 244		
	+D			
· /	т	MD 242		Now, this is the pointer to the correct memory bit+byte
	r ,	MW 200	11	
	ITD SLD	3		
<i>,,</i>	т	MD 246		
· /	г :	EB [MD 246	11	Get ON/OFF-status from input container
	T	MB 213 #TsM		Is it memory bit ?
	SPB	Is_Y		
	υ.	M 213.0 M [MD 242]	11	Write the data to the memory bit!
	SPA	AFTR		
	NOD	0		

SIMA	TIC				ion	1\C	PU3	15	-2DP1\S7 Program(3)\AP-off\FC112 02/12/1997	12:57:58
	L U	MB	213 213.0							
	-	A [MD 242]					//	Write the data to the output bit!	
AFTR:	NOP	0								
	L	MW	210					//	Increase input container pointer	
	+I									
11	т	MW	210							
	L	MW	202					//	Increase output container pointer	
	L +I	T								
	т	MW	202	• 1						
11 .	L	MŴ	202							
	T	MW	222							
11		HANDL	ING OF H	BYTE F	READI	NG (USEI	вз	(E700 V1.1x)	
// M202+	NOP	0								
	L	MW	210					11	Memory address from index	
	SRW	3 MW	214					11	Divide by 8	
	L	MW	200							
LOOP:	NOP	. MW 0	202							
	L	MW	214							
	ITD	3						11	Put byte in upper position (->bit =0)	
	т	MD	242					11	This is the pointer to the data DESTINATION	
//	L	MW	202					ii	Output container pointer	
	ITD							11	Make it double word	
	T	MD	246					11	This is the pointer to the data SOURCE	
11								<i>, ,</i>	Cat data from container	
	UN	EB #IS	(MD 246. M	J				//	Get data from container	
	SPB	L10		· ·				<i>, ,</i>	Weite bute to data doctination	
	T SPA	LDO	[P1D 242] N	,				<i></i>	write byte to data descination	
L10:	NOP	0	IND 040							
LDON:	NOP	0 0	[MD 242,							
11 .			214					<i>, ,</i>	Therement data course neinter	
	L	1	214					<i>''</i>	increment data source pointer	
	+I	2.007	214							
11 :	1 .	PIW	214							
	L	MW	202					//	Increment data destination pointer	
	+I	T								
11	т	MW	202							
	L	MW	216					11	Check if all bytes read according to data length in	index
	-I.	MB	212							
	<1 .	115								
	SPB	LOO	P					//	Go for next byte	
	L	MW	202							
END2:	T NOP	MW O	222							
Netwo	rk:	3	Write	of da	ta wo	ord				
	UN	M	207.3					//	Write dataword ?	
	L	MW	200							
,,	т	MW	216							
11										
	L.	#Da ™™	taBase							
	ÂUF	DB	[MW 100]	1				11	Open desired database	
// 1.03.	NOP									
nr 2 :	L	MW	200					11	Calculate addr in inp.conatiner to data to write	
	ITD	. 3								
	540	ĩ								<u>, 1919 - 1919</u> - 1919
					· · ·					Page 3

SIMA	TIC	1. J. J.		ion	1\CPU31	5-2DP1\S7	Program	(3) \AP-of	f\FC112	02/12/	1997	12:57:58
	т	MD	242									
//	L	MW	210		`. Т.	/ Calculate	position	in databas	e			
	ITD SLD T	3 MD	246									
	L T	EB DBB	[MD 242] [MD 246]			/ Get byte / Store it	from input in the dat	t container tabase				
	L L	MW 1	210		1.	/ Next inpu	t data byt	te				
	+1 T	MW	210									
//	L L	MW 1	200		· /,	/ Next dest	ination ac	ldress				
11	+I T	MW	200									
	L -T	MW	216		1.	Check if	more bytes	s to write				
	L <t< td=""><td>MB</td><td>212</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	MB	212									
END3:	SPB L T NOP L	LP3 MW MW 0	200 220		· /,	/ Done!!						
	L I	MB	100									
m1:	T NOP	m1 MB O	172							е. Э		



A MITSUBISHI ELECTRIC EUROPE

FACTORY AUTOMATION GOTHAER STR. 8, D-40880 RATINGEN TEL.: (0 21 02) 4 86-10, FAX: (0 21 02) 4 86-1 12